

CL200 / CL350 / CL400 / CL500

BT-MADAP

Software manual

Edition

101

CL200 / CL350 / CL400 / CL500

BT-MADAP

Software manual

1070 072 163-101 (97.11) GB

© 1997

by Robert Bosch GmbH, Erbach / Germany
All rights reserved, including applications for protective rights.
Reproduction or distribution by any means subject to our prior written
permission.

Discretionary charge 20,- DM

1	Safety Instructions	1-1
1.1	Proper use	1-1
1.2	Qualified personnel	1-2
1.3	Safety markings on components	1-3
1.4	Safety instructions in this manual	1-4
1.5	Safety instructions for the described product	1-5
2	Introduction	2-1
2.1	Overview	2-1
2.2	Functions and Features	2-1
2.3	Sequential Control and Diagnostics Concept	2-2
2.4	Menu and Module Structure	2-3
2.4.1	BT20 Menu Tree	2-4
2.4.2	BT5 Menu Tree	2-6
2.4.3	CL200 Module Structure	2-8
2.4.4	CL350 / CL400 / CL500 Module Structure	2-9
3	CL200 Control Functions	3-1
3.1	Introduction	3-1
3.2	Definitions	3-1
3.2.1	Modules	3-1
3.2.2	Markers	3-2
3.3	Programming	3-3
3.3.1	Module Call	3-3
3.3.2	Program Structure	3-4
3.3.3	BTSMADAP Parameter Description	3-5
3.3.4	Register Contents	3-5
3.3.5	Messages	3-6
3.4	Operating Modes	3-7
3.4.1	Manual Operation / Setup	3-7
3.4.2	Inching Mode / Single Step	3-8
3.4.3	Semi-automatic Mode	3-9
3.4.4	Automatic Mode	3-10
3.4.5	D6 — Selected Operating Mode	3-11
3.4.5.1	OpMode Bit Priorities	3-14
3.4.6	D8 — OpMode Message	3-14
3.5	Step Module	3-17
3.5.1	Diagnostics	3-19
3.6	Cascade Data Module	3-20
3.7	Command Output	3-22
4	CL350 / CL400 / CL500 Control Functions	4-1
4.1	Introduction	4-1
4.2	Definitions	4-1
4.2.1	Modules	4-1
4.2.2	Markers	4-2
4.3	Programming	4-3
4.3.1	Module Call	4-3
4.3.2	Program Structure	4-3
4.3.3	KETTE Parameter Description	4-4
4.3.4	Register Contents	4-5
4.4	Operating Modes	4-6
4.4.1	Manual Operation / Setup	4-6
4.4.2	Inching Mode / Single Step	4-7
4.4.3	Semi-automatic Mode	4-8
4.4.4	Automatic Mode	4-9

4.4.5	D6 — Selected Operating Mode.....	4-10
4.4.5.1	OpMode Bit Priorities	4-13
4.4.6	D8 — OpMode Message	4-13
4.5	Step Module.....	4-16
4.5.1	Diagnostics	4-18
4.6	Cascade Data Module	4-19
4.7	Command Output	4-21
5	BTSMADAP & BTS_ZV Function Modules	5-1
5.1	BTSMADAP Function Module.....	5-1
5.1.1	Module Functions	5-1
5.2	BTSMADAP Function Module for CL200.....	5-2
5.2.1	Prerequisites and Allocations	5-2
5.2.2	Description of Parameters	5-2
5.3	BTSMADAP Function Module for CL400 / CL500	5-3
5.3.1	Prerequisites and Allocations	5-3
5.3.2	Description of Parameters	5-3
5.3.3	DIAG500E Diagnostic Messages	5-4
5.4	BTS_ZV Function Module.....	5-7
5.4.1	Module Functions	5-7
5.4.2	Calling the BTS_ZV Function Module	5-7
5.4.2.1	Description of Parameters	5-7
5.4.2.2	CL350 / CL400 / CL500 — Allocation of Synchronization Results.....	5-9
6	DM255 / 254 / 120 Data Modules.....	6-1
6.1	BTS_Diag Diagnostics Data Module (DM254)	6-1
6.2	Komm_DB Communication Data Module (DM255).....	6-2
6.3	DM120 Data Module	6-4
6.3.1	Automatic Diagnostic Range	6-5
6.3.2	Control Flags	6-6
6.3.3	Cascade Information Structure.....	6-8
6.3.4	Manual Diagnostic Range	6-8
7	BT5 Menu Description.....	7-1
7.1	Startup Screen.....	7-1
7.2	Setup Menu.....	7-2
7.3	Diagnostic Function	7-3
7.3.1	Cascade Status	7-3
7.3.2	Criteria Display	7-5
7.3.3	Explanation of Terms	7-7
7.4	BT 20 Main Menu.....	7-9
7.4.1	Display Mask Group Branching Menu	7-10
7.4.1.1	Display Mask Groups.....	7-11
7.4.2	Operation Mask Branching Menu	7-12
7.4.2.1	Operation Mask Groups.....	7-13
7.4.3	Message Menu	7-15
7.4.3.1	Status Messages	7-15
7.4.3.2	Serial Messages	7-15
7.4.3.3	Message Parameters.....	7-16
7.5	Service Menu	7-18
7.5.1	PG Communication Mask.....	7-18
7.5.2	Power-Up Conditions.....	7-19
7.5.3	Operand Status Branching Menu	7-20
7.5.3.1	Operand Status Display	7-21
7.5.4	Internal Messages	7-22
7.5.5	Date / Time	7-22

8	BT20 Menu Descriptions	8-1
8.1	Startup Screen	8-2
8.2	Setup Menu	8-3
8.3	Diagnostic Function	8-4
8.3.1	Cascade Status	8-4
8.3.2	Criteria Analysis	8-5
8.3.3	Explanation of Terms	8-7
8.4	BT20 Main Menu	8-9
8.4.1	Display Mask Group Branching Menu	8-10
8.4.1.1	Display Mask Groups	8-11
8.4.2	Operation Mask Branching Menu	8-13
8.4.2.1	Operation Mask Groups	8-14
8.4.3	Message Menu	8-16
8.4.3.1	Status Messages	8-16
8.4.3.2	Serial Messages	8-17
8.4.3.3	Message Parameters	8-18
8.5	Power-Up Conditions	8-19
8.6	Service Menu	8-20
8.6.1	Clock / PLC Status Messages	8-21
8.6.2	I / O / M / EI / EO Status / Control	8-22
8.6.3	Timer / Counter Status	8-24
8.6.4	DM / DF / (DB) Timer / Counter Status	8-26
9	TS Programming System	9-1
9.1	Introduction	9-1
9.2	Menu Tree	9-1
9.3	TS Programming System Operation	9-4
9.3.1	Keyboard and Mouse Operation	9-4
9.3.2	Project	9-4
9.3.3	Masks	9-6
9.3.3.1	Help Text	9-9
9.3.3.2	Messages	9-10
9.3.3.3	Text Lists	9-11
9.3.4	BT5 Operator Terminal — Masks Requiring Editing	9-12
9.3.4.1	BT5 – Operation Mask	9-12
9.3.4.2	BT5 – Power-Up Conditions Mask	9-13
9.3.4.3	BT5 – Display Mask	9-13
9.3.5	BT20 Operator Terminal — Masks Requiring Editing	9-14
9.3.5.1	BT20 – Operation Mask	9-14
9.3.5.2	BT20 – Power-Up Conditions Mask	9-15
9.3.5.3	BT20 – Display Mask	9-16
9.3.6	Variables	9-17
9.3.7	Parameters	9-18
9.4	Procedural Description	9-19
9.4.1	Copying Data From Program Diskette	9-19
9.4.2	Loading Project File for Editing	9-20
9.4.3	Editing Display Masks	9-21
9.4.4	BT5 — Operator Terminal Procedures	9-22
9.4.4.1	BT5 – Operation Mask No. 211	9-22
9.4.4.2	BT5 – Operation Mask No. 212 through 226	9-23
9.4.4.3	BT5 – Power-Up Conditions Mask No. 20	9-23
9.4.4.4	BT5 – Power-Up Conditions Mask No's. 21-23	9-26
9.4.4.5	BT5 – Display Mask No. 110	9-26
9.4.4.6	BT5 – Display Mask No's. 110-113, 120-123, 130-133, 140-143	9-29

9.4.5	BT20 — Operator Terminal Procedures.....	9-29
9.4.5.1	BT20 – Operation Mask No. 211	9-29
9.4.5.2	BT20 – Operation Mask No. 212 through 226	9-30
9.4.5.3	BT20 – Power-Up Conditions Mask No. 20	9-30
9.4.5.4	BT20 – Power-Up Conditions Mask No's. 21-23	9-32
9.4.5.5	BT20 – Display Mask No. 110	9-33
9.4.5.6	BT20 – Display Mask No's. 110-113, 120-123, 130-133, 140-143	9-35
9.4.6	Variables.....	9-36
9.4.7	Compiling Mask Files	9-37
9.4.8	Transferring .S3 File to Operator Terminal.....	9-37
10	Tesi Mod Software Installation	10-1
10.1	Installing the Software.....	10-1
10.2	English-Language User Interface	10-2
10.3	Directory Structure.....	10-3
10.4	BT-MADAP Program Diskette	10-4
10.5	Concluding Remarks	10-6
11	Appendix.....	11-1
11.1	Examples of Step Modules	11-1
11.1.1	Handling the -STOEM Fault Marker	11-1
11.1.2	Using Wait Time	11-2
11.1.3	Monitoring Time Stop	11-3
11.1.4	Using -VERZW Branching Marker.....	11-4
11.2	Characteristic Data of Standard Modules	11-6
11.2.1	KETTE200 Cascade Management Module.....	11-6
11.2.2	KETTE Function Module	11-6
11.2.3	DIAG500E Diagnostics Module.....	11-7
11.3	Fault Messages	11-8
11.3.1	BUEP19E Fault Messages – CL200	11-10
11.3.2	BUEP19E Fault Messages – CL350 / CL400 / CL500	11-11
11.4	BT-MADAP Order Numbers	11-13

1 Safety Instructions

Before you start working with the BT-MADAP software, we recommend that you thoroughly familiarize yourself with the contents of this manual. Keep this manual in a place where it is always accessible to all users.

1.1 Proper use

This instruction manual presents a comprehensive set of instructions and information required for the standard operation of the described products.

The products described hereunder

- were developed, manufactured, tested and documented in accordance with the relevant safety standards. In standard operation, and provided that the specifications and safety instructions relating to the project phase, installation and correct operation of the product are followed, there should arise no risk of danger to personnel or property.
- are certified to be in full compliance with the requirements of the
 - COUNCIL DIRECTIVE 89/336/EEC of May 3rd 1989 on the approximation of the laws of the Member States relating to electromagnetic compatibility, 93/68/EEC (amendments of Directives), and 93/44/EEC (relating to machinery)
 - COUNCIL DIRECTIVE 73/23/EEC (electrical equipment designed for use within certain voltage limits)
 - Harmonized standards EN 50081–2 and EN 50082–2
- are designed for operation in an industrial environment (Class A emissions). The following restrictions apply:
 - No direct connection to the public low-voltage power supply is permitted.
 - Connection to the medium and/or high-voltage system must be provided via transformer.

The following applies for application within a personal residence, in business areas, on retail premises or in a small-industry setting:

- Installation in a control cabinet or housing with high shield attenuation.
- Cables that exit the screened area must be provided with filtering or screening measures.
- The user will be required to obtain a single operating license issued by the appropriate national authority or approval body. In Germany, this is the Federal Institute for Posts and Telecommunications, and/or its local branch offices.

⇒ **This is a Class A device. In a residential area, this device may cause radio interference. In such case, the user may be required to introduce suitable countermeasures, and to bear the cost of the same.**

Proper transport, handling and storage, placement and installation of the product are indispensable prerequisites for its subsequent flawless service and safe operation.

1.2 Qualified personnel

This instruction manual is designed for specially trained personnel. The relevant requirements are based on the job specifications as outlined by the ZVEI and VDMA professional associations in Germany. Please refer to the following German–Language publication:

Weiterbildung in der Automatisierungstechnik
Publishers: ZVEI and VDMA Maschinenbau Verlag
Postfach 71 08 64
60498 Frankfurt/Germany

Interventions in the hardware and software of our products not described in this instruction manual may only be performed by our skilled personnel.

Unqualified interventions in the hardware or software or non–compliance with the warnings listed in this instruction manual or indicated on the product may result in serious personal injury or damage to property.

Installation and maintenance of the products described hereunder is the exclusive domain of trained electricians as per IEV 826–09–01 (modified) who are familiar with the contents of this manual.

Trained electricians are persons of whom the following is true:

- They are capable, due to their professional training, skills and expertise, and based upon their knowledge of and familiarity with applicable technical standards, of assessing the work to be carried out, and of recognizing possible dangers.
- They possess, subsequent to several years' experience in a comparable field of endeavour, a level of knowledge and skills that may be deemed commensurate with that attainable in the course of a formal professional education.

With regard to the foregoing, please read the information about our comprehensive training program. The professional staff at our training centre will be pleased to provide detailed information. You may contact the centre by telephone at (+49) 6062 78–258.

1.3 Safety markings on components



DANGER! High voltage!



DANGER! Corrosive battery acid!



CAUTION! Electrostatically sensitive components!



Disconnect mains power before opening!



Lug for connecting PE conductor only!



Functional earthing or low-noise earth only!



Screened conductor only!

1.4 Safety instructions in this manual



DANGEROUS ELECTRICAL VOLTAGE

This symbol warns of the presence of a **dangerous electrical voltage**. Insufficient or lacking compliance with this warning can result in **personal injury**.



DANGER

This symbol is used wherever insufficient or lacking observance of this instruction can result in **personal injury**.



CAUTION

This symbol is used wherever insufficient or lacking observance of instructions can result in **damage to equipment or data files**.

⇒ This symbol is used to alert the user to an item of special interest.

1.5 Safety instructions for the described product

**DANGER**

Fatal injury hazard through ineffective Emergency-OFF devices! Emergency-OFF safety devices must remain effective and accessible during all operating modes of the system. The release of functional locks imposed by Emergency-OFF devices must never be allowed to cause an uncontrolled system restart! Before restoring power to the system, test the Emergency-OFF sequence!

**DANGER**

Danger to persons and equipment!
Test every new program before operating the system!

**DANGER**

Retrofits or modifications may interfere with the safety of the products described hereunder!

The consequences may be severe personal injury or damage to equipment or the environment. Therefore, any system retrofitting or modification utilizing equipment components from other manufacturers will require express approval by Bosch.

**DANGEROUS ELECTRICAL VOLTAGE**

Unless described otherwise, maintenance procedures must always be carried out only while the system is isolated from the power supply. During this process, the system must be blocked to prevent an unauthorized or inadvertent restart.

If measuring or testing procedures must be carried out on the active system, these must be carried out by trained electricians.

**CAUTION**

Danger to the module!

Do not insert or remove the module while the controller is switched ON! This may destroy the module. Prior to inserting or removing the module, switch OFF or remove the power supply module of the controller, external power supply and signal voltage!

**CAUTION**

Only Bosch-approved spare parts may be used!

**CAUTION****Danger to the module!****All ESD protection measures must be observed when using the module! Prevent electrostatic discharges!**

Observe the following protective measures for electrostatically endangered modules (EEM)!

- The Employees responsible for storage, transport and handling must be trained in ESD protection.
- EEMs must be stored and transported in the protective packaging specified.
- Out of principle, EEMs may be handled only at special ESD work stations equipped for this particular purpose.
- Employees, work surfaces and all devices and tools that could come into contact with EEMs must be on the same potential (e.g. earthed).
- An approved earthing wrist strap must be worn. It must be connected to the work surface via a cable with integrated 1 MW resistor.
- EEMs may under no circumstances come into contact with objects susceptible to accumulating an electrostatic charge. Most items made of plastic belong to this category.
- When installing EEMs in or removing them from an electronic device, the power supply of the device must be switched OFF.

1.6 Trademarks

All trademarks referring to software that is installed on Bosch products when shipped from the factory represent the property of their respective owners.

At the time of shipment from the factory, all installed software is protected by copyright. Software may therefore be duplicated only with the prior permission of the respective manufacturer or copyright owner.

MS-DOSr and Windows™ are registered trademarks of Microsoft Corporation.

2 Introduction

The **BT-MADAP** software is the successor of the proven MADAP software packet which was developed for both the CL400 and the CL500 multiple-processor control unit. As an added feature, BT-MADAP supports the CL200 compact control unit.

2.1 Overview

BT-MADAP requires the following hardware components:

- CL200, CL400 or CL500 programmable logic controller (PLC).
- BT5 or BT20 operator terminal

When compared with the familiar MADAP software, BT-MADAP provides significant advantages providing distinctive cost savings.

BT-MADAP Advantages

- Reduced volume of program code (memory requirements) through direct access to PLC data from the control panel
- Cycle time effectiveness
- No interface module required because access to data is possible via interface of programming unit.
- Visualization module (diagnostics module) no longer required.
- Omission of above mentioned modules results in space savings in physical controller construction.
- For the user switching from MADAP to BT-MADAP, the most significant feature is the absolute compatibility of control functions (sequential function program) for the CL400 and CL500 controllers.

2.2 Functions and Features

A brief listing of the major features appears below:

Controlling machine sequences

For up to 60 sequences with 128 steps each, this function assumes the entire cascade management, complete with MANUAL, INCHING and AUTOMATIC modes, up to the point of command output. For MANUAL and AUTOMATIC modes, different conditions can be programmed in each step.

Machine operation

Ease of operation through 16 preprogrammed screen masks, each handling 8 manual operating functions. Instead of the previous time-consuming programming routines, only simple parameterization (selection of parameter values) remains to be carried out.

Diagnosing Sequencing Faults

All processing sequences can be monitored and diagnosed in both time-specific and peripheral-controlled fashion. In addition, the diagnostic function can be used to cause the current statuses of any cascade sequence, in conjunction with its operating mode and the current cascade information, to be displayed.

When displaying the cascade information of the screen of the operating panel, the step indication uses the instruction list (IL) format.

Displaying and Modifying Operand Statuses

The current status of any control operand can be displayed and modified in different display formats.

Displaying Control Information

Internal controller information, such as CPU Halted, I/O Fixated, Battery Warning, as well as the system time and the values affecting cycle time and the selected watchdog function, are indicated.

2.3 Sequential Control and Diagnostics Concept

The concept is based upon the observation that — similar to the operation of smaller controllers — smaller, more cost-effective operating devices can be used for the visual presentation of diagnostic data, even for the more powerful control units. For this reason, the task of a cascade sequence diagnostic function in the form of a software solution consists of depositing the diagnostic data in a transfer memory buffer for access by subsequent processing functions. The processing and display of the referred data is handled by the external **BT5** and **BT20** operating terminals that are able to read this buffer without requiring assistance. The DM120 data module has been designated as the transfer memory module.

The two main processing tasks, such as:

- Controller procedures, and
- Diagnostic functions

are handled, in the case of the CL200, by the KETTE200 cascade management module. With the CL400/CL500, the KETTE function module and the DIAG500E module assume the control functions. Additional function modules are required to establish the relevant connections with operating and display devices. For the BT5 and BT20 operating terminals, the BTSMADAP and BTS_ZV function modules are available.

In the case of the CL200, the two above mentioned main processing tasks were implemented in the controller firmware, and therefore do not burden the application PLC memory. The function is enabled by the **KETTE200.PBL** module.

Comparison of Diagnostic Concepts, CL200 vs. CL350 / CL400 / CL500


Definition	CL200	CL350 / CL400 / CL500
Cascade management	For all process sequences, the KETTE200 cascade management module is called up only in the BTSMADAP function module.	For each process sequence, a separate module call of the KETTE cascade management module must be programmed.
Synchronization	Not implemented.	All cascades in all steps.
Operating Modes	Are written directly into the data modules.	Are defined by means of parameters in the KETTE module.
Diagnostics	As the function is integrated in the KETTE200, it does not require a specific call-up.	For all process sequences, the DIAG500E function module is called once by the BTSMADAP PM.
BT-MADAP	The menu administration is handled by the BT5/BT20 operating terminal. Parameter processing of standard modules occurs in the PLC program.	
Allocation of KETTE DM's	For the CL200, the binary statuses of both active steps and of command outputs were omitted.	
Marker allocation	As the size of the marker address range varies with different controllers, the addresses of the functionally defined BEFA and WSB markers differ also. The same is true for the scratch marker range.	
Step module programming	Due to variances between the diagnostics routines of different controllers, in the case of the CL200 the JPCY jump instruction (never executed) must be entered for non-bit commands. This is done in order to ensure that, for the purpose of diagnostic functions, such commands (e.g. default values for monitoring and wait intervals) are ignored. In the case of purely bit command programming, identical programming routines can be used.	
Command output programming	On the CL200, the command output is enabled solely via an actual vs. setpoint value comparison of the active step.	

Fig. 2-1 Differences in Diagnostics Concepts

2.4 Menu and Module Structure

As a consequence of differing screen sizes, the utilization of the BT5 and/or BT20 operating terminals results in different menu trees and module structures. The menu trees for BT5 and BT20 appear on the following pages, providing an overview of screen nesting and the respective function key assignments. (It should be noted that the term *mask* still appearing in some editing programs, for example, is gradually being replaced by the more common *screen*.)

2.4.1 BT20 Menu Tree











EMnnn Input/Output screen no. nnn
 MMnnn Message screen no. nnn

Operation: >?< = Screen-specific
 >HOME< = to Main Menu
 >Cursor< Screen switchover within function groups
 >F5< MEL calls up status messages

>F6< DIAG calls up process sequence and toggles back and forth
 between cascade structure and criteria display

<F10> RET Up one menu level

Fx This key not in use



Cursor Up/Down: Toggles screen within a group
 Cursor Right/Left move: Switches screen to adjacent group

Fig. 2-2 BT20 Menu Tree (Part 1)

The screen contents are slightly different, and are adapted to the various controller types (e.g. CL200 without display of data buffer DB).







Fig. 2-3 BT20 Menu Tree (Part 2)

2.4.2 BT5 Menu Tree










EMnnn Inüüt/Output screen No. nnn
 MMnnn Message screen No. nnn
 Operation: >?< = Screen-specific info.
 >HOME< = To Main Menu
 >Cursor< Screen switchover within function groups
 >F7< Print command calls up cascade structure, and toggles between cascade structure and criteria display.
 >F8< Scrolling; calls up status messages
 This key not in use



Cursor to Service Menu →

Fx



Cursor Toggles screen within a group
 Cursor Right/Left move: Switches screen to adjacent group

Fig. 2-4 BT5 Menu Tree (Part 1)

The screen contents are slightly different, and are adapted to the various controller types (e.g. CL200 without display of data buffer DB).




Fig. 2-5 BT5 Menu Tree (Part 2)

2.4.3 CL200 Module Structure




Fig. 2-6 CL200 Module Structure

2.4.4 CL350 / CL400 / CL500 Module Structure




Fig. 2-7 CL350 / CL400 / CL500 Module Structure

3 CL200 Control Functions

3.1 Introduction

Chapter 2 discusses the control sequence management, including the different operating modes it provides, plus process organization and command output functions. Function modules are available to handle the sequential control, diagnostic functions and display processes.

3.2 Definitions

To ensure orderly sequential processing and/or ascertain the production of unambiguous diagnostic values, the use of the BT-MADAP software package shall be governed by the definitions and conventions outlined below.

3.2.1 Modules

The KETTE200 function module manages a maximum of

- 30 control sequences,
- containing 128 steps each,
- with one active step per each cycle.

The following modules are permanently assigned to the above control sequences:

- Function modules PM1 - PM30 (control sequences)
- Data modules DM1 - DM30 (cascade data modules)

Here the PM and DM numbers correspond to the cascade numbers.

Data storage and transfer is handled by the

- DM120 data module.

3.2.2 Markers

Within the range of available markers, the markers listed below are assigned a permanent function.

Symbol	Ad- dress CL200	Function
BEFA	M191.0	Assigned to command output
WSB	M191.1	Assigned to step-on function
STOEM	M191.2	Fault marker; fault is indicated by $STOEM = 0_{bin}$
HALBAUTO	M191.4	Step-on in Inching mode also without S+1 transition
WZT_HLT	M191.5	Wait time stop
WZT	M191.6	Wait time status 0_{bin} : Wait time running 1_{bin} : Wait time expired
	M191.7	Monitoring time check. If $UEKONTR = 1_{bin}$, expiration of monitoring time will not trigger diagnostic function.
VERZW	M188	Branch address (word) Step number within the cascade to which branching is to take place if $WSB = 1_{bin}$.

Fig. 3-1 CL200 Control Functions, Marker Definitions

3.3 Programming

3.3.1 Module Call

The KETTE200 cascade management module (also referred to as *function module*) is called only once per PLC cycle in the BTSMADAP function module, and then services all defined cascade sequences. For this purpose, the number of cascades (i.e., the number of the last cascade sequence to be processed) is transferred to the BTSMADAP function module as a parameter value. The operating modes are directly written into the respective data modules. In order to be able to form functional groups of cascade sequences, it is possible to leave strategic gaps when creating the cascade data modules. Those cascade sequences for which no data module was defined will then be skipped, and processing will continue with the subsequent cascade sequence. In order to exclude step modules from processing, the operating mode for D6 must be described as 0_{hex} , in which case the message returned by the module in D0 of the cascade data module will be 8000_{hex} .

The BTSMADAP.PBL module is called in the OM1 operating module. BTSMADAP is created with the inclusion of a parameter file which greatly facilitates calling it during the programming/configuration phase. In the event that the Call Parameter function is used during programming, the following program part will appear without requiring additional input:

```

CM      -BTSMADAP, 2
;
;          +---+
P0 B -Kett_Anz   ;<   ! Number = No. of last cascade
P1 B -K200       ;<   ! KETTE200 module no. as constr.
;
;          +---+

```

Fig. 3-2 CL200 — Calling BTSMADAP Module

3.3.2 Program Structure




Fig. 3-3 CL200 Control Functions — Module Structure

3.3.3 BTSMADAP Parameter Description

NOTE: No scratch markers belonging to the range indicated below may be used as parameters.

M188.0 - M191.7

P0 W -Kett_Anz
(Input parameter)

Via parameter P0, the BTSMADAP function module receives the number **n** of the last cascade sequence for sequence processing as well as diagnostics.
Each cascade sequence being processed utilizes a cascade data module to store variable data, e.g. current step, monitoring time and wait time.

P1 W -K200
(Input parameter)

This parameter specifies the module number of the KETTE200 function module. It corresponds to the function module number in the symbol file. Subsequent to calling the parameter list, the "-" symbol character must be deleted. Using K200, the PM200 function module number is assigned to the KETTE200 function module.

3.3.4 Register Contents

The PLC registers A, B, C, and D, plus the control flags (e.g. RES, Carry) are not retained beyond the module call. Upon returning from the BTSMADAP to the calling module, the registers will contain the contents that are defined as listed in the following table.

Reg.	Contents
A	Version number of BTSMADAP module.
B	Module release date.
C	No relevance.
D	No relevance.

Fig. 3-4 BTSMADAP Module, Register Contents

3.3.5 Messages

The messages from the KETTE200 module are returned via the DM254/D510 data word.

The messages comprise error messages that cannot be entered in data word D0. The status word has the following meaning:

Bit	Error and/or Status message	Remedy
15	Group error indication	This bit always occurs in conjunction with one or more of the bits listed below.
14		
13	DM120 link is too short	Correct the length of the data module.
12		
11		
10		
9	Number of cascades from P3 = 0 _{dec}	Enter desired number of cascade sequences.
8	Wrong cascade number for manual diagnosis.	Correct default; program/integrate PMn and/or DMn.
7	Step module (PMn) not programmed.	Program PMn module or remove associated DMn.
6	DMn link is too short	Correct length of data module. The cascade data modules must be integrated with a length of ≥ 82 bytes. As deliberate gaps in data module sequences allow the formation of functional cascade groups, non-existing data modules will not cause an error to be entered.
5	Cascade number, bit 5	If bit 6 is set, bits 0 thru 5 indicate the last cascade number in which the error was detected.
4	Cascade number, bit 4	
3	Cascade number, bit 3	
2	Cascade number, bit 2	
1	Cascade number, bit 1	
0	Cascade number, bit 0	

Fig. 3-5 Status Message from KETTE200 in DB254/D510

NOTE:

If the DM120 data module was not integrated into the program, the controller will enter the STOP Mode while returning the *Unknown Module Called* message.

3.4 Operating Modes

For all cascades, the selection of the cascade operating mode (OpMode) prior to the BTSMADAP module call is effected by writing to the D6 data word in the respective valid cascade data module. The same applies to the selection of the wait and monitoring times of the cascades. The D22 (wait time) and D24 (monitoring time) data words are used for this purpose.

3.4.1 Manual Operation / Setup

Function

Manual step operation in consideration of the manual branching conditions.

The step is entered in data word D14 of the associated cascade data module, and accepted as the current step by means of the Set Step instruction (D6.5=1) in D12.

The command output is enabled when

- the conditions of the manual branch have been met (BEFA = 1_{bin} , and WSB = 0_{bin}),
- and
- when the Start (D6.3) = 1_{bin} .

On the CL200, the command output occurs via D16 of the associated cascade data module (see cascade data module).

No **step-on** is enabled.

Programming

The Manual mode and Start bits must be statically set to 1_{bin} .

In the DM1 through DM16 screen data modules, the cascade and step number to be selected (see movement screens) must be entered upwards of data word D32.

Pressing a movement key in a movement screen on the operator terminal causes the associated cascade data module to be activated by means of the cascade number, the step number to be entered in D14, and Set Step (D6.5) and Start (D6.3) to be set to 1_{bin} .

Diagnostics

The display in cascade information indicates **H** ("Hand") for Manual mode at the corresponding cascade sequence.

Display of all criteria of the manual branch, either of the non-executed BEFA command output or of the WSB step-on condition branch.

Monitoring and wait times are loaded with the defined values but not started.

No fault message is returned.

3.4.2 Inching Mode / Single Step

Function

Step-by-step processing of steps in accordance with conditions of the automatic branch.

The command output is enabled when

- the conditions of the automatic branch have been met, (BEFA = 1_{bin}, and WSB = 0_{bin}), and
- when the Start (D6.3) = 1_{bin}.

The command output is effected via D16 of the associated cascade data module (see cascade data module).

There is **no automatic step-on**.

In the case of a positive transition on S+1 (D6.4), if WSB step-on conditions are met, the step-on to the next step will occur.

Programming

The Inching bit is to be statically set to 1_{bin}. Start = 1_{bin} causes the current step to be processed, and a positive transition on S+1 causes the step-on into the subsequent step.

Diagnostics

Display in cascade information indicates **T** (indicating incremental advance by *Touch* control) for Inching mode at the corresponding cascade sequence.

Display of all criteria of the manual branch, either of the non-executed BEFA or of the WSB branch.

The faulty cascade sequence is displayed.

Monitoring and wait time elapse with the default nominal values.

3.4.3 Semi-automatic Mode

Function

Semi-automatic processing of steps in accordance with conditions in the automatic branches.

The command output is enabled when

- the conditions of the automatic branch have been met ($BEFA = 1_{bin}$, and $WSB = 0_{bin}$), and
- when the start ($D6.3$) = 1_{bin} .

In the case of the CL200, the command output is effected via D16 of the associated cascade data module (see cascade data module).

With the WSB step-on conditions met, and the -HALBAUTO (M191.4) marker set, the **step-on occurs automatically**. The step-on ends with the step in which the -HALBAUTO = 0_{bin} marker is located, or if the WSB step-on condition has not been met.

With a positive transition on S+1 (D6.4), the satisfied WSB step-on conditions will cause the subsequent program sequence to be processed up to the reset -HALBAUTO marker.

Programming

The Inching bit is to be statically set to 1_{bin} . Start = 1_{bin} causes the current step to be processed, and a positive transition on S+1 causes the semi-automatic mode to be started.

Diagnostics

Display in cascade information indicates **T** (indicating incremental advance by *Touch* control) for Inching mode at the corresponding cascade sequence.

Display of all criteria of the manual branch, either of the non-executed BEFA or of the WSB branch.

The faulty cascade sequence is displayed.

Monitoring and wait time elapse with the default nominal values.

3.4.4 Automatic Mode

Function

Automatic processing of steps in accordance with conditions in the automatic branches.

The command output is enabled when

- the conditions of the automatic branch have been met (BEFA = 1_{bin}, and WSB = 0_{bin}), and
- when the start (D6.3) = 1_{bin}.

The command output is effected via D16 of the associated cascade data module (see cascade data module).

If the WSB (step-on conditions) = 1_{bin}, the **automatic step-on** occurs.

Programming

Automatic mode (D6.2) and Start (D6.3) bits to be statically set to 1_{bin}.

Diagnostics

Display in cascade information indicates **A** for Automatic mode at the corresponding cascade sequence.

Display of all criteria of the manual branch, either of the non-executed BEFA or of the WSB branch.

The faulty cascade sequence is displayed.

Monitoring and wait time elapse with the default nominal values.

3.4.5 D6 — Selected Operating Mode

Further to the operating modes discussed in the preceding sections, the D6 data word in the cascade data module contains additional information relative to operating modes.

D6 nnBaWahl

This data word is written to by the KETTE200 module.

D6.0	Manual mode H
D6.1	Inching mode T
D6.2	Automatic mode A
D6.3	Start s
D6.4	S + 1
D6.5	Set Step
D6.6	Fault acknowledgement
D6.7	Reset r
D7.0	Halt h
D7.1	
D7.2	
D7.3	
D7.4	
D7.5	
D7.6	WSB does not reset BEFA (Manual mode only) ¹
D7.7	Fault requires acknowledgement

Fig. 3-6 D6 — Selected Operating Mode

D6.0 Manual Mode

Define Manual mode.

D6.1 Inching Mode

Define Inching mode.

D6.2 Automatic Mode

Define Automatic mode.

D6.3 Start

Start / Command output enable

The bit is valid for all operating modes, and is statically transferred to D6.

If Start = 0_{bin}, the following will occur:

- BEFA is deleted
- monitoring time is halted
- wait time continues to elapse

¹ This option applies to the CL200 with firmware version 1.5 and higher.

D6.4 S+1

Execute the subsequent step.

In INCHING mode, a positive transition of this bit and satisfied step-on condition ($WSB = 1_{bin}$) will cause the next step to be executed.

In SEMI-AUTOMATIC mode, a positive transition of this bit, satisfied step-on condition ($WSB = 1_{bin}$), and with -HALBAUTO marker set, cause the subsequent cascade sequence to be processed up to the reset - HALBAUTO marker.

D6.5 Set Step

Accept preselected step number.

In MANUAL mode, the step prepared in D14 is transferred to the active step (D12), and subsequently processed.

D6.6 Halt Acknowledgement

Manual fault acknowledgement.

Effective only if $D7.7 = 1_{bin}$ (manual fault acknowledgement).

A positive transition on this bit acknowledges a fault (cascade halted) that was triggered by an expired monitoring time or by the reset fault marker.

Monitoring and wait times are loaded with the defined values but not started.

D6.7 Reset

Cascade is reset.

$D6.7 = 1_{bin}$ triggers the following actions:

- Deletion of active step
- Reinitialization of cascade sequence

Subsequent to Reset, step 1 is prepared.

D7.0 Halt

Halt cascade sequence processing.

When the bit is set, the cascade is halted, and processing of the current step continues. For $D7.0 = 1_{bin}$, the following applies:

- BEFA is output
- monitoring time is halted
- wait time is halted

D7.4 Step Sequencing

No step-on effected within the same cycle.

Automatic mode only.

- If $D7.4 = 1_{bin}$, only one step is processed per each PLC cycle.
- If $D7.4 = 0_{bin}$, the satisfied WSB step-on condition causes the subsequent step within the same cycle to be activated.

D7.6 WSB does not reset Command Output (BEFA)²

Manual mode only.

- If $D7.6 = 1_{bin}$, a satisfied WSB step-on condition will not reset the associated BEFA command output.
- If $D7.6 = 0_{bin}$, a satisfied WSB step-on condition will cause the BEFA command output to be reset.

D7.7 Acknowledge

Fault acknowledgement

If this bit is set, an occurring cascade fault must be acknowledged by bit D6.6.

If D7.7 is reset, and the WSB step-on condition is satisfied, the cascade will auto-acknowledge.

² This option applies to the CL200 with firmware version 1.5 and higher.

3.4.5.1 OpMode Bit Priorities

If several operating mode bits are selected simultaneously in data word D6 of the cascade sequence, processing is subject to the following priority ranking:

1. Reset		highest priority
2. Halt		↓
3. Start		↓
4. Manual		↓
5. Inching		↓
6. Automatic		lowest priority

Fig. 3-7 OpMode Mode Priorities

3.4.6 D8 — OpMode Message

The D8 data word of each cascade data module contains the return message indicating the operating mode that is enabled once the KETTE200 function module has been processed.

D8 nnBaMldg

D8.0	Manual mode H
D8.1	Inching mode T
D8.2	Automatic mode A
D8.3	Start for all operating modes s
D8.4	Automatic or Inching mode enabled
D8.5	
D8.6	Wait time elapsing
D8.7	Reset, cascade is reset r
D9.0	Halt, cascade is halted h
D9.1	
D9.2	
D9.3	
D9.4	
D9.5	
D9.6	Fault pulse
D9.7	Static fault

Fig. 3-8 D8 — Reported OpMode

D8.0 Manual Mode

The cascade is in Manual mode.

Confirmed by display of symbol **H** in cascade information of operator terminal.

D8.1 Inching Mode

The cascade is in Inching mode.

Confirmed by display of symbol **T** in cascade information of operator terminal.

D8.2 Automatic Mode

The cascade is in Automatic mode.

Confirmed by display of symbol **A** in cascade information of operator terminal.

D8.3 Start

The cascade has received the start bit.

Confirmed by display of symbol **s** in cascade information of operator terminal.

D8.4 Automatic / Inching

The cascade is in Automatic or Inching mode.

This bit is used to select whether the manual or automatic branch is to be processed in the step module.

D8.4 = 1_{bin}, Automatic OR Inching mode is enabled.

D8.4 = 0_{bin}, Manual mode is enabled.

D8.6 Wait Time Running

If the bit is set, this indicates that the wait time for this step has expired.

Prior to calling the step, the cascade management module causes the status of bit D8.6 to be simultaneously written to the WZT wait time halt marker (M191.6), making the wait time available to the steps as a diagnostic operand.

If the wait time has expired, the query:

- A B -WZT (wait time)

returns the value of 1_{bin}.

D8.7 Cascade Reset

The cascade is reset, and the active step deleted (D12 = 1_{bin} subsequent to Reset).

D9.0 Cascade Stopped

The cascade is in Stop mode.

This operating mode is enabled by the following:

- D7.0 = 1_{bin} (Stop),
- Fault marker M191.2 reset, or
- Fault in Automatic mode with monitoring time expired (only with manual acknowledgement via D7.7 = 1_{bin}).

D9.6 Fault Pulse

Returns a pulse for a PLC cycle in the event that a fault was detected. Fault criteria are as follows:

- Reset fault marker
- or
- Expired monitoring time.

D9.7 Static Fault Signal

Returns a static signal in the event that a fault was detected (criteria similar to D9.6).

The bit is reset by:

- Fault acknowledgement

or

- an action subsequent to a change of operating mode (e.g. Set Step in Manual mode).

3.5 Step Module

For each cascade, a step module named -SCHRKn ($1 \leq n \leq 30$) is created.

The step module contains the following for all controller types:

- the jump distributor to the active step, and
- a maximum of 128 steps.

The processing of the step module always begins with the line of the jump distributor belonging to the active step. From here, the jump to the actual step conditions takes place. Only the active step is processed.

As a rule, the step consists of two independent program parts:

- the manual part with the manual conditions,
and
- the automatic part with the conditions for automatic and inching conditions.

Both parts must be separately and independently concluded with the **EM** end module instruction.

In the event that the same conditions exist for the manual and automatic part, only one branch needs to be programmed.

Both the manual and the automatic part are again separated into:

- a command output (BEFA) branch, and
- step-on condition (WSB) branch.

Any number of BEFA and WSB branches can be programmed within a given step.

In the process of diagnosing sequencing faults, the first non-satisfied BEFA branch subsequent to the beginning of the step is indicated. If all BEFA branches are satisfied, the first non-satisfied WSB branch is indicated.

Basic Precepts

- ◆ **Only unconditional jumps may be programmed in the jump distributor. The jump sequence must correspond to the sequence of jump destinations.**
- ◆ **Prior to the jump distributor, other instructions are not permitted. The first instruction of the jump distributor must be JP [A].**
- ◆ **The jump distributor may not be interrupted by extraneous instructions.**
- ◆ **The number of jumps in the jump distributor must correspond to the number of configured steps. If this is not the case, no diagnostics will be possible.**
- ◆ **A module call from within a -SCHRKn step module is not permitted.**
- ◆ **The jump distributor and/or the jump destination in the -SCHRKn step module may not be changed and/or modified with the use of the Replace function in the monitor program.**

The KETTE200 function module ensures that the step is always called with the Carry flag reset. For this reason, the JPCY jump instruction that is inserted only for diagnostic purposes is never executed, and the consequence is a linear program process.

All instructions from the instruction set of the CL200 are permitted within the range between the jump instruction and the diagnoseable links (subsequent to the jump destination).

In the event that only bit links occur during a given step, the JPCY jump can be omitted (as demonstrated here in step 2).

The structure of a step module for the CL200 appears as follows:

```

JP          [A]
JP          -Schritt1
JP          -Schritt2
:          :
JP          -Schrittn

          -Schritt1
JPCY          -VERKN1      ; for diagnostic module only

; Change of wait time for this step only
L          W          Kxxx,A
T          W          O,D18

; Change of monitoring time for this step only
L          W          Kyyy,A
T          W          O,D20

; Transfer of branching address
L          W          Kzzz,A
T          W          O,M188

; Branching of Manual & Automatic mode
          -VERKN1
L          W          D8,A      ; branch selection
A          B          O.4
JPC          -AUTO      ; Automatic branch? -> Yes

; Links for Manual mode
A          B          IO.0
=          B          -BEFA
A          B          IO.1
=          B          -WSB      ; Mandatory requirement
EM          ; for end of step.

```

```

; Links for Automatic and Inching mode
  -AUTO
A   B           I0.6
=   B           -BEFA
A   B           I0.7
=   B           -WSB           ; Mandatory requirement
EM                               ; for end of step.

  -Schritt2
A   B           I0.2
=   B           -BEFA
A   B           I0.3
=   B           -WSB           ; Mandatory requirement
EM                               ; for end of step.

```

Fig. 3-9 Step Module for CL200

In the event that a given step has identical Manual and Automatic mode movements, the selection of the operating mode can be omitted (as in step 2).

3.5.1 Diagnostics

The monitoring function is handled by the KETTE200 function module.

The presence of scratch markers in steps can lead to undefinable diagnostic results (e.g. the wait time also comprises a scratch marker).

3.6 Cascade Data Module

The cascade data module managing the sequential control provides all essential system control data.

	Symbol	Explanation	Data format	Entry made by: K: KETTE200 B: BTSMADAP A: User
D00	nnFehler	Fault bits	binary	K
D02	nnKettNr	Cascade number n (1 thru 30)	decimal	A
D04	nnSchAnz	Number of steps in cascade	decimal	A
D06	nnBaWahl	OpMode selection	binary	A
D08	nnBaMldg	Reported OpMode	binary	K
D10	nnSchr-1	Step number, preceding step	decimal	K
D12	nnSchr.	Step number, current step	decimal	K
D14	nnSchr.S	Step number, Set Step instruction	decimal	B
D16	nnBefaAus	Step number for command output	decimal	K
D18	nn-KWA	Actual value, wait time	dec x 100ms	K/A
D20	nn-KUE	Actual value, monitoring time	dec x 100ms	K/A
D22	nn-SKWA	Setpoint value, cascade wait time	dec x 100ms	A
D24	nn-SKUE	Setpoint value, cascade monitoring time	dec x 100ms	A
D26				K
D28				K
D30				K
D32	nnK/S_1L	HBy = Cascade no./ LBy = Step no. to movement screen, line 1 left	hex	A
::	::	as in D32, for movement left		A
D38	nnK/S_4L	HBy = Cascade no./ LBy = Step no. to movement screen, line 4 left	hex	A
::	::	as in D40 - D46, reserved for movement		A
D48	nnK/S_1R	HBy = Cascade no./ LBy = Step no. to movement screen, line 1 right	hex	A
::	::	as in D48, for movement right		A
D54	nnK/S_4R	HBy = Cascade no./ LBy = Step no. to movement screen, line 4 right	hex	A
::	::	as in D56 - D62, reserved for movement		A
D64	internal	occupied by KETTE200		K
::	::	::		K
D80	internal	occupied by KETTE200		K

Fig. 3-10 CL200 Cascade Data Module

Movement Screen and Data Module Allocations:

Movement screen 211 -> DM1, D32

Movement screen 212 -> DM2, D32, and so forth.

D0 Data Word Allocation

Bit	Error and/or Status Message	Fault Correction
15		
14		
13		
12		
11		
10		
9		
8		
7		
6		
5		
4		
3	Faulty / incorrect step conclusion	Each step must be concluded with the following command sequence: $= \quad B \quad WSB$ EM → Check and correct program code.
2	Step contains opcode that cannot be diagnosed.	Step could contain load or transfer instructions that cannot be diagnosed. → Check and correct program code.
1	Step module (PM) not available.	The program module assigned to a defined data module is not available/not found. → Ensure that module is linked.
0	Number of steps too high or zero.	Number of steps must be > 0 and ≤ 128. → Check and correct program code.

Fig. 3-11 Fault Word in CL200 Cascade Data Module

Interpretation of Actual and Setpoint Values for Wait and Monitoring Time (D18, D22 and D20, D24).

At the point of entry into a new step, the KETTE200 module checks whether the actual values for wait and monitoring time (D18, D20) have been set by the application program. In the case of values $\neq 0_{dez}$, these will be interpreted as valid times for the active step. If this is not the case, the time default values are taken from the setpoint values (D22, D24).

In the event that a wait is defined only within a given step with the use of D18, data word D22 must still be preset with default value of $\neq 0_{dez}$ because otherwise the KETTE200 module will not process data word D18.

3.7 Command Output

It is only logical that the command output occurs directly subsequent to the call-up of the KETTE200 cascade management module.

This is the intended purpose of the BEFAKn command output modules (numbers $1 \leq n \leq 30$) which are called subsequent to the processing of the BTSMADAP module.

Here the current step is compared as an actual value with the setpoint constants for the command and, if both are found to be equal, the command enable is given.

If no BEFA command output branch is satisfied within the cascade sequence, data word D16 is deleted.

The following is an example of command output in the BEFAK1 module for a cascade sequence (SCHRK1) with four steps:

```

CM          DM1      ; Open Kettel cascade module
L   W      D16,A    ; active output

; Step 1
CPLA W      K1,A    ; BEFA for Step 1
A   B      C       ; BEFA = 1 ?
=   B      O1.0    ; Enable output

; Step 2
CPLA W      K2,A    ; BEFA for Step 2
A   B      C       ; BEFA = 2 ?
=   B      O2.0    ; Enable output

; Step 3
CPLA W      K3,A    ; BEFA for Step 3
A   B      C       ; BEFA = 3 ?
=   B      O3.0    ; Enable output

; Step 4
CPLA W      K4,A    ; BEFA for Step 4
A   B      C       ; BEFA = 4 ?
=   B      O4.0    ; Enable output
EM

```

Fig. 3-12 CL200 — Command Output

The above command output program instructions must be repeated for all active cascade sequences and for all steps.

4 CL350 / CL400 / CL500 Control Functions

4.1 Introduction

Chapter 3 discusses the control sequence management, including the different operating modes it provides, plus process organization and command output functions. Function modules are available to handle the sequential control, diagnostic functions and display processes.

4.2 Definitions

To ensure orderly sequential processing and/or ascertain the production of unambiguous diagnostic values, the use of the BT-MADAP software package shall be governed by the definitions and conventions outlined below.

4.2.1 Modules

The KETTE function module manages a maximum of

- 60 control sequences,
- containing 128 steps each,
- with one active step per each cycle.

The following modules are permanently assigned to the above control sequences:

- Function modules PM1 - PM60 (control sequences)
- Data modules DM1 - DM60 (cascade data modules)

Here the PM and DM numbers correspond to the cascade numbers.

Data storage and transfer is handled by the DM120 data module.

4.2.2 Markers

Within the range of available markers, the markers listed below are assigned a permanent function.

Symbol	Address CL400/CL500	Function
BEFA	M255.0	Assigned to command output.
WSB	M255.1	Assigned to step-on function.
STOEM	M255.2	Fault marker; fault is indicated by $STOEM = 0_{bin}$.
HALBAUTO	M255.4	Step-on in Inching mode also without S+1 transition.
WZT_HLT	M255.5	Wait time stop.
WZT	M255.6	Wait time status 0_{bin} : Wait time running 1_{bin} : Wait time expired
UEKONTR	M255.7	Monitoring time check If $UEKONTR = 1_{bin}$, expiration of monitoring time will not trigger diagnostic function.
VERZW	M242	Branching address (word) Step number within the cascade to which branching is to take place if $WSB = 1_{bin}$.

Fig. 4-1 CL400 / CL500 Control Functions, Marker Definitions

4.3 Programming

4.3.1 Module Call

The KETTE cascade management module is called within the function modules designated KETTE1 (PM101) through KETTE60 (PM160), and then services all defined cascade sequences. The required operating modes are transferred to the respective parameter of the KETTE module. In order to be able to form functional groups of cascade sequences, it is possible to leave strategic gaps when creating the cascade data modules. Those cascade sequences for which no data module was defined in the OM1 organization module will then be skipped, and processing will continue with the subsequent cascade sequence. In the event that step modules are to be excluded from processing, the associated cascade module must be declared as a comment at the time it is called up.

For the CL400 / CL500, the module call is structured as follows:

```

CM      -KETTE,4
;
;          +----+
P0 W   -PM/DM   ; < ! Cascade and DM number (1≤n≤60)
P1 W   -BETR    ; < ! Operating mode selection
P2 W   -KUE     ; < ! Time value, monitoring time
P3 W   -KWA     ; < ! Time value, wait time
;          . +----+
    
```

Fig. 4-2 CL400 / CL500 Calling KETTE Module

4.3.2 Program Structure




Fig. 4-3 CL400 / CL500 Control Functions — Module Structure

4.3.3 KETTE Parameter Description

NOTE: No scratch markers belonging to the range indicated below may be used as parameters.

CL400/CL500 M230.0 - M255.7

P0	W	-PM/DM	(Input parameter)	<p>Via parameter P0, the KETTE cascade management module receives the current cascade number n for the following modules:</p> <ul style="list-style-type: none"> • Number of step module SCHRKn • Number of cascade data module DMn <p>Each cascade sequence n being processed utilizes a cascade data module to store variable data, e.g. current step, monitoring time and wait time.</p>
P1	W	-BETR	(Input parameter)	<p>This parameter is used to transfer the selected OpMode (operating mode) to the KETTE module:</p> <ul style="list-style-type: none"> • P1.0 Manual mode (H) • P1.1 Inching mode (T) • P1.2 Automatic mode (A) • P1.3 Start • P1.4 S + 1 • P1.5 Set Step • P1.6 Halt acknowledgement • P1.7 Reset • P1.8 Halt • P1.9 Synchronize • P1.10 • P1.11 Generate cascade data module • P1.12 No step-on in same cycle • P1.13 • P1.14 WSB does not reset BEFA • P1.15 Fault acknowledgement <p>The KETTE cascade management module writes the OpMode data into data word D6 (nnBAWAHL) of the associated cascade data module. When in Manual mode (H), the Start and Set Step command value is transferred only upon actuating the movement keys on the operator terminal.</p>
P2	W	-KUE	(Input parameter)	<p>Parameter P2 is used to transfer the value for the monitoring time to the KETTE cascade management module. Unless it is again defined within the individual steps, this value will remain the same for every step. The time base is always 100 ms. For example, a default value of</p> <ul style="list-style-type: none"> • P2W K20D <p>will result in a monitoring time of 20 x 100 ms = 2 seconds</p>

The maximum monitoring time is 109 minutes.
 The monitoring time value is entered into data word D20 of the associated cascade data module.

P3 W KWA
 (Input parameter)

Parameter P3 is used to transfer the value for the monitoring time to the KETTE cascade management module. Unless it is again defined within the individual steps, this value will remain the same for every step. The time base is always 100 ms. For example, a default value of

- P3 W K15D

will result in a monitoring time of 15 x 100 ms = 1.5 seconds

The maximum wait time is 109 minutes.

The wait time value is entered into data word D18 of the associated cascade data module.

4.3.4 Register Contents

The PLC registers A, B, C, and D, plus the control flags (e.g. RES, Carry) are not retained beyond the module call. Upon returning from the KETTE cascade management module to the calling module, the registers will contain the contents that are defined as listed in the following table.

Reg.	Contents
A	Version number of KETTE module.
B	Fault codes, if cascade data module not generated.
C	No relevance.
D	No relevance.

Fig. 4-4 KETTE Module, Register Contents

Fault Codes in Register B

Accu B Contents	Fault remedy
FFFF _{hex}	Cascade data module not found
0001 _{hex}	P0 of KETTE module = 0 _{dec}
0002 _{hex}	P0 of KETTE module = > 64 _{dec}
0004 _{hex}	Cascade data module is too short = < 96 _{dec}

Fig. 4-5 Fault Codes in Register B of KETTE Module

4.4 Operating Modes

The operating mode (briefly called *OpMode*) is transferred via parameter P1 in the KETTE cascade management module, from where it is mirrored into data word D6 of the associated cascade data module.

Data word D30 is used for parallel operation of the function module via interfaces.

The Manual, Inching and Automatic OpModes cannot be operated in parallel.

The following definitions are used for parallel operation:

D6.3 / D30.3 Start

D6.5 / D30.5 Set Step

D7.1 / D31.1 Synchronize, only if $D24.2 = 1_{bin}$

4.4.1 Manual Operation / Setup

Function

Manual step operation in consideration of the manual branching conditions.

The step is entered in data word D14 of the associated cascade data module, and accepted as the current step by means of the Set Step instruction ($D6.5 = 1_{bin}$) in D12.

The command output is enabled when

- the conditions of the Manual branch have been met ($BEFA = 1_{bin}$ and $WSB = 0_{bin}$), and
- when the Start ($D6.3$) = 1_{bin} .

The command output occurs via the data bits of data words D80 through D94 of the associated cascade data module (see cascade data module).

No **step-on** is enabled.

Programming

The Manual mode and Start bits must be statically set to 1_{bin} .

In the DM1 through DM16 screen data modules, the cascade and step number to be selected (see movement screens) must be entered upwards of data word D32.

Pressing a movement key in a movement screen on the operator terminal causes the associated cascade data module to be activated by means of the cascade number, the step number to be entered in D14, and Set Step ($D6.5$) and Start ($D6.3$) to be set to 1_{bin} .

Diagnostics

The display in cascade information indicates **H** ("Hand") for Manual mode at the corresponding cascade sequence.

Display of all criteria of the manual branch, either of the non-executed BEFA command output or of the WSB step-on condition branch.

Monitoring and wait times are loaded with the defined values but not started.

No fault message is returned.

4.4.2 Inching Mode / Single Step

Function

Step-by-step processing of steps in accordance with conditions of the automatic branch.

The command output is enabled when

- the conditions of the automatic branch have been met, ($BEFA = 1_{bin}$, and $WSB = 0_{bin}$), and
- when the Start ($D6.3$) = 1_{bin} .

The command output occurs via the data bits of data words D80 through D94 of the associated cascade data module (see cascade data module).

No **step-on** is enabled.

In the case of a positive transition on S+1 ($D6.4$), if WSB step-on conditions are met, the step-on to the next step will occur.

Programming

The Inching bit is to be statically set to 1_{bin} . Start = 1_{bin} causes the current step to be processed, and a positive transition on S+1 causes the step-on into the subsequent step.

Diagnostics

Display in cascade information indicates **T** (indicating incremental advance by *Touch* control) for Inching mode at the corresponding cascade sequence.

Display of all criteria of the automatic branch, either of the non-executed BEFA or of the WSB branch.

The faulty cascade sequence is displayed.

Monitoring and wait time elapse with the default nominal values.

4.4.3 Semi-automatic Mode

Function

Semi-automatic processing of steps in accordance with conditions in the automatic branches.

The command output is enabled when

- the conditions of the automatic branch have been met (BEFA = 1_{bin}, and WSB = 0_{bin}), and
- when the start (D6.3) = 1_{bin}.

The command output occurs via the data bits of data words D80 through D94 of the associated cascade data module (see cascade data module).

With the WSB step-on conditions met, and the -HALBAUTO (M255.4) marker set, the **step-on occurs automatically**. The step-on ends with the step in which the -HALBAUTO = 0_{bin} marker is located, or if the WSB step-on condition has not been met.

With a positive transition on S+1 (D6.4), the satisfied WSB step-on conditions will cause the subsequent program sequence to be processed up to the reset -HALBAUTO marker.

Programming

The Inching bit is to be statically set to 1_{bin}. Start = 1_{bin} causes the current step to be processed, and a positive transition on S+1 causes the semi-automatic mode to be started.

Diagnostics

Display in cascade information indicates **T** (indicating incremental advance by *Touch* control) for Inching mode at the corresponding cascade sequence.

Display of all criteria of the automatic branch, either of the non-executed BEFA or of the WSB branch.

The faulty cascade sequence is displayed.

Monitoring and wait time elapse with the default nominal values.

4.4.4 Automatic Mode

Function

Automatic processing of steps in accordance with conditions in the automatic branches.

The command output is enabled when

- the conditions of the automatic branch have been met ($BEFA = 1_{bin}$, and $WSB = 0_{bin}$), and
- when the start ($D6.3$) = 1_{bin} .

The command output occurs via the data bits of data words D80 through D94 of the associated cascade data module (see cascade data module).

If the WSB (step-on conditions) = 1_{bin} , the **automatic step-on** occurs.

Programming

Automatic mode (D6.2) and Start (D6.3) bits to be statically set to 1_{bin} .

Diagnostics

Display in cascade information indicates **A** for Automatic mode at the corresponding cascade sequence.

Display of all criteria of the manual branch, either of the non-executed BEFA or of the WSB branch.

The faulty cascade sequence is displayed.

Monitoring and wait time elapse with the default nominal values.

4.4.5 D6 — Selected Operating Mode

Further to the operating modes discussed in the preceding sections, the D6 data word in the cascade data module contains additional information relative to operating modes.

D6 nnBaWahl

This data word is written to by the KETTE cascade management module via parameter P1 (-BETR).

D6.0	Manual mode H
D6.1	Inching mode T
D6.2	Automatic mode A
D6.3	Start s
D6.4	S + 1
D6.5	Set Step
D6.6	Fault acknowledgement
D6.7	Reset r
D7.0	Halt h
D7.1	
D7.2	
D7.3	
D7.4	
D7.5	
D7.6	WSB does not reset BEFA (Manual only)
D7.7	Fault requires acknowledgement

Fig. 4-6 D6 — Selected Operating Mode

D6.0 Manual Mode

Define Manual mode.

D6.1 Inching Mode

Define Inching mode.

D6.2 Automatic Mode

Define Automatic mode.

D6.3 Start

Start / Command output enable

The bit is valid for all operating modes, and is statically transferred to parameter P1 of the KETTE cascade management module.

If Start = 0_{bin}, the following will occur:

- BEFA is deleted
- monitoring time is halted
- wait time continues to elapse

To generate the cascade data modules, and to effect synchronization in Automatic mode, the Start instruction must be deleted.

D6.4 S+1

Execute the subsequent step.

In INCHING mode, a positive transition of this bit and satisfied step-on condition ($WSB = 1_{bin}$) will cause the next step to be executed.

In SEMI-AUTOMATIC mode, a positive transition of this bit, satisfied step-on condition ($WSB = 1_{bin}$), and with -HALBAUTO marker set, cause the subsequent cascade sequence to be processed up to the reset - HALBAUTO marker.

D6.5 Set Step

Accept preselected step number.

In MANUAL mode, the step prepared in D14 is transferred to the active step (D12), and subsequently processed.

D6.6 Halt Acknowledgement

Manual fault acknowledgement.

Effective only if $D7.7 = 1_{bin}$ (manual fault acknowledgement).

A positive transition on this bit acknowledges a fault (cascade halted) that was triggered by an expired monitoring time or by the reset fault marker.

Monitoring and wait times are loaded with the defined values but not started.

D6.7 Reset

Resetting the cascade

$D6.7 = 1_{bin}$ will initiate the following actions:

- Deletion of active step
- Reinitialization of cascade sequence
- Generates new cascade data module

Subsequent to Reset, step 1 is prepared.

D7.0 Halt

Stop cascade progress.

If this bit is set, the cascade is stopped, and the current step continues to be processed. For $D7.0 = 1_{bin}$, the following applies:

- BEFA is output
- monitoring time is halted
- wait time is halted

D7.1 Synchronize

Cascade is synchronized.

This option is available in both Manual and Automatic OpModes. For Automatic mode, $D6.3 = 0_{bin}$ is also required.

If this bit is set, the KETTE cascade management module searches the cascade for satisfied preconditions, and synchronizes the step processing procedure in accordance with the selected OpMode.

The following comprise the preconditions for a successful synchronization:

- $BEFA = 1_{bin}$, and
- $WSB = 0_{bin}$

For all steps that meet the preconditions for synchronization, the bit associated with the respective step is set in the data block comprising D48 through D62.

In the event that in Automatic mode exactly one step is found that meets the preconditions for synchronization, this step will be prepared.

In the case of AND branches, because the cascades are viewed independent of each other, the options for synchronization with Automatic mode are limited.

D7.3 Learning

Generate cascade data module

The KETTE cascade management module generates the data for the cascade data modules when one of the following conditions applies: Bit D7.3 is set; subsequent to program loading, subsequent Power-On of controller, or subsequent to Reset. This cascade-specific data is determined on the basis of the associated step modules, and the parameter settings of the KETTE module. As a prerequisite for this, $D6.3 = 0_{bin}$ must be true.

D7.4 Step Sequencing

No step-on effected within the same cycle.

Automatic mode only.

- If $D7.4 = 1_{bin}$, only one step is processed per each PLC cycle.
- If $D7.4 = 0_{bin}$, the satisfied WSB step-on condition causes the subsequent step within the same cycle to be activated.

D7.6 WSB does not reset Command Output (BEFA)

Manual mode only.

- If $D7.6 = 1_{bin}$, a satisfied WSB step-on condition will not reset the associated BEFA command output.
- If $D7.6 = 0_{bin}$, a satisfied WSB step-on condition will cause the BEFA command output to be reset.

D7.7 Acknowledge

Fault acknowledgement

If this bit is set, an occurring cascade fault must be acknowledged by bit D6.6.

If D7.7 is reset, and the WSB step-on condition is satisfied, the cascade will auto-acknowledge.

4.4.5.1 OpMode Bit Priorities

If several operating mode bits are selected simultaneously in data word D6 of the cascade sequence, processing is subject to the following priority ranking:




Fig. 4-7 OpMode Mode Priorities

4.4.6 D8 — OpMode Message

The D8 data word of each cascade data module contains the return message indicating the operating mode that is enabled once the KETTE cascade management module has been processed.

D8 nnBaMldg

D8.0	Manual mode H
D8.1	Inching mode T
D8.2	Automatic mode A
D8.3	Start for all operating modes s
D8.4	Automatic or Inching mode enabled
D8.5	Synchronization in progress
D8.6	Wait time elapsing
D8.7	Reset, cascade is reset r
D9.0	Halt, cascade is halted h
D9.1	No synchronization possible
D9.2	More than one step with BEFA = 1 _{bin} , synchronization
D9.3	Cascade data module generated
D9.4	
D9.5	
D9.6	Fault pulse
D9.7	Static fault

Fig. 4-8 D8 — Reported OpMode

D8.0 Manual Mode

The cascade is in Manual mode.

Confirmed by display of symbol **H** in cascade information of operator terminal.

D8.1 Inching Mode

The cascade is in Inching mode.

Confirmed by display of symbol **T** in cascade information of operator terminal.

D8.2 Automatic Mode

The cascade is in Automatic mode.

Confirmed by display of symbol **A** in cascade information of operator terminal.

D8.3 Start

The cascade has received the start bit.

Confirmed by display of symbol **s** in cascade information of operator terminal.

D8.4 Automatic / Inching

The cascade is in Automatic or Inching mode.

This bit is used to select whether the manual or automatic branch is to be processed in the step module.

D8.4 = 1_{bin}, Automatic OR Inching mode is enabled.

D8.4 = 0_{bin}, Manual mode is enabled.

D8.5 Synchronization in Progress

The cascade is being synchronized, confirming this status by indicating D8.5 = 1_{bin}.

D8.6 Wait Time Running

If the bit is set, this indicates that the wait time for this step has expired.

Prior to calling the step, the cascade management module causes the status of bit D8.6 to be simultaneously written to the WZT wait time halt marker (M255.6), making the wait time available to the steps as a diagnostic operand.

If the wait time has expired, the query:

- A B -WZT (wait time)

returns the value of 1_{bin}.

D8.7 Cascade Reset

The cascade is reset, and the active step deleted (D12 = 1_{bin} subsequent to Reset).

D9.0 Cascade Stopped

The cascade is in Stop mode.

This operating mode is enabled by the following:

- D7.0 = 1_{bin} (Stop)
- Fault marker M255.2 reset, or
- Fault in Automatic mode with monitoring time expired (only with manual acknowledgement via D7.7 = 1_{bin}).

D9.1 Synchronization Not Possible

The synchronization conditions:

- $BEFA = 1_{bin}$, and
- $WSB = 0_{bin}$

are not met in or by any step.

D9.2 More Than One Sync Step

In the process of synchronizing in Automatic mode, more than one step was found in which the conditions $BEFA = 1_{bin}$ and $WSB = 0_{bin}$ were true. The synchronized start of the Auto Continue automatic mode is not possible.

D9.3 Cascade Data Module Generated

If $D9.3 = 1_{bin}$ is true, this indicates that the learning cycle or generation of the cascade data module has been concluded.

Fault Pulse

Returns a pulse for a PLC cycle in the event that a fault was detected. Fault criteria are as follows:

- Reset fault marker
- or
- Expired monitoring time.

D9.7 Static Fault Signal

Returns a static signal in the event that a fault was detected (criteria similar to D9.6).

The bit is reset by:

- Fault acknowledgement
- or
- an action subsequent to a change of operating mode (e.g. Set Step in Manual mode).

4.5 Step Module

For each cascade, a step module named -SCHRKn ($1 \leq n \leq 60$) is created.

The step module contains the following for all controller types:

- the jump distributor to the active step, and
- a maximum of 128 steps.

The processing of the step module always begins with the line of the jump distributor belonging to the active step. From here, the jump to the actual step conditions takes place. Only the active step is processed.

As a rule, the step consists of two independent program parts:

- the manual part with the manual conditions, and
- the automatic part with the conditions for automatic and inching conditions.

Both parts must be separately and independently concluded with the **EM** end module instruction.

In the event that the same conditions exist for the manual and automatic part, only one branch needs to be programmed.

Both the manual and the automatic part are again separated into:

- a command output (BEFA) branch, and
- step-on condition (WSB) branch.

Any number of BEFA and WSB branches can be programmed within a given step.

In the process of diagnosing sequencing faults, the first non-satisfied BEFA branch subsequent to the beginning of the step is indicated. If all BEFA branches are satisfied, the first non-satisfied WSB branch is indicated.

Basic Precepts

- ◆ **Only unconditional jumps may be programmed in the jump distributor. The jump sequence must correspond to the sequence of jump destinations.**
- ◆ **Prior to the jump distributor, other instructions are not permitted. The first instruction of the jump distributor must be JP [A].**
- ◆ **The jump distributor may not be interrupted by extraneous instructions.**

- ◆ Only jump instructions or comments may be inserted between the command
SP [A]
 and the 1st jump destination. Network branch identifiers are not permitted here.
- ◆ The number of jumps in the jump distributor must correspond to the number of configured steps.
 If this is not the case, no diagnostics will be possible.
- ◆ A module call from within a -SCHRKn step module is not permitted.
- ◆ The jump distributor and/or the jump destination in the -SCHRKn step module may not be changed and/or modified with the use of the Replace function in the monitor program.
- ◆ Non-bit instructions (e.g. links, time manipulation) must be programmed at the beginning of a branch.

The structure of a step module appears as follows:

```

JP          [A]
JP          -Schritt1
JP          -Schritt2
:           :
JP          -Schrittn

           -Schritt1

; Change of wait time for this step only
L   W      Kxxx,A
T   W      O,D18

; Change of monitoring time for this step only
L   W      Kyyy,A
T   W      O,D20

; Transfer of branching address
L   W      Kzzz,A
T   W      O,M242

; Branching of Manual & Automatic mode
L   W      D8,A           ; branch selection
A   B      0.4
JPM          -AUTO       ; Automatic branch? -> Yes

; Links for Manual mode
A   B      E0.0
=   B      -BEFA
A   B      E0.1
=   B      -WSB           ; Mandatory requirement
EM                               ; for end of step.

; Links for Automatic and Inching mode
           -Schritt2
A   B      I0.6
=   B      -BEFA
A   B      I0.7
=   B      -WSB           ; Mandatory requirement
EM                               ; for end of step.

```

```

-Schritt2
A   B           I0.2
=   B           -BEFA
A   B           I0.3
=   B           -WSB           ; Mandatory requirement
EM                               ; for end of step.

```

Fig. 4-9 Step Module for CL400 / CL500

In the event that a given step has identical Manual and Automatic mode movements, the selection of the operating mode can be omitted (as in step 2).

4.5.1 Diagnostics

The machine is monitored by the DIAG500E module.
The presence of scratch markers in steps can lead to undefinable diagnostic results (e.g. the wait time also comprises a scratch marker).

4.6 Cascade Data Module

The cascade data module managing the sequential control provides all essential system control data.

	Symbol	Explanation	Data format	Entry made by: K: KETTE B: BTSMADAP A: User
D00	nnFehler	Fault bits	binary	K
D02	nnKettNr	Cascade number n (1 through 60)	decimal	K
D04	nnSchAnz	Number of steps in cascade	decimal	K
D06	nnBaWahl	OpMode selection	binary	K
D08	nnBaMldg	Reported OpMode	binary	K
D10	nnSchr-1	Step number, preceding step	decimal	K
D12	nnSchr.	Step number, current step	decimal	K
D14	nnSchr.S	Step number, Set Step instruction	decimal	B
D16				
D18	nn-KWA	Actual value, wait time	dec x 100 ms	K/A
D20	nn-KUE	Actual value, monitoring time	dec x 100 ms	K/A
D22	nnINT0	internal use		
::	::	internal use		
D28	nnINT3	internal use		
D30	nnBa_Ext	OpMode selection for external operator terminals	binary	K
D32	nnINT4	internal use		
::	::	internal use		
D46	nnSyn16	Synchronization step 1 through 16	binary	K
::	::	::		K
D62	nnSyn128	Synchronization step 113 through 128	binary	K
D64	nnSch16	Steps 1 through 16	binary	K
::	::	::		K
D78	nnSch128	Steps 113 through 128	binary	K
D80	nnBef16	Command output for steps 1 thru 16	binary	K
::	::	::		K
D94	nnBef128	Command output for steps 113 thru 128	binary	K
D100	nnK/S_1L	HBy = Cascade no./ LBy = Step no. to movement screen, line 1 left	hex	A
::	::	as in D100, for movement left		A
D106	nnK/S_4L	HBy = Cascade no./ LBy = Step no. to movement screen, line 4 left	hex	A
::	::	as in D108 - D114, res'd for movement		A
D116	nnK/S_1R	HBy = Cascade no./ LBy = Step no. to movement screen, line 1 right	hex	A
::	::	as in D116, for movement right		A
D122	nnK/S_4R	HBy = Cascade no./ LBy = Step no. to movement screen, line 4 right	hex	A
::	::	as in D124 - D130, res'd for movement		A

Fig. 4-10 CL400 / CL500 Cascade Data Module

Movement Screen and Data Module Assignments:

Movement screen 211 -> DM1, D32

Movement screen 212 -> DM2, D32, and so forth.

D0 Data Word Assignment

Bit	Fault and/or Status message	Fault Correction
15	Structural fault in step module	The structure of the jump distributor does not correspond with the programmed step sequence. Step sequence runs correctly but diagnostics not possible. → Correct the program structure.
14		
13		
12		
11		
10		
9		
8		
7		
6		
5		
4		
3	Jump instruction fault	The 1st instruction in the step module must be the following jump instruction: SP [A] Between this and the 1st jump destination, for example: -S1 only the jump instruction or comment lines may be inserted. Attention Networks! → Check and correct program code.
2	Reference list	The available module is faulty. → Recompile and reload program.
1	Step module (PB) not available	The function module assigned by a defined data module is not available. → Ensure that module is linked.
0	Number of steps too high or zero	Number of steps must be between > 0 and \leq . → Check and correct program code.

Fig. 4-11 Fault Word in CL400 / CL500 Cascade Data Module

Interpretation of Wait and Monitoring Time (D18, D20)

At the point of entry into a new step, the KETTE200 module checks whether the actual values for wait and monitoring time (D18, D20) have been set by the application program. In the case of values $\neq 0_{dec}$, these will be interpreted as valid times for the active step. If this is not the case, the time default values are taken from parameters P2 and P3 of the KETTE cascade management module.

4.7 Command Output

It stands to reason that the command output occurs immediately subsequent to the call-up of the KETTE cascade management module.

This is the intended purpose of the KETTE_n modules (numbers $1 \leq n \leq 60$) which handle the command output subsequent to the processing of the KETTE cascade management module.

For this purpose, the corresponding data word (D80 - D94) for command output is loaded.

The following is an example of command output for a cascade sequence (KETTE1) with four steps:

```

CM          -KETTE,4   ;Call cascade management
P0   W      -PB/DM     ;Cascade and DM no.
P1   W      -BETR      ;OpMode selection
P2   W      -KUE       ;Time value, monitoring time
P3   W      -KWA       ;Time value, wait time

CM          DM1        ; Open Kettle cascade module
L    W      D80,A      ; active output

; Step 1
A     B        0.0      ; BEFA = 1 for step 1
=     B        01.0     ; Enable output

; Step 2
A     B        0.1      ; BEFA = 1 for step 2
=     B        02.0     ; Enable output

; Step 3
A     B        0.2      ; BEFA = 1 for step 3
=     B        03.0     ; enable output

; Step 4
A     B        0.3      ; BEFA = 4 for step 4
=     B        04.0     ; Enable output
EM

```

Fig. 4-12 CL400 / CL500 — Command Output

Subsequent to calling the KETTE cascade management module, the above command output program instructions must be repeated for all active cascade sequences and for all steps in the corresponding KETTE1 through KETTE60 modules.

5 BTSMADAP & BTS_ZV Function Modules

5.1 BTSMADAP Function Module

The BTSMADAP function module prepares the data from the programmable logic controller (PLC) for the operator terminal, and transfers requests issued by the operator terminal to the PLC. The relevant parameterization is almost identical for all controller variants³. In the case of the CL200, the respective module number for the KETTE200 function module must be taken from the symbol file and transferred to parameter P1 in the form of a decimal constant. This results in the subsequent module calls discussed in 4.2 and 4.3, below, that can be loaded into the module editor by means of the Load Parameter List function of the programming device.

5.1.1 Module Functions

The BTSMADAP module

- controls the manual operation,
- calls up the diagnostic module,
- prepares the diagnostic data stored in DM120 for display on the operator terminal,

and

- controls the status display,

as well as the

- status messages.

In order to handle the described tasks, the BTSMADAP module requires two data modules — one for processing the diagnostic data, and the other for general communications between operator terminal and PLC.

³ Applies to CL200 with BTSMADAP, version 1.1 and higher.

5.2 BTSMADAP Function Module for CL200

5.2.1 Prerequisites and Allocations

Hardware:

BT5, variant HF000040 and up

BT20, variant HB000400 and up

ZE200, version 1.1 and higher, type 1 front panel

Software:

TesiMod, version 4.0 and higher

KETTE200, version 1.1 and higher

Allocations:

Counter: C0

Scratch markers: M188 through M191

BT Markers, M178 through M188

Data field, DF8196 through DF8190

5.2.2 Description of Parameters

CM		-BTSMADAP, 2		
			; +----+	
P0	W	-Kett_Anz	; <	! Number corresponds to the last cascade number
P1	W	-K200	; <	! KETTE200 module number as a constant
			; +----+	

Fig. 5-1 Call-up of BTSMADAP Function Module for CL200

P0-Kett_Anz

At this point the number of the last cascade sequence is entered in the form of a decimal constant. Gaps in the cascade sequence numbers are permitted.

Example: Cascade sequences 1 through 5, 7, and 10 through 15 are available. Therefore, parameter P0 is structured as follows:

- P0 word K15

P1 K200 (delete "-" symbol)

Absolute address as decimal constant of the KETTE200 function module which is internally called from within the BTSMADAP module.

5.3 BTSMADAP Function Module for CL400 / CL500

5.3.1 Prerequisites and Allocations

Hardware:

BT5, variant HF000040 and up

BT20, variant HB000400 and up

ZE400, version 1.2 and higher, front panel 1

SK500, version 102 and higher, front panel 2

with ZS500, version 104 and higher, type 3 front panel, OR

with ZS501, version 103 and higher, type 2 front panel, OR

with ZS510, version 301 and higher, type 1 front panel

Software:

TesiMod, version 4.0 and higher

DIAG500E, version 2.1 and higher

KETTE, version 2.1 and higher

Allocations:

Counter: C0

Scratch markers: M230 through M254

BT Markers: M178 through M188

5.3.2 Description of Parameters

CM		-BTSMADAP, 3		
			; +----+	
P0	W	-Kett_Anz	; <	! Number corresponds to the last cascade number
P1	W	-K180	; <	! Start addr. in oper. screen, delete "-"
P2	W	-DIAG500E	; <	! Diagnostics module
			; +----+	

Fig. 5-2 Call-up of BTSMADAP Function Module for CL400 / CL500

P0 -Kett_Anz

At this point, the number of the last cascade sequence is entered in the form of a decimal constant. Gaps in the chronological sequence of cascade sequence numbers are permitted.

Example: Cascade sequences 1 through 5, 7, and 10 through 15 are available. Therefore, parameter P0 is structured as follows:

- P0 word K15

P1 K180 (delete "-" symbol)

Parameter P1 is used to establish the reference to the movement screens. The base address is defined as the decimal constant of the markers used in the movement screens. As a default, the BT-MADAP module uses the markers from M180 upward. Accordingly, the following applies to P1:

- P1 K180

P2-DIAG500E

Symbolic address of DIAG500E diagnostic module that is internally called from within the BTSMADAP module.

5.3.3 DIAG500E Diagnostic Messages

Data word DM254/D510 is used to return the messages of the DIAG500E diagnostic module.

The messages comprise fault messages that cannot be entered in the cascade data module in data word D0. The status word has the following meaning:

Bit	Cause of Fault	Troubleshooting
15	Group fault indication.	At least one of the following faults, except bit 0, is present:
14	No significance.	
13	Number of main station cascades (P6) > Total number, cascades (P3).	Number of main station cascades (P6) > Total number, cascades (P3). →Correct the parameterization.
12	Data module for cascade not available or too short.	The DIAG500E module attempts to diagnose a cascade sequence but is either unable to find the corresponding data module, or module is incomplete. →Link data modules of correct length with the program.
11	No free memory capacity in data field.	BOSCH standard modules occupy blocks in data fields. A total of 12 data field blocks are available. →Reduce the total number of call-ups of BOSCH modules.
10	Step number too high.	The step number to be diagnosed is 128. You may have selected a number larger than 128 in the Manual mode of the cascade sequence.

Bit	Cause of Fault	Troubleshooting
9	Cascade number not permitted with manual diagnostics.	Parameter P2 of DIAG500E module is not within permitted range between 1 and 64. → Modify parameter settings.
8	Invalid number of cascade sequences.	Parameter P3 of DIAG500E module has a value higher than 64. You cannot, however, process more than the maximum of 64 cascade sequences. → Modify parameter settings.
7	Fault in system area (system instruction).	This bit indicates that too many system instructions (e.g. LAD and TAD) are being used in the entire PLC program. → Reduce the number of system instruction calls or utilize sequential call coordination. In this context, see also the manual entitled CL500 System Instructions , order no. 1070 072 068.
6	Structural fault in cascade sequence jump distributor.	The DIAG500E module has detected a structural fault in the jump distributor for the cascade sequence. The cause may be that the step sequence in the jump distributor does not correspond to that in the step program. → Modify the step sequence either in the cascade module or in the jump distributor.
5	Data field address (P7) too high.	The data field base address has been defined too high, denying the requested substations needed space in the data field area. → Define a smaller start address.
4	Too many conditions in the branch to be diagnosed.	In the BEFA command output or WSB step-on condition branch, the maximum number of 64 conditions per BEFA or WSB allocation was exceeded. → Divide the branch into several subbranches.

Bit	Cause of Fault	Troubleshooting
3	Illegal instruction in the branch to be diagnosed.	In the BEFA or WSB branch, you gave user instructions that cannot be diagnosed. You can program these instructions at any time prior or subsequent to the cascade branches. →Modify your cascade sequence.
2	No significance.	
1	No significance.	
0	Warning: number of cascades = 0, without group fault indication.	Parameter P3 of the DIAG500E module has the value of 0. →Change this value to suit your application.

Fig. 5-3 DIAG500E Status Message in DB254/D510 Data Word

5.4 BTS_ZV Function Module

The BTS_ZV function module services the end position and active bits in the operating screens of the BT operator terminals. The parameterization is identical for all controller variants. The module must be called for each operating screen that is used. This results in the subsequent module call (discussed in 4.4.2, below) that can be loaded into the module editor by means of the Load Parameter List function of the programming device.

5.4.1 Module Functions

The BTS_ZV function module

- indicates the active end positions, and
 - indicates the active outputs
- in the screens used on the operator terminals.

5.4.2 Calling the BTS_ZV Function Module

```

CM          -BTS_ZV,18
; +----+
P0  W      -MASKNR      ; <  ! Screen no. in which the variables are used.
P1  W      -K180        ; <  ! Start addr. disp'd in oper. screen, delete "-"
P2  B      -I_Z_1       ; <  ! EndPosit  1 Z = STRPOS (Start position)
P3  B      -O_Z_1       ; <  ! ComdExec  1 Z = STRPOS
P4  B      -I_Z_2       ; <  ! EndPosit  2 Z = STRPOS (Start position)
P5  B      -O_Z_2       ; <  ! ComdExec  2 Z = STRPOS
P6  B      -I_Z_3       ; <  ! EndPosit  3 Z = STRPOS (Start position)
P7  B      -O_Z_3       ; <  ! ComdExec  3 Z = STRPOS
P8  B      -I_Z_4       ; <  ! EndPosit  4 Z = STRPOS (Start position)
P9  B      -O_Z_4       ; <  ! ComdExec  4 Z = STRPOS
P10 B      -I_V_1       ; <  ! EndPosit  1 V = WRKPOS (Work position)
P11 B      -O_V_1       ; <  ! ComdExec  1 V = WRKPOS
P12 B      -I_V_2       ; <  ! EndPosit  2 V = WRKPOS (Work position)
P13 B      -O_V_2       ; <  ! ComdExec  2 V = WRKPOS
P14 B      -I_V_3       ; <  ! EndPosit  3 V = WRKPOS (Work position)
P15 B      -O_V_3       ; <  ! ComdExec  3 V = WRKPOS
P16 B      -E_V_4       ; <  ! EndPosit  4 V = WRKPOS (Work position)
P17 B      -O_V_4       ; <  ! ComdExec  4 V = WRKPOS
; +----+

```

Fig. 5-4 Call-up of BTS_ZV Function Module

5.4.2.1 Description of Parameters

If a marker address deviating from the standard is to be used, the corresponding parameterized constant value must be changed accordingly. This means that changes are also required of the respective parameters P2 through P17, and of the addresses in the variables file.

Upward of the base address defined with parameter P1, 4 marker bytes are used.

P0 -MASKNR

In this case, the number of the movement screen is entered in the form of a decimal constant in which the display of end positions and active bits is to be accomplished. Each movement screen that is used requires a corresponding module call of the BTS_ZV function module.

Example: Movement mask Hand 1/1 (Manual) is being used. The corresponding screen number (*MASKNR*) is 211:

- P0 word K211

P1 K180 (delete "-")

Parameter P1 is used to establish the reference to the movement screens. The base address is defined as the decimal constant of the markers used in the movement screens. As a default, the BT-MADAP function module uses the markers from M180 upward. Accordingly, the following applies to P1:

- P1 K180

Additional Parameters

No.	Bit	Abs.addr.	Symbol	Explanation
P2	B	M180.0	-E_Z_1	End position display, start position, 1st movement left
P3	B	M181.0	-A_Z_1	Active display, command output, start position, 1st movement left
P4	B	M180.1	-E_Z_2	End position display, start position, 2nd movement left
P5	B	M181.1	-A_Z_2	Active display, command output, start position, 2nd movement left
P6	B	M180.2	-E_Z_3	End position display, start position, 3rd movement left
P7	B	M181.2	-A_Z_3	Active display, command output, start position, 3rd movement left
P8	B	M180.3	-E_Z_4	End position display, start position, 4th movement left
P9	B	M181.3	-A_Z_4	Active display, command output, start position, 4th movement left
P10	B	M182.0	-E_V_1	End position display, work position, 1st movement left
P11	B	M183.0	-A_V_1	Active display, command output, work position, 1st movement left
P12	B	M182.1	-E_V_2	End position display, work position, 2nd movement left
P13	B	M183.1	-A_V_2	Active display, command output, work position, 2nd movement left
P14	B	M182.2	-E_V_3	End position display, work position, 3rd movement left
P15	B	M183.2	-A_V_3	Active display, command output, work position, 3rd movement left
P16	B	M182.3	-E_V_4	End position display, work position, 4th movement left
P17	B	M183.3	-A_V_4	Active display, command output, work position, 4th movement left

Fig. 5-5 Parameters P2 through P17 of BTS_ZV Function Module

In the symbol file, the symbolic addresses -I_C_1 through -O_V_4 must be arranged in a new order in accordance with system requirements. For example, I10.0 = -I_C_1, and similar modifications are required for additional movement masks.

Unused bit parameters must be set to "logic 0."

5.4.2.2 CL350 / CL400 / CL500 — Allocation of Synchronization Results

As a default, the display of the synchronization results in the movement screens is assigned to the following markers:

Abs. addr.	Explanation
M184.0	Display of 1st synchronization result, 1st movement left
M184.1	Display of 1st synchronization result, 2nd movement left
M184.2	Display of 1st synchronization result, 3rd movement left
M184.3	Display of 1st synchronization result, 4th movement left
M185.0	Display of 1st synchronization result, 1st movement right
M185.1	Display of 1st synchronization result, 2nd movement right
M185.2	Display of 1st synchronization result, 3rd movement right
M185.3	Display of 1st synchronization result, 4th movement right

Fig. 5-6 CL350 / CL400 / CL500 — Allocation of Synchronization Results

6 DM255 / 254 / 120 Data Modules

6.1 BTS_Diag Diagnostics Data Module (DM254)

The BTS_Diag diagnostics data module is permanently allocated to the address occupied by DM254. Its data contents are listed below.

BTS_Diag (DM254)

No.	Symbol	Explanation	Data format	Entry made by: B: BTSMADAP A: User
		DIAGNOSTIC DATA TRANSFERRED FROM DM120		
D0	DIA1	Cascade no. / Step no.	hex	B
D2	DIA2	Faulty, OpMode / Number of criteria	hex	B
D4	DIA3	Day / Month	hex	B
D6	DIA4	Year / Hour	hex	B
D8	DIA5	Minute / Second	hex	B
		DECODED CRITERIA DISPLAY, 18 lines		
D10	Krit1	"faulty" symbol	ASCII	B
D46	Krit2	Instruction	ASCII	B
D82	Krit3	Operand identifiers I/O/M/T/C...	ASCII	B
D118	Krit4	Byte address 100's / 10's	ASCII	B
D154	Krit5	Byte address 1's / Decimal point	ASCII	B
D190	Krit6	Bit address / Blank	ASCII	B
D226	Krit7	Operand text code	decimal	B
D262	DIA_Save	Stored screen no. for Diagnostics call-up (for RETURN)	decimal	B
D264	Kett_Anw	Cascade selection for Manual diagnostics CASCADE STATUS FOR 60 CASCADES Step no. for 60 cascades in D270 through D329	decimal	B
D270	1.K_StSn	Kette2/Kette1	hex	B
:				
D328	30K_StSn	Kette60/Kette59 "faulty" identifier and OpMode for 60 cascades in D330 through D389	hex	B
D330	1.K_StBa	Kette2/Kette1	hex	B
:				
D388	30K_StBa	Kette60/Kette59 Cascade text code for 60 cascades in D390 thru D449	hex	B
D390	1.K_StTx	Kette2/Kette1	hex	B
:				
D448	30K_StTx	Kette60/Kette59	hex	B
:				
D506	DF_Adr	Parameter P7 in DIAG500E	hex	A
D508	KopfKett	Parameter P6 in DIAG500E	hex	A
D510	DiagMldg	Status word of parameter P5, DIAG500E	hex	B

Fig. 6-1 DB254 (BTS_Diag) Data Module Allocation

The servicing of data words D506 and D508 becomes effective only in the case of decentralized diagnostics with head stations and substations.

6.2 Komm_DB Communication Data Module (DM255)

The Komm_DB communication data module is permanently allocated to the address occupied by DM255. Its data contents are listed below.

With the exception of the operator terminal identification in D478, all data is initialized by the BTSMADAP function module.

Komm_DB (DM255)

No.	Symbol	Explanation	Data format	Entry made by: B: BTSMADAP A: User
		STATUS DISPLAY		
D0	Status1	OPD identifier code DF, DP / I,O,M,EI,EO	hex	B
D2	Status2	DM number	decimal	B
D4	Status3	DM length	decimal	B
D6	Status4	Byte address, line 1	decimal	B
D8	Status5	Byte address, line 2	decimal	B
D10	Status6	Byte address, line 3	decimal	B
D12	Status7	Byte address, line 4	decimal	B
D14	Status8	Byte address, line 5	decimal	B
D16	Status9	Byte address, line 6	decimal	B
D18	Status10	Byte address, line 7	decimal	B
D20	Status11	Byte address, line 8	decimal	B
D22	Status12	Value, line 1	hex	B
D24	Status13	Value, line 2	hex	B
D26	Status14	Value, line 3	hex	B
D28	Status15	Value, line 4	hex	B
D30	Status17	Value, line 5	hex	B
D32	Status18	Value, line 6	hex	B
D34	Status19	Value, line 7	hex	B
D36	Status20	Value, line 8	hex	B
		Stored screen switchover addresses		B
D40	Save1	Status I / O	hex	B
D42	Save2	Status EI / M	hex	B
D44	Save3	Status - / EO	hex	B
D46	Save4	Status DF	decimal	B
D48	Save5	Status DP	decimal	B
D50	Save6	Status D	decimal	B
D52	Save7	Control O / I	hex	B
D54	Save8	Control EI / M	hex	B
D56	Save9	Control - / EO	hex	B
D58	Save10	Control DF	decimal	B
D60	Save11	Control DP	decimal	B
D62	Save12	Control D	decimal	B
		OPERAND CONTROL		B
D64	Steuern1	DM number	dezimal	B
D66	Steuern2	Data word/ Operand address	hex	B
D68			hex	B
D70	Steuern3	Value	hex	B
D72			hex	B
:				
D400	SMerker	Scratch marker range, D400 thru D438	hex	B
:				
D438			hex	B
		INTERNAL DATA		B
D440	STindBit	Control fucntions, internal helper bits	hex	B
D442	Kette+-1	Cascade number +-1	hex	B
D444	Kette+10	Kette +10	hex	B
D446	Curpos	Cursor position in movement screens	hex	B

No.	Symbol	Explanation	Data format	Entry made by: B: BTSMADAP A: User
D448	STEU_FRG	Control enabled if contents =1 (0: "control disabled") INTERNAL PLC MESSAGES	hex	A
D450	Battvorw		hex	B
D452	Ages/Fix		hex	B
D454	Watchdog		decimal	B
D456	Zykl_max		decimal	B
D458	Zykl_akt		decimal	B
		READ/WRITE AREAS OF BT5 / BT20 TERMINALS		B
		16 (bytes) x 8 status messages (parallel)		B
D460	BT_ZM	Bosch-internal status messages no. 1 thru 16	binary	B
D462		User status messages, no's. 17 thru 32	binary	B
D464		User status messages, no's. 33 thru 48	binary	B
D466		User status messages, no's. 49 thru 64	binary	B
D468		User status messages, no's. 65 thru 80	binary	B
D470		User status messages, no's. 81 thru 96	binary	B
D472		User status messages, no's. 97 thru 112	binary	B
D474		User status messages, no's. 113 thru 128	binary	B
D476			hex	B
D478	BT5?	BT5 Application	hex	User
D480	BT_Uhr	BT clock, 8 bytes	hex	B
D482			hex	B
D484			hex	B
D486			hex	B
D488	BT_MskNr	Screen number	decimal	B
D490	BT_DIP	DIP switch	binary	B
D492	BT_KO	Write coordination byte	binary	B
		8 bytes BT polling range		B
D494	BT_Poll1	Read coordination byte, / ----	binary	B
D496	BT_Poll2	Serial message channel	hex	B
D498	BT_Poll3	LED 1 thru 8, e.g. bit1=LED On/Off, bit0=flashes	hex	B
D500	BT_Poll4	LED 9 thru 16	hex	B
		Clear serial message buffer		B
D502	BT_M_loe	with code E216H + 7FFEh on serial message channel	hex	B
D504	BT_Tast	Function key code for operator terminal	hex	B

Fig. 6-2 Allocation of Komm_DB Communication Module (DM255)

D478 of the data module defines which operator terminal is connected to the PLC. With D478=5, a BT5, and with D478=0, a BT20 is declared. In the event that this identifier is not entered during the operation of the BT5, the movement function keys (F1, F2, F5, and F6) will be disabled. In the case of the CL400 / CL500 controllers, the same condition will prevent the synchronization result (LED in the respective movement keys) to be displayed.

6.3 DM120 Data Module

The DM120 data module is used for the automatic storage of information about the first-value error message of a cascade in a data range that is specifically reserved for that purpose (D0 through D148).

Data related to errors occurring in subsequent cascade processing within the controller can be queried via the manual diagnostics range (D278 through D 410).

	DW	HIGH Byte contents	LOW Byte contents	
	D0	Control flags		
Auto-Diag-nostics Range (Fist-value message)	D2	Day	Month	
	D4	Year	Hour	
	D6	Minute	Second	
	D8	Weekday (0 = Sunday)	unused	
	D10	Cascade number	Step number	
	D12	Module type	Module number	
	D14	Cascade status	Number of messages	
	D16	1. OpCode		
	D18	2. OpCode		
	:	:		
	D142	64. OpCode		
		D144	Reserved	
		D146	Reserved	
		D148	Reserved	
	D150	1st Cascade information		
	:	:		
	D276	64th Cascade information		
Manual Diag-nostics Range	D278	Cascade number	Step number	
	D280	Module type	Module number	
	D282	Cascade status	Number of messages	
	D284	1st OpCode		
	:	:		
	D410	64th OpCode		

Fig. 6-3 DM120 Data Module

- ◆ For the CL200, the DM120 data module must be opened for the full length (512).

For application with the CL400 / CL500, opening up to and including D410 (410) will suffice.

6.3.1 Automatic Diagnostic Range

In the event of a fault occurrence, the DIAG500E diagnostics module will automatically enter diagnostic data into the data words identified below. The respective data words are then read by BTSMADAP and, subsequent to processing for display in the BT5 / BT20 operator terminals, will be written to the BTS_Diag data module (DM254).

Date Format

The system time and date of an occurring first-value error are written to the data words **D2** through **D8** in hex notation. The weekday is coded as follows:

- 0 = Sunday
- 1 = Monday
- 2 = Tuesday
- 3 = Wednesday
- 4 = Thursday
- 5 = Friday
- 6 = Saturday

Step Number

Data byte D10 indicates the step number of the faulty cascade.

Cascade Number

Data byte D11 indicates the cascade number of the faulty cascade.

Module Number

Each cascade is programmed by the user in an associated function module. The number of that function module is stored in data byte D12, and corresponds to both the cascade number and the cascade data module number.

Module Type

Data byte D13 indicates the module type of the faulty cascade. In the case of the CL200, CL400, and CL500, the value of = 1_{bin}, indicating the function module, is entered here.

Number of Messages

Data byte D14 contains the number of conditions belonging to the first-value error. The representation occurs in hex notation. As only the first 64 conditions are stored, the number of messages is set to 65 in the event that the BEFA command output or WSB step-on condition branch should consist of more than 64 conditions.

Cascade Status

Data byte D15 indicates the OpMode of the faulty cascade at the time the first-value error occurred.

- Bit 0 (value 1) = Cascade in Manual mode
- Bit 1 (value 2) = Cascade in Inching mode
- Bit 2 (value 4) = Cascade in Automatic mode

6.3.2 Control Flags

Data word D0 contains the control flags. The individual data bits carry various default functions.

D0.0

Data bit D0.0 is set to HIGH (1) by the DIAG500E diagnostics module in the event that a first-value error was entered. Subsequent to the read-out of the first-value error, this data bit is reset by the BTSMADAP function module. There exists a functional interrelation between data bits D0.0 and D0.1.

D0.1

Data bit D0.1 controls the response to an occurring first-value error.

- **D0.1 = 0 Default setting in BT-MADAP**

The first-value error is always entered. If an unacknowledged first-value error is stored in the data module, it will be overwritten by the newly occurring first-value error.

- **D0.1 = 1 User-defined setting**

A new first-value error can be entered only if the acknowledgement of a previous first-value error was effected by means of D0.0. If this is not the case, the new first-value error will be lost.

D1.0

In the event that a first-value error is present, the bit is set to the value = 1_{bin} by the DIAG500E diagnostics module. If no error is present, the bit is reset automatically.

D1.2

In the event that status changes in the diagnosed conditions occur, or if a fault message is coming and/or going, the bit assumes the value = 1_{bin} for the duration of one PLC cycle.

OpCode

Beginning with data word D16, the OpCode of the criteria of the faulty branch are stored. One data word is available for each line of instructions. The significance of a data word is indicated in the table below.

Command Codes and Link Statuses

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Instruction
Z	Commd Code			Operand +				Byte addr.				Bit 0 thru 7					
z	0	0	0														A
z	0	0	1														AN
z	0	1	0														O
z	0	1	1														ON
z	1	0	0														S
z	1	0	1														R
z	1	1	0														=
	1	1	1											0	0	0	(
	1	1	1											0	0	1	O(
z	1	1	1											0	1	0)
z	1	1	1											0	1	1)N
	1	1	1											1	X	X	Reserved

Status of operand or of link: Satisfied = 1, Not satisfied = 0

Fig. 6-4 OpCode Definiton for Operator

Operand Identifier and Byte Address Ranges

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Hex. Screen	Operand
Z	Instruct.			Operand +				Byte address				Bit 0-7						
from					0	0	0	0	0	0	0	0	0				0000	C: Counter status 8 bytes
to									0	1	1	1					0038	
from					0	0	0	0	1	0	0	0	0				0080	T: Timer status 16 bytes
to									1	1	1	1					00F8	
from					0	1	0	0	0	0	0	0	0				0400	I: Inputs Bytes 0 thru 23
to									0	1	0	1	1	1			04B8	
from					0	1	1	0	0	0	0	0	0				0600	O: Outputs Bytes 0 thru 15
to									0	0	1	1	1	1			0678	
from					1	0	0	0	0	0	0	0	0				0800	M: Markers Bytes 0 thru 191
to									1	0	1	1	1	1			0EB8	

The same representation is valid for C+T
E.g.: C 127 is shown as C 15.7⁴.

Subsequent to masking bits 0-2 and 12-15

CL200

Fig. 6-5 CL200 — OpCode Definition for Operand Identifiers and Byte Addresses

⁴ Applies to version number < 1.2

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Hex.	Operand
	Z	Instruct.	Operand + <i>Byte address</i>										Bit 0-7	Mask				
from to					0	0	0	0	0	0	0	0	0				0000 0078	C: Counter status 128 bytes
from to					0	0	0	0	1	0	0	0	0				0080 00F8	T: Timer status 128 bytes
from to					0	0	0	1	0	0	0	0	0				0100 01F8	SM: Special marker Bytes 0 thru 31
from to from to					0	0	1	0	0	0	0	0	0				0200 03F8 0400 05F8	I: Inputs Bytes 64 thru 127 Bytes 0 thru 63
from to					0	1	1	0	0	0	0	0	0				0600 07F8	O: Outputs Bytes 0 thru 63
from to					1	0	0	0	0	0	0	0	0				0800 0FF8	M: Markers Bytes 0 thru 255
The same representation is valid for C+T E.g.: C 127 is shown as C 15.7 ⁵ .																	Subsequent to masking bits 0-2 and 12-15	

Fig. 6-6 CL400 / CL500 — OpCode Definition for Operand Identifiers and Byte Addresses

6.3.3 Cascade Information Structure

Beginning with D150 in the DM120 data module, the data range containing information about first-value messages is followed by a block of information on the available cascades. The structure of the cascade information is shown in the table below.

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Z											OpMode					
											Step no.					
											0 0 1 = Manual mode					
											0 1 0 = Inching mode					
										1 0 0 = Automatic mode						
										0 X 1 = Stop						
										0 1 X = Start						
										1 0 0 = Reset						
Cascade status: 0 = fault-free 1 = faulty																

Fig. 6-7 Cascade Information in DM120 Data Module

6.3.4 Manual Diagnostic Range

The data range covering manual diagnostics is identical to the function contents of automatic diagnostics. However, the system date and time of an entry are not stored. Manual diagnostics begin with step number D278, and the OpCode range is allocated to data word D284 and up.

⁵ Applies to version number < 3.1








7 BT5 Menu Description

Text / Symbol Conventions in Chapter 6

The key symbols used in Chapter 6 appear only once in the section below, opposite their respective text representations. These text representations will be used throughout this chapter.

For example, the first symbol below, representing *Multiple Pages*, will be replaced by the term **[SCROLL]** in the text hereunder, and the third symbol below, representing an *Up Arrow*, will be replaced by the term **[CURSOR UP]** throughout the text, and so forth.

For enhanced clarity, all key symbols will appear in boldface, and enclosed in square brackets.

	[SCROLL] key, status messages
	[HOME] key, back one menu level
	[CURSOR UP] key
	[CURSOR RIGHT] key
	[CURSOR DOWN] key
	[CURSOR LEFT] key
	[EDIT] key
	[ENTER] key
?	[?] key, Help text for current screen
+ / -	[+/-] key, toggles entry in Edit mode
print	[print] key, Cascade status

7.1 Startup Screen

The Startup screen (mask number M2) appears, subsequent to Power-Up of the 24 V- power supply, during the initialization phase of the BT5 operator terminal.

A short time thereafter, the Main menu screen (mask number 4) is displayed.

```

S t e u e r n ,   b e d i e n e n ,
d i a g n o s t i z i e r e n ,
u n d   a n z e i g e n   m i t
M A D A P   v o n   B o s c h

```

Fig. 7-1 Startup Screen

The Startup screen is the only operating element containing an **[ENTER]** key. If **[ENTER]** is pressed within the wait time interval, the Setup screen is displayed.

7.2 Setup Menu

The Setup menu (mask number M1) provides the options to change the terminal initialization data, and the configuration data for the X2 communications interface, without the use of a programming device.

```

SETUP  inaktiv
38400B 8D 1S eP noHS
SPS  BP19E4.8 LCD <<<
BT5  HF000045 Laden 0

```

Fig. 7-2 Setup Menu

The Edit mode is toggled On and Off by pressing the **[EDIT]** key. The changes are made by means of the **[+/-]** key.

The cursor movement from one field to the next or back again is controlled by the **[CURSOR DOWN]** and **[CURSOR UP]** keys.

A Download sequence is initiated by selecting Load 1 (**[+]** key), and subsequent confirmation by pressing the **[ENTER]** key. Once the Flash-EEPROM has been flushed, the operator terminal is again set to Download mode.

In the event that X2 interface configuration data is modified, each change requires confirmation by pressing **[ENTER]**. The transfer of setup data is effected only subsequent to pressing the **[ENTER]** key, and switching Off the Edit mode by pressing the **[EDIT]** key.

7.3 Diagnostic Function

The **[print]** key is used to display the Cascade Status (mask number 10). The BT5 operator terminal receives the diagnostic data from the BTS_Diag diagnostics module (DM254). This is where the data from the DM120 data module is stored once it has been processed by the BTSMADAP function module.

7.3.1 Cascade Status

The operator terminal receives the cascade status information from the BTS_Diag data module.

Cascade Status

B A	K / S C H	Be z e i c h n .
☐ A h	1 / 1	S t a r t v o r .
A s	2 / 1	E n d s c h l t .
H r	3 / 0	H a n d b e w e g

Fig. 7-3 Cascade Status

The cascade designations (cascade text) are entered in the TS (TesiMod) software. The appropriate level/location is reached by using the following sequence of menu commands:

Edit /Masks file / Edit /Edit text lists /Select text list. At the location reached in this manner, cascade text diagnostics can be entered.

The displayed Cascade Status displays the programmed cascades in groups of three.

Controller	Max. Number of Cascades
CL200	30
CL400 / CL500	60

Fig. 7-4 Maximum Number of Cascades

Display Contents

Cascade status:

- ☐ Cascade faulty
- ⊕ Cascade fault-free

OpMode:

- H Manual mode
- T Inching mode
- A Automatic mode
- s Start
- h Stop
- r Reset

Cascade number (K) and active step (S)

Cascade text, up to 9 characters in length.

Menu Control

- [F1]** Page Down (display next cascade group)
- [F2]** Page Up (display previous cascade group)
- [F6]** Return (back to first cascade group display)
- [HOME]** Main menu

7.3.2 Criteria Display

While in Cascade Status, pressing the **[print]** key accesses the Criteria Analysis (mask number 11).




Fig. 7-5 Example of Criteria Display

Designations for inputs and markers (criteria text) must be entered in the TS (TesiMod) software. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Masks file / Edit /Edit text lists /Select text list.

At the location thus reached, and building on a base code, criteria text diagnostics can then be entered in the form of decimal values.

Operand	Base Code
Inputs I	1000
Outputs O	3000
Markers M	4000
Special markers Sm	7000
Timers T	8000
Counters C	9000

Fig. 7-6 Operand Base Codes

Example: Input I0.2 (base code + byte address + bit address)

Base code 1000 = I0.0, base code 1001 = I0.1, etc.

Therefore, in the example shown in the screen mask in Fig. 6-5, above, the following will apply:

for I0.2 = Z2 n. vor (*fwd.*) -> Enter: 1002 = C2 n vor (*fwd.*)

Display Contents

Cascade number and active step

System date and time of first-value message occurrence

OpMode:

- H Manual mode
- T Inching mode
- A Automatic

Cascade status:

- F Cascade faulty

Automatic or Manual diagnostics

Criteria status:

- ☐ Conditions not met
- ⊕ Conditions met

Criteria text, up to 8 characters in length.

Menu Control

- [F1]** Page Down (displays next criteria)
- [F2]** Page Up (displays previous criteria)
- [F3]** Toggle: Manual and Automatic diagnostics
- [print]** Cascade status
- [HOME]** Main menu

Manual diagnostics mode:

- [EDIT]** Edit mode, cascade no., manual diagnostics
- [+]** Cascade no. +1 for cascade selection
- [-]** Cascade no. -1 for cascade selection

7.3.3 Explanation of Terms

First-value Error

A system runs fault-free if all cascade sequences contributing to the operation (a maximum of 60) are processed without error. If an error occurs in a cascade, it is recognized by the controller. As this error comprises the first error in the course of system sequence processing, it is declared the *first-value error* (also known as *first-up value error*).

Secondary Fault

As a rule, the consequence of the occurrence of a first-value error in the system will give rise to the occurrence of additional cascade faults. These faults are referred to as *secondary faults*. Because normal system operation can often be restored by remedying only the first-value error, secondary faults are generally deemed to be of minor importance.

Fault Entry Criteria

There are two options for triggering a fault entry in the cascade sequence.

Monitoring Time

Each step of a cascade sequence is allocated to a default function. While the respective function can be a movement of the system, it may also comprise the preparation for additional movements. A measurable time interval is attached to each function. The monitoring time is used to control this interval, and a fault entry is generated as soon as the time interval is exceeded.

Fault Marker

In the case of time-critical faults, e.g. with the opening of safety-interlocked protective system doors, there is little usefulness in utilizing the monitoring time interval.

In such cases, the occurrence of a fault will cause an immediate reset of the fault marker, triggering an instant fault entry.

Further Linking of BEFA or WSB Marker

In order to process a step for the subsequent display in the BT5 operator terminal, or for the display of the ladder diagram in the monitor (of the PG programming device), or for documentation purposes, it is required to use the BEFA or WSB marker as an AND starting condition for a new branch. For display in the operator terminal, the pointer for the BEFA or WSB marker must occur after 17 AND links, and for the ladder diagram the same applies after 7 AND links.

Permitted Operands and Address Ranges

Operand	Address range, ZE200	Addr. range, ZS400/500	Address range, ZS501
Inputs I	I0.0 through I23.7	I0.0 through I63.7	I0.0 through I27.7
Outputs O	O0.0 through O15.7	O0.0 through O63.7	O0.0 through O63.7
Markers M	M0.0 through M191.7	M0.0 through 255.7	M0.0 through 255.7
Timers T	T0 through T127	T0 through T127	T0 through T127
Counters C	C0 through C63	C0 through C127	C0 through C127
Special markers SM	not available	SM0.0 through SM31.7	SM0.0 through SM31.7

Fig. 7-7 Permissible Address Ranges

Example of further linking of BEFA command output:

The display always indicates the first BEFA part, the criteria of which are not met.

```

-Schritt1
A   B       I0.6
:   :       :       up to 16 criteria
=   B       -BEFA
A   B       -BEFA
:   :       :       up to 16 criteria
=   B       -BEFA
A   B       I0.7
=   B       -WSB

```

Fig. 7-8 Further Linking of BEFA Command Output

Example of further linking of WSB step-on condition:

The display always indicates the first WSB part, the criteria of which are not met.

```

-Schritt3
A   B       I0.6
=   B       -BEFA
A   B       I0.7
:   :       :       up to 16 criteria
=   B       -WSB
A   B       -WSB
O   B       I1.3
:   :       :       up to 16 criteria
=   B       -WSB

```

Fig. 7-9 Further Linking of WSB Step-on Condition

Permissible Bit Instructions and Special Instructions

```

A   (
O   )
AN  )N
ON  Network instructions
S
R
=

```

7.4 BT 20 Main Menu

The Main menu (mask number 4) is the first screen to be displayed after switching on the operator terminal. From this point, branching to the various functions of the operator terminal takes place.

```

B A S I S M E N Ü           S e r v i c e →
> F 1 <   A n z e i g e
> F 2 <   B e d i e n u n g
> F 3 <   M e l d u n g e n
  
```

Fig. 7-10 Main Menu

The function keys of the Main menu are used to access all other menus. The **[F6]** function key provides a lamp test. As is the case with the BT20 operator terminal, pressing **[F6]** causes the **LT⁶** marker (M179.7) to be set, and the marker is again reset upon releasing the **[F6]** function key.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

Menu Control

[F1]	Switches to Display menu
[F2]	Switches to Operating menu
[F3]	Switches to Message menu
[F6]	Selects Lamp Test
[CURSOR LEFT] or [CURSOR RIGHT]	Switches to Service menu

⁶ See <name>.TSV variables file

7.4.1 Display Mask Group Branching Menu

Pressing **[F1]** in the Main menu opens the branching menu of the display groups (mask number 100).

In the display of the BT operator terminal, the user can access 16 display masks in a 4x4 matrix (e.g. 4 groups of four masks each).

Each mask comprises a matrix of 20 horizontal by 4 vertical characters. The masks can be used, for example, for displaying application-specific text messages, and/or the statuses of PLC operands.

```

> F 1 <  A n z e i g e  G r p . 1
> F 2 <  A n z e i g e  G r p . 2
> F 3 <  A n z e i g e  G r p . 3
> F 4 <  A n z e i g e  G r p . 4

```

Fig. 7-11 Display Mask Group Distribution Menu

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

Menu Control

[F1]	Switches to the 1st group of display masks
[F2]	Switches to the 2nd group of display masks
[F3]	Switches to the 3rd group of display masks
[F4]	Switches to the 4th group of display masks
[HOME]	Returns to Main menu

7.4.1.1 Display Mask Groups

Each display mask group is composed of four display masks.

	Mask Group Masks	Mask numbers
Display mask group 1	1: 1/1 thru 1/4	110 thru 113
Display mask group 2	2: 2/1 thru 2/4	120 thru 123
Display mask group 3	3: 3/1 thru 3/4	130 thru 133
Display mask group 4	4: 4/1 thru 4/4	140 thru 143

Fig. 7-12 Mask Numbers of Display Mask Groups

The display masks can be used to display plain-text, system-specific messages and/or system statuses as reflected by their images in the controller operands, for example.

Piece count, blue:	1 2 3 4
Piece count, grey:	5 6 7
Piece count, green:	8 9 1 0

Fig. 7-13 Example of Application-specific Display Mask

Using the TS software, and under their respective mask no's, the display masks must be completed with the required text and desired variables. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Edit masks /Mask /Select mask /Number of mask.

It may also be necessary to enter a new variable description under **Edit masks /Variable**. If new variables are to be used, these must also be declared in the variables file under **Edit /Variables file**.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) by the flashing LED in the [?] key. The messages are displayed in plain text by pressing the [SCROLL] key.

Menu Control

[HOME]	Displays group distribution menu
[CURSOR UP]	Previous group display mask
[CURSOR RIGHT]	Displays mask at same level of next higher display group
[CURSOR DOWN]	Next display mask of same group
[CURSOR LEFT]	Displays mask at same level of next lower display group

7.4.2 Operation Mask Branching Menu

Pressing **[F2]** in the Main menu opens the distribution menu of the operation mask groups (mask number 200).

In the display of the BT operator terminal, , the user can access 16 display masks in a 4x4 matrix (e.g. 4 groups of four masks each).

Each mask comprises a matrix of 20 horizontal by 4 vertical characters. For each mask a maximum of 2 x 2 application-specific manual operations are available.

>F1<	Operation Group 1
>F2<	Operation Group 2
>F3<	Operation Group 3
>F4<	Operation Group 4

Fig. 7-14 Operation Mask Group Branching Menu

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

Menu Control

[F1]	Switches to 1st group of operation masks
[F2]	Switches to 2nd group of operation masks
[F3]	Switches to 3rd group of operation masks
[F4]	Switches to 4th group of operation masks
[HOME]	Returns to Main menu

7.4.2.1 Operation Mask Groups

Each operation mask group is composed of four operation masks. Each operation mask provides for the operation of 2 x 2 movements.

	Mask group Masks	Mask number
Operation mask group 1	1: 1/1 thru 1/4	211 thru 213
Operation mask group 2	2: 2/1 thru 2/4	215 thru 218
Operation mask group 3	3: 3/1 thru 3/4	219 thru 222
Operation mask group 4	4: 4/1 thru 4/4	223 thru 226

Fig. 7-15 Mask Numbers of Operation Mask Groups

For each movement, the display indicates the end position bit (limit switch) and the active bit (output). (The 1_{bin} status is represented by a black rectangle.)

Z		Z y l i n d e r 1	V
Ⓢ	-		-
Z		Z y l i n d e r 2	V
-	Ⓢ		-

Fig. 7-16 Example of Application-specific Operation Mask

Using the TS (TesiMod) software, and under their respective mask numbers, the operation masks must be completed with the required text entries. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Masks file / Edit /Mask.

The addresses of the variables for end position and active bit display are predefined by default (upward of marker M180), and are serviced by the BTS_ZV function module.

In the cascade data modules (upward of D32 in the CL200, and upward of D100 for the CL400 / CL500), the cascade numbers and step numbers required for executing the movements must be entered.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the [?] key. The messages are displayed in plain text by pressing the [SCROLL] key.

CL400 / CL500

The executability of the movements (synchronization) is indicated via the LEDs in the [F1], [F2], and/or [F5] and [F6] movement keys.

Menu Control

[F1]	Line 1, Move backward
[F2]	Line 2, Move backward
[F6]	Line 1, Move forward
[F5]	Line 2, Move forward
[HOME]	Returns to branching menu,operation mask group.
[CURSOR UP]	Previous operation mask of same group.
[CURSOR RIGHT]	Operation mask at same level of next higher group.
[CURSOR DOWN]	Next operation mask of same group.
[CURSOR LEFT]	Operation mask at same level of next lower group.

7.4.3 Message Menu

Pressing **[F3]** in the Main menu opens the Message menu.

In the display of the BT operator terminal, the user can access status messages (mask number 31), plus serial messages (mask number 33) and their respective parameterization (mask number 30).

```
Z u s t a n d s m e l d u n g e n
> B a t t e r i e v o r w a r n u n g
```

Fig. 7-17 Example of Status Messages

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

Menu Control

[F2]	Serial messages
[F3]	Message parameters
[SCROLL]	Additional status messages
[HOME]	Returns to Main menu

7.4.3.1 Status Messages

Status messages comprise not only default messages as listed in the following table but also additional user-defined messages.

Using the TS (TesiMod) software, and starting with message no. 17, user-defined system-specific status messages must be manually entered in text form. The appropriate level / location is reached using the following sequence of menu commands:

Edit /Messages. These messages are enabled by entries in DM255, beginning with data word DW462.

Example: Message no. 18 (second free user message) is to be displayed.

The PLC program must write the contents of 0002_{hex} into data word DW462.

7.4.3.2 Serial Messages

Serial messages are entered, together with their message number, in data word D496 in data module DM255. For this purpose, the following handshake must be performed:

- Load contents of D496
- If D496=0, the PLC program will be able to write a message number into the data word.

- Once the message number has been transferred to the BT operator terminal, the BT will write the value of O_{hex} into the data word, and the PLC program can send a new message.

```
S e r i e l l e   M e l d u n g e n
> D i a g n o s e   s t e h t   a n
```

Fig. 7-18 Example of Serial Messages

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the [?] key. The messages are displayed in plain text by pressing the [SCROLL] key.

Menu Control

- [F1] Status messages
- [F3] Message parameters
- [HOME] Returns to Main menu

7.4.3.3 Message Parameters

In the Message Parameters mask, the parallel messages (status messages) and serial messages are provided with the following parameters:

- On/Off
- Date On/Off
- Time On/Off
- Sort criteria Number <-> Time point

```
M e l d u n g s p a r a m e t e r
>        N r .    D a t    U h r    S o r t
p a r    a u s    a u s    a u s    N r .
s e r    a u s    a u s    a u s    Z e i t
```

Fig. 7-19 Example of Message Parameters

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the [?] key. The messages are displayed in plain text by pressing the [SCROLL] key or the [F1] function key.

Menu Control

[F1]	Status messages
[F2]	Serial messages
[HOME]	Returns to Main menu
[EDIT]	Toggles Edit mode. With Edit mode selected, only the [+ / -] and [ENTER] keys are enabled.
[+ / -]	Toggles message parameters
[ENTER]	Press to accept/confirm parameter value, and to step on to next message parameter.

7.5 Service Menu

Using the **[CURSOR RIGHT]** and **[CURSOR LEFT]** keys in the Main menu opens the Service menu (mask number 5).

The Service menu displays the Power-Up conditions, status indications of several controller-specific operands, date and time of the BT (both changeable), and internal messages.

S E R V I C E	B a s i s ->
> F1 <	E i n s c h a l t b e d .
> F2 <	O P D - S t a t u s
> F3 <	U h r / i n t . M e l d .

Fig. 7-20 Service Menu

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

Menu Control

[F1]	Power-Up conditions
[F2]	Operand status
[F3]	Clock / internal messages
[F6]	PG programming device communication mask
[HOME]	Main menu
[CURSOR LEFT] or [CURSOR RIGHT]	Main menu

7.5.1 PG Communication Mask

Pressing **[F6]** in the Service mask starts the communication with the PG programming device. During this process, the data interchange between the PLC and the BT operator terminal is disabled, and is routed (looped) via appropriate cables to the interface of the PG programming device. This looped connection may be used to load PLC programs, for example.

K o m m u n i k a t i o n
m i t P G
i s t a k t i v !
A u s s c h a l t e n m i t > F 6

Fig. 7-21 Communications with PG Programming Device

Menu Control

[F6]	Toggles communication with PG programming device ON/Off
-------------	---

7.5.2 Power-Up Conditions

Pressing **[F1]** in the Service menu opens the Power-Up menu (mask numbers 20 through 23).

In the display of the BT operator terminal, the user can access 4 display masks.

Each mask comprises a matrix of 20 horizontal by 4 vertical characters. The masks can be used, for example, for displaying application-specific text messages, and/or the statuses of PLC operands.

Each mask allows the plain-text display of 4 system-specific power-up conditions in conjunction with their respective statuses by means of their images in the control operands.

H	y	d	r	a	u	l	i	k	1	e	i	n	Ⓢ
H	y	d	r	a	u	l	i	k	2	e	i	n	Ⓢ
H	y	d	r	a	u	l	i	k	3	e	i	n	
H	y	d	r	a	u	l	i	k	4	e	i	n	

Fig. 7-22 Example of Application-specific Power-Up Conditions

Using the TS (TesiMod) software, and under their respective mask numbers, the display masks must be completed with the required text and the desired variables. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Edit masks /Mask /Select mask /Number of mask.

It may also be necessary to enter a new variable description under **Edit masks /Variable**. If new variables are to be used, these must also be declared in the variables file under **Edit /Variables file**.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

Menu Control

[HOME]	Service menu
[CURSOR DOWN]	Next group of four
[CURSOR UP]	Previous group of four

7.5.3 Operand Status Branching Menu

Pressing **[F2]** in the Service menu opens the Operand Status branching menu (mask number 50).

This menu is used to select the display of the PLC operands and their respective statuses.

> F3 <	E / A / M / (E Z / A Z)
> F4 <	T / Z
> F5 <	(D F) / D P
> F6 <	U hr / int . M e l d .

Fig. 7-23 Operand Status Branching Menu

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

Menu Control

[F3]	I, O, M operand status
[F4]	T, C operand status
[F5]	DF (DB) operand status
[F6]	DM operand status
[HOME]	Returns to Service menu

7.5.3.1 Operand Status Display

Stat..	E / A / M	aktiv: A
2	000000000000000000	
4	000000000000000000	
	^ ^ ^ ^	

Fig. 7-24 Example of Output Operand Status Display

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the [?] key. The messages are displayed in plain text by pressing the [SCROLL] key.

Menu Control

[F3]	Operands, I -> O -> M -> (EI -> AI) -> I
[F4]	Operands, Timers -> Counters
[F5]	Operands, DF <-> (DB)
[F6]	Operand, DM, display in decimal / hexadecimal <-> byte decimal / ASCII
[CURSOR LEFT] or [CURSOR RIGHT]	Toggles display formats, I, O, M, DF, (DB), DM
[HOME]	Operand status branching menu
[EDIT]	Toggles Edit mode On/Off. With Edit mode enabled, editing is possible only in active mask. The [HOME] key is disabled.
[1], [2], [3] ...	Enter desired operand address.
[ENTER]	Accepts/adopts entered operand address, or transfers default of 0/1 _{bin} status to desired controller mask.

CAUTION!

Pressing the [ENTER] key one more time will cause the control mask to be written into the PLC!

Prerequisite:

The Control function is initially disabled. It is enabled by entering the value of 1_{hex} in data word D448 of data module DM255.

7.5.4 Internal Messages

Pressing the **[F3]** key in the Service menu causes the display of internal PLC messages (mask number 2) (e.g. current / maximum cycle time).

```

a k t . Z y k l . Z e i t :      3 m s
m a x . Z y k l . Z e i t :      5 m s
W a t c h   D o g           :    2 0 0 m s

```

Fig. 7-25 Example of Internal Messages

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[?]** key. The messages are displayed in plain text by pressing the **[SCROLL]** key.

The Battery Fault, Fixation and Output Enabled messages are also displayed directly in the mask.

Menu Control

[HOME] Service menu

[CURSOR LEFT]
[CURSOR RIGHT] Date and time

7.5.5 Date / Time

```

D a t u m   u n d   U h r z e i t
F r e i t a g
1 6 . 0 6 . 9 5   1 0 : 4 5 : 1 5

```

Fig. 7-26 Date and Time

Menu Control

[CURSOR LEFT] or
[CURSOR RIGHT] Internal messages

[EDIT] Edit mode: Toggles weekday, date and time On/Off. With Edit mode enabled, the **[HOME]** key is disabled.

[- / +] Selects weekday

[ENTER] Accepts/confirms entries. Data and time settings by means of numerical keys. **[ENTER]** key to accept/confirm, and step-on to next entry.








8 BT20 Menu Descriptions

Text / Symbol Conventions in Chapter 7

The key symbols used in Chapter 7 appear only once in the section below, opposite their respective text representations. These text representations will be used throughout this chapter.

For example, the first symbol below, representing an *Up Left Arrow*, will be replaced by the term **[HOME]** in the text hereunder, and the third symbol below, representing an *Up Arrow*, will be replaced by the term **[CURSOR UP]** throughout the text, and so forth.

For enhanced clarity, all key symbols will appear in boldface, and enclosed in square brackets.

	[HOME] key, returns to Main menu
RET	[RETURN] key, back one mask level
	[CURSOR UP] key
	[CURSOR RIGHT] key
	[CURSOR DOWN] key
	[CURSOR LEFT] key
	[EDIT] key
	[ENTER] key
<<<	[<<< MOVE LEFT] key
>>>	[>>> MOVE RIGHT] key
MELD	[MELD] key, status messages
DIAG	[DIAG] key, cascade status, criteria analysis
?	[?] key, Help text on current mask/screen

Also, the following applied to all masks/screens:

- In the event that the controller enters a STOP condition, the legend *ZE STOP* will appear in Line 1, beginning with Column 34 of the display.
- Line 15 of the display is reserved for status messages. At this point, the Bosch-proprietary internal status messages (e.g. *Outputs Disabled*), are displayed in their order of priority.

8.1 Startup Screen

The Startup screen (mask number M2) appears, subsequent to Power-Up of the 24 V- power supply, during the initialization phase of the BT5 operator terminal.

A short time thereafter, the Main menu screen (mask number 4) is displayed.




Fig. 8-1 Startup Screen, BT20 Operator terminal

The Startup screen is the only operating element containing an **[ENTER]** key. If **[ENTER]** is pressed within the wait time interval, the Setup screen is displayed.

8.2 Setup Menu

The Setup menu (mask number M1) provides the options to change the terminal initialization data, and the configuration data for the X2 communications interface, without the use of a programming device.

SETUP - MASKE			
Baudrate	X2	:	38400
Parity	X2	:	Even
Datenbits	X2	:	8
Stopbits	X2	:	1
Datenübernahme		:	inaktiv
Protokoll-Software		:	BP19E4.5
Terminal-Software		:	HB000045
Datum		:	16.06.95
Uhrzeit		:	8:15:00
Display-Kontrast		:	<<<
Download		:	inaktiv

Fig. 8-2 BT20 Setup Menu

The Edit mode is toggled On and Off by pressing the **[EDIT]** key. The changes are made by means of the **[+/-]** key.

The cursor movement from one field to the next or back again is controlled by the **[CURSOR DOWN]** and **[CURSOR UP]** keys.

A Download sequence is initiated by selecting *Download aktiv*, and subsequent confirmation by pressing the **[ENTER]** key. Once the Flash-EEPROM has been flushed, the operator terminal is again set to Download mode.

In the event that X2 interface configuration data is modified, each change requires confirmation by pressing **[ENTER]**. The transfer of setup data is effected only subsequent to pressing the **[ENTER]** key, and switching Off the Edit mode by pressing the **[EDIT]** key.

8.3 Diagnostic Function

Pressing the **[DIAG]** key displays the cascade status (DIAGNOSE, mask number 10). The BT20 operator terminal receives the diagnostic data from the BTS_Diag diagnostics module (DM254).

This is where the data from the DM120 data module is stored once it has been processed by the BTSMADAP function module.

8.3.1 Cascade Status

The operator terminal receives the cascade status information from the BTS_Diag data module.

K e t t e n s t a t u s					Z E S T O P
B A		K / S c h		B e z e i c h n u n g	
█	A h	1 /	1	G r u n d s t a r t v o r a u s s e t z u n g e n	
▒	A s	2 /	1	E n d s c h a l t e r p a a r ü b e r w a c h u n g	
▒	H r	3 /	0	H a n d b e w e g u n g e n	
▒	T s	4 /	2	Z y l i n d e r m o d e l l	

> Z e i l e f ü r S t a t u s m e l d u n g e n

⌚ ↓ ⌚ ↑ ⌚ ⌚ ⌚ ⌚ ⌚ ⌚ ⌚

Fig. 8-3 Cascade Status

Selecting the cascade status causes the programmed cascade sequences to be displayed. The display encompasses up to 60 cascades for the CL400 / CL500, and up to 30 cascades for the CL200.

The cascade designations (cascade text) are entered in the TS (TesiMod) software. The appropriate level/location is reached by using the following sequence of menu commands:

Edit /Masks file / Edit /Edit text lists /Select text list. At the location reached in this manner, cascade text diagnostics can be entered.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Cascade status:

- █ Cascade faulty
- ⊕ Cascade fault-free

OpMode:

- H Manual mode
- T Inching mode
- A Automatic mode
- s Start
- h Stop
- r Reset

Cascade number (K) and active step (S)

Cascade text, up to 26 characters in length.

Menu Control

[F1] Page Down (display next cascade group)

[F2] Page Up (display previous cascade group)

8.3.2 Criteria Analysis

While in Cascade Status, pressing the **[DIAG]** key accesses the Criteria Analysis (mask number 11). The Criteria Analysis displays the first-value error or the current step.

Diagnose		Kette	1	Schritt		1	ZE	STOP
Betr. Art:		AUTO		16.06.95			9:45:15	
Krit. Anz:		4					gestört!	
UN	E	14.2	Zylinder	Z2	nicht	vorne		
UN	E	14.4	Zylinder	Z3	nicht	vorne		
UN	A	20.6	Schutzvorrichtung	offen				
C=	M	255.1	WSB	Weiterschaltbedingung				
> Zeile für Statusmeldungen ⌚ ↓ ⌚ ↑ ⌚ HandD ⌚ ⌚ ⌚ ⌚ ⌚								

Fig. 8-4 Criteria Analysis

For the Criteria Analysis, 2 pages with 9 criteria are available. This means that, in the case of branches containing more than 18 criteria, further linking of either the BEFA command output or WSB step-on condition marker will be required.

Designations for inputs and markers (criteria text) must be entered in the TS (TesiMod) software. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Masks file / Edit /Edit text lists /Select text list.

At the location thus reached, and building on a base code, criteria text diagnostics can then be entered in the form of decimal values.

Operand	Base Code
Inputs I	1000
Outputs O	3000
Markers M	4000
Special markers Sm	7000
Timers T	8000
Counters C	9000

Fig. 8-5 Operand Base Codes

Example: Input I0.2 (base code + byte address + bit address)

Base code 1000 = I0.0, base code 1001 = I0.1, etc.

Therefore, the following will apply:

For E0.2 = Zylinder2 fwd. -> Eingabe: 1002 = Zylinder2 backwd.

Display Contents

Cascade number and active step

OpMode:

- H Manual mode
- T Inching mode
- A Automatic



System date and time of first-value message occurrence

Number of criteria

Cascade status:

- F Cascade faulty!

Criteria status:

-  Conditions not met
-  Conditions met

Criteria text, up to 28 characters in length.

Menu Control

[F1] Page Down (displays next criteria)

[F2] Page Up (displays previous criteria)

[F3] Toggle: Manual and Automatic diagnostics

Manual diagnostics mode:

[F7] Cascade no. + 10 for cascade selection

[F8] Cascade no. + 1 for cascade selection

[F9] Cascade no. - 1 for cascade selection

8.3.3 Explanation of Terms

First-value Error

A system runs fault-free if all cascade sequences contributing to the operation (a maximum of 60) are processed without error. If an error occurs in a cascade, it is recognized by the controller. As this error comprises the first error in the course of system sequence processing, it is declared the *first-value error* (also known as *first-up value error*).

Secondary Fault

As a rule, the consequence of the occurrence of a first-value error in the system will give rise to the occurrence of additional cascade faults. These faults are referred to as *secondary faults*. Because normal system operation can often be restored by remedying only the first-value error, secondary faults are generally deemed to be of minor importance.

Fault Entry Criteria

There are two options for triggering a fault entry in the cascade sequence.

Monitoring Time

Each step of a cascade sequence is allocated to a default function. While the respective function can be a movement of the system, it may also comprise the preparation for additional movements. A measurable time interval is attached to each function. The monitoring time is used to control this interval, and a fault entry is generated as soon as the time interval is exceeded.

Fault Marker

In the case of time-critical faults, e.g. with the opening of safety-interlocked protective system doors, there is little usefulness in utilizing the monitoring time interval.

In such cases, the occurrence of a fault will cause an immediate reset of the fault marker, triggering an instant fault entry.

Further Linking of BEFA or WSB Marker

In order to process a step for the subsequent display in the BT5 operator terminal, or for the display of the ladder diagram in the monitor (of the PG programming device), or for documentation purposes, it is required to use the BEFA or WSB marker as an AND starting condition for a new branch. For display in the operator terminal, the pointer for the BEFA or WSB marker must occur after 17 AND links, and for the ladder diagram the same applies after 7 AND links.

Permitted Operands and Address Ranges

Operand	Address range, ZE200	Addr. range, ZS400/500	Address range, ZS501
Inputs I	I0.0 through I23.7	I0.0 through I63.7	I0.0 through I27.7
Outputs O	O0.0 through O15.7	O0.0 through O63.7	O0.0 through O63.7
Markers M	M0.0 through M191.7	M0.0 through 255.7	M0.0 through 255.7
Timers T	T0 through T127	T0 through T127	T0 through T127
Counters C	C0 through C63	C0 through C127	C0 through C127
Special markers SM	not available	SM0.0 through SM31.7	SM0.0 through SM31.7

Fig. 8-6 Permissible Address Ranges

Example of further linking of BEFA command output:

The display always indicates the first BEFA part, the criteria of which are not met.

-Schritt1			
A	B	I0.6	
:	:	:	up to 16 criteria
=	B	-BEFA	
A	B	-BEFA	
:	:	:	up to 16 criteria
=	B	-BEFA	
A	B	I0.7	
=	B	-WSB	

Fig. 8-7 Further Linking of BEFA Command Output

Example of further linking of WSB step-on condition:

The display always indicates the first WSB part, the criteria of which are not met.

-Schritt3			
A	B	I0.6	
=	B	-BEFA	
A	B	I0.7	
:	:	:	up to 16 criteria
=	B	-WSB	
A	B	-WSB	
O	B	I1.3	
:	:	:	up to 16 criteria
=	B	-WSB	

Permissible Bit Instructions and Special Instructions

A (

O)

AN)N

ON Network instructions

S

R

=

8.4 BT20 Main Menu

The Main menu (mask number 4) is the first screen to be statically displayed after switching on the operator terminal. From this point, branching to the various functions of the operator terminal takes place.

```

B a s i s m e n ü                               Z E S T O P
> A n z   <   A n z e i g e n
> B e d   <   B e d i e n e n
> M e l d  <   M e l d u n g e n
> E B e d  <   E i n s c h a l t b e d i n g u n g e n
> S e r v  <   S e r v i c e
>   L T   <   L a m p e n t e s t
> Z e i l e   f ü r   Z u s t a n d s m e l d u n g e n
⌚ Anz ⌚ Bed ⌚ Meld ⌚ EBed ⌚ Serv ⌚ LT ⌚

```

Fig. 8-8 Main Menu

The function keys of the Main menu are used to access all other menus. The **[F9]** function key provides a lamp test. Pressing **[F9]** causes the **LT**⁷ marker (M179.7) to be set, and the marker is again reset upon releasing **[F9]**.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

- [F1]** Switches to Display menu
- [F2]** Switches to Operating menu
- [F3]** Switches to Message menu
- [F7]** Power-up conditions
- [F8]** Switches to Service menu
- [F9]** Selects Lamp test

⁷ See <name>.TSV variables file

8.4.1 Display Mask Group Branching Menu

Pressing **[F1]** in the Main menu opens the branching menu of the display groups (mask number 100).

In the display of the BT operator terminal, the user can access 16 display masks in a 4x4 matrix (e.g. 4 groups of four masks each).

```

Anzeige - Menü                                     Z E S T O P
> AnzG1 < Anzeigegruppe 1
> AnzG2 < Anzeigegruppe 2
> AnzG3 < Anzeigegruppe 3
> AnzG4 < Anzeigegruppe 4

> Zeile für Zustandsmeldungen
⌚AnzG1 ⌚AnzG2 ⌚AnzG3 ⌚AnzG4 ⌚

```

Fig. 8-9 Display Group Branching Menu

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

- [F1]** Switches to the 1st group of display masks
- [F2]** Switches to the 2nd group of display masks
- [F3]** Switches to the 3rd group of display masks
- [F7]** Switches to the 4th group of display masks

8.4.1.1 Display Mask Groups

Each display mask group is composed of four display masks.

	Mask Group Masks	Mask numbers
Display mask group 1	1: 1/1 thru 1/4	110 thru 113
Display mask group 2	2: 2/1 thru 2/4	120 thru 123
Display mask group 3	3: 3/1 thru 3/4	130 thru 133
Display mask group 4	4: 4/1 thru 4/4	140 thru 143

Fig. 8-10 Mask Numbers of Display Mask Groups

The display masks can be used for indicating system-specific data. The display can take advantage of the outstanding graphical capabilities of the BT20 operator terminal. (For additional information, please consult the manuals supplied with the operator terminal.)

Figure 7-12, below, depicts an example of a partial system diagram with OpMode selection via the function keys of the operator terminal.




Fig. 8-11 Example of Display Mask

Using the TS software, and under their respective mask no's, the display masks must be completed with the required text and desired variables. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Edit masks /Mask /Select mask /Number of mask.

It may also be necessary to enter a new variable description under **Edit masks /Variable**. If new variables are to be used, these must also be declared in the variables file under **Edit /Variables file**.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

The function keys [F1] through **[F3]**, and F7 through F9, are available for user-defined functions.

[CURSOR UP]	Previous group display mask
[CURSOR RIGHT]	Displays mask at same level of next higher display group
[CURSOR DOWN]	Next display mask of same group
[CURSOR LEFT]	Displays mask at same level of next lower display group

8.4.2 Operation Mask Branching Menu

Pressing **[F2]** in the Main menu opens the distribution menu of the operation mask groups (mask number 200).

In the display of the BT operator terminal, the user can access 16 display masks in a 4x4 matrix (e.g. 4 groups of four masks each).

Each mask provides the user with a maximum of 8 application-specific manual operations (4 movements Left, 4 movements Right).

```

Handbedienungen                                Z E S T O P
> BedG1 < B e d i e n g r u p p e  1
> BedG2 < B e d i e n g r u p p e  2
> BedG3 < B e d i e n g r u p p e  3
> BedG4 < B e d i e n g r u p p e  4

> Zeile für Zustandsmeldungen
🕒 BedG1 🕒 BedG2 🕒 BedG3 🕒 🕒 BedG4 🕒 🕒

```

Fig. 8-12 Operation Functions Branching Menu

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

- [F1]** Switches to 1st group of operation masks
- [F2]** Switches to 2nd group of operation masks
- [F3]** Switches to 3rd group of operation masks
- [F4]** Switches to 4th group of operation masks

8.4.2.1 Operation Mask Groups

Pressing function keys [F1] through [F3], and [F7] causes the operation mask groups to be displayed. Each operation mask group is composed of four operation masks.

Each operation mask provides for the operation of 4 x 2 movements.

	Mask group Masks	Mask number
Operation mask group 1	1: 1/1 thru 1/4	211 thru 213
Operation mask group 2	2: 2/1 thru 2/4	215 thru 218
Operation mask group 3	3: 3/1 thru 3/4	219 thru 222
Operation mask group 4	4: 4/1 thru 4/4	223 thru 226

Fig. 8-13 Mask Numbers of Operation Mask Groups

For each movement, the display indicates the end position bit (limit switch) and the active bit (output). (The 1_{bin} status is represented by a black rectangle.)




Fig. 8-14 Example of Application-specific Operation Mask

Using the TS (TesiMod) software, and under their respective mask numbers, the operation masks must be completed with the required text entries. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Masks file / Edit /Mask.

The addresses of the variables for end position and active bit display are predefined by default (upward of marker M180), and are serviced by the BTS_ZV function module.

In the cascade data modules (upward of D32 in the CL200, and upward of D100 for the CL400 / CL500), the cascade numbers and step numbers required for executing the movements must be entered.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

[F1]	Line 1, Move backward
[F2]	Line 2, Move backward
[F6]	Line 1, Move forward
[F5]	Line 2, Move forward
[CURSOR UP]	Previous operation mask of same group.
[CURSOR RIGHT]	Operation mask at same level of next higher group.
[CURSOR DOWN]	Next operation mask of same group.
[CURSOR LEFT]	Operation mask at same level of next lower group.

8.4.3 Message Menu

Pressing **[F3]** in the Main menu opens the Message menu.

In the display of the BT operator terminal, the user can access status messages (mask number 31), plus serial messages (mask number 33) and their respective parameterization (mask number 30).

8.4.3.1 Status Messages

Status messages comprise not only default messages but also additional user-defined messages.




Fig. 8-15 Example of Status Messages

Display Contents

The display indicates status messages. The *ZE STOP* message cannot be displayed at this location.

Menu Control

[F2] Serial messages

[F3] Message parameters

Using the TS (TesiMod) software, and starting with message no. 17, user-defined system-specific status messages must be manually entered in text form. The appropriate level / location is reached using the following sequence of menu commands:

Edit /Messages. These messages are enabled by entries in DM255, beginning with data word DW462.

Example: Message no. 18 (second free user message) is to be displayed.

The PLC program must write the contents of 0002_{hex} into data word DW462.

8.4.3.2 Serial Messages

Serial messages are entered, together with their message number, in data word D496 in data module DM255. For this purpose, the following handshake must be performed:

- Load contents of D496
- If D496=0, the PLC program will be able to write a message number into the data word.
- Once the message number has been transferred to the BT operator terminal, the BT will write the value of 0_{hex} into the data word, and the PLC program can send a new message.




Fig. 8-16 Example of Serial Messages

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key. The *ZE STOP* message is not displayed here.

Menu Control

- [F1]** Status messages
- [F3]** Message parameters

8.4.3.3 Message Parameters

In the Message Parameters mask, the parallel messages (status messages) and serial messages are provided with the following parameters:

- On/Off
- Date On/Off
- Time On/Off
- Sort criteria Number <-> Time point

```

M e l d u n g e n                                     Z E S T O P
> F 1 <      Z u s t a n d s m e l d u n g e n
> F 2 <      S e r i e l l e M e l d u n g e n

M e l d u n g e n   N r .   D a t u m   U h r   S o r t K r i t
s e r i e l l       e i n   e i n   e i n   Z e i t
Z u s t ä n d e    a u s   a u s   a u s   N r .

> Z e i l e   f ü r   Z u s t a n d s m e l d u n g e n
⌚ Z u s t M ⌚ S e r i M ⌚           ⌚           ⌚           ⌚           ⌚

```

Fig. 8-17 Example of Message Parameters

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

- [F1]** Status messages
- [F2]** Serial messages
- [EDIT]** Toggles Edit mode. With Edit mode selected, only the **[+ / -]** and **[ENTER]** keys are enabled.
- [+ / -]** Toggles message parameters
- [ENTER]** Press to accept/confirm parameter value, and to step on to next message parameter.

8.5 Power-Up Conditions

Pressing the [F7] key in the Main menu displays the Power-Up conditions (mask numbers 20 through 23).

The terminal display provides the user with 4 display masks.

Each mask allows the plain-text display of system-specific power-up conditions in conjunction with their respective statuses by means of their images in the control operands.




Fig. 8-18 Example of Application-specific Power-Up Conditions

Using the TS (TesiMod) software, and under their respective mask numbers, the display masks must be completed with the required text and the desired variables. The appropriate level / location is reached by using the following sequence of menu commands:

Edit /Edit masks /Mask /Select mask /Number of mask.

It may also be necessary to enter a new variable description under **Edit masks /Variable**. If new variables are to be used, these must also be declared in the variables file under **Edit /Variables file**.

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the [MELD] key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the [MELD] function key.

Menu Control

[CURSOR DOWN] Next group of four

[CURSOR UP] Previous group of four

8.6 Service Menu

Pressing the **[F8]** key in the Main menu opens the Service menu (mask number 50).

The Service menu displays the Power-Up conditions, status indications of several controller-specific operands, date and time of the BT (both changeable), and internal messages.

```

Servicefunktionen                Z E  S T O P
>  U h r      <  U h r / S P S - Z u s t a n d s m e l d u n g e n

>  E / A / M  <  S t a t u s   E / A / M / E Z / A Z

>  T / Z      <                Z e i t e n / Z ä h l e r

>  D F / D P  <                D a t e n f e l d / - p u f f e r

>  D B s      <                D a t e n b a u s t e i n e

> Z e i l e   f ü r   Z u s t a n d s m e l d u n g e n
⌚ U h r ⌚           ⌚ E / A / M ⌚   ⌚ T / Z ⌚   ⌚ D F / D P ⌚   ⌚ D B s ⌚

```

Fig. 8-19 Service Menu

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

[F1]	Clock / internal messages
[F3]	Switches to PLC I, O, M operand menu
[F7]	Status, times and counters
[F8]	Status, data field and data buffer
[F9]	Status, data module

8.6.1 Clock / PLC Status Messages

Pressing the **[F3]** key in the Service menu displays the clock data and internal PLC status messages (mask number 51).

```

Uhr / SPS - interne Meldungen                Z E S T O P
      Fr      16 . 06 . 95      10 : 45 : 15

aktuelle Zykluszeit :           5  ms
maximale Zykluszeit :           6  ms
Watchdog :                   2000  ms

Fixierung :                      e i n
Ausgänge gesperrt :              a u s

Batterievorwarnung :            a u s

> Zeile für Zustandsmeldungen
⌚      ⌚      ⌚      ⌚      ⌚      ⌚      ⌚      ⌚

```

Fig. 8-20 Example of Clock Data and Internal Messages

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

[EDIT]	Edit mode: Toggles weekday, date and time On/Off. With Edit mode enabled, only the [1] , [2] , [3] ... numerical keys, as well as [+] and [ENTER] keys, are enabled.
[+ / -]	Selects weekdays
[1], [2], [3] ...	Numerical keys, enter date and time
[ENTER]	Accepts/confirms entries. [ENTER] key to accept/confirm, and step-on to next entry.

8.6.2 I/O/M/EI/EO Status / Control

Pressing the **[F3]** key in the Service menu displays the Status / Control menu (mask numbers 60, 61, 70, 71, 80, 81, 90, 91).

The referred menus display the statuses of the PLC operands in the binary, hexadecimal, decimal and ASCII formats. Subsequent to being enabled, the displayed PLC operands can be controlled in DM255/D448 by means of the BT operator terminal.

Status	E/A/M/EZ/AZ	aktiv:	EZ	ZE	STOP
By	HEX.	Dezim.	HBy / LBy	ASCII	
200	4241	16961	066 / 065	>BA<	
202	0000	00000	000 / 000	> <	
204	0000	00000	000 / 000	> <	
206	0000	00000	000 / 000	> <	
208	0000	00000	000 / 000	> <	
210	0000	00000	000 / 000	> <	
212	0000	00000	000 / 000	> <	
214	0000	00000	000 / 000	> <	
120	0000	00000	000 / 000	> <	
> Zeile für Zustandsmeldungen					
⌚ E → A → M ⌚ ⌚ T / Z ⌚ DF / DP ⌚ DBs ⌚					

Fig. 8-21 I/O/M/EI/EO Status in Hexadecimal, Decimal <-> Byte decimal /Byte decimal and ASCII Formats

Status	E/A/M/EZ/AZ	aktiv:	M	ZE	STOP
By	HBy	binär	LBy	Hex.	Dezim.
0	00000000	00000000	0000	00000	
2	10000000	00000000	8000	32768	
4	00000000	00000000	0000	00000	
6	00000000	00000000	0000	00000	
8	00000000	00000000	0000	00000	
10	00000000	00000000	0000	00000	
12	00000000	00000000	0000	00000	
14	00000000	00000000	0000	00000	
26	00000001	00000000	0100	00512	
> Zeile für Zustandsmeldungen					
⌚ E → A → M ⌚ ⌚ T / Z ⌚ DF / DP ⌚ DBs ⌚					

Fig. 8-22 I/O/M/EI/EO Status Menu in Binary, Hexadecimal <->, Hexadecimal, Decimal, and ASCII Formats

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

[F3]	Switches statuses between inputs ->, outputs ->, markers ->, inputs.
[CURSOR RIGHT] or [CURSOR LEFT]	Switches between inputs -> extended input, and/or outputs -> extended output.
[F7]	Status T, C (in the case of the CL200, times and counters are displayed in two separate masks).
[F8]	Operand status DF, (DB).
[F9]	Operand status, DM
[EDIT]	Toggles Edit mode On/Off. With Edit mode enabled, editing is possible only in the selected mask.
[1], [2], [3] ...	Enter desired operand address.
[ENTER]	Accepts/adopts entered operand address, or transfers default of 0/1 _{bin} status to desired controller mask.

CAUTION!

Pressing the **[ENTER]** key one more time will cause the control mask to be written into the PLC!

Prerequisite:

The Control function is initially disabled. It is enabled by entering the value of 1_{hex} in data word D448 of data module DM255.

8.6.3 Timer / Counter Status

Status	Zeiten	ZE	STOP
T 12	0 0 0 0 , 0 0		
T 13	0 0 0 0 , 0 0		
T 14	0 0 0 0 , 0 0		
T 15	0 0 0 0 , 0 0		
T 16	0 0 0 0 , 0 0		
T 17	0 0 0 0 , 0 0		
T 18	0 0 0 0 , 0 0		
T 19	0 0 0 0 , 0 0		
T 20	0 0 0 0 , 0 0		
T 21	0 0 0 0 , 0 0		
T 22	0 0 0 0 , 0 0		
T 23	0 0 0 0 , 0 0		

> Zeile für Zustandsmeldungen

⌚ ↓ ⌚ ↑ ⌚ E / A / M ⌚ ⌚ Z ⌚ DF / DP ⌚ DBs ⌚

Fig. 8-23 Timer Status Menu for CL200

Status	Zähler	ZE	STOP
Z 24	0 0 0 0		
Z 25	0 0 0 0		
Z 26	0 0 0 0		
Z 27	0 0 0 0		
Z 28	0 0 0 0		
Z 29	0 0 0 0		
Z 30	0 0 0 0		
Z 31	0 0 0 0		
Z 32	0 0 0 0		
Z 33	0 0 0 0		
Z 34	0 0 0 0		
Z 35	0 0 0 0		

> Zeile für Zustandsmeldungen

⌚ ↓ ⌚ ↑ ⌚ E / A / M ⌚ ⌚ T ⌚ DF / DP ⌚ DBs ⌚

Fig. 8-24 Counter Status Menu for CL200

Z e i t e n			Z ä h l e r		Z E S T O P	
T	12	0000,00	Z	12	0000	
T	13	0000,00	Z	13	0000	
T	14	0000,00	Z	14	0000	
T	15	0000,00	Z	15	0000	
T	16	0000,00	Z	16	0000	
T	17	0000,00	Z	17	0000	
T	18	0000,00	Z	18	0000	
T	19	0000,00	Z	19	0000	
T	20	0000,00	Z	20	0000	
T	21	0000,00	Z	21	0000	
T	22	0000,00	Z	22	0000	
T	23	0000,00	Z	23	0000	

> Zeile für Zustandsmeldungen

⌚ ↓ ⌚ ↑ ⌚ E / A / M ⌚ ⌚ T / Z ⌚ DF / DP ⌚ DBs ⌚

Fig. 8-25 Timer / Counter Status Menu for CL400 / CL500

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

- [CURSOR LEFT]** or **[CURSOR RIGHT]** Previous / next messages
- [F3]** Switches statuses between inputs ->, outputs ->, markers ->, inputs.
- [F8]** Operand status DF, (DB)
- [F9]** Operand status, DM

8.6.4 DM /DF /(DB) Timer / Counter Status

Status DB 128, Länge 410		ZE STOP					
DB / By	HBy	binär	LBy	Hex.	Dezim.		
128 / 200	00000000	00000000	0000	00000	00000		
202	00000000	00000000	0000	00000	00000		
204	00000000	00000000	0000	00000	00000		
206	00000000	00000000	0000	00000	00000		
208	00000000	00000000	0000	00000	00000		
210	00000000	00000000	0000	00000	00000		
212	00000000	00000000	0000	00000	00000		
214	00000000	00000000	0000	00000	00000		
255 / 478	00000000	00000000	0000	00000	00000		
> Zeile für Zustandsmeldungen							
⌚	⌚	⌚E / A / M	⌚	⌚ T / Z	⌚ DF / DP	⌚ DBs	⌚

Fig. 8-26 Data Module / Data Words in Binary, Hexadecimal and Decimal Formats

Display Contents

The display indicates current status messages (e.g. *Outputs Disabled*) via the flashing LED in the **[MELD]** key. The messages appear in the display line for status messages. Additional messages can be displayed in plain-text form by pressing the **[MELD]** function key.

Menu Control

[F3]	Switches statuses between inputs ->, outputs ->, markers ->, inputs.
[F7]	Toggles between timers / counters
[F8]	Operand status DF, (DB)
[F9]	Operand status, DM

[EDIT]	Toggles Edit mode On/Off. With Edit mode enabled, editing is possible only in the selected mask.
[1], [2], [3] ...	Enter desired operand address.
[ENTER]	Accepts/adopts entered operand address, or transfers default of 0/1 _{bin} status to desired controller mask.

CAUTION!

Pressing the **[ENTER]** key one more time will cause the control mask to be written into the PLC!

Prerequisite:

The Control function is initially disabled. It is enabled by entering the value of 1_{hex} in data word D448 of data module DM255.

9 TS Programming System

9.1 Introduction

The TesiMod Programming System software – also referred to as *TS Programming System* – is used for programming tasks on the BT5 and BT20 operating terminals.

For the referred terminals, completely predefined screen masks and menus – generally called *menu tree* – are provided. There is a slight difference between the menu trees for the BT5 and BT20 operating terminals. The benefit of the menu trees is that the entire programming requirement for a given terminal is reduced to making minor touch-up corrections to several display masks.

The present chapter discusses the utilization of the preprogrammed TS software, i.e., its menu tree, and its adaptation to the functions and features of the respective BT5 and/or BT20 operator terminal.

More detailed information can be found in the technical manual, and in the User Manual provided by the firm of

SÜTRON electronic GmbH
Kurze Strasse 29
D-70794 Filderstadt / Germany.

9.2 Menu Tree

The supplied software includes the menu tree for the BT5 and BT20 operator terminals (differentiated by PLC controller variants), as well as the PLC software modules for the CL200, CL400, and CL500 control units.

In the event that several projects are being handled, each project will be allocated its own menu tree.

As a separate menu tree exists for each operator terminal and each controller, the menu trees for the BT5 / CL200 and BT20 / CL400 terminal / controller combinations shall be used as standard examples throughout the following sections.

The software data encompasses four files for each menu tree, listed in the table below.

BT5 / CL200	Filename	Explanation
	BT5_200.PRJ	Project definition
	BT5.TSG	Definition of parameters
	BT5_200.TSM	Mask definitions
	BT5_200.TSV	Definitions of variables
BT20 / CL400		
	BT20_400.PRJ	Project definition
	BT20.TSG	Definition of parameters
	BT20_4_5.TSM	Mask definitions
	BT20_400.TSV	Definitions of variables

Fig. 9-1 BT Project Files

To edit a given project, it is first loaded (by entering the directory name and the filename of the project definition). Once loaded, a project always contains the data ranges required for display masks, variables, and parameters. As a rule, to accomplish the adaptation of menu tree, only the editing of display masks and variables will be required.

Some display screens that contain project-specific data (e.g. defined text segments and/or variables) may contain blank areas requiring the user to fill in the missing text and variables. The tables appearing below identify all display masks for the BT5 and BT20 menu trees, providing notes regarding the editing action – if any – that will be required.

BT5 Menu Tree		
Editing	Number	Name
-	M1	Setup Menu
-	M2	Startup mask
-	EM4	Main menu
-	EM5	Service menu
-	EM6	Interface switchover
1	EM10	Cascade status
1	EM11	Criteria display
2	EM20	Power-up conditions 1, EM21 thru EM23 Power-up conditions 2 thru 4
-	EM30	Message parameters
1	MM31	Status messages
-	MM33	Serial messages
-	EM50	Status / Control menu
-	EM51	Date / Time
-	EM52	Internal PLC messages
-	EM60	Statuses (binary)
-	EM61	Statuses (hexadecimal)
-	EM62	Statuses (byte)
-	EM70	T and C statuses
-	EM80	Statuses DM (hexadecimal)
-	EM81	Statuses DM (binary)
-	EM90	Statuses DF,DB (hexadecimal)
-	EM91	Statuses DF,DB (binary)
-	EM100	Display menu
2	EM110	Display mask Group 1/1 EM111 - EM113 - Group 1/2-1/4 EM120 - EM123 - Group 1/2-1/4 EM130 - EM133 - Group 1/2-1/4 EM140 - EM143 - Group 1/2-1/4
-	EM200	Operation menu
1	EM211	Operation mask Group 1/1 EM212 - EM214 - Group 1/2-1/4 EM215 - EM218 - Group 1/2-1/4 EM219 - EM222 - Group 1/2-1/4 EM223 - EM226 - Group 1/2-1/4

Fig. 9-2 Mask Table — BT5 Operator Terminal

The menu tree for the CL200 controller contains one modified and one additional mask.		
-	EM70	Timer statuses (T)
-	EM71	Counter statuses (C)

Fig. 9-3 Timer and Counter Masks — CL200

BT20 Menu Tree		
Editing	Number	Name
-	M1	Setup Menu
-	M2	Startup mask
-	EM4	Main menu
1	EM10	Cascade status
1	EM11	Criteria display
2	EM20	Power-up conditions 1, EM21 thru EM23 - Power-up conditions 2 thru 4
-	EM30	Message parameters
1	MM31	Status messages
-	MM33	Serial messages
-	EM50	Service menu
-	EM51	Clock / internal messages
-	EM60	Statuses (binary)
-	EM61	Statuses (hexadecimal)
-	EM70	T and C statuses
-	EM80	Statuses DM/DF,DB (hexadecimal)
-	EM81	Statuses DM/DF,DB (binary)
-	EM90	Statuses DM/DF,DB (hexadecimal)
-	EM91	Statuses DM/DF,DB (binary)
-	EM100	Display menu
2	EM110	Display mask Group 1/1 EM111 - EM113 - Group 1/2-1/4 EM120 - EM123 - Group 1/2-1/4 EM130 - EM133 - Group 1/2-1/4 EM140 - EM143 - Group 1/2-1/4
-	EM200	Operation menu
1	EM211	Operation mask Group 1/1 EM212 - EM214 - Group 1/2-1/4 EM215 - EM218 - Group 1/2-1/4 EM219 - EM222 - Group 1/2-1/4 EM223 - EM226 - Group 1/2-1/4
The menu tree for the CL200 controller contains one modified and one additional mask.		
-	EM70	Timer statuses (T)
-	EM71	Counter statuses (C)

Fig. 9-4 Mask Table — BT20 Operator Terminal; T and C Masks — CL200

Editing = - → No editing required.

= 1 → Text must be inserted.

= 2 → Text and variables must be inserted.

9.3 TS Programming System Operation

The TS programming software is used to design and generate the masks to be displayed, and to transfer them to the BT operator terminals. The masks for the PLC controllers are already defined, and are merely adapted to specific requirements.

9.3.1 Keyboard and Mouse Operation

The TS software can be alternatively operated via keyboard or mouse input device.

The menu bar at the top edge of the screen can be enabled by pressing the **[Alt]** or **[F10]** key. Within the opened drop-down menus, the highlighting, or *selection*, can be moved between menu commands with the use of the **[CURSOR UP]** or **[CURSOR DOWN]** cursor keys. Pressing the **[RETURN]** key executes the selected menu command. To the right of some menu commands in the menus, a special *shortcut key* is indicated that can be used for starting the respective menu command directly from within the display masks of the operator terminal. Several display masks contain switches, or *action buttons*, that are labelled with the name of the key that needs to be pressed to carry out the respective action. A significant function is that of the **[TAB]** key, which causes the cursor to jump from one screen area to another within a given window.

The required mouse action to operate the various menus, menu commands and switches consists of pointing at the desired menu command, and then pressing the LEFT mouse button. (In more recent software parlance, this action is also referred to as *Clicking the menu command*.)

Pressing **[F1]** displays a Help text for the current display mask or window. In the case of some windows, this Help text is context-sensitive. This means, for example, that if the cursor is positioned in one display area, e.g. *Area A*, the displayed Help text will be different from the Help text that which would be displayed if **[F1]** had been pressed with the cursor positioned in *Area B*.

9.3.2 Project

Subsequent to creating a project with the aid of the PLC software, the PLC modules and the menu tree must be copied from the BT-MADAP diskette into the subdirectories assigned to the respective project. The required instructions are provided in Chapter 9, "TS Software Installation."

To start the TS programming system, the command **TS** is typed at the DOS prompt of the installation directory, followed by pressing **[RETURN]**. The main menu bar is displayed. The **File** menu contains the **Load project** command. Selecting it causes a window to be displayed in which the program selection takes place.

File	Edit	Options
New Project		
Load project		
Operating system		
End		

Fig. 9-5 Main Menu Bar

Each project is stored in a subdirectory of the PG directory. The menu trees are stored in a suitably named subdirectory of the respective project, i.e., `... \project\BT`. The project itself is loaded by selecting the project file, which is identified by the `.PRJ` filename extension.

Selecting the project file can be a simple matter of entering its full path-name, including drive letter, directory path and filename. Another method would be to locate and select the desired project file with the use of the file search utility. In the **Directory** area of the window, the drive and directory can be changed by positioning the highlight and pressing **[RETURN]**. In the event that the current directory contains files with a `.PRJ` filename extension, these will be listed. They can then be marked and selected by pressing **[RETURN]**.

The required data for masks, variables, and parameters that is also stored in the subdirectory, e.g. `... \project\BT`, is loaded along with the selected project file.

Selecting the **Edit** menu command of the TS **Main menu** opens the menu with its menu commands.

File	Edit	Options
	Masks file	
	Variables file	
	Parameters file	
	Graphical objects	
	Projekt management	
	Simulation	

Fig. 9-6 Edit Menu Commands in Main Menu Bar

The first four menu commands are used for selecting the correct menu tree. The **Project management** menu command is used to translate the files, and subsequently load them into the operator terminal (**Edit / Download** command). The **Simulation** menu command can be used to display the menu tree for the purpose of testing appearance and function. To accomplish the adaptation of the predefined masks, the execution of the bold-type menu commands is always required.

9.3.3 Masks

To accomplish the adaptation of the menu tree, the bold-type menu commands of the displayed menus must be carried out.

In the **Edit** menu on the **Main menu** bar, selecting the **Masks file** command causes the mask data to be loaded.

This causes the **Main menu** bar to be replaced by the **Edit masks** menu bar.

File	Edit	Terminal	Options
	Edit masks		
	Edit messages		
	Edit system messages		
	Edit default help text		
	Edit textlists		
	Edit recipes		
	Function keys		
	Cursor keys		

Fig. 9-7 Edit Masks Menu Bar

The **Edit masks** menu displays the following menu bar and the mask last edited in a window. The **Edit**, **Mask** and **Editing** submenus are required for mask adaptation.

File	Edit	Mask	Editing	Attribute
	Insert line			
	Delete line			
	Graphic character			
	Insert			
	Overwrite			

Fig. 9-8 Edit Masks Menu

File	Edit	Mask	Editing	Attribute
		Select mask		
		Copy mask		
		Delete mask		
		Load mask		
		Mask parameters		
		Softkeys for mask		
		Help text for mask		
		Background image for mask		
		Edit short name		
		Mask listing		
		Regenerate mask		

Fig. 9-9 Select Mask Menu

File	Edit	Mask	Editing	Attribute
			Variable	
			Edit textlists	
			Table description	
			Help text of variable	
			Recipe description	
			Position selection items	
			Edit selection items	
			Position messages	
			Message parameters	

Fig. 9-10 Edit Masks Menu, Variable

The **Select mask** menu command can be used to display the desired mask for editing by entering its specific mask number. The **Selection** menu command (available subsequent to selecting **Select mask**) causes all masks to be displayed in a list (with number and short designation), where they can be marked and also displayed for editing by pressing **[RETURN]**. In the event that changes have been made to the mask that was displayed prior to the mask selection, the system issues a safety query requesting a response to the question whether changes are to be saved or not.

In the displayed mask, permanent text can be inserted, moved or deleted. With the **Graphic character** command, graphic characters that are not available on the standard keyboard can be displayed in a list for subsequent selection and direct insertion into the mask. The last selected graphic character (displayed in the *Editing status* window) can also be inserted at the cursor position by pressing **[F8]**.

To provide a visual identifier for text and variables, they can be assigned the following attributes:

- Flashing (blinking)
- Reverse video
- Underlined
- Zoom

To establish this assignment, the desired attributes must be checked with the mouse in the *Editing status* window, or selected in the **Attribute** menu. Text or variables that have already been entered cannot be provided with an attribute. For this reason, if a change of attributes is desired, the previous text or variable must be deleted, and reentered, keeping in mind that the desired attributes must be set prior to entering the text or variable.

The **Zoom** attribute comprises a special feature. It can be used to enlarge a character to a size of max. four characters (i.e., a square of 2x2 size). At this point, the enlarged character can be represented by placeholder characters only. However, the character appears in its full size on the display of the operator terminal.

The **Variables** menu command of the **Edit** menu is used to insert variables. With this menu command selected, the **Variables description** menu opens, displaying the menu bar shown below.

File	Edit	Editor
	Select name	
	Select format	
	Select textlist	
	Edit textlist	
	Select graphical object	
	Select image list	
	Size of variable	

Fig. 9-11 Variables Description Menu

File	Edit	Editor
		Integer
		Real
		Floating point
		Coded text
		Alphanumerical
		Hexadecimal
		Binary
		Timer
		Counter
		Password
		Selection item
		Curve
		Beam
		Coded image
		BCD number

Fig. 9-12 Available Variables Format Menu

Pressing **[F2]** (or selecting the **Select name** command in the **Edit** menu) displays the list of available variables for selection. A new variable is generated by entering a new variable name. In the event that, in the case of a new and/or selected variable, the display format is missing, pressing **[F4]** (or selecting the **Select format** command in the **Edit** menu) displays the list of available formats. Selecting a format from this list causes it to be adopted for the current variable.

The user also has the option to define a new format by typing a new name in the *Format name* text box. The new format will adopt the settings displayed in this window. The extensive options for formatting variables are described in more detail in the User Manual furnished by SÜTRON electronic GmbH.

The variables contained in the menu tree are fully defined for general PLC controller tasks. However, in the event that a special task requires a variable that is not provided in the menu tree, such variable can be inserted as a new variable in the mask that is currently being edited. As a prerequisite, starting from the **Main menu** with the **Variables file** menu command, the new variable must be sufficiently defined (see also Section 8.3.6, "Variables").

Variables are used, for example, to represent an operand status that is transmitted by the controller to the operator terminal, or simply to display a text that is assigned to that value. The relationship between the value of the variable and the display text is indicated in the text list that appears in the window as a part of the format. The text lists can be edited with the use of the **Edit textlists** menu command (see Section 8.3.3.3, "Text Lists").

9.3.3.1 Help Text

For each mask, a Help text not exceeding the size of the mask can be entered. Based upon the mask that is currently active, this Help text can be displayed on the operator terminal by pressing a specific function key.

File	Edit	Mask	Editing	Attribute
		Select mask		
		Copy mask		
		Delete mask		
		Load mask		
		Mask parameters		
		Softkeys for mask		
		Help text for mask		
		Background image for mask		
		Edit short name		
		Mask listing		
		Regenerate mask		

Fig. 9-13 Help Text For Mask Menu

Selecting the **Edit masks** menu command displays the menu bar for mask editing, and the mask to be edited. Selecting the Help text for mask menu command opens the *Help for mask xxx* window (where xxx is the mask number). With the **Graphic character** command, graphic characters that are not available on the standard keyboard can be displayed in a list for subsequent selection and direct insertion into the mask. The last selected graphic character (displayed in the *Editing status* window) can also be inserted at the cursor position by pressing **[F8]**.

9.3.3.2 Messages

User-defined messages can be added in addition to the status messages defined for the PLC controller. For this purpose, the allocated bit in the responsible data word (data module 255) in the PLC program must be set to 1_{bin}. The message text is entered in the message list, beginning with number 17.

If the event occurs in the controller, and the corresponding bit is set, the message text is allocated via the message number, and then displayed (see also technical manual).

Starting from the **Edit masks** menu bar, the **Messages** menu containing the **Edit messages** command is opened.

File	Edit	Terminal	Options
	Edit masks		
	Edit messages		
	Edit system messages		
	Edit default help text		
	Edit textlists		
	Edit recipes		
	Function keys		
	Cursor keys		

Fig. 9-14 Edit Messages Menu

At the end of the default message list, a new message text can be entered. In the **Edit** menu of the current menu bar, messages can also be inserted into the list at any desired position (beginning with message number).

The message numbers 1 through 16 are reserved for permanent messages. The messages located in the reserved range may not be removed.

Declaration

- Entries, _{bin} between D255/460 and D255/474 for status messages 1 through 128 (1-16 reserved for internal messages).
- Entries, _{hex} in DM255/D496, upward of message number 129, for serial messages.

9.3.3.3 Text Lists

Starting from the **Edit masks** menu bar, the **Edit textlists** menu command opens the *Edit textlists* window.

File	Edit	Terminal	Options
	Edit masks		
	Edit messages		
	Edit system messages		
	Edit default help text		
	Edit textlists		
	Edit recipes		
	Function keys		
	Cursor keys		

Fig. 9-15 Edit Textlists Menu

Entering a name causes an available list to be displayed for editing in the *Textlist* window. If a text list of this name is not available, the displayed *Textlist* window will be blank, and a new text list can be entered. Upon closing the window, the modifications and/or new entries can be saved or discarded.

As an alternative, the list of names identifying the available text lists can be displayed by pressing **[F2]** (or by selecting the **Select textlist** menu command). Pressing **[RETURN]** causes the text list that is marked to be displayed for editing in the *Textlist* window.

The text list contains the allocation of the value of the variable to the text that is displayed on the operator terminal. The variables values are entered at the left-hand side of the window, and the assigned text sections at the right. In this process, a blank text segment accompanying the value of a variable is permissible. The valid variables values are a consequence of the PLC program.

Cascade no.	Text
1	Rotary table
2	Conveyor belt
3	etc.
4	etc.

Fig. 9-16 Example of Cascade Text Entry

Code	Criteria text
1002	E0.2 End position switch, exit hatch
1003	E0.3 Conveyor occupied
1004	etc.
1005	etc.

Fig. 9-17 Example of Criteria Text Entry

9.3.4 BT5 Operator Terminal — Masks Requiring Editing

9.3.4.1 BT5 – Operation Mask

The description of one Operation mask (here, M211 - Group 1/1) also applies to the other operation masks (Group 1/2 thru 4/4).

The operation masks are used to enable control in Manual mode. Each mask contains two lines with two steps each.

As only 4 steps are represented, the example used in the present section discusses the editing of only one operation mask.

The designation of the steps is absent in the operation masks, and is entered in the respective line as permanent text (example of absent designation: *Cylinder, C, V*).

The assignment of the actual movement of a machine to the position in the operation mask is defined by the fixed assignment of data words of the cascade data module to the position within the mask.

The definition of text sections within the mask does not require a specific sequence.

Mask 211		
C	Cylinder 1	V
ó ó		ó ó
C	Cylinder 2	V
ó ó		ó ó

Fig. 9-18 Example of BT5 Operation Mask

ó : Placeholder (also: *wildcard character*) for variable.

The following table lists all variables of the single-step controller in conjunction with their respective assignments.

Line	Col.	Name of Variable	Marker assigned in standard	BTS-ZV parameter
2	1	I_C_1	M180.0	P2
2	3	O_C_1	M181.0	P3
2	18	O_V_1	M183.0	P11
2	20	I_V_1	M182.0	P10
4	1	I_C_2	M180.1	P4
4	3	O_C_2	M181.1	P5
4	18	O_V_2	M183.1	P13
4	20	I_V_2	M182.1	P12

Fig. 9-19 BT5 Parameters, Assignment of Variable Operation Masks

9.3.4.2 BT5 – Power-Up Conditions Mask

The description of one Power-up Conditions mask (here, M20-1) also applies to the remaining Power-up Conditions masks.

The Power-up Conditions mask can be used to display the various pre-conditions existing for the start of the controller. A total of 4 masks is available.

The contents of these masks may be freely configured.

In the example used in the present section, two fixed texts and two variables are inserted into the Power-up Conditions mask.




Fig. 9-20 Example of BT5 — Power-Up Conditions Mask

Ó: Placeholder (also: *wildcard character*) for variable.

9.3.4.3 BT5 – Display Mask

The description of one Display mask (here, M110 - Group 1/1) also applies to the remaining Display masks.

The display masks are used to indicate several current controller statuses. A total of 16 Display masks is available.

In the example used in the present section, two fixed texts and two variables are inserted into the Display mask.




Fig. 9-21 Example of BT5 Display Mask

Ó: Placeholder (also: *wildcard character*) for variable.

The following table lists all variables of the single-step controller in conjunction with their respective assignments.

Line	Col.	Name of Variable	Marker assigned in standard	BTS-ZV parameter
4	3	I_C_1	M180.0	P2
4	11	O_C_1	M181.0	P3
4	31	O_V_1	M183.0	P11
4	39	I_V_1	M182.0	P10
7	3	I_C_2	M180.1	P4
7	11	O_C_2	M181.1	P5
7	31	O_V_2	M183.1	P13
7	39	I_V_2	M182.1	P12
10	3	I_C_3	M180.2	P6
10	11	O_C_3	M181.2	P7
10	31	O_V_3	M183.2	P15
10	39	I_V_3	M182.2	P14
13	3	I_C_4	M180.3	P8
13	11	O_C_4	M181.3	P9
13	31	O_V_4	M183.3	P17
13	39	I_V_4	M182.3	P16

Fig. 9-23 BT20 Parameters, Assignment of Variable Operation Masks

9.3.5.2 BT20 – Power-Up Conditions Mask

The description of one Power-up Conditions mask (here, M20-1) also applies to the remaining Power-up Conditions masks (2-4).

The Power-up Conditions mask can be used to display the various pre-conditions existing for the start of the machine. A total of 4 masks is available.

The contents of these masks are predefined only to the extent that the short name of the mask, and the *ZENTRALEINHEIT STEHT* (ZE STOP) and *SYSREPOUTREPTXT* (diagnostics message) variables are provided as default entries. These two variables are present in almost every mask.

In the example used in the present section, two fixed texts and two variables are inserted into the Power-up Conditions mask.




Fig. 9-25 Example of BT20 Display Mask

9.3.6 Variables

The variables contained in the masks are fully defined for general PLC controller tasks. This makes the editing of the variables file unnecessary. However, if a variable required for a special task should not be available, this variable must be entered, or defined, at this point.

File	Edit	Options
	Masks file	
	Variables file	
	Parameters file	
	Graphical objects	
	Project management	
	Simulation	

Fig. 9-26 Edit / Variables File Menu

In the **Edit** menu on the **Main menu** bar, the **Variables file** command is selected, and started by pressing **[RETURN]**.

File	Edit	PLC-linking
	Insert line	
	Delete line	
	Delete content	

Fig. 9-27 Edit Line Variables File Menu

The list of all available variables is displayed in the *Bosch BUEP19E Protocol* window. A new variable can be inserted at the end of the variables list, or inserted into the list with the use of the **Edit** menu, and the **Insert line** menu command. For the new variable, the name (use of the variable in a mask of this name), and the relation to the controller variables, must be established. To accomplish this, the values of the controller variable to be assigned must be entered in the list columns labelled *Data type*, *Access*, *Parameter1*, *Parameter2* and *Slave*.

If a new variable is entered into a mask, a format that determines its display within the mask must be attached to it during the insertion procedure.

9.3.7 Parameters

The parameters file provides the means for adjusting various parameters that regulate, for example, the communications between controller and operator terminal. As the predefined menu trees contain the settings that are configured for both the respective controller and operator terminal, no modifications will be normally required here.

However, if adaptations should be required, more detailed information can be taken from the technical manual. Also the procedure for changing parameters, as outlined in the User Manual furnished by SÜTRON electronic GmbH, must be observed.

9.4 Procedural Description

The procedural description encompasses the complete sequence of events, starting with the copying of the menu tree from the supplied program diskette, and concluding with the transfer of the completed menu to the respective operator terminal.

To facilitate enhanced understanding of procedural steps, the subsections of Section 8.4, "Procedural Description" shall utilize the procedural steps associated with the project labelled MACHINE1 and the BT20 operator terminal plus the CL400 controller. Only with regard to mask descriptions will parallel procedural steps apply to the BT5 operator terminal. Throughout the remaining subsections, the description of procedures will be restricted to those required for the BT20 operator terminal. These steps are listed analogous for the BT5 operator terminal, whereby merely the file-names and directory names must be replaced.

9.4.1 Copying Data From Program Diskette

For the BT20 operator terminal and the CL400 controller, the required data must be copied from the program diskette into the working project directory. The project directory named C:\PG\MACHINE1.C00 was previously created by means of the PLC software.

To create the menu tree directory, use the following command:

- MD C:\PG\MACHINE1.C00\BT

Copying files supplied on BT-MADAP program diskette:

- COPY A:\BT20\BT20.TSG C:\PG\MACHINE1.C00\BT
- COPY A:\BT20\BT20_400.PRJ C:\PG\MACHINE1.C00\BT
- COPY A:\BT20\BT20_4_5.TSM C:\PG\MACHINE1.C00\BT
- COPY A:\BT20\BT20_400.TSV C:\PG\MACHINE1.C00\BT
- COPY A:\CL400*.* C:\PG\MACHINE1.C00\ZSO

(For detailed information, see Chapter 9, "Installing TS Programming System.")

9.4.2 Loading Project File for Editing

- The TS Programming System is started by typing **TS** on the command line of the working directory, followed by pressing **[RETURN]**.
- With the **Main menu** bar displayed, pressing the **[Alt-F]** shortcut opens the **File menu**. The **Load project** menu command is highlighted, and executed by pressing **[RETURN]**.

File	Edit	Options
New project		
Load project		
Operating system		
End		

Fig. 9-28 Load Project Menu

- In the *Load project file window*, using the **[TAB]** key, the cursor is moved from the *Directory* box to the *Filename* box.
- In the text box, the menu tree directory and the name of the project file `C:\PG\MACHINE1.C00\BT\BT20_400.PRJ` are typed.
- Pressing **[RETURN]** causes the project to be loaded.
- The *Main menu* window displays the menu tree directory, the name of the project file, and the working files.

If the project to be edited was already loaded during the previous working session, this project will remain loaded the next time the TS application is launched, and this step will not be required.

9.4.3 Editing Display Masks

File	Edit	Options
	Masks file	
	Variables file	
	Parameters file	
	Graphical objects	
	Project management	
	Simulation	

Fig. 9-29 Edit Display Masks Menu

With the **Main menu** bar displayed, pressing the **[Alt-E]** shortcut opens the **Edit** menu. The **Masks file** menu command is highlighted, and executed by pressing **[RETURN]**.

File	Edit	Terminal	Options
	Edit masks		
	Edit messages		
	Edit system messages		
	Edit default help text		
	Edit textlists		
	Edit recipes		
	Function keys		
	Cursor keys		

Fig. 9-30 Edit Masks Menu

In the menu bar that is displayed next, pressing **[Alt-E]** opens the **Edit** menu, and the **Edit masks** menu command is executed by pressing **[RETURN]**.

File	Edit	Mask	Editing	Attribute
		Select mask		
		Copy mask		
		Delete mask		
		Load mask		
		Mask parameters		
		Softkeys for mask		
		Help text for mask		
		Background image for mask		
		Edit short name		
		Mask listing		
		Regenerate mask		

Fig. 9-31 Edit Select Mask Menu

The previously edited mask is displayed. In the menu bar that is displayed now, pressing **[Alt-M]** opens the **Mask** menu, and the **Select mask** menu command is executed by pressing **[RETURN]**.

By typing in the mask number, or by selecting from the list of all masks that can be opened by pressing **[F2]**, the mask to be edited can be selected and displayed by pressing **[RETURN]**.

9.4.4 BT5 — Operator Terminal Procedures

The mask modifications described below are based upon the mask used as an example in Section 8.3.4.1, "BT5 – Operation Masks."

9.4.4.1 BT5 – Operation Mask No. 211

Insertion into the Operation mask is restricted to fixed text sections describing the steps possible in Manual mode.

File	Edit	Mask	Editing	Attribute
				Normal
				*Reverse
				Flashing
				*Underlined
				*Zoom

Fig. 9-32 Edit Masks Menu, Example BT5 Attributes

The attributes identified with an asterisk (*) are not available on the BT5 operator terminal.

Pressing the **[Alt-A]** shortcut opens the **Attribute** menu, and the **Normal** menu command is executed by pressing **[RETURN]**.

Using the cursor keys, the cursor is moved to the position indicated by the intersection of Line1 / Column1. Using the keyboard, the text, e.g. C, is typed directly into the mask. All text entries are listed in the table below.

Line	Column	Text
1	1	V
1	6	Cylinder
1	15	1
1	20	V
2	1	V
2	6	Cylinder
2	15	1
2	20	V

Fig. 9-33 Example of Text Entries in Operation Mask, BT5

The described text entries conclude the mask editing procedure. In the case of mask changes or when exiting the application, a security query will remind the user to save the changes.

9.4.4.2 BT5 – Operation Mask No. 212 through 226

Editing these masks is similar to procedure for mask no. 211.

9.4.4.3 BT5 – Power-Up Conditions Mask No. 20

Insertions into the Power-up Conditions mask are restricted to fixed text sections and variables (with text lists) describing the prerequisites for starting the machine.

File	Edit	Mask	Editing	Attribute
				Normal
				*Reverse
				Flashing
				*Underlined
				*Zoom

Fig. 9-34 Power-Up Conditions Mask Menu, Example BT5 Attributes

The attributes identified with an asterisk (*) are not available on the BT5 operator terminal.

Pressing the **[Alt-A]** shortcut opens the **Attribute** menu, and the **Normal** menu command is executed by pressing **[RETURN]**.

Inserting text into mask

Using the cursor keys, the cursor is moved to the position indicated by the intersection of Line1 / Column1. Using the keyboard, the text, e.g. *Hydraulic pump*, is typed directly into the mask. All text entries are listed in the table below.

Line	Column	Text
1	1	Hydraulic pump
1	15	On
2	1	Lubrication pump
2	15	On

Fig. 9-35 Example of Text Entries in Power-Up Conditions Mask, BT5

Example: Inserting E_HPumpe variable into mask

The cursor is moved to the position indicated by the intersection of Line1 and Column20. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

File	Edit	Mask	Editing	Attribute
			Variable	
			Edit textlists	
			Table description	
			Help text of variable	
			Recipe description	
			Position selection items	
			Edit selection items	
			Position messages	
			Message parameters	

Fig. 9-36 Edit Variables Text Lists, Example BT5

The **Variables description** menu and the following menu are displayed:

File	Edit	Editor
	Select name	
	Select format	
	Select textlist	
	Edit textlist	
	Select graphical object	
	Select image list	
	Size of variable	

Fig. 9-37 Variables Description Menu, Example BT5

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection. The cursor keys are used for navigation between the individual text boxes within the mask. In text boxes permitting direct entry, the text or number is simply typed in. In check-boxes (the entry is enclosed by brackets), cursor navigation uses either the **[SPACE]** bar or the mouse. The display type for the variable is selected via the **Display** menu on the current menu bar.

Text box designation	Entry	Entry type
Variable name	E_HPumpe	Text entry
Format name	OffON	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-38 Entry Fields of Variables Description, Example BT5

The Variable name, Format name, and Text list text boxes can also be edited by means of the **Edit** menu with the use of selection lists of preexisting variable names, format names and/or text lists.

In this mask, the new text list named *OffOnList* has been created which will still be entered by means of the **Edit textlist** menu command. Selecting this menu command causes the *Textlist* window to be displayed. The variables values are entered at the left-hand side of the window, and the assigned text sections at the right.

Variables value	Text (here of length 1)
0	— (corresponds to: space bar)
1	▬ (corresponds to: filled rectangle)

Fig. 9-39 Variables Values, Example BT5

The space character is directly typed in with the keyboard. Entering the filled rectangle requires the use of the **Edit** menu, and invoking the **Graphical character** menu command. Upon exiting the window (by pressing the **[ESCAPE]** key or **[SHIFT+F10]** shortcut), a security query reminds the user to save the changes.

With the above entries completed, the variable is ready for insertion into the mask. Upon closing the window by pressing **[ESCAPE]** or the **[SHIFT+F10]** shortcut, the changes can be saved or discarded. If the mask is saved, the placeholder for the display length variable will be displayed in the mask.

Example: Inserting E_SPumpe variable into mask

As the procedure is largely similar to that discussed with the E_HPumpe variable, a short description of the required steps will suffice at this point.

The cursor is moved to the position indicated by the intersection of Line1 and Column20. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection.

Text box designation	Entry	Entry type
Variable name	E_SPumpe	Text entry
Format name	OffON	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-40 Entry Fields of Variables Description, Example BT5

The E_SPumpe variable is assigned the same format as the E_HPumpe variable in the preceding example. Accordingly, only the variable name and format name are entered (format name also as selection list). In the case that the preexisting format is confirmed and accepted, the remaining fields will be automatically filled with the correct entries (these entries form the format with the format name).

Attention!

The assignment of the new variables to the controller variables remains to be entered in the variables file (see Section 8.4.6, "Variables" later in this chapter).

9.4.4.4 BT5 – Power-Up Conditions Mask No's. 21-23

Editing these masks is similar to the procedure used for Power-up Conditions mask no. 20.

9.4.4.5 BT5 – Display Mask No. 110

Insertions into the Display mask are restricted to fixed text sections and variables (with text lists) describing specific tasks occurring in the course of sequential controller processing.

File	Edit	Mask	Editing	Attribute
				Normal
				*Reverse
				Flashing
				*Underlined
				*Zoom

Fig. 9-41 Power-Up Conditions Mask Menu, Example BT5 Attributes

The attributes identified with an asterisk (*) are not available on the BT5 operator terminal.

Pressing the **[Alt-A]** shortcut opens the **Attribute** menu.

Inserting text into mask

Using the cursor keys, the cursor is moved to the position indicated by the intersection of Line1 / Column1. Using the keyboard, the text, e.g. *Teil*, is typed directly into the mask. All text entries are listed in the table below.

Line	Column	Text
1	1	Teil
1	6	A
1	8	Processing
2	1	Teil
2	6	B
2	8	Processing

Fig. 9-42 Example of Text Entries in Display Mask, Example BT5

Example: Inserting E_TeilA variable into mask

The cursor is moved to the position indicated by the intersection of Line1 and Column20. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

File	Edit	Mask	Editing	Attribute
			Variable	
			Edit textlist	
			Table description	
			Help text of variable	
			Recipe description	
			Position selection items	
			Edit selection items	
			Position messages	
			Message parameters	

Fig. 9-43 Edit Variable Display Mask, Example BT5

The **Variables description** menu and the following menu are displayed:

File	Edit	Editor
	Select name	
	Select format	
	Select textlist	
	Edit textlist	
	Select graphical object	
	Select image list	
	Size of variable	

Fig. 9-44 Edit, Variables Description Menu, Text List, Example BT5

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection. The cursor keys are used for navigation between the individual text boxes within the mask. In text boxes permitting direct entry, the text or number is simply typed in. In check-boxes (the entry is enclosed by brackets), cursor navigation uses either the **[SPACE]** bar or the mouse. The display type for the variable is selected via the **Display** menu on the current menu bar.

Text box designation	Entry	Entry type
Variable name	E_TeilA	Text entry
Format name	OffOn	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-45 Entry Fields of Variables Description, Example BT5

The E_TeilA variable is assigned the same format as the E_HPumpe. Accordingly, only the variable name and format name are entered (format name also as selection list). In the case that the preexisting format is confirmed and accepted, the remaining fields will be automatically filled with the correct entries (these entries form the format with the format name).

The complete procedural steps required to generate a new variable possessing a new format is described in detail in the preceding Section 8.4.4.3, "BT5 – Power-Up Conditions Mask No. 20."

With the above entries completed, the variable is ready for insertion into the mask. Upon closing the window by pressing **[ESCAPE]** or the **[SHIFT+F10]** shortcut, the changes can be saved or discarded. If the mask is saved, the placeholder for the display length variable will be displayed in the mask.

Example: Inserting E_TeilB variable into mask

As the procedure is largely similar to that discussed with the E_TeilA variable, a short description of the required steps will suffice at this point.

The cursor is moved to the position indicated by the intersection of Line1 and Column20. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection.

Text box designation	Entry	Entry type
Variable name	E_TeilB	Text entry
Format name	OffON	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-46 Entry Fields of Variables Description, Example BT5

The E_TeilB variable is assigned the same format as the E_HPumpe variable in the preceding example. Accordingly, only the variable name and format name are entered (format name also as selection list). In the case that the preexisting format is confirmed and accepted, the remaining fields will be automatically filled with the correct entries (these entries form the format with the format name).

With the above entries completed, the variable is ready for insertion into the mask. Upon closing the window by pressing **[ESCAPE]** or the **[SHIFT+F10]** shortcut, the changes can be saved or discarded. If the mask is saved, the placeholder for the display length variable will be displayed in the mask.

Attention!

The assignment of the new variables to the controller variables remains to be entered in the variables file (see Section 8.4.6, "Variables" later in this chapter).

9.4.4.6 BT5 – Display Mask No's. 110-113, 120-123, 130-133, 140-143

Editing these masks is similar to the procedure used for Display mask no. 110.

9.4.5 BT20 — Operator Terminal Procedures

The mask modifications described below are based upon the mask used as an example in Section 8.3.5.1, "BT20 – Operation Mask."

9.4.5.1 BT20 – Operation Mask No. 211

Insertion into the Operation mask is restricted to fixed text sections describing the steps possible in Manual mode.

File	Edit	Mask	Editing	Attribute
				Normal
				Reverse
				Flashing
				Underlined
				Zoom

Fig. 9-47 Edit Masks Menu, Example BT20 Attributes

Pressing the **[Alt-A]** shortcut opens the **Attribute** menu, and the **Normal** menu command is executed by pressing **[RETURN]**.

Using the cursor keys, the cursor is moved to the position indicated by the intersection of Line3 / Column16. Using the keyboard, the text, e.g. *Cylinder*, is typed directly into the mask. All text entries are listed in the table below.

Line	Column	Text
3	16	Cylinder
3	25	1
4	4	rear
4	12	backward
4	28	forward
4	34	front
6	16	Cylinder
6	25	2
7	4	rear
7	12	backward
7	28	forward
7	34	front

Fig. 9-48 Example of Text Entries in Operation Mask, BT20

The described text entries conclude the mask editing procedure. In the case of mask changes or when exiting the application, a security query will remind the user to save the changes.

9.4.5.2 BT20 – Operation Mask No. 212 through 226

Editing these masks is similar to procedure for mask no. 211.

9.4.5.3 BT20 – Power-Up Conditions Mask No. 20

Insertions into the Power-up Conditions mask are restricted to fixed text sections and variables (with text lists) describing the prerequisites for starting the machine.

File	Edit	Mask	Editing	Attribute
				Normal
				Reverse
				Flashing
				Underlined
				Zoom

Fig. 9-49 Power-Up Conditions Mask Menu, Example BT20 Attributes

Pressing the **[Alt-A]** shortcut opens the **Attribute** menu, and the **Normal** menu command is executed by pressing **[RETURN]**.

Inserting text into mask

Using the cursor keys, the cursor is moved to the position indicated by the intersection of Line5 / Column3. Using the keyboard, the text, e.g. *Hydraulic pump*, is typed directly into the mask. All text entries are listed in the table below.

Line	Column	Text
5	1	Hydraulic pump
5	18	On
7	1	Lubrication pump
7	18	On

Fig. 9-50 Example of Text Entries in Power-Up Conditions Mask, BT20

Example: Inserting E_HPumpe variable into mask

The cursor is moved to the position indicated by the intersection of Line5 and Column22. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

File	Edit	Mask	Editing	Attribute
			Variable	
			Edit textlists	
			Table description	
			Help text of variable	
			Recipe description	
			Position selection items	
			Edit selection items	
			Position messages	
			Message parameters	

Fig. 9-51 Edit Variables Text Lists, Example BT20

The **Variables description** menu and the following menu are displayed:

File	Edit	Editor
	Select name	
	Select format	
	Select textlist	
	Edit textlist	
	Select graphical object	
	Select image list	
	Size of variable	

Fig. 9-52 Variables Description Menu, Example BT20

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection. The cursor keys are used for navigation between the individual text boxes within the mask. In text boxes permitting direct entry, the text or number is simply typed in. In check-boxes (the entry is enclosed by brackets), cursor navigation uses either the **[SPACE]** bar or the mouse. The display type for the variable is selected via the **Display** menu on the current menu bar.

Text box designation	Entry	Entry type
Variable name	E_HPumpe	Text entry
Format name	OffON	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-53 Entry Fields of Variables Description, Example BT20

The Variable name, Format name, and Text list text boxes can also be edited by means of the **Edit** menu with the use of selection lists of preexisting variable names, format names and/or text lists.

In this mask, the new text list named *OffOnList* has been created which will still be entered by means of the **Edit textlist** menu command. Selecting this menu command causes the *Textlist* window to be displayed. The variables values are entered at the left-hand side of the window, and the assigned text sections at the right.

Variables value	Text (here of length 1)
0	— (corr esponds to: space bar)
1	(corr esponds to: filled rectangle)

Fig. 9-54 Variables Values, Example BT20

Entering the filled rectangle requires the use of the **Edit** menu, and invoking the **Graphical character** menu command.

With the above entries completed, the variable is ready for insertion into the mask. If the mask is saved, the placeholder for the display length variable will be displayed in the mask.

Example: Inserting E_SPumpe variable into mask

As the procedure is largely similar to that discussed with the E_HPumpe variable, a short description of the required steps will suffice at this point.

The cursor is moved to the position indicated by the intersection of Line7 and Column22. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection.

Text box designation	Entry	Entry type
Variable name	E_SPumpe	Text entry
Format name	OffON	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-55 Entry Fields of Variables Description, Example BT20

The E_SPumpe variable is assigned the same format as the E_HPumpe variable in the preceding example. Accordingly, only the variable name and format name are entered (format name also as selection list). In the case that the preexisting format is confirmed and accepted, the remaining fields will be automatically filled with the correct entries (these entries form the format with the format name).

With the above entries completed, the variable is ready for insertion into the mask. If the mask is saved, the placeholder for the display length variable will be displayed in the mask.

Attention!

The assignment of the new variables to the controller variables remains to be entered in the variables file (see Section 8.4.6, "Variables" later in this chapter).

9.4.5.4 BT20 – Power-Up Conditions Mask No's. 21-23

Editing these masks is similar to the procedure used for Power-up Conditions mask no. 20.

9.4.5.5 BT20 – Display Mask No. 110

Insertions into the Display mask are restricted to fixed text sections and variables (with text lists) describing specific tasks occurring in the course of sequential controller processing.

File	Edit	Mask	Editing	Attribute
				Normal
				Reverse
				Flashing
				Underlined
				Zoom

Fig. 9-56 Power-Up Conditions Mask Menu, Example BT20 Attributes

Pressing the **[Alt-A]** shortcut opens the **Attribute** menu, and the **Normal** menu command is executed by pressing **[RETURN]**.

Inserting text into mask

Using the cursor keys, the cursor is moved to the position indicated by the intersection of Line5 / Column3. Using the keyboard, the text, e.g. *Teil*, is typed directly into the mask. All text entries are listed in the table below.

Line	Column	Text
5	3	Teil
5	8	A
5	10	being
5	13	processed
7	3	Teil
7	8	B
7	10	being
7	13	processed

Fig. 9-57 Example of Text Entries in Display Mask, Example BT20

Example: Inserting E_TeilA variable into mask

The cursor is moved to the position indicated by the intersection of Line5 and Column25. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

File	Edit	Mask	Editing	Attribute
			Variable	
			Edit textlist	
			Table description	
			Help text of variable	
			Recipe description	
			Position selection items	
			Edit selection items	
			Position messages	
			Message parameters	

Fig. 9-58 Edit Variable Display Mask, Example BT20

The **Variables description** menu and the following menu are displayed:

File	Edit	Editor
	Select name	
	Select format	
	Select textlist	
	Edit textlist	
	Select graphical object	
	Select image list	
	Size of variable	

Fig. 9-59 Edit, Variables Description Menu, Text List, Example BT20

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection. The cursor keys are used for navigation between the individual text boxes within the mask. In text boxes permitting direct entry, the text or number is simply typed in. In check-boxes (the entry is enclosed by brackets), cursor navigation uses either the **[SPACE]** bar or the mouse. The display type for the variable is selected via the **Display** menu on the current menu bar.

Text box designation	Entry	Entry type
Variable name	E_TeilA	Text entry
Format name	OffOn	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-60 Entry Fields of Variables Description, Example BT20

The E_TeilA variable is assigned the same format as the E_HPumpe. Accordingly, only the variable name and format name are entered (format name also as selection list). In the case that the preexisting format is confirmed and accepted, the remaining fields will be automatically filled with the correct entries (these entries form the format with the format name).

The complete procedural steps required to generate a new variable possessing a new format is described in detail in the preceding Section 8.4.4.3, "BT5 – Power-Up Conditions Mask No. 20."

With the above entries completed, the variable is ready for insertion into the mask. If the mask is saved, the placeholder for the display length variable will be displayed in the mask.

Example: Inserting E_TeilB variable into mask

As the procedure is largely similar to that discussed with the E_TeilA variable.

The cursor is moved to the position indicated by the intersection of Line7 and Column25. In the **Edit** menu, the **Variable** menu command is selected, and executed by pressing **[RETURN]**.

The text boxes listed in the table below must be typed into, checked or filled by completing a menu selection.

Text box designation	Entry	Entry type
Variable name	E_TeilB	Text entry
Format name	OffON	Text entry
Length	1	Number entry
Cyclical display	•	Checking
Red text below Length text box	Coded text	Selection from Display menu
Text list	OffOnList	Text entry

Fig. 9-61 Entry Fields of Variables Description, Example BT20

The E_TeilB variable is assigned the same format as the E_HPumpe variable in the preceding example. Accordingly, only the variable name and format name are entered (format name also as selection list). In the case that the preexisting format is confirmed and accepted, the remaining fields will be automatically filled with the correct entries (these entries form the format with the format name).

With the above entries completed, the variable is ready for insertion into the mask. If the mask is saved, the placeholder for the display length variable will be displayed in the mask.

Attention!

The assignment of the new variables to the controller variables remains to be entered in the variables file (see Section 8.4.6, "Variables" later in this chapter).

9.4.5.6 BT20 – Display Mask No's. 110-113, 120-123, 130-133, 140-143

Editing these masks is similar to the procedure used for Display mask no. 110.

9.4.6 Variables

Four new variables have been inserted into Power-up Conditions mask no. 20 and in Display mask 110. These variables must still be set into relation to the controller variables.

File	Edit	Options
	Masks file	
	Variables file	
	Parameters file	
	Graphical objects	
	Project management	
	Simulation	

Fig. 9-62 Opening Variables File

Starting from the **Main menu**, the **Variables file** menu command is selected and started by pressing **[RETURN]**.

File	Edit	PLC-linking
	Insert line	
	Delete line	
	Delete content	

Fig. 9-63 Edit Line Variables File Menu

The list of all variables available to date is displayed in table form in the *Bosch BUEP19E Protocol* window. The cursor keys are used to navigate within the table. The **[CURSOR DOWN]** key is used to scroll down to the last variable in the list.

For the four new variables, the following entries are made in the table columns:

Var.	Variable name	D type	Access	Par. 1	Par. 2	Slave
x	E_HPumpe	E	B	10	0	0
x	E_SPumpe	E	B	10	1	0
x	E_TeilA	E	B	10	2	0
x	E_TeilB	E	B	10	3	0

Fig. 9-64 Example of Entering Variables

9.4.7 Compiling Mask Files

File	Edit	Options
	Masks file	
	Variables file	
	Parameters file	
	Graphical objects	
	Project management	
	Simulation	

Fig. 9-65 Project Management Menu to Access Compile Function

From the **Main menu**, pressing the **[Alt-E]** shortcut opens the **Edit** menu, followed by selecting the **Project management** menu command, and executing it by pressing **[RETURN]**.

File	Edit	Options	Terminal	EPROM Version
	Compile			
	Show errors			
	Download			
	Show map file			
	Show listing			

Fig. 9-66 Compiling and Loading

In the menu that now opens, pressing the **[Alt-E]** shortcut opens the **Edit** menu. The **Compile** menu command is selected, and executed by pressing **[RETURN]**.

The progress of the compiling process is indicated in the *Compile* window. Once the project has been completely compiled, the *Compiling messages* window is opened, containing possible errors and/or warnings and information. The compiled project files is stored under the same name as the project file but with the .S3 filename extension, in the menu tree directory belonging to the project. (In the example used here, this is C:\PG\MACHINE1.C00\BT\B00\BT20_400.S3).

Example of an error and the required user response:

A new variable was inserted into a mask without entering this variable in the variables file.

As a consequence, the error message "Universal Address of 'Name' output variable is missing" is displayed.

To remedy the error, the **Edit** menu is opened from the **Main menu**, followed by selecting the **Variables file** menu command, and executing it by pressing **[RETURN]**. The new variable, complete with name and access address, can now be entered in the variables file.

9.4.8 Transferring .S3 File to Operator Terminal

Once the project has been compiled error-free, the .S3 file can be loaded into the operator terminal.

For this purpose, the operator terminal must be set to Download mode.

File	Edit	Options
	Masks file	
	Variables file	
	Parameters file	
	Graphical objects	
	Project management	
	Simulation	

Fig. 9-67 Project Management Menu, Download Menu Command

From the **Main menu**, pressing the **[Alt-E]** shortcut opens the **Edit** menu, followed by selecting the **Project management** menu command, and executing it by pressing **[RETURN]**.

File	Edit	Options	Terminal	EPROM Version
	Compile			
	Show errors			
	Download			
	Show map file			
	Show listing			

Fig. 9-68 Download Procedure

In the menu that now opens, pressing the **[Alt-E]** shortcut opens the **Edit** menu. The **Download** menu command is selected, and executed by pressing **[RETURN]**. The **[F6]** key is now used to download the data of the displayed project into the BT operator terminal.

File	Edit	
	COM1 Interface	
	COM2 Interface	

Fig. 9-69 Selecting Serial Interface

The interface can be changed by making the appropriate selection in the **Edit** menu.

In the **File** menu, the **Load program file** menu command can be used to send any project (that does not necessarily have to be loaded) to the connected operator terminal. For this purpose, the names of the directory and of the program file can be typed in directly, or selected by moving through the displayed directory lists.

Prior to transferring the .S3 file to an operator terminal, the menu tree can be simulated on the PC. To do so, the **Edit** menu is opened from the **Main menu** level, the **Simulation** menu command is selected, followed by pressing **[RETURN]** to start the simulation.

10 Tesi Mod Software Installation

Both the **TS Programming System** software (briefly referred to as "TS") and the menu trees are shipped on individual 3.5 inch diskettes. As a first step, the installation program on the diskette is used to install the TS application. Next, the menu tree data and the PLC files associated to machine control functions are copied from the diskette into the respective PLC directories.

10.1 Installing the Software

The installation diskette is loaded into the 3.5 inch disk drive (drive letter A: \ or B: \). Starting at the command line of the current directory, you start the installation program by typing:

```
A: \INSTALL Or, if the installation diskette is in the B:\ drive,  
B: \INSTALL
```

and by pressing **[RETURN]**.

The German-language sign-on screen shown below is displayed. It enables you to select both the destination drive and destination directory for the installation.




Fig. 10-1 TesiMod Sign-On Screen and Installation Start Menu

The default settings of C:\ (*Ziellaufwerk* = destination hard disk) and \TS4 (*Zielverzeichnis* = destination directory) can be changed. Pressing the **[CURSOR UP]** and/or **[CURSOR DOWN]** key switches the cursor to the respective entry option. Invalid drive destinations and/or directory names will cause a cautionary message to be returned, and must be changed. At this point, the installation procedure can be cancelled by pressing the **[ESCAPE]** key.

It is instructive to note that the installation routine is fully automatic, and does not require user intervention. However, to avoid confusion, the two German-language messages appearing during the installation procedure are translated below.

Pressing the **[SHIFT+F10]** shortcut starts the installation.

The sign-on screen is removed, and a message displayed.
 [German message text:]
 Das TesiMod Programmiersystem wird installiert!

[English translation:]
Installing the TesiMod Programming System!

The TS application data is stored on the diskette in compressed form. It will be unpacked during the installation, and installed in the destination directory. The unpacking progress ("melting") is indicated throughout subsequent screens, followed by a second message to announce the conclusion of the installation. The current directory is now also the destination directory of the installation.

Starting the Application

The completed installation is confirmed with the message: [German message text:]
 Sie können jetzt mit dem Befehl TS das Programmiersystem starten!

[English translation:]
You can now start the Programming System by entering TS (followed by pressing [RETURN])!

10.2 English-Language User Interface

The program initially starts up in the original German-language version which can be subsequently switched to English. Once the installation has been successfully completed, the displayed menus will still be in German.

With the Main menu displayed, the top menu bar will show three commands, **Datei**, **Bearbeiten**, and **Optionen**. To access the **Optionen** menu, press the **[Alt-O]** shortcut. You will see a drop-down menu containing 5 menu commands.

Maussteuerung...
Warnton...
Farbpalette wählen...
Ländereinstellung...
Druckereinstellung...

Using the **[CURSOR DOWN]** key, place the highlight on the menu command named **Ländereinstellung** (see above), and press **[ENTER]**.

The *Neue Sprache auswählen* window will be displayed. In the window, you will see that the **deutsch** (German) option is selected, which is indicated by the dot between the brackets to the right.

To change the language to English, first press the **[CURSOR DOWN]** key. The dark selection rectangle moves downward between the brackets to the right of the **English** language option, while the dot remains in its original position. To move it downward, press the **[SPACE BAR]** on your keyboard. Now, to confirm the selection, press **[RETURN]**. After a brief moment, the English user interface of TesiMod will appear. From now on, the program will always start up in English.

10.3 Directory Structure

Both the PLC data and the menu trees are project-specific, and are stored in a directory structure, parts of which are predetermined and must not be changed.

The installation of the PLC software generates a main directory (the PG directory) in which the projects are stored as subdirectories. If the default installation settings are accepted, the following will apply:

Main directory: C:\PG

For each new project that is started with the PLC software, the name of the project directory is composed as follows:

anyname + .B00, .C00 or .500 filename extension for CL200, CL400 or CL500 controller variants, plus PLC directories: ... \ZS0, etc.

Example 1: For the CL400 project named MACHINE1, these two directories are generated:

Project directory: C:\PG\MACHINE1.C00

PLC file directory: C:\PG\MACHINE1.C00\ZS0

Example 2: For a CL500 project named EXAMP1, these two directories are generated:

Project directory: C:\PG\EXAMP1.500

PLC file directory: C:\PG\EXAMP1.500\ZS0

It is thus demonstrated that each project corresponds to one project directory and one subdirectory ... \ZS0. This directory stores the PLC data that is thus clearly allocated to the respective project. As the menu trees must also permit an unambiguous allocation to the respective project, it is good practice to locate the menu tree directory ... \BT5 or \BT20 also directly beneath the respective project directory. The required directories must be generated by means of DOS commands. For Examples 1 and 2, above, the menu tree directories are set up with the following DOS commands:

Example 1: MD C:\PG\MACHINE1.C00\BT5

Example 2: MD C:\PG\EXAMP1.500\BT20

(Caution: blank space between MD and C:\PG...)

Therefore, the directory structure for the above examples appears as follows:

C:\PG
C:\PG\MACHINE1.C00
C:\PG\MACHINE1.C00\BT5
C:\PG\MACHINE1.C00\ZS0
C:\PG\EXAMP1.500
C:\PG\EXAMP1.500\BT20
C:\PG\EXAMP1.500\ZS0
C:\PG\other projects ...

Fig. 10-2 Example of Directory Structure

10.4 BT-MADAP Program Diskette

This diskette contains the menu trees for the BT5 and BT20 operator terminals, plus the PLC software modules for the CL200, CL400 and CL500 controller variants.

The menu trees comprise all control menus of the respective operator terminal, in part without the application-specific text and variables.

Also provided on the diskette is an example suitable for the CL200 controller and BT20 operator terminal. The files are located in the directories listed below.

```

\BT20
\BT5
\CL200
\CL200\BEISPIEL\BT20
\CL200\BEISPIEL\CL200
\CL400
\CL500
  
```

Fig. 10-3 Directory Structure of BT-MADAP Diskette

Dependent upon the employed controller and operator terminal, different files must be copied from the various directories belonging to a given project. In the event that identical data is to be provided to several different projects, the respective files must be copied into the subdirectories of each of the projects in question. (See also **CAUTION** note at the head of next page.)

Menu tree destination directory: ... \BT

BT	Controller	Directory on diskette	File to be copied
20	CL200	\BT20	BT20.TSG BT20_200.PRJ BT20_200.TSM BT20_200.TSV
20	CL400	\BT20	BT20.TSG BT20_400.PRJ BT20_4_5.TSM BT20_400.TSV
20	CL500	\BT20	BT20.TSG BT20_500.PRJ BT20_4_5.TSM BT20_500.TSV
5	CL200	\BT5	BT5.TSG BT5_200.PRJ BT5_200.TSM BT5_200.TSV
5	CL400	\BT5	BT5.TSG BT5_400.PRJ BT5_4_5.TSM BT5_400.TSV
5	CL500	\BT5	BT5.TSG BT5_500.PRJ BT5_4_5.TSM BT5_500.TSV

Fig. 10-4 Directories of BT5 / BT20 Project Files on BT-MADAP Diskette

CAUTION — Possible Data Loss!

In the event that the required files are already stored in the ... \ZS0 PLC directory or the ... \BT menu tree directory of a given project, the identical filenames will cause existing files to be overwritten in the process of copying files from the diskette.

To prevent the loss of essential data, a data backup of existing project files is always recommended prior to any new installation procedures.

PLC file destination directory : ... \ZS0

	Controller	Directory on diskette	Files to be copied
	CL200	\CL200	all files
	CL400	\CL400	all files
	CL500	\CL500	all files

Fig. 10-5 Directories of PLC Program Files on BT-MADAP Diskette

Example:

The project named MACHINE1.C00 requires the CL400 controller, and the BT20 operator terminal is used. The following files must be copied:

BT	Controller	Diskette directory	Files to be copied
20	CL400	\BT20	BT20.TSG BT20_400.PRJ BT20_4_5.TSM BT20_400.TSV
	CL400	\CL400	all files

Fig. 10-6 Example of Mask Files for CL400 / BT20 Combination

```

COPY A:\BT20\BT20.TSG C:\PG\MACHINE1.C00\BT20

COPY A:\BT20\BT20_400.PRJ C:\PG\MACHINE1.C00\BT20

COPY A:\BT20\BT20_4_5.TSM C:\PG\MACHINE1.C00\BT20

COPY A:\BT20\BT20_400.TSV C:\PG\MACHINE1.C00\BT20

COPY A:\CL400\*.* C:\PG\MACHINE1.C00\ZS0
    
```

The example provided on the diskette contains menus that were specifically edited (normally missing text and variables were already inserted), as well as associated PLC datafiles.

BT	Controller	Diskette directory	Files to be copied
20		\CL200\BEISPIEL\BT20	all files
	CL200	\CL200\BEISPIEL\CL200	all files

Fig. 10-7 Example Project for CL200 / BT20 Combination on Diskette

For the purpose of testing the TS software, the example provided on diskette should be copied into a project directory. In the following example, this is the project `SAMPLE1.B00`.

```
COPY A:\CL200\BEISPIEL\BT20\BT20.TSG C:\PG\SAMPLE1.B00\BT20
COPY A:\CL200\BEISPIEL\BT20\BT20_400.PRJ C:\PG\SAMPLE1.B00\BT20
COPY A:\CL200\BEISPIEL\BT20\bt20_4_5.TSM C:\PG\SAMPLE1.B00\BT20
COPY A:\CL200\BEISPIEL\BT20\BT20_400.TSV C:\PG\SAMPLE1.B00\BT20
COPY A:\CL200\BEISPIEL\CL200\*.* C:\PG\SAMPLE1.B00\ZS0
```

10.5 Concluding Remarks

This concludes the installation of the TesiMod TS Programming System software, and of the associated data supplied on the BT-MADAP program diskette.

To start the TS software, the `TS` command is entered on the command line of its installation directory. Using the **Open Project** menu command, the installed example (the `BEISP1` project) can be opened. The masks contained in this sample project can be edited (refer to the description of the TS software appearing in Chapter 8 of this manual, "TS Programming System").

11 Appendix

11.1 Examples of Step Modules

11.1.1 Handling the -STOEM Fault Marker

Symbol	CL200	CL400/CL500
-STOEM	M191.2	M255.2

The -STOEM fault marker makes it possible to provide fault indications independent of the monitoring time. This may comprise the detection of an exceeded temperature regulation threshold value, or simply an excess RPM.

NOTE!

The fault marker is influenced only by the user.

In the fault-free system condition, the -STOEM fault marker is logical 1_{bin}. It is reset in the event that a fault must be indicated.

Example:

```

: Step conditions
: Step 1
  -S1

; Conditions for Automatic and/or Inching mode

:Fault marker programming
CPLA W      -GRENZW,A ;Threshold value exceeded ?
A   B      SM31.0    ;arithmetical A > threshold
R   B      -STOEM    ;Diagnostics are triggered

; Links for Automatic and Inching Mode
  -AUTO
A   B      I0.6
=   B      -BEFA
A   B      I0.7
=   B      -WSB      ; Compulsory requirement
EM                               ; for end of step.

```

Further cascade processing depends upon d7.7 of the associated cascade data module:

- D7.7 = 0_{bin} Subsequent to correction of the fault, or when WSB step-on condition is met, the cascade will start automatically.

OR

- D7.7 = 1_{bin} The cascade starts only subsequent to acknowledgement via **D6.6**.

11.1.2 Using Wait Time

Wait time Stop

Symbol	CL200	CL400/CL500
-WZT_HLT	M191.5	M255.5

Using the -WZT_HLT wait time halt marker, and dependent upon conditions, the wait time can be stopped in each step.

Example:

```

: Step conditions
: Step 2
  -S2

; Influence wait time countdown via -WZT_HLT marker:
;      0_bin = Wait time counting
;      1_bin = Wait time is stopped

A   B           -LOG1      ;Stop wait time always
=   B           -WZT HLT   ;when step is active

; Links for Automatic and Inching Mode
  -AUTO
A   B           I1.6
=   B           -BEFA
A   B           I1.7
=   B           -WSB      ; Compulsory requirement
EM                                ; for end of step.

```

Querying wait time

Symbol	CL200	CL400/CL500
-WZT	M191.6	M255.6

The -WZT wait time marker indicates the wait time status.

Example:

```

: Step conditions
: Step 3
  -S3

; Querying wait time status via -WZT:
;      0_bin = Wait time counting
;      1_bin = Wait time is stopped

; Links for Automatic and Inching Mode
  -AUTO
A   B           I1.6
=   B           -BEFA
A   B           -WZT      ; Step-on only if wait time
=   B           -WSB      ; interval has expired.
EM                                ; Compulsory requirement
                                   ; for end of step.

```

11.1.3 Monitoring Time Stop

Symbol	CL200	CL400/CL500
-UEKONTR	M191.7	M255.7

Using the -UEKONTR monitoring time marker, and dependent upon conditions, the monitoring time can be stopped in each step.

Example:

```

; Step conditions
; Step 4
  -S4

; Influence monitoring time via -UEKONTR marker:
;      0 bin = Monitoring time counting
;      1 bin = Monitoring time is stopped

A      B          -LOG1      ;Stop monitoring time
=      B          -UEKONTR   ;when step is active.

; Links for Automatic and Inching Mode
  -AUTO
A      B          I1.2
=      B          -BEFA
A      B          I1.3
=      B          -WSB      ; Compulsory requirement
EM                                     ; for end of step.

```

11.1.4 Using -VERZW Branching Marker

Symbol	CL200	CL400/CL500
-VERZW	M188	M242

Using the -VERZW branching marker, step numbers defining the subsequent program progress are transferred to the cascade data module. This facilitates the implementation of simple OR links.

Example:




Fig. 11-1 OR Link

```
-Schritt3           ; Enter point of step 3
```

; OR decision

```
; 1st Alternative branch
```

```
A      -BED1/1      ; Decision criterion 1 for step 4
```

```
:
```

```
A      -BED1/n      ; Decision criterion n for step 4
```

```
= B    -SCHRITT4    ; Auxiliary marker for step 4 criteria (no scratch marker)
```

```
; 2nd Alternative branch
```

```
A      -BED2/1      ; Decision criterion 1 for step 6
```

```
:
```

```
A      -BED2/n      ; Decision criterion n for step 6
```

```
= B    -SCHRITT6    ; Auxiliary marker step 6 criteria (no scratch marker)
```

```
; 3rd Alternative branch
```

```
A      -BED3/1      ; Decision criterion 1 for step 7
```

```
:
```

```
A      -BED3/n      ; Decision criterion n for step 7
```

```
= B    -SCHRITT7    ; Auxiliary marker step 7 criteria (no scratch marker)
```

```
:
```

```
; 4th Alternative branch
```

```
A      -BED4/1      ; Decision criterion 1 for step 8
```

```
:
```

```
A      -BED4/n      ; Decision criterion n for step 8
```

```
= B    -SCHRITT8    ; Auxiliary marker step 8 criteria (no scratch marker)
```

; OR branch

A	-SCHRITT4	; Group criterion for step 4
O	-SCHRITT6	; Group criterion for step 6
O	-SCHRITT7	; Group criterion for step 7
O	-SCHRITT8	; Group criterion for step 8
=	-WSB	; Step is completed, continue with -VERZW branching

; Transferring step number for further processing

A	-LOG1	; In each step, use log. 1 to
RC	-VERZW	; set decision counter to definite 0.
A	-SCHRITT4	; Group criterion for step 4.
L	K4,A	; Load constant with step number,
SC	A,-VERZW	; and transfer to decision counter.
A	-SCHRITT6	; Group criterion for step
L	K6,A	; Load constant with step number,
SC	A,-VERZW	; and transfer to decision counter.
:		
A	-SCHRITT7	; Group criterion for step 7
L	K7,A	; Load constant with step number,
SC	A,-VERZW	; and transfer to decision counter.
:		
A	-SCHRITT8	; Group criterion for step 8
L	K8,A	; Load constant with step number,
SC	A,-VERZW	; and transfer to decision counter.
L	-VERZW,A	; Load constant with step number,
T	A,-VERZW	; and transfer to branching marker.
EM		

11.2 Characteristic Data of Standard Modules

11.2.1 KETTE200 Cascade Management Module

Processing times	Cascade Mgmt.	1.8 ms + step processing time
	Diagnostics	50 μ s per instruction
Number:	Cascades	max. 32
	Steps	max. 128 /Cascade
	Step-on conditions	max. 32 /Step
Monitoring time:	minimum	100 ms
	maximum	1 h 49 min
	Resolution	100 ms
Wait time:	minimum	100 ms
	maximum	1 h 49 min
	Resolution	100 ms

11.2.2 KETTE Function Module

Processing times:	Step with 16 instructions; WSB = 0 _{bin} Automatic mode;	0.32 ms
	Step with 16 instructions; WSB = 1 _{bin} Automatic mode; step-on in same cycle (D7.4 = 0 _{bin})	0.47 ms
	Step with 16 instructions; WSB = 1 _{bin} Automatic mode; no step-on in same cycle (D7.4 = 1 _{bin});	0.36 ms
Number:	Cascades	max. 64
	Steps	max. 128 /Cascade
	Step-on conditions	max. 64 /Step
Monitoring time:	minimum	100 ms
	maximum	1 h 49 min
	Resolution	100 ms
Wait time:	minimum	100 ms
	maximum	1 h 49 min
	Resolution	100 ms

11.2.3 DIAG500E Diagnostics Module

Processing times, without diagnostics module:	1 cascade, no fault, no manual diagnostics.	0.5 ms	
	30 cascades, no fault, no manual diagnostics.	1.4 ms	
	30 cascades, no fault, manual diagnostics of 64 conditions.	2.1 ms	
	30 cascades, no fault, manual diagnostics of 64 conditions.	5.0 ms	
Number:	Cascades	max. 64	
	Steps	max. 128	/Cascade
	Step-on conditions	max. 64	/Step

11.3 Fault Messages

Code	Subcode _{dec}	Subcode _{hex}	Fault	Fault description
0	0	0	NO ERROR	Fault-free processing.
1	1	1	E SLAVE NOT READY	Level 1 and level 2 fault.
1	2	2	E PROTOKOL	Packet sequence.
1	3	3	E FRAME	Protocol frame fault.
1	4	4	E TIMEOUT	Timeout fault.
1	5	5	E CRC BCC	CRC fault.
1	6	6	E PARITY	Parity fault.
1	7	7	E SEND ABORT	Transmission abort.
1	8	8	R REC ABORT	Reception abort.
1	9	9	E BUF SIZE	Cyclical buffer too small.
1	10	A	E NO DEFINE	No cyclical data defined.
1	12	C	E DEFINE	Cyclical data already defined.
1	15	F	E NO PROTOKOL	Selected protocol is not supported.
1	16	10	E OVERRUN	Reception overflow.
1	40	28	E SYS ADDRESS	Illegal system variable.
1	50	32	E QUITTUNG START	No connection established.
1	51	33	E QUITTUNG OPEN	Invalid connection setup acknowledgement.
1	52	34	E QUITTUNG DATA	Wrong acknowledgement on transmitted information block.
1	53	35	E NO RESPONSE WRONG CHAR	No response telegram.
1	54	36	E TIMEOUT NO RE- SPONSE	Timeout - No response telegram.
1	55	37	E TIMEOUT BLOCKZEIT	Timeout - Block time exceeded.
1	56	38	E TIMEOUT QUIT RE- SPONSE	Timeout - No acknowledgement.
1	57	39	E ABRUCH SPS	End Of Text marker (EOT) - PLC abort.
2	58	3A	E RECEIVE COUNT	Wrong data size received. Check and verify whether, in the mask in which the fault occurs, a variable with odd number of bytes is being read from a word or double-word address.

Fig. 11-2 Fault Messages

Fault messages (cont'd.)

Code	Subcode _{dec}	Subcode _{hex}	Fault description
3	1	1	Addressed module is not available.
3	16	10	Module does not respond.
3	35	23	Access to this address field is prohibited.
3	36	24	Access to this address field is protected by the user.
3	37	25	Timer may not be written to.
3	38	26	Module number too high.
3	39	27	Module not available.
3	40	28	Module too small.
4	32	20	Addressed data type (command code) unknown in PST.
4	33	21	Protocol ID is unknown to the peripheral station (PST).
4	35	23	Addressed coordination marker unknown in PST.
4	37	25	Parameter ID in message does not match specified parameters.
4	38	26	Difference between block length and actual data volume.
4	40	28	Unknown message type.
4	41	29	Unknown command type.
4	58	3A	Start address does not match operand type (word on odd address).
4	59	3B	Start address is outside of specified address range.
4	60	3C	Invalid parameter for specified instruction.
4	61	3D	Invalid operand type.
4	64	40	Peripheral station has not yet received identification message.
4	99	63	Specified data size is larger than addressed data range.
4	210	D2	Coordination marker is disabled.

Fig. 11-3 Fault Messages

11.3.1 BUEP19E Fault Messages – CL200

Fault code _{hex}	Fault	Fault description
02	Memory access problem	Faults occurred during access to the specified memory range, or access temporarily not possible.
03	Wrong memory type	The specified access mode is not possible for the addressed memory range (e.g. EPROM write-access), or no physical memory capacity is available at the stated address range.
05	Internal communication fault	During processing of the command, a fault has occurred which may possibly be remedied by repeating the command.
20	Command code unknown	The specified command code is not known on the PST.
21	Protocol ID unknown	The protocol ID specified in the message is unknown on the PST.
23	Invalid coordination marker	Specified coordination marker is not defined on the PST.
25	Wrong parameter ID	The parameter ID specified in the request message does not match the parameters specified for this command.
26	Block length error	The block length specified in the command does not correspond to the actual data size.
28	Unknown message type	The specified message type does not match the message types specified in the BUEP19E specification.
29	Unknown command type	The specified command type does not match the command types ("E", "A") specified in the BUEP19E specification.
3A	Wrong alignment	Then specified address is not aligned to the limit required for this operand type. This fault may occur, for example, if an odd-numbered word address or double-word address is specified that cannot be divided by 4.
3B	Invalid address range	The address range specified in the command is outside of the address range specified for this command.
3C	Invalid parameter	A parameter specified in the command has a value that is not specified for this command.
3D	Invalid operand type	The operand type specified in the command is not specified for the BUEP19E protocol, or the command is invalid.
40	Identification not yet completed	The PST has not yet received an identification command. Without the processing having been completed, the PST refuses the processing of other commands.
63	Buffer overflow	The data size specified in the command exceeds the size of the memory location that is available on the PST.
82	Module-specific fault	This fault message indicates that the error byte 2 of the response message contains a module-specific fault.
D2	Coordination marker disabled	The command could not be executed because the coordination marker is disabled.

Fig. 11-4 BUEP19E Fault Messages — CL200

11.3.2 BUEP19E Fault Messages – CL350 / CL400 / CL500

Fault code _{hex}	Fault	Fault description
01	Module not available	The block address specified in the block command addresses a system bus station in which no module is available, or addresses a module that is unable to effect command processing (slave without command reception buffer).
10	Module not addressable	The SK500 has transferred to this module a command that is addressed to another module. The SK500, however, has not received an execution acknowledgement, and reports this as a fault to the AST. An attempt may be made to eliminate this fault by repeating the command.
20	STOP error	The module is in STOP status. The specified command cannot be executed while the module is in STOP status.
21	RUN error	The module is in RUN status. The specified command cannot be executed while the module is in RUN status.
22	OperMode change not possible	The module was unable to enter into the operation mode specified in the command.
23	Field access prohibited	The defined access mode (read, write, bit access) is not permitted for the specified field. Example: Write-access to a field for which only read-access is permitted.
24	Field protection enabled	The access to the field could not be executed because the field has been protected by the user.
25	Timer disabled	This fault message is used upon write-access to the Timer actual value/Status field. The actual value of a timer may be changed only while the time has not yet expired. It is not possible to restart a timer because the time type cannot be definitely reconstructed.
26	Module number too high	The specified module number is larger than the maximum module number permitted for this module type.
27	Module not available	The module with the specified number is not listed in the reference list.
28	Data module too small	The address range specified in the command exceeds the limits of the data module.

Fig. 11-5 BUEP19E Fault Messages — CL400/CL500

BUEP19E Fault Messages – CL400/CL500 (cont'd.)

29	Monitor disabled	Two peripheral devices are simultaneously attempting to use the monitor of a ZS via the module interface and the interface of the SK.
2A	Reference list disabled	Two peripheral devices are simultaneously attempting to access the reference list of a ZS via the module interface and the interface of the SK.
2B	RTC error	Error upon reading or writing the system clock of the SK500.
2C	Reference list entry cannot be changed	On the ZS500 it is not permitted to move a data module into another memory range. The reason is that in the case of system command the absolute address is transferred to the partner module. If an attempt is made to modify the reference list entry of an existing data module, this fault message will result.

Fig. 11-6 BUEP19E Fault Messages — CL400/CL500 (cont'd.)

11.4 BT-MADAP Order Numbers

BT-MADAP

Software package, including the individual components listed below.

1070 077 814

BTSMADAP, BTS_ZV;
operation via BT5/BT20
for CL200, CL350 /
CL400 and CL500

1070 077 815

KETTE200 for CL200

1070 077 186

KETTE, DIAG500E for
CL350 / CL400 and
CL500

1070 077 508

