

Rexroth Rho 4.1/BT155, BT155T Rexroth Rho 4.1/BT205 Connectivity manual

1070072363
Edition 04

Project planning



Title Rexroth Rho 4.1/BT155 BT155T
Rexroth Rho 4.1/BT205
Connectivity manual

Type of Documentation Project planning

Document Typecode DOK-RHO*4*-RHO*BT*ANBE-PR04-EN-P

Purpose of Documentation The present manual informs about:

- specifications, configuration and
- operation of the rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 robot control

Record of Revisions

Description	Release Date	Notes
DOK-RHO*4*-RHO*BT*ANBE-PR03-EN-P	10.2003	Valid from VO07
DOK-RHO*4*-RHO*BT*ANBE-PR04-EN-P	01.2005	Valid from VO08

Copyright © Bosch Rexroth AG, 1998 – 2005

Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34–1).

Validity The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

Published by Bosch Rexroth AG
Postfach 11 62
D-64701 Erbach
Berliner Straße 25
D-64711 Erbach
Tel.: +49 (0) 60 62/78-0
Fax: +49 (0) 60 62/78-4 28
Abt.: BRC/ESH (KW)

Overview of all manuals

Overview of all manuals

Manual	Contents
Connection conditions Rho 4.0	2 System overview
	3 Installation
	4 Electrical connection
	5 Interfaces
	6 LED display
	7 Maintenance and replacement
	8 Order numbers
System description Rho 4.0	2 System overview
	3 Structure of the rho4.0
	4 PCLrho4.0
	5 CAN-Bus peripheral unit
	6 SERCOS interface
	7 Software
	8 File management
Connection conditions Rho4.1, Rho 4.1/IPC300	2 System overview
	3 Security functions
	4 Installation
	5 Electrical connection
	6 Interfaces
	7 LED display
	8 Maintenance and replacement
	9 Software
	10 Order numbers
Connection conditions Rho 4.1/BT155, Rho 4.1/BT155T, Rho 4.1/BT205	2 System overview
	3 Security functions
	4 Installation
	5 Electrical Connections
	6 Interfaces
	7 Display and Operating Controls
	8 Maintenance and Replacemant
	9 Software
	10 Order numbers
System description Rho 4.1	2 Structure of the rho4.1
	3 PCL
	4 CAN-Bus peripheral unit
	5 SERCOS interface

Overview of all manuals

Manual	Contents
	6 Software
	7 File management
	8 Scope of the rho4.1 Software

Manual	Contents
Control functions	2 Survey of special functions
	3 Accurate position switching
	4 Setting the machine position
	5 Calling operating system functions
	6 Parameterization of the belt characteristic
	7 Selecting a point-file
	8 Mirroring
	9 Belt type
	10 System date and time
	11 System counter
	12 WC main range
	13 Setting the belt counter
	14 Recording of reference path
	15 Flying measurement (rho4.1 only)
	16 MOVE_FILE
	17 Setting the block preparation
	18 Exception-Handling
	19 Belt counter current value
	20 Automatic velocity adjustment for PTP movements
	21 Belt-synchronous working area belt kind 4
	22 Current belt speed
	23 Changing the belt simulation speed
	24 General functions
	25 Process-oriented functions
	26 BAPS3 keywords
	Machine parameters
3 Application of the machine parameters	
4 General system parameters	
5 Speeds	
6 Positions	
7 Kinematic parameters	

Overview of all manuals

Manual	Contents
	8 Measuring system parameters
	9 Belt parameters
	10 Drive parameters Servodyn-GC
	11 Drive parameter Servodyn-D
	12 Table of parameters
Manual	Contents
BAPS3 Programming manual	2 Program structure
	3 Constants
	4 Variables
	5 Program control
	6 Value assignments and combinations
	7 Functions
	8 Movement statement
	9 Write/read functions
	10 BAPS3 keywords
	BAPS3 Short description
3 Constants and variables	
4 Program structure	
5 Value assignments and combinations	
6 Standard functions	
7 Movements and speeds	
8 Belt synchronous	
9 Workspace limitation	
10 Write/read functions	
11 Special functions	
12 Library functions	
13 Fix files	
14 BAPS3 keywords	
Signal descriptions	
	3 Signal description of PCL inputs
	4 Signal description of PCL outputs
Status messages and warnings	2 rho4 status messages
	3 Warnings
	4 CANopen error codes
ROPS4/Online	2 General information
	3 Activation and functions of Online
	4 The function key box

Overview of all manuals

Manual	Contents
	5 Function key assignment
	6 The marker box
	7 File ROPS4WIN.ini
	8 Selection of a file
	9 TCP/IP settings for ROPS4
Manual	Contents
DLL library	2 Library functions
	3 Calling library functions in BAPS
	4 Block structure of the rho4.1
	5 Library server
	6 Application development
	7 rho4 library functions
	8 Variable access per DLL
	PHG2000
3 PHG2000 system variables	
4 Selection of PHG functions	
5 Info function of the PHG	
6 Controlling the PHG2000 output	
7 Define/Teach	
8 SRCAN functions	
9 File and User Memory Functions	
10 File list	
11 Process info	
12 Restoring the PGH display	
13 Variable assignment of PHG keys	
14 Select point file and point name	
15 BDT editor	
Connection conditions Rho 4.1/IPC 40.2	
	3 Security Functions
	4 Installation
	5 Eelectrical Connections
	6 Interface Ports & Connectors
	7 Display- and Operating Components
	8 Maintenance and Replacement
	9 Software
	10 Ordering Informations

Overview of all manuals

Manual	Contents
DDE-Server	2 Introduction
	3 Hardware and Software
	4 Operation
	5 Items of Server 4
	6 Scope of function

Overview of all manuals

Notes:

Contents

Contents

	Page
1	Safety Instructions 1–1
1.1	Intended use 1–1
1.2	Qualified personnel 1–2
1.3	Safety markings on products 1–3
1.4	Safety instructions in this manual 1–4
1.5	Safety instructions for the described product 1–5
1.6	Documentation, software release and trademarks 1–7
2	System Overview 2–1
2.1	Variants 2–3
2.2	Technical data 2–5
2.3	Expansion slots 2–6
2.4	Rechargeable battery pack 2–6
2.5	LS120/CD-ROM drive unit 2–6
2.6	Operating conditions 2–7
2.7	Standards compatibility 2–9
3	Security Functions 3–1
3.1	Temperature monitoring function 3–1
3.2	Uninterruptible power supply (UPS) 3–2
3.3	UPS program 3–5
3.3.1	Functionality 3–5
3.3.2	Operating and configuring 3–6
4	Installation 4–1
4.1	Installed positions and clearances 4–2
4.1.1	Dimensioned drawings 4–3
4.1.2	Installation cutout 4–6
5	Electrical Connections 5–1
5.1	Protective Earth conductor (PE) & screening information 5–2
5.2	Interference suppression information 5–3
5.3	Power supply 5–6
5.3.1	24 VDC-power supply 5–6
5.3.2	230/115 VAC power supply 5–9
6	Interfaces 6–1
6.1	Overview 6–1
6.2	Serial PC ports COM1...COM4, USB 6–5
6.2.1	Pin assignment 6–5
6.2.2	COM1...COM4 settings 6–10
6.3	LPT1 parallel port 6–11

Contents

6.4	Ethernet-interface	6-12
6.4.1	External monitor	6-13
6.5	Keyboard ports	6-15
6.6	Mouse port	6-17
6.7	DP slave interface	6-18
6.8	24 Vout connector	6-19
6.9	LS120/CD-ROM drive connector	6-20
6.10	rho4.1connection	6-21
6.11	Interfaces on the PCI_rho card	6-27
6.12	SERCOS interface	6-28
6.13	AF_PCI rho interface	6-28
6.14	Expansion Card Interfaces	6-30
6.14.1	PCI_BM-xxx Card	6-30
6.14.2	PCI_CAN Card	6-32
7	Displays and Operating Controls	7-1
7.1	Display	7-1
7.1.1	Backlight switch-off	7-2
7.1.2	Touch screen	7-3
7.2	LED displays	7-4
7.3	Keyboard	7-5
7.3.1	Blocks of function keys	7-5
7.3.2	ASCII, number and cursor control blocks	7-6
7.3.3	Special key functions	7-7
7.4	Front panel legends	7-9
7.5	Keyboard controller	7-11
7.5.1	Scanning front panel keyboard	7-11
7.5.2	Exceptions when keys are pressed simultaneously	7-13
7.5.3	Software download for keyboard controller	7-13
8	Maintenance and Replacement	8-1
8.1	Hard disk	8-2
8.2	LS120/CD-ROM drive unit	8-6
8.2.1	Swap entire unit	8-6
8.2.2	Replacing drives separately	8-10
8.3	Backlight and display panel	8-14
8.4	Rechargeable Battery Pack	8-16
8.5	Expansion cards	8-20
8.5.1	Installing an expansion card	8-20
9	Software	9-1
9.1	BIOS software	9-1
9.2	Operating system and utilities	9-1
9.3	Application software	9-2
9.3.1	PCI field bus cards	9-2
10	Order numbers	10-1
10.1	rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205	10-1
10.2	Accessories	10-1
10.3	Spare parts	10-2

Contents

A	Appendix	A-1
A.1	Abbreviations	A-1
A.2	Index	A-2

Contents

Notes:

1 Safety Instructions

Please read this manual before you startup the rho4.
Store this manual in a place to which all users have access at any time.

1.1 Intended use


This instruction manual presents a comprehensive set of instructions and information required for the standard operation of the described products. The described products are used for the purpose of operating with a robot control rho4.

The products described

- have been developed, manufactured, tested and documented in compliance with the safety standards. These products normally pose no danger to persons or property if they are used in accordance with the handling stipulations and safety notes prescribed for their configuration, mounting, and proper operation.
- comply with the requirements of
 - the EMC Directives (89/336/EEC, 93/68/EEC and 93/44/EEC)
 - the Low-Voltage Directive (73/23/EEC)
 - the harmonized standards EN 50081-2 and EN 50082-2
- are designed for operation in industrial environments, i.e.
 - no direct connection to public low-voltage power supply,
 - connection to the medium- or high-voltage system via a transformer.

The following applies for application within a personal residence, in business areas, on retail premises or in a small-industry setting:

- Installation in a control cabinet or housing with high shield attenuation.
- Cables that exit the screened area must be provided with filtering or screening measures.
- The user will be required to obtain a single operating license issued by the appropriate national authority or approval body. In Germany, this is the Federal Institute for Posts and Telecommunications, and/or its local branch offices.

 **This is a Class A device. In a residential area, this device may cause radio interference. In such case, the user may be required to introduce suitable countermeasures, and to bear the cost of the same.**

The faultless, safe functioning of the product requires proper transport, storage, erection and installation as well as careful operation.

Safety Instructions

1.2 Qualified personnel

The requirements as to qualified personnel depend on the qualification profiles described by ZVEI (central association of the electrical industry) and VDMA (association of German machine and plant builders) in:

Weiterbildung in der Automatisierungstechnik

edited by: ZVEI and VDMA

MaschinenbauVerlag

Postfach 71 08 64

D-60498 Frankfurt.

The present manual is designed for RC technicians. They need special knowledge on handling and programming robots.

Interventions in the hardware and software of our products, unless described otherwise in this manual, are reserved to specialized Rexroth personnel.

Tampering with the hardware or software, ignoring warning signs attached to the components, or non-compliance with the warning notes given in this manual may result in serious bodily injury or damage to property.

Only electrotechnicians as recognized under IEC 60947-1 (modified) who are familiar with the contents of this manual may install and service the products described.

Such personnel are

- those who, being well trained and experienced in their field and familiar with the relevant norms, are able to analyze the jobs being carried out and recognize any hazards which may have arisen.
- those who have acquired the same amount of expert knowledge through years of experience that would normally be acquired through formal technical training.

With regard to the foregoing, please note our comprehensive range of training courses. Please visit our website at

<http://www.boschrexroth.com>

for the latest information concerning training courses, teachware and training systems. Personal information is available from our Didactic Center Erbach,

Telephone: (+49) (0) 60 62 78-600.

Safety Instructions

1.3 Safety markings on products

Warning of dangerous electrical voltage!



Warning of danger caused by batteries!



Electrostatically sensitive components!



Warning of hazardous light emissions
(optical fiber cable emissions)!



Disconnect mains power before opening!



Lug for connecting PE conductor only!



Functional earthing or low-noise earth only!



Connection of shield conductor only

Safety Instructions

1.4 Safety instructions in this manual



DANGEROUS ELECTRICAL VOLTAGE

This symbol is used to warn of a **dangerous electrical voltage**. The failure to observe the instructions in this manual in whole or in part may result in **personal injury**.



DANGER

This symbol is used wherever insufficient or lacking compliance with instructions may result in **personal injury**.



CAUTION

This symbol is used wherever insufficient or lacking compliance with instructions may result in **damage to equipment or data files**.

☞ This symbol is used to draw the user's attention to special circumstances.

★ This symbol is used if user activities are required.

Safety Instructions

1.5 Safety instructions for the described product**DANGER**

Danger of life through inadequate EMERGENCY-STOP devices! EMERGENCY-STOP devices must be active and within reach in all system modes. Releasing an EMERGENCY-STOP device must not result in an uncontrolled restart of the system! First check the EMERGENCY-STOP circuit, then switch the system on!

**DANGER**

**Danger for persons and equipment!
Test every new program before starting up a system!**

**DANGER**

**Retrofits or modifications may adversely affect the safety of the products described!
The consequences may include severe injury, damage to equipment, or environmental hazards. Possible retrofits or modifications to the system using third-party equipment therefore have to be approved by Rexroth.**

**DANGER**

Do not look directly into the LEDs in the optical fiber connection. Due to their high output, this may result in eye injuries. When the inverter is switched on, do not look into the LED or the open end of a short connected lead.

**DANGEROUS ELECTRICAL VOLTAGE**

Unless described otherwise, maintenance works must be performed on inactive systems! The system must be protected against unauthorized or accidental reclosing.

Measuring or test activities on the live system are reserved to qualified electrical personnel!

Safety Instructions

**CAUTION****Danger to the module!**

Do not insert or remove the module while the controller is switched ON! This may destroy the module. Prior to inserting or removing the module, switch OFF or remove the power supply module of the controller, external power supply and signal voltage!

**CAUTION****use only spare parts approved by Rexroth!****CAUTION****Danger to the module!**

All ESD protection measures must be observed when using the module! Prevent electrostatic discharges!

The following protective measures must be observed for modules and components sensitive to electrostatic discharge (ESD)!

- Personnel responsible for storage, transport, and handling must have training in ESD protection.
- ESD-sensitive components must be stored and transported in the prescribed protective packaging.
- ESD-sensitive components may only be handled at special ESD-workplaces.
- Personnel, working surfaces, as well as all equipment and tools which may come into contact with ESD-sensitive components must have the same potential (e.g. by grounding).
- Wear an approved grounding bracelet. The grounding bracelet must be connected with the working surface through a cable with an integrated 1 M Ω resistor.
- ESD-sensitive components may by no means come into contact with chargeable objects, including most plastic materials.
- When ESD-sensitive components are installed in or removed from equipment, the equipment must be de-energized.

Safety Instructions

1.6 Documentation, software release and trademarks

Documentation

The present manual provides information about specifications, configuration and operation of the rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 robot control.

Overview of available documentation	Part no.	
	German	English
Rho 4.0 Connectivity Manual	1070 072 364	1070 072 365
Rho 4.0 System description	1070 072 366	1070 072 367
Rho 4.1/IPC 40.2 Connectivity Manual	R911308219	R911308220
Rho 4.1/BT155, Rho 4.1/BT155T, Rho 4.1/BT205 Connectivity manual	1070 072 362	1070 072 363
Rho 4.1, Rho 4.1/IPC300 Connectivity manual	1070 072 360	1070 072361
Control panels BF2xxT/BF3xxT, connection	1070 073 814	1070 073 824
Rho 4.1 System description	1070 072 434	1070 072 185
ROPS4/Online	1070 072 423	1070 072 180
BAPS plus	1070 072 422	1070 072 187
BAPS3 Short description	1070 072 412	1070 072 177
BAPS3 Programming manual	1070 072 413	1070 072 178
Control functions	1070 072 420	1070 072 179
Signal descriptions	1070 072 415	1070 072 182
Status messages and warnings	1070 072 417	1070 072 181
Machine parameters	1070 072 414	1070 072 175
PHG2000	1070 072 421	1070 072 183
DDE-Server 4	1070 072 433	1070 072 184
DLL-Library	1070 072 418	1070 072 176
Rho 4 available documentation on CD ROM	1070 086 145	1070 086 145

 **In this manual the floppy disk drive always uses drive letter A:, and the hard disk drive always uses drive letter C:.**

Special keys or key combinations are shown enclosed in pointed brackets:

- Named keys: e.g., <Enter>, <PgUp>,
- Key combinations (pressed simultaneously): e.g., <Ctrl> + <PgUp>

Safety Instructions

Release

 **This manual refers to the following versions:**

Hardware version: rho4

Software release: ROPS4

Trademarks

All trademarks of software installed on Rexroth products upon delivery are the property of the respective manufacturer.

Upon delivery, all installed software is copyright-protected. The software may only be reproduced with the approval of Rexroth or in accordance with the license agreement of the respective manufacturer.

MS-DOS® and Windows™ are registered trademarks of Microsoft Corporation.

PROFIBUS® is a registered trademark of the PROFIBUS Nutzerorganisation e.V. (user organization).

MOBY® is a registered trademark of Siemens AG.

AS-I® is a registered trademark of AS-International Association.

SERCOS interface™ is a registered trademark of Interessengemeinschaft SERCOS interface e.V. (Joint VDW/ZVEI Working Committee).

INTERBUS-S® is a registered trade mark of Phoenix Contact.

DeviceNet® is a registered trade mark (TM) of ODVA (Open DeviceNet Vendor Association, Inc.).

System Overview

2 System Overview

The robot controllers rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 consist of:


- A powerful industrial PC, at rear of housing
- Flat-panel display, some with touch screen
- Operator panel with keyboard and LED status displays
- CD-ROM- and LS120-drives
- Additionally integrated UPS, temperature monitoring, safe operating system shutdown, 3 expansion slots for PCI- and ISA-cards.

The construction is very compact and easy to service. It is distinguished by **its high fault tolerance** (e.g. shock and vibration resistant mounted hard disk, uninterruptible power supply UPS) and **easy maintenance**.


The operating system used is Windows NT4.0 and associated Rexroth application software is installed (see section 9.3).

System Overview

Robot controller with control terminal BT155 or BT155T with 10.4" display



Robot controller with control terminal BT205 with 12.1" display



System Overview


2.1 Variants

Every one of the basic devices rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 may be equipped with one of the following real-time cards (PCI_rho expansion cards):

- **PCI_rho_CAN**
CAN-Bus for drive and I/O with incremental measuring system input
- **PCI_rho_CAN2**
CAN-Bus for drive and I/O without incremental measuring system input
- **PCI_rho_SERCOS**
SERCOS interface for drive, CAN for drive and I/O with incremental measuring system input
- **PCI_rho_SERCOS2**
SERCOS interface for drive, CAN for drive and I/O without incremental measuring system input

System Overview

Versions with different power supplies (examples)




☞ In the 230/115 VAC-version the 24 VDC-input (X10_1) has no function.

System Overview

2.2 Technical data

Feature	rho4.1/BT155T	rho4.1/BT155	rho4.1/BT205
Display (TFT): Size	10.4"	10.4"	12.1"
Touch screen Touch-sensitive screen for operations without keyboard and mouse	Yes	No	No
Intel Pentium processor or compatible CPU (socket 7) with Intel MMX™ technology	≥ 266 MHz, optional 400 MHz Pentium™ III		
RAM	64 MB or 128 MB (with 266 MHz processor) 128 MB or 256 MB (with 400 MHz processor)		
Hard disk	> 5 GB IDE (spring suspension with Autopark feature)		
CD-ROM drive	32times (minimum)		
LS120 drive	3.5"drive with the following diskette capacity: 120 MB, 1.44 MB or 720 KB		
Free expansion slots	2 PCI expansion slots, 1 PCI/ISA combi-expansion slot		
Power supply (alternative to)	230/115 VAC, 50/60 Hz 24 VDC		
UPS (uninterruptible power supply)	Via internal rechargeable battery pack		
Temperature monitoring	With warning function & safe shutdown		
5 LED's at the front 1 LED at the back	Display of essential operating statuses		
Standard interfaces	2 x serial, freely usable 1 x USB, 1x parallel PS/2 keyboard, PS/2 mouse, VGA Ethernet	3 x serial, freely usable 1 x USB, 1x parallel PS/2 keyboard, PS/2 mouse, VGA Ethernet	
Real-time interfaces	V24/20 mA, PHG connection, CAN-Bus, incremental transducer, measuring sensor		
Weight:	Approx. 9 kg		
Dimensions	Housing: 448 x 195 x 98 mm		
Operating system	Microsoft Windows NT4.0		

 **All specifications are subject to change as a result of technological developments. This also means that components providing higher than the specified performance (e.g. a faster processor) may be integrated in the devices without explicit reference in this documentation.**

2.3 Expansion slots

There are 3 slots available for expansion cards (a1 to A3):

- 2 PCI bus cards
- 1 PCI or ISABUS card (combination slot)

The A4 slot is taken by the PCI_rho insertion card.



CAUTION

Damage to PC or application software through unauthorized expansion cards.

Use only approved expansion cards, and have them installed by a specialist.

For more information on installing expansion cards, refer to section 8.5.

2.4 Rechargeable battery pack

The robot controllers rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 are equipped with an internal battery pack (2 in series connected 6 V batteries).

In case of a power failure, the rechargeable battery pack facilitates a controlled and safe shutdown of the PC operating system, as described in section 3.2 (**UPS Functions**). Loss of data held in PC RAM is thus prevented.

The rechargeable battery pack has a limited useful life and must be replaced if it cannot be charged up adequately any more. Refer also to section 8.4.

2.5 LS120/CD-ROM drive unit

All basic devices are equipped with a drive unit consisting of an LS120 drive and CD-ROM drive. The LS120 drive supports the following 3.5" diskette types:

- LS120 (120 MB)
- Double density (720 kB)
- High density 3.5 in. (1.44 MB)

Both drives are at the back of the housing. During installation please make sure that the drive bays remain accessible.

For the installation of the LS120/CD-ROM drive unit see section 8.2.

System Overview

2.6 Operating conditions

The PC basic devices are designed for continuous, 24 hour/day operation. The display backlight can be switched off. Unless stated otherwise in specific sections, these specifications apply:

Temperatures

Storage temperature:

- -20°C to $+60^{\circ}\text{C}$

Ambient temperature:

- $+5^{\circ}\text{C}$ to $+45^{\circ}\text{C}$

Ambient temperatures apply to installation conditions described in section 4.

Temporary temperature fluctuations of up to 3°C per minute are permitted.

**CAUTION****Excessive operating temperature!****Do not expose to direct sunlight or any other sources of heat radiation!**

Relative humidity

Climate class 3K3, as per EN 60529; condensation not permitted.

Atmospheric pressure

To DIN 60204, when operating at altitudes up to 2000 m above sea level.

Protection category ratings

Front panel: IP65, otherwise IP00

Control cabinets and installation compartments must conform to IP 54 rating (dust filters upstream of air intake and exhaust).

**CAUTION****Conditions hazardous to the product!****The ambient air must be free of electrically conductive pollutants (e.g. acids, alkalis, corrosives, salts, metallic vapours, etc.).**

System Overview

Vibration-resistant operation

Frequency range: 10 to 150 Hz
Amplitude: 0.075 mm at 10 to 57 Hz
Acceleration: 1 g at 57 to 150 Hz
to EN 60068-2-6

Impact resistance


15 g as per DIN IEC 68-2-27, no functional impediment.

System Overview

2.7 Standards compatibility

The robot controllers rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 conform to the following standards:

- EN 60,204-1 Electrical systems on machines
- EN 50,081-2 Basic specification for interference emission (industrial environment)
- EN 50,082-2 Basic technical standard, interference resistance (industrial environment)
- EN 60,742 Transformer for 24 V power supply, protective separation
- EN 60,950 Overvoltage category II
- EN 61,131 24 V output requirements
- EN 61 131-2 24 V power supply requirements
- EN 418 Machine safety, Emergency-STOP devices
- EN 60,529 Protection categories (incl. housings and installation compartments)
- EN 60 068-2-6 Vibration test
- EN 60 068-2-27 Impact test
- .IS.114 "X-ray Radiation" Directive, as per Official Federal Gazette

 **As shipped from the factory, robot controllers conform to the requirements of the CE mark of certification. However, the subsequent insertion of additional expansion cards will necessitate a supplementary CE certification.**

System Overview

Notes:

Security Functions

3 Security Functions

3.1 Temperature monitoring function

The ambient air temperature must not exceed +45°C (see section 2.6). To ensure operational reliability, a temperature monitoring function measures the internal housing temperature.

A temperature warning, occurring at internal housing temperatures **exceeding 50°C**, manifests itself as follows:

- via the flashing “Temp” LED on the front panel of the housing.
- via a message window displayed by the operating system.
This message must also be capable of interpretation by all application programs. The Rexroth application software meets this requirement.

This temperature warning can be disabled by the program **UPS_{NT} for Windows NT 4.0** (see section 3.3).

If temperatures in the housing **exceed 65°C**, the PC **will be shut down and switched off** via the UPS logic circuit (see section 3.2).



DANGER

Inadvertent machine movements.

Always ensure that temperatures remain within the non-critical range. In the case of application sensitive procedures, ensure that machine movements are terminated in a controlled fashion in the event that the temperature monitoring function disables the PC.

3.2 Uninterruptible power supply (UPS)

In the event of a power failure exceeding 800 ms in duration, or of an internal housing temperature in excess of 65°C (refer to section 3.1, above), the UPS logic integrated in the power supply is activated, effecting a safe operating system shutdown procedure assisted by the rechargeable battery pack.

Power interruptions of shorter durations are bridged by the battery pack. In the robot controllers rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 with Windows NT power supply interruptions of up to 5 sec are permissible before the UPS logic cuts in.

Please note:

- To allow the rechargeable battery pack to attain its full charge capacity, the device must remain powered up for a minimum of 5 hours subsequent to initial start-up. Sufficient UPS protection cannot be ensured during this charging period.
- Frequent On/Off cycling of power tends to cause rapid discharge of the battery pack. You should never cycle the power more often than 4 times in succession. The battery pack must again be fully recharged thereafter.
- The UPS logic function requires hard disk capacity for intermediate data storage. Ensure that the hard disk never fills up completely.



CAUTION


If there are no batteries in the unit, or if the batteries are defective or discharged, the PC will RESET without warning after a voltage dip in excess of 20 ms! A possible consequence may be a loss of data.

Observe UPS program messages indicating that the battery pack may be discharged. This test is run during each PC boot phase.

Power dropouts below 800 ms duration

Voltage drops below 800 ms duration are bridged by the battery pack, and do not trigger the UPS logic circuit.


Security Functions



Power dropouts between 800 ms and 60 s

A voltage drop exceeding 800 ms in duration causes the PC operating system to be shut down after a selectable interval (delay time).


- If the voltage supply returns within 5 sec (short break), then the UPS does not cut in (for appropriate settings).
- If the mains power is restored within the next 60 seconds, the UPS will interrupt the operating voltage for another 8 seconds (up to t_3), and then the operating system is restarted again.




Security Functions

Power dropout > 60 s (without short break)

After approx. 60 sec the UPS internally switches off the power supply.



 **Setting the delay time is in the additional software “UPS_{NT}” for rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 (from page 3–6).**

Security Functions

3.3 UPS program

3.3.1 Functionality

The “UPS_{NT}” uninterruptible power supply program controls and monitors the integrated uninterruptible power supply (UPS). The program also checks the function of the rechargeable battery and controls the system temperature monitoring function.

In the rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 with Pentium III, 400 MHz the operation of the fans and internal operating voltages are also monitored.

Communications between program and UPS are handled via the COM4 serial port.

In the case of a power supply failure it is the task of the UPS program to:

- To send a message to all active applications so that they can be shut-down by appropriate routines.
- To shut down the operating system after the delay time has elapsed. Once the UPS power monitoring function has been triggered, aborting the system shutdown routine is no longer possible.

Closing all active applications prevents data loss in the event of a sudden voltage interruption.

In the event that the mains power has not been restored after a maximum of 60 seconds, the UPS will switch off the power supply in the PC (refer to shutdown conditions in section 3.2).

**CAUTION****Loss of data through manual restart!**

Note that the UPS switches off the device in any case. For this reason, once the operating system has been shut down, the “Restart” dialog button must not be pressed.

In the case of voltage interruptions below 60 seconds, the operating system is restarted automatically.

The operator cannot access the UPS_{NT} program during normal operation. Operation and settings can be effected only if the user possesses special access rights and only after the operating system has been restarted.

 **Changes to the UPS_{NT} parameters must not be carried out without consulting Rexroth first.**


Security Functions

3.3.2 Operating and configuring

Configuration UPS_{NT}


- ☞ **UPS_{NT} is properly configured when the rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 are shipped from the factory and must not be changed without consulting Rexroth first.**

For the purposes of service and control select "UPS NT Control" in the control panel:



- ☞ **The UPS_{NT} program always runs as a Windows NT service. Changing user logins have no influence on this characteristic. A user without Administrator authorization is neither able to terminate the program nor stop the monitoring function.**

Security Functions



- ☞ **To allow new parameter values to take effect subsequent to their modification, the UPS is automatically stopped and restarted. No monitoring function is enabled during this interval (5 to 10 sec).**

COM Port

The UPS program is always connected to the UPS via the COM4 serial port.

Advanced Controls**Shutdown Delay Time**

A time of 45 seconds must be entered here. During this time period the rho4.1 application is closed and user data are saved. Upon expiry of the Delay Time, all application programs will be terminated without prior security query!

Security Functions

In the period between the end of the Delay Time and the expiry of the 60 seconds after the shutdown signal the operating system is shut down (close Windows system files and back them up). If the interval is too short, the shutdown process will be interrupted because the UPS disrupts the mains power. This may cause loss of data in some circumstances.

**CAUTION**


Upon expiry of the Delay Time, the operating system is shut down without prior security query. Unsecured data belonging to open applications will be lost.

Enable Startup Battery Test

When this check box is checked, the system performs a test of the battery pack during each restart. Upon detection of a fault the red LED "UPS" flashes and an error message is generated and distributed throughout the system. The UPS program continues to operate.

The battery test is automatically repeated after 12 hours:


- If no error is found, there is an automatic repetition of the test every 12 hours.
- If a fault is found:
 - an error dialog is created
 - a message is distributed throughout the system
 - the output E80.2 UPS_ACCU_RCA is set to "1"
 - the UPS program terminates and the red LED "UPS" begins to flash.



Security Functions

Enable Temp Control


When this checkbox is checked, the ambient temperature is monitored on a continuous basis. Excessive temperatures will produce the following warning message:




The power monitoring function is retained even after a temperature warning. Upon detection of a fault the red LED "Temp" flashes and the rho4.1 sets the output E80.1 UPS_TEMP_RCA to "1".

Enable Fan Control

When this checkbox is checked the housing and CPU fans are monitored in the rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 with Pentium III, 400 MHz. In the event of a fault the red LED "Temp" flashes and a relevant message is displayed and distributed throughout the system.

**Enable Voltage Control**

When this checkbox is activated, internal supply voltages are monitored. In the event of a fault the green LED "Vout" goes out and a relevant message is displayed and distributed throughout the system.



Disable Auto Power Off



CAUTION

Loss of data!

Activation of this checkbox no longer makes a safe shutdown possible in the event of a power failure. The device switches off instantly!

This option disables both the UPS monitoring function and the power-off delay for the power supply:

- A voltage interruption will cause the PC to shut down immediately.
- After a normal shutdown, the wait interval of approx. 60 seconds prior to the shutdown of the power supply is omitted.


This function shortens the wait times for startups and software installations. During normal operations it must always be disabled!

No Powerdown on Shortbreak

When this checkbox has been activated, interruptions in the power supply of up to 5 seconds are permitted without affecting ongoing operations. Only in the case of power interruptions lasting in excess of 5 seconds will the UPS logic be started and the safe shutdown of the system initiated.

Command

This dialog box provides for the linking and activation of an executable program (*.exe; *.bat) which is to be started and executed after the initialization of the shutdown. This is helpful in situations where applications failing to respond to the system-wide messages must be backed up and terminated. To this end, appropriate housekeeping and termination programs can be entered and activated in this dialog. If there are several programs, or if the programs require transfer parameters, they must be combined and entered in a batch file.

 **The entry itself may not contain any invocation parameters, and the declared program itself must not initiate a shutdown!**

Default Settings

Selecting the "Default" button returns all settings to their **default values**.

These are:

- COM port: COM4
- Shutdown Delay Time: 45 sec
- Enable Startup Battery Test: enabled
- Enable Temp Control: enabled
- Enable Fan Control: enabled

Security Functions


- Enable Voltage Control: enabled
- Disable Auto Power Off: disabled
- No Powerdown on Shortbreak: enabled
- Execute Command File: disabled

Health Monitor

This dialog section indicates the current readings for internal voltages, battery voltage, system temperature and fan functions.

The **Battery Voltage** reading is updated only after a battery test. The battery test occurs automatically after a system start, and in 12-hour intervals thereafter; it can also be initiated by pressing the `Test Battery` button.

- The LED illuminates red when the voltage reading of the battery voltage measured under load is low.
- The LED illuminates green when the battery pack is fully functional.

 **Excessive repetitions of the battery test will discharge the battery pack. Never perform more than 5 battery tests within a 24-hour period.**

The following applies to **Fan Speed monitoring**:

- Red LED: Fan at standstill, or fan speed is too low or too high.
- Green LED: Fan is working properly.

Pressing the `<StopAutoRefresh>` button disables the automatic updating of measured readings, and the legend on the button changes to `<AutoRefresh>`.

Pressing the `<AutoRefresh>` button again enables automatic measurement updating, again changing the legend on the button to `<StopAutoRefresh>`.

Info

Shutdown Count

The value displayed here indicates the number of times the UPS has already shut down the system. The number of maximum permissible load cycles depends on the ambient temperature, see the figures in section 8.4.

 **Windows NT stores all important events under the following: ADMINISTRATIVE TOOLS ► EVENT VIEWER ► LOG/APPLICATION**

Security Functions

Notes:

Installation

4 Installation

Before you start on the installation, refer to the information on applicable standards and operating conditions in sections 2.7 and 2.6.

**CAUTION**

Conditions hazardous to the product!

The ambient air must be free of electrically conductive pollutants (e.g. acids, alkalis, corrosives, salts, metallic vapours, etc.).

**CAUTION**

The operational reliability of components designed to be installed in housings or control cabinets will be severely impeded if they are used or operated without having first been installed.

Therefore, do not use or operate the robot controllers unless they have been properly installed.

 **Note**


- The use of silicon-based sealing compounds, adhesives and insulating agents is prohibited.
- Ensure that the installation is maintenance friendly, i.e. that it provides unrestricted access to connections, cables and fuses.
- Precede all installation procedures by writing down the information on equipment rating plates. In the event that rating plates are hidden from view as a result of the installation, you will still have quick access to this information whenever required.

Installation

4.1 Installed positions and clearances

Housing:	19"-Front panel, protection category IP 65, PC housing, protection category IP 00
Weight:	approx. 9 kg
Installed position:	0° to max. $\pm 45^\circ$ incline
Installation type:	In console frame or hinged frame, sealed as per IP54

 **Please consider that the control panel may become dirty more readily when installed at an angle.**



- Install the device in such a way that ergonomical operation is ensured. In addition, the operator must be provided with a permanent and unobstructed line of sight to moving machine components!
- To prevent reduced screen readability and additional thermal load, avoid installation locations that are exposed to direct sunlight.
- Install the device in a manner ensuring easy access to the connector panel side.
- The LED displays on the front panel must not be obstructed or concealed.
- To provide sufficient ventilation and cable routing space, allow an all-round minimum clearance of 50 mm (refer to diagram).


Installation

- Allow for connecting loops in all cable routings; provide strain relief for all cables.
- Maintain a suitably large distance from sources of interference.


4.1.1 Dimensioned drawings

The following diagrams show the dimensioned drawings of the robot controllers rho4.1/BT155(T) and rho4.1/BT205:

Installation



Installation




Installation

4.1.2 Installation cutout

Installation cutout for rho4.1/BT155(T), rho4.1/BT205:

- ★ Make an installation cutout with four holes \varnothing 5 mm in accordance with the following diagram.
- ★ Insert the control panel of the robot controller into the cutout from the front while inserting the M4 stud bolts into the drilled holes.
- ★ Fasten the control panel by screwing M4 nuts on the stud bolts protruding at the rear of the control panel.



Electrical Connections

5 Electrical Connections

Please note that, with respect to all electrical connections, the terminal connection plans and work instructions provided by the machine manufacturer shall always be binding!

The system planner is also charged with providing and planning for the integration and implementation of required components, such as Emergency-STOP circuits, mains switches, etc. in accordance with the current state of the art and at the highest level of safety attainable.



CAUTION

Risk of damage to system components through insertion or removal of plug connectors on energized circuits!

Connections must be made only while the system is switched off.

Observe the following to prevent functional failures:

- Provide for insulated 24 VDC and 0 V terminal bars inside the control cabinet. When routing cables, maintain a minimum distance of 10 cm from all power cables.
- Design the system control circuits in a manner ensuring the simultaneous power up of PC and other industrial components, such as CNC and PLC.

Electrical Connections

5.1 Protective Earth conductor (PE) & screening information

**DANGER**

Dangerous conditions, functional failures and equipment damage on machine plant caused by substandard potential equalization or screening properties between system components!

Potential equalization currents must not be allowed to flow across the screening of connecting cables.

- ★ The protective earthing conductors (PE conductors) of the system must be arranged in a tightly meshed grid. All components, control cabinet housings and doors, including the mounting plate, must be earthed.
- ★ The potential equalization conductors / PE conductors of all system components should be kept as short as possible, resulting in low-resistance connections.
- ★ Install the PE rails, preferably electrically conductive, on the mounting plate in the control cabinet. Both sides of the insulated installed PE rails must be connected to the mounting plate with max. 20 cm long, adequately dimensioned copper bands.
Position the PE lines so that the length of the outgoing protective earth conductor connections to the individual modules in the control cabinet does not exceed 1 m.
- ★ When specifying the PE wiring, ensure sufficiently dimensioned cross-section. In this regard, also observe EN 60204, Part 1 (max. electrical resistance and testing PE wiring installations).
- ★ If at all possible, apply screening connections on both ends of a cable.
- ★ Ensure that equipotential equalization currents do not flow across the interface signal lines via the shielded conductors. Therefore, even before taking a system into operation for the first time, ensure that there is proper potential equalization between devices which are to be connected. Do not forget the interfaces which connect devices to each other at different locations (irrespective of distance or power supply).

**DANGER**

Dangerous shock currents due to poor PE connections! The effectiveness of PE connections must not be impeded by mechanical, chemical or electrochemical influences. Connections must be permanent and tight.

5.2 Interference suppression information

When designing the machine plant, observe and comply with governing regulations and statutory law with regard to interference suppression on individual components. This will increase the operational safety of the entire system.



DANGER

Dangerous conditions, functional failures and equipment damage on the machine plant caused by substandard EMC measures or line transient interference!

Install signal voltage cables only screened and at a sufficient distance from high-voltage cables (e.g. motor power cables). If this is not possible, separate metallic cable channels must be used.

The following sections are designed to provide you with a brief overview of possible interference suppression measures in the control cabinet. Among these are, for example:

- Filters
- Spark quenching circuits
- Damping of inductive switching peaks
- Limitation of switching voltage of high-speed semiconductors
- Screening


To ensure optimum suppress interference, **all** of these components should be taken into consideration because they are most effective when working in combination. In principle, interference suppression should be implemented as follows:

- Apply suppression measures as close to the source of interference as possible
- Use only components that are identified as interference suppressors
- Limit leakage currents in accordance with safety regulations
- Provide touch guards
- Prevent vibration fatigue breakage by providing secure mechanical support for interference suppressors.

To ensure that interference suppression measures are successful, electrical symmetry or asymmetry must also be taken into consideration. Besides symmetrical components of interference voltage that occur between the mains connection cables, asymmetrical interference voltages occur as well. They are caused by capacitive coupling of the interference source with the mains network.

The following diagram shows a standard interference suppression circuit. The asymmetrical interference voltages are discharged to the housing via C_y . C_x damps the symmetrical interference.


Electrical Connections



Interference suppression examples

Suppression of **contacts**


(Alternating current, direct current, offset DC current)



- to b) For sensitive contacts, residual current when contact open!
- to c) Voltage-dependent resistance, residual current when contact open!

Suppression of an **inductive load**


(Motors, solenoid, relay and contactor coils)



- to c) For relay, drop-off delay.
- to d) For relay, defined drop-off delay
- to e) Must be optimized for inductance!

Electrical Connections

Suppression example – mains input:



Electrical Connections


5.3 Power supply**5.3.1 24 VDC-power supply****X10_1 24 VDC power connection (with integrated 24 V-power supply)**

Alternative to 230/115 VAC power connection. All internally required voltages are provided by a DC/DC converter.

Additionally the 24 Vout interface is powered via X10_1. In this case X10_1 must also be connected to a 230/115 VAC-supply.

Weidmüller push-lock terminal, MSTB 1.5, 4-pin

Max. conductor cross-section: 1.5 mm² (see next page)



Rated voltage U_N : 24 VDC ; +20%, -15%

Residual ripple at U_N : See diagram below

Interference / surge immunity: $U_{max} = 35$ V (at $t < 100$ ms)

Current draw at U_N : Max. 5 A

Input fuse: 6.3 A (5x20) medium time-lag


Reverse polarity protection: Via decoupling diode. Polarity reversal will blow input fuse.

**DANGEROUS ELECTRICAL VOLTAGE**


The 24 VDC input power must comply with the requirements for “protective separation”!

Electrical Connections


Safety transformer, as per EN 60742



Offset AC components of the type produced by an unregulated rotary current bridge circuit without smoothing, with a ripple factor of 5% (refer to DIN 40110/10.75, section 1.2), are permissible. As an upper voltage limit, this produces a maximum absolute value of 30.2 V and, as a minimum voltage limit, the minimum absolute value of 18.5 V.



Electrical Connections



Electrical Connections

5.3.2 230/115 VAC power supply**X20 230/115 VAC power connection (with integrated AC power supply)**

Alternative to the 24 VDC power connection.

All internally required voltages are produced by the integrated power supply.

**CAUTION**

The supply voltage must satisfy the requirements of Overvoltage Category II. Otherwise, the integrated power supply may be destroyed.

Use a separation transformer to generate the 230/115 VAC (refer to next page).

Coupler for non-heating apparatus,
3-pin

Max. conductor cross-section: 1.5 mm²



Rated voltage:

85VAC ... 264VAC;
Extended-range input

Current draw at $U_N = 230$ VAC:

0.6 A

Current draw at $U_N = 115$ VAC:

1.2 A

Inrush current at 230 VAC:

30 A cold start 25 °C

at 115 VAC:


15 A cold start 25 °C

Input fuse:


1.25 A (5x20) medium time-lag

Electrical Connections

Power connection 230 VAC via separation transformer



Electrical Connections



Electrical Connections

Notes:

Interfaces

6 Interfaces

6.1 Overview

The table below describes the connector types integrated into the rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 robot controllers and the required mating connectors.

	Label on housing	Interface service	Connector type (integrated)	Mating connector or cable
Connectors standard interfaces				
o	COM1	Serial port: RS-232, freely assignable	Male DB 9 pin	Female DB 9 pin
o	COM2	Serial port: R-232 – reserved for BT155T with touch screen – freely assignable for BT155/205	Male DB 9 pin	Female DB 9 pin
o	COM3	Serial port: RS-232 – for kbd download or freely assignable	Male DB 9 pin	Female DB 9 pin
o	COM4	Serial port: RS-232 – for UPS logic, reserved	Male DB 9 pin covered	–
o	LPT1	Parallel port: Supports SPP, EPP, ECO modes	Female DB 25 pin	Male DB 25 pin (e.g. printer cable)
o	Ethernet	Ethernet Network connection:	Female RJ45 connector, 8 pin.	Male RJ45 connector, 8 conductor, twisted pairs
o	24 Vout	Keyboard code output	Female DB 15 pin	Male DB 15 pin
o	DP slave	PROFIBUS-DP Keyboard codeoutput (slave)	Female DB 9pin	Male DB bus IP20 9 pin
o	VGA	VGA connection for external CRT monitor	Female VGA HD connector, 15 pin	Monitor cable with male VGA HD connector, 15 pin
o	USB	USB port	USB socket 4 pin	USB plug 4 pin
o	KBD	PS/2 mini DIN keyboard	Female mini DIN PS/2, 6 pin	Keyboard cable with male mini-DIN PS/2, 6 pin
o	Mouse	PS/2 mini-DIN mouse	Female mini-DIN PS/2, 6 pin	Male mini-DIN PS/2, 6 pin
rho4.1 connection				
o	X10	24 VDC, PHG-power supply, READY-contacts, acknowledgement button, Emergency STOP	Male Weidmüller push-lock terminal, MSTB 1.5, 14 pin	Female Weidmüller push-lock terminal, MSTB 1.5, 14 pin
o	X31	V24_1	Male DB 9 pin	Female DB 9 pin
o	X32	V24_2	Male DB 9 pin	Female DB 9 pin
o	X33	V24_3	Male DB 9 pin	Female DB 9 pin
o	X34	V24_4	Male DB 9 pin	Female DB 9 pin
o	X35	Connector PHG2000	Female DB 25 pin	Male DB 25 pin
o	X41	Ribbon connector (optional)	Female DB 15 pin	Male DB 15 pin
o	X51	CAN-Bus 1	Male DB 9 pin	Female DB 9 pin
o	X52	CAN-Bus 2	Male DB 9 pin	Female DB 9 pin

Interfaces


	Label on housing	Interface service	Connector type (integrated)	Mating connector or cable
PCI_rho4.1 card				
e	SERCOS interface	Light wave conductor (LWL)	LWL conductor	
e	Interface on the PCI_rho card (external)	Combi-connection for CAN, increm. encoder (optional), measuring sensor, serial IF, power supply, PHG, READY signals.	Female DB 44 pin	Male DB 44 pin
r	Interface on the PCI_rho card (internal)	Interface for connection AF:PCI rho	Male inline connector 44 pin	Female inline connector 44 pin
Connector power supply (already described in section 5.3)				
o	X20	PC power supply: 230/115 VAC, alternative to X10_1	PC power cable connector, male	Netzleitung mit Kaltgeräte-Buchse Power cord with female PC connector
o	X10_1	PC power supply 24 VDC, alternative to X20. Power supply of 24Vout	Male Weidmüller push-lock terminal, MSTB 1.5, 4 pin	Female Weidmüller push-lock terminal, MSTB 1.5, 4 pin
Other connectors				
c	X76	CD-ROM and floppy disk power supply	CD-ROM and FDD female mains connector 4 pin on carrier board	CD-ROM and FDD male mains connector 4 pin (Conductor Y-Power)
m	IDE2	IDE-data connector for 3.5" floppy disk drive and CD-ROM drive	Male inline connector 44 pin (IDC) on motherboard	Female inline connector 44 pin (IDC) (Ribbon cable floppy disk and CD-ROM drive)
c	X53	PS/2 mini-DIN keyboard	Female mini-DIN PS/2, 6 pin	Keyboard cable with male mini-DIN PS/2, 6 pin
c	–	Connector for LC display	Male inline connector, multi-polar	Female plug connector, multi-polar Cable to front panel LCD
c	–	Front panel keys	Male inline connector 50pin	Female inline connector 50 pin Cable to front keyboard card
c	X19	Battery	Male inline connector 2pin	Female inline connector 2 pin cable to int./ext. Battery
c	–	IDE hard disk	Male inline connector 44 pin (on carrier board)	Female inline connector 44 pin (data cable for IDE hard disk)
f	KBD	Keyboard (BT front LCD)	Female MF2, 5 pin	Male MF2 DIN, 5 pin

Connector location:
o= Top of housing
c= Bottom of housing (on carrier board),
f= Front of control terminal,
m= On motherboard,
e = External cable connection,
r = rho4.1 connection (internal)


Interfaces

Port and connector layout

All externally accessed connectors are located on the top of the device.
All connectors are clearly labelled.
Additionally the DIP switches SEL COM3 and DP-ADR on the underside can be set.



Interfaces



Interfaces

6.2 Serial PC ports COM1...COM4, USB**6.2.1 Pin assignment****CAUTION**


Functional failures caused by poor screening!

Use only metallic or conductive connector/coupling shells providing large-area screen contact.

COM1 Serial port, freely assignable

Male DB-9 pin connector

Type:	RS-232
Cable length:	Max. 15 m
Cable type:	Screened, min. cross-section 0.14 mm ²
Transmission rate:	Max. 115200 bps
Handshake:	Hardware and software handshake (XON, XOFF)
Interrupt (IRQ):	4
I/O address:	3F8H or AUTO (recommended)
BIOS preset:	COM1: Enabled

**Assignment as an RS-232:**

DCD	Data Carrier Detect. RCV channel used, for example, by a connected modem to inform the PC that it is receiving a carrier signal (active connection).
RX	Receive Data. Line on which data is received.
TX	Transmit Data. Line on which data is transmitted to peripheral.

Interfaces

DTR	Data Terminal Ready. XMIT channel used by the PC to signal to a connected peripheral device that its interface is switched on and initialized.
DSR	Data Set Ready. RCV channel used by the connected peripheral device to inform the PC that it is switched on and initialized.
GND	Signal Ground
RTS	Request to Send. RCV channel used by the connected peripheral device to signal to the PC that it wishes to transmit data.
CTS	Clear to Send. XMIT channel used by the PC to signal to the connected peripheral device that it is permitted to transmit data.
RI	Ring Indicator. Receive line on which a connected modem informs the PC of the presence of an active call.
Screen	Contact with housing frame via metallic shell of the D-Sub connector.

COM2 Serial port, assigned to touch screen


The COM2 on the rho4.1/BT155T is reserved for the connection to the touch screen controller.

 **For rho4.1/BT155 and rho4.1/BT205 without a touch screen the port is freely available.**

Male DB-9 pin
connector

Type:	RS-232
Cable length:	Max. 15 m
Cable type:	Screened, min. cross-section 0.14 mm ²
Transmission rate:	Max. 115200 bps
Handshake:	Hardware and software handshake (XON, XOFF)
Interrupt (IRQ):	3
I/O address:	2F8H or AUTO (recommended)
BIOS preset:	COM2: Enabled

Interfaces




Refer to page 6-5 for explanations on pin assignments.

COM3 Serial port

For applications that require a software download of new key codes, COM3 is used internally. The software download is only possible if the COM3 port is connected to the keyboard controller by the DIP switch SEL COM3. In this case the download runs from the BT via COM3 (see section 7.5.3).

Male DB, 9 pin connector

- Type: RS-232
- Cable length: Max. 15 m
- Cable type: Screened, min. cross-section 0.14 mm²
- Transmission rate: Max. 115200 bps
- Handshake: Hardware/software handshake (XON, XOFF)
- Interrupt (IRQ): 10
- I/O address: 3E8H
- BIOS preset: COM 3: Enabled



Refer to page 6-5 for explanations on pin assignments.


Interfaces

COM4 Serial port, assigned to UPS logic (see section 3.2)

COM4 is internally assigned to the Uninterruptible Power Supply (UPS). The port connector is fitted with a cap at the factory.

Male DB, 9 pin connector

Type:	RS-232
Cable length:	Max. 15 m
Cable type:	Screened, min. cross-section 0.14 mm ²
Transmission rate:	Max. 115200 bps
Handshake:	Hardware and software handshake (XON, XOFF)
Interrupt (IRQ):	11
I/O address:	2E8H (if equipped for free assignment)
BIOS preset:	COM4: Enabled



Refer to page 6-5 for explanations on pin assignments.


USB Serial interface (Universal Serial Bus), currently not supported

The USB interface provides for the connection of up to 128 devices equipped with USB functions.

USB socket, 4-pin

BIOS preset:

USB controller: Disabled



Interfaces

PIN	Function
1	USB power supply (max. 500 mA)
2	File
3	File
4	USB Ground

Interfaces

6.2.2 COM1...COM4 settings

Control Panel

Settings for the transfer parameters for the serial ports.
Please refer to the description contained in the installed Windows NT operating system under "Settings, Control Panel, etc."

BIOS

The default BIOS presets for COM1 (serial port A) and COM2 (serial port B) are **AUTO** (automatic parameter assignment). If you desire direct parameter assignment, you should adopt the following settings:

- COM1 = 3F8H
- COM2 = 2F8H

COM3 and COM4 (serial ports C and D) are factory-set as "available", i.e. **(Enabled)**.



CAUTION

Interrupt (IRQ) and I/O address must correspond to BIOS settings.


In the case of address conflicts regarding COM3/4, e.g. if IRQ 10 or 11 are already in use by other PC expansion cards, free IRQs must be used instead.

Interfaces

6.3 LPT1 parallel port**LPT1 Parallel port for printer, scanner, etc.**

Female DB, 25 pin
connector

Type: SPP (ex works), EPP, ECP
 Cable length: Max. 3 m
 Cable type: Screened, min. cross-section 0.14 mm²
 Interrupt (IRQ): 7
 I/O address: AUTO or 378H (recommended)



The parallel port normally runs in the default SPP mode. Provided that suitable peripheral devices are present, it can also be operated in EPP (Enhanced Parallel Port) or ECP (Extended Capabilities Port) mode. The operating mode is changed in the BIOS settings.



CAUTION
Functional failures caused by poor screening!
 Use only metallic or conductive connector/coupling shells providing large-area screen contact.

Interfaces


6.4 Ethernet-interface

Ethernet network connection


The Ethernet connection allows the PC to communicate on an Ethernet network. To facilitate data communications, the required network protocols (e.g. TCP/IP) must be recognized by the operating system and the network application programs running on the PC.

Female RJ45 connector, 8 pin.

Type:	Ethernet 10 Base T
Cable length:	Max. 100 m
Cable type:	Screened, twisted pair
Transmission rate:	10 10Mbit/s or 100Mbit/s
Interrupt (IRQ):	5
I/O address:	340H



The driver configuration functions for the network connection can be accessed via the task bar or via the Control Panel under the Network Card symbol. A dialog box allows the selection of data transmission speed over the network e.g. 10 Mbit/s or 100 MBit/s.

 **Note that the network card of the remote communication partner must be able to handle the same data transfer rate.**

Interfaces

6.4.1 External monitor**VGA External monitor port**

The VGA port accepts an external monitor (CRT) for operation via the built-in video adapter. The external monitor can be operated in parallel with the operator panel.

- Video RAM: 2 MB


 **The insertion of a graphics card disables the integrated video adapter.**

HD socket 15 pin

Cable length: Max. 1.5 m

Cable type: Screened, min. cross-section 0.14 mm²

Max. resolution: 1280 x 1024 pixels, max. 16 million colours



Interfaces

CRT monitor resolution

It should be noted that it is technically possible to bypass the stated resolution and colour settings by changing them in the Control Panel while the rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 are running. However, such changes would again be overwritten during a subsequent system start:

- VGA mode: 640 x 480 pixels, 72 Hz, 24 bit colours
- SVGA mode: 800 x 600 pixels, 72 Hz, 24 bit colours
- XGA mode: 1024 x 768 pixels, 72 Hz, 16 bit colours
- SXGA: 1280 x 1024 pixels, 72 Hz, 8 bit colours

**CAUTION**

Setting incorrect resolutions and colours can destroy your monitor!

Observe the specifications applying to your CRT or LCD monitor, and adapt the operating system parameters accordingly.

Recommended monitors for external use are low-radiation models to TCO99. In addition, you should achieve the desired display resolution at a refresh rate of no less than 72 Hz.

Interfaces

6.5 Keyboard ports


KBD MF2 front-panel keyboard port

MF2 DIN socket, 5 pin

Cable length: Max. 1.5 m

Cable type: Screened, min. cross-section 0.14 mm²

BIOS preset: System Keyboard: Present




KBD and X53 PS/2 mini-DIN keyboard port

Female mini-DIN PS/2, 6 pin

Cable length: Max. 1.5 m

Cable type: Screened, min. cross-section 0.14 mm²

BIOS preset: System keyboard: Present



⚠ Only one of the two connectors may accommodate an external keyboard. Otherwise, proper functioning cannot be guaranteed.


Interfaces

Keyboard adapter

In the event that the MF2 keyboard is equipped with a standard DIN plug, you will require a keyboard plug adapter to a female PS/2 mini-DIN connector.

A suitable adapter is approx. 20 cm in length with a DIN connector and a mini-DIN coupling at the ends. Connector assignment as per diagram below.

These pre-fabricated adapters are available from computer stores.



Interfaces

6.6 Mouse port

Mouse PS/2 mouse port


Female mini-DIN PS/2, 6 pin

Cable length: Max. 1.5 m

Cable type: Screened, min. cross-section 0.14 mm²

Interrupt (IRQ): 12

BIOS preset: Enabled



If the system fails to recognize the PS/2 mouse, it must be activated by setting the interface in the BIOS from “Disabled” to “Autodetect”. The operating system will not recognize the insertion of an external mouse after completed startup because the mouse initialization occurs during the boot phase.

- ☞ **The connected mouse must be PS/2-compatible.**
The BIOS normally reserves IRQ12 for the PS/2 mouse. If there are address conflicts, e.g. if IRQ 12 has already been occupied by another PC expansion card, you should change the IRQ of the expansion card to one that is still free.

Interfaces

6.7 DP slave interface

DP slave PROFIBUS-DP connector


The keyboard codes of the movement keys and softkeys on the front panel are transferred to the DP slave connector. From there, the key codes can be copied via an external PROFIBUS-DP station for further processing. For keyboard codes see page 7-11.

Female DB 9 pin

Cable length: depending on baud rate
(as per EN 19245, part 3):


500 kBit/s	400 m
1500 kBit/s	200 m
3000 kBit/s	100 m
6000 kBit/s	100 m
12000 kBit/s	100 m

Cable type: Screened, min. cross-section 0.14 mm²



PROFIBUS slave address

The PROFIBUS slave address for the DP slave connection is set using the DP-ADR DIP switches (for location, refer to page 6-3). A total of 7 switch segments are reserved for this purpose.



DIP switch 1 must remain in the "OFF" position; it controls the keyboard controller.

Interfaces

6.8 24 Vout connector

24 Vout output key codes

The key codes of the movement keys and softkeys are transferred to eight outputs of the 24 Vout connector. From there, they can be copied via an external PROFIBUS-DP station for further processing. For keyboard codes see page 7-12.


Female DB 15 pin


Cable length:

Max. 20 m

Cable type:

Screened, min. cross-section 0.14 mm²



 **The 24 Vout connector receives 24 VDC power via the X10_1 connector. X10_1 must also be connected to a control terminal equipped with a 230 VAC power supply.**

Interfaces

6.9 LS120/CD-ROM drive connector

IDE2 connector LS120/CD-ROM drive unit

LS120 and CD-ROM drive are connected to the IDE2 interface using a ribbon cable.


The ribbon cable is equipped with one socket for connecting to the IDE2 and two sockets for attaching the two drives.

Male inline connector, 44 pin, internal on the mother board

Cable length: Max. 0.5 m

Cable type: 40-pin ribbon cable, unshielded

BIOS preset: Local Bus IDE adapter: Both




X76 power supply LS120/CD-ROM drive unit

The drives are connected using a Y-Power cable. It is equipped with a plug for connecting to the X76 and with two sockets for connecting the LS120 and CD-ROM drives.

Socket, 4 pin, internal on carrier board

Supply voltages: +5 V, +12 V, 0.9 A max.

X76, socket	Pin	Assignment
1	1	+12 V
2	2	GND
3	3	GND
4	4	+5 V

 **The +5 V and +12 V operating voltages are monitored for overvoltage and undervoltage conditions. The detection of a faulty voltage causes the PC power supply to switch off immediately.**

For the installation of the LS120/CD-ROM drive unit see section 8.2.

Interfaces

6.10 rho4.1connection**X10 PCI rho-interface**


X10 is a real-time interface. It provides:

- PHG power supply, 24 VDC
- Connection for READY-contacts, Emergency STOP contacts and acknowledgement buttons.

Weidmüller push-lock terminal: MSTB 1.5, 14 pin

Cable type: Screened, min. cross-section 0.14 mm²

The mating connector must be ordered separately, see page 10–1.

**READY2 relay:**

Breaking capacity:	Maximum 32 W
Switching current:	Maximum 0.8 A
Switching voltage DC:	Maximum 40 V
Watch dog time, analogue	50 ms ±22 %
WD:	

Interfaces

X31, X32 Serial combi-interfaces V24_1 (channel 1), V24_2 (channel 2)

X31, X32 are real-time interfaces. Serial data transmission according to the standards V24 and 20 mA is made possible by the combi-interfaces.

Male DB, 9 pin connector


V24


Type: V24
 Cable length: Max. 15 m
 Cable type: Screened, min. cross-section 0.14 mm²
 Data driver: Short-circuit resistant, no voltaic separation
 Transmission rate: Max. 19200 bps
 Handshake signals: DSR, DTR


20 mA

Type: 20 mA active
 Cable length: Max. 100 m
 Cable type: Screened, min. cross-section 0.14 mm²
 Transmission rate: Max. 19200 bps
 Data driver: Short-circuit resistant, no voltaic separation
 No-load voltage: 12 V
 Internal resistance: 464 Ω
 Maximum short-circuit current: 26 mA
 Receiver: up to 4.5 mA is recognised as low
 from 7.5 mA is recognised as high
 Handshake signals: Channel 1 has 20 mA control signal (RTS) for the connection of a PHG

For connecting cable see page 6-23.

 **Switching from V24 to 20 mA is achieved via a bridge in the plug from pin 4 to pin 2.**




 **The PHG connection X35 and the serial interface X31 must not be occupied simultaneously.**

Interfaces

X33, X34 Serial interfaces V24_3 (channel 3), V24_4 (channel 4)


X33, X34 are real-time interfaces. Serial data transmission according to the standard V24 is achieved with these interfaces.

Male DB, 9 pin connector	
Type:	V24
Cable length:	Max. 15 m
Cable type:	Screened, min. cross-section 0.14 mm ²
Data driver:	Short-circuit resistant, no voltaic separation
Transmission rate:	Max. 19200 bps
Handshake signals:	none



Connecting cable between interface X31..X34 and an external PC (e.g. for ROPS4 coupling):

2 x female DB 9 pin	
Cable length:	Max. 20 m with internal power supply and a maximum of 350 mA



Interfaces

X35 PHG2000

To connect a manual programming unit PHG2000. Serial transmission, 24 V power supply, connection for Emergency STOP contacts and acknowledgement button.

 **In order to close the Emergency STOP circuit, the X35 is fitted with a dummy plug as long as no PHG is connected.**


Male DB, 25 pin connector.

Type:

Serial 20 mA , plus additional safety functions

Cable type:

Screened, min. cross-section 0.14 mm²



DANGER

In order for the PHG Emergency STOP to work, it must be connected. Otherwise it must not remain attached to the system! Remove a PHG that is not connected.

 **The PHG connection X35 and the serial interface X31 must not be occupied simultaneously.**

Interfaces

X41 Incremental interface, measuring sensor

X41 is only active in conjunction with a PCI_rho4 insertion card with incremental measurement system input. It contains:

- The incremental interface for encoders
- The measuring sensor input.

Female DB 15 pin

Cable length: Max. 20 m with internal power supply and a maximum of 350 mA. A longer cable is possible with external power supply for the encoder. A possible limitation depends only on the encoder specification.

Cable type: Screened, min. cross-section 0.14 mm²

Incremental interface

Maximum input frequency: 800 kHz

Minimum edge separation between active count impulses: ≥ 250 ns

Input resistance: 120 Ω

Minimum voltage difference: ≥ 600 mV

Encoder power supply: 5 V ± 5 % maximum 0.35 A, 1.75 W. In the event of a short-circuit, the PC switches itself off

Maximum permitted encoder current draw: 350 mA


Measuring sensor input

Rapid 24-V-input for measuring sensor, voltaic separation, opto-coupler.

Voltage range 0: -3 V to 5 V maximum 0.5 A

Voltage range 1: 11 V to 30 V, 4 mA to 30 mA

Switching time (delay): Maximum 1.5 μ s



Interfaces

X51, X52 CAN drives, CANopen encoder , SR-CAN module, CAN application I/O

X51 and X52 are two **separate** CAN bus interfaces for:

- Drives
- CANopen encoder
- Digital output module
- Digital input module
- SR-CAN module
- Several rho4 controllers for coupling with each other.

X51, X52 are real-time interfaces.

Male DB, 9 pin connector

Type:

CAN

Cable length:

Max. 25 m at 1 MBit/s

Max. 200 m at 128 kBit/s

Cable type:

Screened, min. cross-section 0.14 mm²

Transmission rate:


Max. 1 MBit/s

Data driver:

Short-circuit resistant, no voltaic separation

Bus connection:

120 Ω internal, cannot be switched off




Interfaces

6.11 Interfaces on the PCI_rho card

The interfaces of the connection (X10, X31..X34, X35, X41, X51..X52) are lead out again to this external interface of the PCI_rho insertion card. The assignment is identical to the internal interface AF_PCI rho.


ⓘ The interfaces of the connection (X10, X31..X34, X35, X41, X51..X52) and the external interface of the PCI_rho insertion card must not be operated in parallel.

Female DB, 44 pin connector



Interfaces

6.12 SERCOS interface



There is a complete SERCOS channel on the PCI_rho card. The connection to the digital drives takes place via the SERCOS interface. The SERCOS interface is a standard serial LWL ring system. The SERCOS interface is designed for a maximum transmission speed of 4 M baud.

For available light wave conductors in various lengths see chapter 10.2 'Accessories' or the manual 'Indramat Verbindungstechnik LWL-Handling', DOK-CONNEC-CABLE*LWL**-AW02-DE-P.


6.13 AF_PCI rho interface

This internal interface connects the rho4.1 connection (X10, X31..X34, X35, X41, X51..X52) to the PCI_rho insertion card.

Male inline connector, 44 pin

Cable type: Ribbon cable, unshielded

Interfaces



Interfaces

6.14 Expansion Card Interfaces

6.14.1 PCI_BM-xxx Card

This busmaster expansion card is the interface of the software PLC. The PLC signals are transmitted over the integrated system bus.


Depending on model, X71 has been assigned one of the following **bus systems**:

Name	Bus system
PCI_BM-CAN	CAN bus
PCI_BM-IBS	InterBus-S
PCI_BM-DP	PROFIBUS-DP

X71 CAN-Bus "PCI_BM-CAN"

Male DB-9 connector

Type:	CANopen bus
Cable length:	depending on baud rate max. 25 m with 1 Mbit/s
Cable type:	Screened, min. cross-section 0.14 mm ²
Transmission rate:	up to 1 Mbit/s



X72 This interface is currently not supported by the rho4.1


Interfaces


X71 Interbus S "PCI_BM-IBS"

Female DB-9

Type InterBus-S Remote (as per EN 50178)

:



 Please comply with the installation instructions and recommendations of Phoenix-Contact, e.g. IBS SIG Part 1 UM or the IBS SYS INST UM installation manual.

X72 This interface is currently not supported by the rho4.1


X71 PROFIBUS DP "PCI_BM-DP"

Female DB-9

Max. cable length	500 kbit/s	400 m
depending on baud rate	1500 kbit/s	200 m
(as per DIN EN 19245 Part 3):	3000 kbit/s	100 m
	6000 kbit/s	100 m
	12000 kbit/s	100 m

Cable type:	Screened, min. cross-section 0.14 mm ²
-------------	---

Interfaces



X72 This interface is currently not supported by the rho4.1


6.14.2 PCI_CAN Card

This interface is a second CAN bus for fast transmission of measured data to the PC.

X71 CAN bus

Male DB-9 connector

Type:	CAN-Bus
Cable length:	depending on baud rate max. 25 m with 1 Mbit/s
Cable type:	Screened, min. cross-section 0.14 mm ²
Transmission rate:	up to 1 Mbit/s



Displays and Operating Controls

7 Displays and Operating Controls

The following displays and operating control elements are contained in the robot controllers rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205:

- Display, touch screen optional
- LED displays
- Keyboard, DIN keyboard connector
- Front panel legends
- Keyboard controller
- Keyboard mouse

7.1 Display

All robot controllers are equipped with a flat screen display using LCD technology.

For optimum legibility the following is recommended:

Type	Display resolution	No. of colours
rho4.1/BT155 and rho4.1/BT155T	640 x 480 pixels (factory setting)	max. 256,000
rho4.1/BT205	800 x 600 pixels (factory setting)	max. 256,000

Brightness and contrast are preset at the factory. The display colours can be adapted to operating requirements via the operating system or by means of the application software.

For the purpose of maintenance procedures on the display, the front panel of the control terminal can be folded away toward the front while still installed. For a detailed description of the display removal procedure, refer to section 8.3.


Displays and Operating Controls

7.1.1 Backlight switch-off


The fluorescent backlight tube provides the background lighting for the TFT display. After approx. 15,000 operating hours, because the tube has a limited service life, it will produce only 50% of its original brightness. Refer to section 8.3 for information about replacing the backlight unit.

To extend the service life of both display and backlight tube, the flat screen display features a timer ("sleep") function for the backlight. This function "darkens" the display when no operation has occurred on the control terminal for a defined period of time. The length of the defined interval can be selected in the PC BIOS and in the Windows Control Panel.

Any keyboard input, mouse movement or contact with the touch screen will again activate the backlight, and the display will again appear.

 **If when in the "darkened" state keyboard input, mouse movement or contact with the touch screen does not cause the backlight to be switched on, as a rule this can be achieved by pressing the key combination <CTRL> + <Tab>.**

Activating the backlight timer:

- ★ In the BIOS setup program, go to the "Power Management Setup" menu option. Select the "OnBoard LCD Backlight Timer OFF" submenu, and select a time interval between 28 seconds and 14 minutes.
 - ★ In your operating system, install a screen saver such as "Blank Screen" that will switch the display to a "black signal" (blank screen, i.e. no objects visible on the display). Select the "Wait" period after which the screen saver will be activated. The interval selected here is added to the "Backlight Timer OFF" interval that was selected in the BIOS.
-  **Ensure that the period set for screen saver activation is shorter than the time for activation of the backlight switch-off. If this is not the case, in certain circumstances it can lead to problems with display reactivation.**

Displays and Operating Controls

7.1.2 Touch screen

In the rho4.1/BT155T a touch screen is employed, that permits operation using the contact-sensitive surface of the display.


Mechanical considerations prohibit the installation of the touch screen in a control terminal featuring a 12.1 in. display.

The COM2 serial port is reserved for communications between the touch screen controller and the PC system. The external COM2 port connector must therefore not be used to connect any devices.

The operation of the touch screen requires appropriate software drivers for the respective operating system; these are preinstalled at the factory. Modifications can be made in the **Elo Touchscreen** application program in the "Control panel" in Windows.

Starting Elo Touchscreen opens a dialog box in which the following options and settings are available:


- Mouse pointer response to touch screen contact (Mouse Button Emulation Mode)
- Calibrating the touch screen by "tweaking" the touch screen coordinates to match the screen coordinates (Calibrate button).
- Setup button (COM port, etc.)



 To obtain detailed online Help information, select the "Help" button in the "Touchscreen" dialog box.

Displays and Operating Controls

7.2 LED displays



On the front panel there are 5 LEDs with the following meaning:

LED	Display	Explanation	Remedial measure
V _{in}	LED green	Standard operation	–
	LED Off	No 230/115 V AC or 24 V DC power supply	Check mains power input on power supply.
V _{Out}	LED green	Standard operation	–
	LED Off	No internal +5 V/+12 V power available	Check mains power input on power supply.
HD	LED yellow	Hard disk access	–
Temp	LED Off	Standard operation	–
	LED flashes red	Internal housing temperature above 50°C, shutdown will occur if temperature continues to rise.	Lower ambient temperature. Check PC cooling fan.
UPS	LED Off	Standard operation	–
	LED red	Device is currently operating in battery mode i.e. no mains power available.	Restore power supply and initiate controlled PC restart.
	LED flashes red	Battery pack discharged, defective or not connected	Check battery charge level. Maintain 5 hour charging cycle.

There is also a RESET button with LED on the plug side:

LED	Operating panel/display	Explanation	Remedial measure
RESET	Button	Trigger a reboot.	–
	LED red	RESET button has been pressed.	–

Displays and Operating Controls


7.3 Keyboard

7.3.1 Blocks of function keys

All blocks of function keys can be programmed via the **application program**:

- 2 vertical rows of 8 keys each, to the right and left of the display.
Key designations, left-hand key column: 1...8
Key designations, right-hand key column: 1...8
- 2 horizontal rows of 9 keys each, below the display (e.g. for the common industrial softkey functionality)
Key designations, row 1: F1...F8, level return
Key designations, row 2: S1...S8, ZOOM

The labelling can also be changed for all function keys, see section 7.4.




Displays and Operating Controls

7.3.2 ASCII, number and cursor control blocks

The following blocks of keys are permanently assigned. However, the assignment can be changed by Rexroth at customer request:

- **ASCII and number block** (block of 40 keys to the right of the display)
- **Cursor control block** (block of 9 keys, bottom right corner beside display)



Displays and Operating Controls

ASCII and number block key assignments

- ASCII characters and various special characters
- alpha (access to special characters and special functions, refer to section 7.3.3)
- del (Delete)
- ← (Backspace)
- ins (Insert)
- tab (Tab)
- space (Space)
- esc (Escape)
- ctrl (Control)
- alt (Alternate)
- shift (Upper / lower case)
- ↵ (Return)

Cursor block key assignments

Covering the following key designations:

- Cursor keys: Right Arrow, Left Arrow, Up Arrow, Down Arrow keys
- home (to Home pos.)
- end (to End pos.)
- pg up (to Top of page)
- pg dn (to End of page)

7.3.3 Special key functions

The alpha key can be used to invoke the following special functions:


- Keyboard mouse <Alpha> + <M>
- CAPS Lock <Alpha> + <C>
- NUM Lock <Alpha> + <N>

Keyboard mouse

<alpha> + <M> enables the keyboard mouse. This key function toggles back and forth.


When enabled, a keyboard mouse replaces the mouse movement by means of the **cursor-keys**. The cursor control block function is no longer available.

Displays and Operating Controls



The active keyboard mouse is indicated by the LED of the alpha key in the following manner:

Keyboard mouse	Alpha key LED prior to activating the keyboard mouse	Keyboard mouse	Alpha key LED after activating the keyboard mouse
Disabled	Off	Enabled	Flashing: Short On / long Off
Disabled	On	Enabled	Flashing: Long On / short Off

 In the event that during startup or after a RESET an external mouse is inserted, it will be recognized automatically, and the keyboard mouse disabled. It will then not be possible to re-enable the keyboard mouse, not even by removing the external mouse. The PC has to be re-booted.

CAPS-Lock

<alpha> + <C> activates CAPS-Lock. This key function toggles back and forth.

The function is confirmed by the "Caps " LED.

The CAPS-Lock function fixes the access to capital letters, special characters, etc., until it is again de-selected.

Pressing the <shift> key disables the CAPS-Lock function.

NUM-Lock

<alpha> + <N> activates NUM-Lock. This key function toggles back and forth.

Confirmation via "Num " LED.


The NUM-Lock function activates the numerical keypad on an external DIN keyboard.

Displays and Operating Controls

7.4 Front panel legends

Providing for customer-specific terminal legends, individual insertion labels can be inserted at the outside edges, and pushed under the plastic film of the front panel:

- Type designation and corporate logo
- Function key columns to the left and right of the display
- Function key rows below the display



Displays and Operating Controls

The insertion strips/labels are inserted and pushed through an insertion gap at the rear of the front panel.

- ☞ **When preparing to insert a label, it is helpful to start by inserting a flexible plastic or metal strip of approx. 0.1 mm thickness that is slightly longer than the label. On this strip, the insertion label can be mounted more easily. Remove the plastic or metal strip after installation of the insertion label.**

The table below indicates the dimensions of the various insertion strips.

Type	Dimensions [mm]
Type designation, corporate logo	124.8 x 18
Keys 1 to 8	22 x 195
Function keys	22 x 44.2

Replacing insertion labels

1. The control terminal must be switched off and de-energized.
2. Remove the mounting screws holding the front panel on the installation frame.
3. If necessary, also remove all cable connections on the BT.
4. The insertion gaps for the insertion labels are located at the rear of the front panel. Replace the old insertion labels with new ones.
5. Installation is in reverse sequence to disassembly described above.
6. Restore power to the system. Ensure that the label is easily read, and that the keyboard labels correspond to the function indicated on the label.

- ☞ **In certain circumstances, faulty labelling may cause faulty operation of the connected machine!
Check and verify that the legends on the insertion labels correctly match the function of the labelled keys.**

Displays and Operating Controls

7.5 Keyboard controller

For many industrial applications it is important to determine the key status (pressed/not pressed, key LED ON/OFF) of the front panel keyboard.

To this end, a keyboard controller scans the front panel keyboard and transfers the key codes to various interfaces.

7.5.1 Scanning front panel keyboard

The keyboard controller transfers the current status of the front panel keyboard to various interfaces:

- to the PC via MF2
- to the PROFIBUS slave station
- to the 24 Vout outputs


Via these interfaces, the supplied codes can then be further processed by the respective application program.

Transferring key codes to the PC via MF2

The 1st input byte contains the following values (in the standard version):

BT155, BT155T, BT205	
Keys	MF2 key code
Overview:	shift + space
Display basic screen:	ctrl + home
Info:	shift + return
Softkeys F1 to F8:	F1 to F8
Softkeys S1 to S8:	shift + F1 to shift + F8
Movement keys 1 to 4 left of display:	F9 to F12
Movement keys 5 to 8 left of display:	shift + F9 to shift + F12
Movement keys 1 to 4 right of display:	ctrl + F9 to ctrl + F12
Movement keys 5 to 8 right of display:	ctrl + shift + F9 to ctrl + shift + F12
Standard ASCII character set	1,2,3,... a,b,c,...
Cursor block	Cursor: Left, Right, Up, Down, home, end, pgup, pgdn
””, \$”, ’ ’, ’~’, ””, ’^’, ’@’, ;, ””, are entered with the alpha key pressed down	Alpha active: Alt +

Displays and Operating Controls

-  **The alpha key is a toggle function, which does not return a key code. It controls the keyboard controller. When the alpha key is active, the key LED illuminates.**

The alphanumeric keys, and the <ctrl>, <alt> and <shift> keys in particular, have the same effect as those on a standard PC keyboard.

Transfer to the PROFIBUS slave station / to the 24 Vout outputs

By default, the codes of the following keys are transferred:

- Movement (motion) keys
- Softkeys

BT155, BT155T, BT205	
Key	Key code to: – PROFIBUS slave – 24 Vout output
Softkeys F1 to F8:	0x20 to 0x27
Softkeys S1 to S8:	0x28 to 0x2F
Movement keys 1 to 8 (left of display):	0x10 to 0x17
Movement keys 1 to 8 (right of display):	0x18 to 0x1F
No key pressed:	0x00
Arrow keys:	0xFF
pg up, pg dn:	0xFF

PROFIBUS slave station

The key transfer uses codes via 8 input bytes sent to the PROFIBUS slave.

24 Vout outputs

The key codes are placed on the 24 Vout outputs in bit-encoded form. The value indicated in the preceding table corresponds to the 1st input byte.

The respective outputs can then be read via an external PROFIBUS station.


Displays and Operating Controls

7.5.2 Exceptions when keys are pressed simultaneously

When keys are pressed simultaneously, the key code output is supported by special processing logic.

Only in the case of movement keys is simultaneous key actuation not supported; only one key may be active at a time:

- 2 movement keys are pressed: Key code of first recognized key is output
- Releasing key that was pressed first: No code is output

 **If a movement key is pressed, all other key actuations will be ignored until a movement key no longer remains pressed.**


7.5.3 Software download for keyboard controller

 **Customer-specific key codes can be downloaded by Rexroth upon request and by appointment.**

The BT uses the COM3 serial port to download new key codes into the keyboard controller.


In the event that problems occur during the download, the first step should be to check the SEL COM3 DIP switch settings.

The SEL COM3 DIP switch is located on the bottom panel of the control terminal (see page 6-3). Switch segments 1 and 2 must be in the "ON" position.



If the download continues to fail, a forced download may be initiated. This entails explicitly switching the keyboard controller to download mode by means of the DIP switch DP-ADR, which is also located underneath the control terminal. Set switch segment 1 to "ON" then reboot the control terminal to activate the download mode.

Displays and Operating Controls



Once the download has been completed successfully, return switch segment1 of the DP-ADR to the **"OFF"** position.

Maintenance and Replacement

8 Maintenance and Replacement

rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205 are maintenance free. However, some components are subject to wear and must be replaced.

Maintenance schedule

Include the following tasks in your maintenance schedule

- Clean the surface of the screen at least once a week with an anti-static cloth or window cleaning agent containing denatured alcohol.

**CAUTION**

Dissolution of sealed key panel surface and display seal through contact with solvents!

Do not use any solvents (e.g. paint thinner)!

-
- At least once a year, check all plug and terminal connections of components for proper tightness and damage. Check that cables are not broken or crushed. Replace damaged parts immediately.
 - Check fan and fan filter mats at least once a year. Clogged and contaminated filter mats reduce the air volumes required for proper ventilation and cooling. Therefore wash dirty filter mats in soapy water or replace with new mats. Allow washed filter mats to dry completely before reinstalling.

**DANGER**

Risk of injury through rotating fan impeller!

Keep hands and fingers clear, and do not insert any items into the fan impeller.

-
- Ensure that the rechargeable batteries (battery pack) are fully functional. Enable automatic testing of the rechargeable battery during each restart by activating the so-called "Accu Test" option of the UPS control program.

**CAUTION**

Loss of data!

Back up the data from the hard disk at regular intervals .

-
- Depending on temperature, vibration and daily operating hours, the service life of the hard disk may last anywhere between 2.5 and 10 years.
Back up your data at regular intervals using the program ROPS4.

Maintenance and Replacement

8.1 Hard disk

The hard disk is replaced complete with installation frame.




CAUTION

Loss of data!

Back up all required application data and operating system settings to an external storage medium!

1. Switch off the supply voltage. If required, unplug all connectors.
2. Wait until the power supply switches off automatically after UPS operation (the **UPS LED** on the front illuminates **red** until the UPS switches off the power supply).
3. Remove the 4 Phillips-head screws holding the control terminal. Pull out the control terminal by approx. 3 cm, and tilt forward (refer to diagram on page 8-3).


Maintenance and Replacement



4. The ribbon cable is secured by a spot of hot glue which must be broken (cut) for de-installation. Disconnect the IDE ribbon cable **from the hard disk**. Unless this cable is defective, disconnecting it from the main board will not be required.


Maintenance and Replacement

View A: Control terminal with control panel folded down



5. A **retaining screw** holding the installation frame in place is located below the hard disk. Loosen the retaining screw and pivot the installation frame slightly to the right at its base (near the retaining screw). The pivoting motion releases the installation frame from the clamping gaps at the top side of the housing. Now, pull the installation frame slightly downward in order to remove it toward the front.

View A: Control terminal with control panel folded down



Maintenance and Replacement

6. The new hard disk is always installed in its installation frame and in reverse order from that described above.

 **Secure the hard disk connector again by applying a spot of "hot glue".**

Testing the new component:

7. The new hard disk must be declared in the BIOS. To access the BIOS menu of the PC, press the <F2> key during the booting up phase.

In the main menu, select the **Primary Master**" menu command to enable automatic recognition of the new hard disk parameters by the system. In the Master submenu, go to the "Transfer Mode" menu option and select "Fast PIO 3" for the hard disk. Prior to leaving the BIOS, in the Exit menu, press F10, "**Exit Saving Changes**" to save the hard disk parameters.

To confirm this, press the <Z> key (= interpreted as Y for Yes on German keyboards).


8. In the event that the operating system fails to start up, interrupt the power supply to the unit again for a minimum of 10 seconds, and then reboot.
9. If the system still fails to start, check for the following:
 - Positive connection of hard disk controller cable
 - Proper seating of all cables and connectors.
 - Functioning power supply
10. Reset the entire system to the state it was in when delivered using the CD-ROM and boot diskette supplied.
11. Once the PC has completed its boot process and started properly, the user data and operating system settings must again be restored for standard operation.

Maintenance and Replacement

8.2 LS120/CD-ROM drive unit

8.2.1 Swap entire unit

The drive unit and holding bracket can be replaced in the installed control terminal.


 **In order to replace the drive unit whilst leaving the control terminal in place, the clearance at the rear must be at least 400 mm, with respect to the cover surface, to be able to remove the covers.**

The rear of the control terminal housing is fitted with a large and a small cover plate. The covers are connected by rotating joints so that they can be removed separately. The covers are fastened to the control terminal housing by 2 screws and 2 tabs each. The tabs are located underneath a cant in the housing (beneath the rotating joints).

A carrier plate for the LS120 drive is fastened to the larger cover by four screws. Behind it is the CD-ROM drive, attached to the cover plate by 4 screws.

The ribbon cable (for data flow) and the Y-power cable (for power supply) are lead under the LS120/CD-ROM drive unit to the main board and to the carrier board.


Maintenance and Replacement



Replacement


1. Switch off the supply voltage. If required, unplug all connectors.
2. Wait until the power supply switches off automatically after UPS operation (the **UPS LED** on the front illuminates **red** until the UPS switches off the power supply).
3. Remove both screws from the large cover and swing it out by approx. 170°

Maintenance and Replacement



4. Pull the IDE ribbon cable off from the main board and the plug for the power supply from the carrier board. Remove the cable binding that holds the ribbon cable. Swing the large cover back to its original position.

Maintenance and Replacement



5. Now remove the two screws from the small cover. Hold on to the large cover while doing this!
Swing the small cover with its tabs a little under the housing cant until it becomes free. Now both covers can be removed.
6. Insert the new drive unit including the covers in reverse order from that described above.
Please make sure when replacing the covers that the tabs are pushed under the housing cant.


Testing the new components:

7. In the event that the operating system fails to start up, interrupt the power supply to the unit again for a minimum of 10 seconds, and then reboot.
8. If the system still fails to start, check for the following:
 - Proper seating of the controller cable to the LS120 and CD-ROM drives
 - Proper seating of all cables and connectors.
 - Proper seating of the Y-power cable
 - Functioning power supply.
9. Once the PC has completed its boot process and started properly, the user data and operating system settings must again be restored for standard operation.

Maintenance and Replacement

8.2.2 Replacing drives separately


The drives of the LS120/CD-ROM drive unit can also be replaced separately.




1. Switch off the supply voltage. If required, unplug all connectors.
2. Wait until the power supply switches off automatically after UPS operation (the **UPS LED** on the front illuminates **red** until the UPS switches off the power supply).

LS120 drive

3. Remove the two screws from the large cover and swing it out by approx. 170° so that you can remove the ribbon cable and power supply from the LS120 drive (see diagram on page 8-7). Swing the large cover back to its original position.

 **For the subsequent installation, make a note of how the ribbon cable plug was attached to the drive (as a rule pin 1 data cable marked in red is at the right-hand edge of the plug of pin 1 of the data connection). A similar process can be used for the power supply connections as the cables are colour coded.**

Maintenance and Replacement



4. Remove the 4 screws from the carrier plate. Pull them out of the rotating joint of the small cover and lift the carrier plate complete with LS120 drive off.
5. Remove the 4 LS120 drive retaining screws from the carrier plate and take the drive off.
6. Install the new LS120 drive in the reverse order from that described above.
Please make sure when replacing the covers that the tabs are pushed under the housing cant.


CD-ROM drive

3. After steps 1 and 2 above remove the two screws from the large cover and swing it out by approx. 170° so that you can remove the ribbon cable and power supply from the CD-ROM drive (see diagram on page 8-7). Swing the large cover back to its original position.

☞ For the subsequent installation, make a note of how the ribbon cable plug was attached to the drive (as a rule pin 1 data cable marked in red is at the right-hand edge of the plug of pin 1 of the data connection).

A similar process can be used for the power supply connections as the cables are colour coded.

Maintenance and Replacement



4. Remove the 4 screws from the carrier plate. Pull them out of the rotating joint of the small cover and lift the carrier plate complete with LS120 drive off.
5. Remove the 4 retaining screws that are used to fasten the CD-ROM drive to the large cover and take the drive off.
6. Install the new CD-ROM drive in the reverse order from that described above.
Please make sure when replacing the covers that the tabs are pushed under the housing cant.

**CAUTION**

The CD-ROM drive may be destroyed by incorrect installation or screws that are too long!

It is imperative that the distance washers of the retaining screws (4x) are used as otherwise the screws may penetrate too far into the drive housing and destroy the device.

Testing the new components:

1. In the event that the operating system fails to start up, interrupt the power supply to the unit again for a minimum of 10 seconds, and then reboot.
2. If the system still fails to start, check for the following:
 - Proper seating of the controller cable to the LS120 and CD-ROM drives
 - Proper seating of all cables and connectors.
 - Proper seating of the Y-power cable
 - Functioning power supply.

Maintenance and Replacement

3. Once the PC has completed its boot process and started properly, the user data and operating system settings must again be restored for standard operation.

8.3 Backlight and display panel

 **Backlight replacement is only possible for the rho4.1/BT155 and rho4.1/BT155T.**

A fading backlight causes a progressive deterioration of LCD display readability, making a backlight replacement advisable. Both the backlight source and the display panel can be replaced while the control terminal remains in its installed position:

1. Switch off the supply voltage. If required, unplug all connectors.
2. Wait until the power supply switches off automatically after UPS operation (the **UPS LED** on the front illuminates **red** until the UPS switches off the power supply).
3. Remove the 4 Phillips-head screws holding the control terminal. Pull out the control terminal by approx. 3 cm, and tilt forward (refer to diagram on page 8-15).
4. Remove the 2 display mount retaining screws. You can now pull the display including its display mount from its retainer, as far as the display ribbon cable will allow.
5. Remove the 4 display mounting screws.
6. To replace the display: Carefully remove ribbon cable connector from display. Replace old display with new display panel.
7. To replace the backlight source: Remove the 2 backlights from the retainer, and replace with new backlight unit.




CAUTION

Use only the same type of displays!

Replace the backlight unit only with one matching the display!

8. The installation is performed in the reverse order of the removal procedure.
9. In the event that, subsequent to the installation, the display does not produce an image, check for the following:
 - Proper seating and positive contact of display ribbon cable
 - Proper seating and positive contact of backlight unit

Maintenance and Replacement



8.4 Rechargeable Battery Pack



CAUTION

Before replacing the battery always back up important data. If there is a voltage dip while the battery is being replaced, data in the RAM may be lost.

The rechargeable battery pack must be replaced in the following cases:

- The battery test fails during system startup.
- The number of completed charge cycles exceeds the number depending on the ambient temperature stated below ("Shutdown count" in the UPS program, see section 3.3.2)
- The red UPS LED on the front panel flashes for longer than 8 hours (see page 7-4).

A charging cycle is determined by switching the PC power supply on and off.

The number of battery pack charging cycles that can be carried out, and so its useful life, is dependent on the ambient temperature in which the battery pack is used. Ambient temperature is defined as the temperature in which the battery pack is situated, e.g. the temperature within the unit or the internal temperature of the control cabinet.

The following table can be used as a guide:

Ambient temperature	Charge cycles	Maintenance interval
+ 25 °C	4000 cycles	6 years
+ 35 °C	2000 cycles	3 years
+ 45 °C	1000 cycles	1.5 years

The rechargeable battery packs used are recyclable, and can be returned to Rexroth after replacement. They must not be disposed of in standard household refuse.


X19 Battery pack connector

Male inline connector, 2 pin

Cable length: Max. 0.5 m

Cable type: Unscreened, min. cross-section 1.5 mm²

Maintenance and Replacement




For rechargeable battery pack order number see section 10.3.

Replacements


The rechargeable battery pack consists of 2x3 batteries and is built into the device. The batteries are connected to each other and must be replaced as an entity:

1. Switch off the supply voltage. If required, unplug all connectors.
2. Wait until the power supply switches off automatically after UPS operation (the **UPS LED** on the front illuminates **red** until the UPS switches off the power supply).
3. Open the small cover at the rear (2 screws) and swing it open.



Maintenance and Replacement

4. Lift the battery pack carrier plate up.
5. Pull off the cables with the plugs in positions 1 and 2 on the battery pack (see diagram below).
Take a note of which cables lead to the plus and minus poles of the battery pack.
If the cables need to be changed over then also remove the plug from the X19 connector.




6. Replace the battery pack and re-connect the cables.

**CAUTION**

Ensure that the polarity of the batteries is correct. Polarity reversal of the rechargeable battery packs will result in an F10A (5x20) fuse being blown on the power supply module. Further damage may also result. UPS operation will then no longer be possible.

7. Re-insert the carrier with the battery pack. Close the cover.

Maintenance and Replacement

-  **If the new rechargeable battery pack is not yet charged up there will not be adequate UPS protection to effect a controlled shutdown of the PC during the approx. 5 hours required for charging to 2.5 Ah capacity. Therefore install fully charged batteries if at all possible.**

Testing the new component

8. Restore power to the system.
9. Observe the "UPS" LED on the front panel:
 - Battery pack already charged: UPS LED **OFF**
 - Battery pack discharged: UPS LED **flashes red**Wait approx. 5 hours until the battery pack is fully charged and the UPS LED **extinguishes**.

8.5 Expansion cards

The unit provides 2 slots for PCI bus and combined ISA/PCI bus expansion cards :



CAUTION


Risk of damage to the PC or corruption of application software due to the installation of non-approved expansion cards. Use only approved expansion cards, and have them installed by a specialist.

8.5.1 Installing an expansion card

1. Switch off the supply voltage. If required, unplug all connectors.
2. Wait until the power supply switches off automatically after UPS operation (the **UPS LED** on the front illuminates **red** until the UPS switches off the power supply).
3. Remove both screws from the large cover and swing it out by approx. 170°
4. Remove the mounting screw holding the slot cover.
5. Insert the expansion card, and secure it with the mounting screw.
6. Return the large cover to its original position and fasten it with the two screws. Please make sure when replacing the covers that the tabs are pushed under the housing cant.

Maintenance and Replacement

Arrangement of expansion slots in the housing

**CAUTION**

Destruction of expansion card or main board!

The PCI/ISA bus combination slot must never be populated with a PCI board and an ISA board at the same time!

If the card is equipped with a Plug-and-Play (PnP) function, it is automatically recognized by and integrated into the system, provided that this creates no hardware conflicts (IRQ, etc.) with other expansion cards or connected devices.

In the event that subsequent to a system reboot the functions based on the newly added card are not available, there may be several reasons for this:

- The card is not properly seated in the PCI or ISA slot contacts.
- The software driver for the card has **not** been installed or its installation is **faulty**.
- IRQ (interrupt) conflict with other PC hardware components.
- The software for the card has not been installed.

Maintenance and Replacement



CAUTION

Destruction of main board or ISA cards through address conflicts (IRQ, memory access, I/O address)!

Observe the information provided by the card manufacturer. You may have try out new configuration settings in both BIOS and operating system.

Software

9 Software

For the purposes of software loading and data backup a CD-ROM drive and a 3.5" floppy disk drive are required.

Please refer to the documentation of the particular operating system for restoring backup files.

Depending on the intended application, a variety of software programs are installed on the robot controller as shipped from the factory:

- BIOS
- Operating system
- Utilities
- Application software

9.1 BIOS software

The PC requires the BIOS software for its initial boot process to enable it to find and start an operating system which provides a more user-friendly and comfortable platform for running the application software.

The BIOS software on the devices is licensed from the Phoenix company.

9.2 Operating system and utilities

Software	rho4.1/BT155	rho4.1/BT155T	rho4.1/BT205
Operating system Windows NT4.0	●	●	●
UPS utility program UPS _{NT}	●	●	●
ELO touch screen	–	●	–

- = available

Software

9.3 Application software

The following Rexroth application software options are available:

Application	rho4.1/BT155 rho4.1/BT155T rho4.1/BT205
WinSPS PLC programming software	●
WinDP Field bus parameterization for PROFIBUS-DP	●
WinCan Field bus parameterization for CAN-bus	●


● = available

9.3.1 PCI field bus cards

A field bus can be connected with the following bus master expansion cards:

- for PROFIBUS-DP: PCI_BM-DP
- for CANrho or CANopen: PCI_BM-CAN
- for Interbus-S: PCI_BM-IBS

Example: PROFIBUS-DP



Order numbers

10 Order numbers

10.1 rho4.1/BT155, rho4.1/BT155T and rho4.1/BT205

Order numbers for the available options from:

- Various basic devices
- Various rho4.1 real-time cards
- PCI field bus cards

see "Price list rho3, rho4".

10.2 Accessories

Designation		Order no.:	
Power cord 230 V	Length 2.5 m, PC power cable socket cranked	1070 048 937	
PC power cable socket	Cranked for self-installation	1070 912 881	
Mating connector X10	PHG2000 power supply and signals, 14 pin	1070 916 914	
Ethernet cable for connection to programming unit	Crossed: 10BaseT, length	0.15 m	1070 919 187
		2.5 m	1070 919 188
		5 m	1070 919 257
		10 m	1070 918 795
		25 m	1070 918 797
	Uncrossed (connection via HUB): 10BaseT, length	2.5 m	1070 918 793
		5 m	1070 919 258
		10 m	1070 921 384
		25 m	1070 918 796
		Light wave conductor, pre-fabricated	23 cm without strain relief
33 cm without strain relief	1070 917 884		
43 cm without strain relief	on request		
2 m with strain relief	1070 917 885		
5 m with strain relief	1070 917 887		
10 m with strain relief	1070 918 956		
Manual programming unit	PHG2000 incl. 8 m connecting cable	1070 918 443	
	PHG2000EL incl. 8 m connecting cable	1070 919 860	
	Extension cable, by the meter min. 20 m to max. 60 m	1070 919 062	
	Download cable (connection PHG ↔ PC), 5 m	1070 918 830	

Order numbers

Designation		Order no.:
PCI bus master	PCI_BM-DP (PROFIBUS-DP)	1070 078 905
	PCI_BM-CAN (CANrho, CANopen)	1070 080 381
	PCI_BM-IBS (InterBus-S)	1070 080 379
Operating block	Operating block without connecting cable	3842 405 602
	Connecting cable, 1 m	3842 405 555

10.3 Spare parts

Designation		Order no.:
Fuses	6.3 A (5x20), medium time-lag, for 24 VDC power	1070 900 850
	1.25 A (5x20), medium time-lag, for 230 VAC power	1070 900 839
	10 A (5x20), quick-blow, for battery pack	1070 904 575
Rechargeable battery pack	1/2 battery pack for UPS (always order 2 off)	1070 919 399
Hard disk 5 GB with installation frame (cassette)		1070 084 205
LS120/CD-ROM drive unit, kit		1070 084 233
CD-ROM drive incl. IDE40 adapter, single unit		1070 920 530
LS120 floppy disk drive (3.5 in.), single unit		1070 920 410
RAM modules	266 MHz: 64 MB	1070 920 827
	128 MB	1070 920 459

Appendix

A Appendix

A.1 Abbreviations

Abbreviation	Meaning
BAPS3	Movement and sequence programming language, version 3
C:	Drive designation, here drive C (hard disk drive)
CAN	Controller Area Network
DDE	Dynamic Data Exchange
DLL	Dynamic Link Library
EGB	Subassemblies at risk from electrostatic discharge
ESD	Electrostatic discharge Abbreviation for all terms concerning electrostatic discharges, eg ESD protection, ESD hazard
I/O	Input / Output
LCD	Liquid Crystal Display
LED	Light Emitting Diode
MMI	Man-Machine-Interface
OEM	Original Equipment Manufacturer
PCL	PC-programmable logic control
PE	Protective Earth
PHG	Hand-held programmer (Programmier Handgerät)
PLC	Programmable logic controller
ROPS4	Robot programming system for rho4
TCP/IP	Transmission Control Protocol / Internet Protocol
UPS	Uninterruptible Power Supply

Appendix

A.2 Index**Numbers**

- 230/115 VAC power connection, 5–9
- 24 VDC power connection, 5–6
- 24 Vout output, 6–19

A

- Ambient temperature, 2–7
- Application software, 9–2

B

- Backlight switch-off, 7–2
- BIOS software, 9–1

C

- CAN bus, 6–32
- CAN interface, 6–26
- CAPS-Lock, 7–8
- CD-ROM, Connector, 6–20
- COM1, 6–5
- COM1–4, Settings, Operating system, 6–10
- COM2, 6–6
- COM3, 6–7
- COM4, 6–8
- Combi-slot, 2–6
- Connecting cable, X31...X34, 6–23

D

- Data backup, 8–1
- Delay Time, 3–7
- Dimensions, 4–3
 - BT150(T), 4–3
 - BT205, 4–3
- Documentation, 1–7

E

- EMC Directive, 1–1
- EMERGENCY–STOP devices, 1–5
- ESD
 - Electrostatic discharge, 1–6
 - grounding, 1–6
 - workplace, 1–6
- ESD-sensitive components, 1–6
- Ethernet connection, 6–12
- Expansion cards, PCI bus master, 9–2
- Expansion slots, 2–6, 8–20
 - Arrangement, 8–21
- External monitor, 6–13

F

- Floppy disk drive, 1–7
- Front panel, MF2 keyboard connection, 6–15

G

- Grounding bracelet, 1–6

H

- Hard disk drive, 1–7
- hardware, variants, 2–3

I

- Impact resistance, 2–8
- Incremental interface, 6–25
- Insertion strip, 7–9
- Installation, 4–1
- Installation cutout, 4–6
- installed positions, clearances, 4–2
- Interfaces
 - 24 Vout output, 6–19
 - AF_PCI rho, 6–28
 - Battery pack connector, 8–16
 - CAN, 6–26
 - CAN bus, 6–32
 - COM1, 6–5
 - COM2, 6–6
 - COM3, 6–7
 - COM4, 6–8
 - Ethernet, 6–12
 - Expansion Cards, 6–30
 - Incremental for encoder , 6–25
 - LPT1, 6–11
 - LS120/CD-ROM connector, 6–20
 - Measuring sensor, 6–25
 - MF2 keyboard, 6–15
 - Overview, 6–1
 - PCI-rho interface, 6–21
 - PCI_rho card, 6–27
 - PHG2000, 6–24
 - PROFIBUS-DP, 6–18
 - PS/2 keyboard, 6–15
 - PS/2 mouse, 6–17
 - SERCOS interface, 6–28
 - Serial combi-interfaces, 6–22
 - Serial interfaces X33,X34, 6–23
 - USB, 6–8
 - VGA port, 6–13
- Interference suppression, 5–3

Appendix

ISA slot, 8–20

K

Keyboard

- ASCII, number and cursor blocks, 7–6
- Controller, 7–11
- Function key block, 7–5
- Key codes
 - simultaneously pressed keys, 7–13
 - Software download, 7–13
 - Transfer to the 24 Vout output, 7–12
 - Transfer to the PROFIBUS slave station, 7–12
 - Transfer via MF2, 7–11

LED display, 7–4

Scanning front panel keys, 7–11

Special functions, 7–7

Keyboard mouse, 7–7

L

Labels, 7–9

Display

LCD, 7–1

Touch screen, 7–3

LED displays, 7–4

Low-Voltage Directive, 1–1

LPT1 parallel port, 6–11

CD-ROM drive, separate replacement, 8–10

LS120

Connector, 6–20

separate replacement, 8–10

LS120/CD-ROM drive unit, Swap, 8–6

M

Maintenance schedule, 8–1

Measuring sensor input, 6–25

MF2 keyboard connection, 6–15

Modules sensitive to electrostatic discharge. *See*
ESD-sensitive components

Mouse port, 6–17

N

NUM-Lock, 7–8

O

Operating conditions, 2–7

Operating system, 9–1

P

PCI field bus cards, 9–2

PCI slot, 8–20

PCI-CAN card, 6–32

PCI-rho interface

on the connector, 6–21

on the insertion card, 6–27

PCI_BM-CAN card, 6–30

PCI_BM-DP card, PROFIBUS DP, 6–31

PCI_BM-IBS card, InterBus S, 6–31

PE conductor system, 5–2

PE connections, 5–2

PHG2000, 6–24

Pin assignment

COM1 through COM4, 6–5

LPT1, 6–11

Power supply, 5–6

230/115 VAC power supply, 5–9

24 VDC power supply, 5–6

PROFIBUS-DP connector, 6–18

Protection categories, 2–7

PS/2 keyboard port, 6–15

PS/2 mini-DIN to MF2 keyboard adapter, 6–16

PS/2 mouse port, 6–17

Q

Qualified personnel, 1–2

R

Rechargeable battery pack, 2–6, 8–16

Charge cycle, 8–16

Connector, 8–16

Replacement, 8–17

Relative humidity, 2–7

Release, 1–8

Replacement

Backlight, 8–14

Display, 8–14

Hard disk, 8–2

LS120/CD-ROM drive unit, 8–6

of drives separately, 8–10

RS-232 interface, COM1, 6–5

S

Safety instructions, 1–4

Safety markings, 1–3

Safety transformer, 5–7

Screening, 5–2

SERCOS interface, 6–28

Serial combi-interfaces, 6–22

Serial interfaces:, 6–23

Software, 9–1

Spare parts, 1–6

Standard operation, 1–1

Standards, 2–9

Storage temperature, 2–7

System Overview, 2–1

T

Technical data, 2–5

Temperature monitoring, 3–1

Appendix

Temperatures, 2–7

Test activities, 1–5

Touch screen, 7–3

Trademarks, 1–8

U

Uninterruptible power supply

 Functionality, 3–2

 UPS program, 3–5

 Default setting:, 3–10

 Operating and configuration, 3–6

USB, 6–8

Utilities, 9–1

V

Variants, 2–3

VGA port, 6–13

Vibration– resistant, 2–8

Video adapter, CRT, 6–14

X

X10, PCI–rho interface, 6–21

X10_1, Power connection 24 VDC, 5–6

X20, Power connection 230/115 VAC, 5–9

X31, X32, Serial combi–interfaces, 6–22

X33, X34, Serial interfaces:, 6–23

X35, PHG2000 interface, 6–24

X41, Incremental interface, measuring sensor, 6–25

X51, X52, CAN, 6–26

Bosch Rexroth AG
Electric Drives and Controls
P.O. Box 13 57
97803 Lohr, Germany
Bgm.-Dr.-Nebel-Str. 2
97816 Lohr, Germany
Phone +49 (0)93 52-40-50 60
Fax +49 (0)93 52-40-49 41
service.svc@boschrexroth.de
www.boschrexroth.com

