

rho 3

BAPS2

Brief description



Version

105



rho 3

BAPS2

Brief description

1070 073 035-105 (94.12) GB



Reg. Nr. 16149-03

© 1993

by Robert Bosch GmbH,

All rights reserved, including applications for protective rights.
Reproduction or handing over to third parties are subject to our written permission.

Discretionary charge 10.– DM

1. BAPS2

GENERAL	2
PROGRAM STRUCTURE	3
COMPILER STATEMENTS	4
PROGRAM DECLARATIONS	6
SUBROUTINE DECLARATIONS	7
STANDARD CONSTANTS	8
DATA TYPES	9
POINT DECLARATIONS	10
GLOBAL VARIABLES	11
ARRAY DECLARATIONS	12
I/O ARRAY DECLARATIONS	13
CHANNEL DECLARATIONS	14
PROGRAM FLOW CONTROL	16
LOGIC – ARITHMETIC OPERATIONS	18
VALUE ASSIGNMENTS	19
STANDARD FUNCTIONS	20
MOVEMENT INSTRUCTIONS	26
ACTUAL POSITION	28
MEASUREMENT POSITION	29
SPEEDS	30
V / A / D FACTORS	32
SLOPE MODES	33
BELT SYNCHRONIZATION	34
WORKING AREA LIMITS	35
WRITE / READ INTERFACES	36
FILES – I/O (READ)	38
FILES – I/O (WRITE)	39
PARALLEL PROCESSES	40
SPECIAL FUNCTIONS	41
TOOL – DAT	47
FIXED FILES	48

2. BAPSPIC

BAPSPIC–SYNTAX	49
----------------------	----

3. INDEX	53
-----------------------	-----------

GENERAL

This manual provides a summary and brief description of the language instructions available in **BAPS2** and **BAPSPIC**.

Please refer to the **BAPS2** programming instructions for an in–depth description of the individual instructions of **BAPS2**.

PROGRAM STRUCTURE

```

;;CONTROL = RHO3

;;KINEMATICS: ( 1 = ma_1 ,
                2 = ma_2 )

;;ma_1.JC_NAMES = A_1,A_2,A_3,A_4
;;ma_1.WC_NAMES = X_K,Y_K,Z_K,A_K

;;ma_2.JC_NAMES = B_1,B_2,B_3
;;ma_2.WC_NAMES = X_B,Y_B,Z_B

PROGRAM example

;;KINEMATICS = ma_1

EXTERNAL:maon, maoff

INPUT:      1 = partthere,
            2 = slide_forwar

OUTPUT:     1 = belt_on

SPC_FCT:   1 = path_io ( VALUE INTEGER:
                        .
                        .
                        . )

ma_1.POINT : pal_corner1,pal_corner2
ma_2.JC_POINT : @stroke_cent

BEGIN
.
.
    MOVE ma_2 TO @stroke_cent
    sub_example
.
.
.
PROGRAM_END

SUBROUTINE sub_example
    INPUT: 4 = le_shi
    REAL: counter

    BEGIN
    .
    belt_on = 1
    .
SUB_END
    
```

Control type declaration

Number of kinematics with kinematic names (as defined in MPP).

Number of axes and axis names in JC for Kin 1. Number of axes and axis names inWC for Kin 1

Number of axes and axis names in JC for Kin 2. Number of axes and axis names inWC for Kin 2

Program name max. 8-character

All movement instructions and point entries without kinematic entry relate to the kinematic ma_1 (default kinematic).

Declarations for external subroutines or processes.

Declarations for inputs/outputs

Declaration of the special functions

Order of other variable declarations is arbitrary, but they must be in front of **BEGIN**.

Declaring points for different kinematics.

Main program begin

Subroutine call

Main program end

Subroutine identification (max. 12-character)
Declaration part for the subroutine

Subroutine begin

Subroutine end

COMPILER STATEMENTS

Except the instructions **KINEMATICS**, **INCLUDE** and **INT** all compiler instructions must be declared before the program name. Lines containing compiler instructions should have no other characters following the statement.

<pre>;;CONTROL = rho3</pre>	applies as of Version- TO01E	Control type declaration currently available: <p style="margin-left: 100px;">rho3 IQ120 IQ140</p>
<pre>;;DEBUGINFO+ ;;DEBUGINFO -</pre>	applies as of Version TO01I	Compiler statement DEBUGINFO + permits programs to be debugged with the debug system. In the case of DEBUGINFO - , debugging is not possible but the IRD file is smaller and is executed more quickly (default: DEBUGINFO +).
<pre>;;WARNING+ ;;WARNING -</pre>	applies as of Version TO01I	Compiler statement WARNING - suppresses output of warnings to the error file (default: WARNING +).
<pre>;;ERROR = 10</pre>	applies as of Version TO01I	Consequential errors frequently occur during the compiling process, thus very greatly increasing the size of the error file. By defining the maximum number of errors (1...100), this statement can be used to abort the compiling process prematurely when the specified number of errors have been detected. All errors are output without this statement.
<pre>;;KINEMATICS: (1=ma_1, 2=ma_2)</pre>	applies as of Version TO01E	Defines the number of kinematics with the relevant kinematic numbers and kinematic names.
<pre>;;ma_1.JC_NAMES= A_1,A_2</pre>	applies as of Version TO01E	Defines the number of axes and axis names in JC for Kin1. (!!! This statement must be in one line)
<pre>;;ma_1.WC_NAMES= X_C,Y_C</pre>	applies as of Version TO01E	Defines the number of axes and axis names in WC for Kin1. (!!! this statement must be in one line)
<pre>;;PROCESS_KIND=PERMA- NENT</pre>	applies as of Version TO01E	Defining that this program can run as a permanent process. A permanent process runs in operating modes Auto and Manual and is not aborted with Reset etc. (!!! this statement must be in one line)



<pre>;;KINEMATICS = ma_2</pre>	<pre>applies as of Version TO01E</pre>	<p>Changes the default kinematic(the default kinematic is always no. 1 unless otherwise defined in this declaration. (!!! this statement must be in one line)</p>
<pre>;;DRIVE_TYPE (sr_1.A_1 = SM, sr_2.A_1 = SM_CAN)</pre>	<pre>applies as of Version "ECO"</pre>	<p>The drive type is defined. The statement is skipped by the BAPS 2 compiler. It only affects the BAPS–ECO compiler for the BOSCH IQ120 control.</p>
<pre>;;INCLUDE exdat</pre>	<pre>applies as of Version TO01E</pre>	<p>The compiler includes file EXDAT.QLL at this point and generates the IRD code for it. EXDAT.QLL may have no other INCLUDE statements.</p>
<pre>;;INT = PTP ;;INT = LINEAR ;;INT = CIRCULAR</pre>	<pre>applies as of Version TO01E</pre>	<p>Interpolation mode presetting The interpolation mode can be defined by the compiler statement in a program. The default is PTP.</p>
<pre>;;ma_2.INT = PTP ;;ma_2.INT = LINEAR ;;ma_1.INT = CIRCULAR</pre>	<pre>applies as of Version TO01E</pre>	<p>Ditto with kinematic assignment</p>
<pre>;;SER_IO_STOP-</pre>	<pre>applies as of Version TO02F</pre>	<p>The compiler statement can be used to prevent a user program being aborted if an interface error occurs.</p>
<pre>;;SER_IO_STOP+</pre>	<pre>applies as of Version TO02F</pre>	<p>The compiler statement indicates that a user program is to be aborted if an interface error occurs.The default is SER_IO_STOP+.</p>

PROGRAM DECLARATIONS

PROGRAM dana . . .	applies as of Version TO01E	MAIN PROGRAM DECLARATION The program name may have a maximum length of 8 characters. The first character must be a letter. The only special character permitted is the underscore character "_".
BEGIN . PROGRAM_END	applies as of Version TO01E	MAIN PROGRAM BEGIN-END The declaration part is followed by the start of the main program with instruction BEGIN. It ends with the keyword "PROGRAM_END".
BEGIN . HALT PROGRAM_END	applies as of Version TO01E	MAIN PROGRAM-END BY HALT HALT is optional and may occur at several points in the main program. Program execution is stopped (e.g. in the case of decisions IF...THEN...).
EXTERNAL: subrout_name . subrout_name	applies as of Version TO01E	EXTERNAL SUBROUTINE CALLS The names of the external subroutines must be declared before the keyword "BEGIN".
EXTERNAL: subrout_name (VALUE INTEGER : sp,ze, VALUE REAL : de_z) subrout_name (3,2,-50)	applies as of Version TO01E	CALLING EXTERNAL SUBROUTINES with parameter transfer.
PROGRAM subrout_name (VALUE INTEGER: sp,ze VALUE REAL: de_z)	applies as of Version TO01E	PROGRAM DECLARATION with parameter transfer. Can be called as an external subroutine.

SUBROUTINE DECLARATIONS

<p>SUBROUTINE subrout_name BEGIN . SUB_END</p>	<p>applies as of Version TO01E</p>	<p>SUBROUTINE DECLARATION The subroutine name may have a maximum length of 12 characters. The first character must be a letter. The only special character permitted is the underscore "_".</p>
<p>SUBROUTINE subrout_name (VALUE REAL:aw) BEGIN SUB_END</p>	<p>applies as of Version TO01E</p>	<p>SUBROUTINE DECLARATION with parameter-list. If variable 'aw' is modified in subroutine SUBROUTINE_NAME, variable 'oh' is unchanged after the return (see below).</p>
<p>SUBROUTINE subrout_name (REAL:aw) BEGIN SUB_END</p>	<p>applies as of Version TO01E</p>	<p>SUBROUTINE DECLARATION with parameter-list. If variable 'aw' is changed in subroutine SUBROUTINE_NAME, variable 'oh' has the same value after the return (see below).</p>
<p>. subroutine name . .</p>	<p>applies as of Version TO01E</p>	<p>SUBROUTINE CALL A subroutine call can be performed from the main program. A subroutine, in turn, can call another subroutine.</p>
<p>. subroutine name (oh) . .</p>	<p>applies as of Version TO01E</p>	<p>SUBROUTINE CALL with parameter transfer.</p>
<p>RETURN</p>	<p>applies as of Version TO01E</p>	<p>SUBROUTINE-END This can be used optionally if you wish to quit the subroutine at various points.</p>

STANDARD CONSTANTS

WRITE PHG,CLS

applies as of
Version
TO02F

CLEAR SCREEN CLS

You can clear the PHG display by output of "CLS".

**IF VERSION < 2.31
THEN WRITE
'Old compiler version'**

applies as of
Version
TO02F

VERSION

You can scan the version number of the compiler in the BAPS program.

The constant is of the type REAL.

DATA TYPES

POINT: p_name JC_POINT: @p_name	applies as of Version TO01E	Points in world coordinate representation. Points in joint coordinate representation.
ma_1.POINT: kp_name ma_2.JC_POINT: @kp_name	applies as of Version TO01E	Ditto with kinematic assignment.
INTEGER: i_var REAL: r_var	applies as of Version TO01E	Integer values (whole numbers) Decimal (real) floating point
BINARY: b_var	applies as of Version TO01E	Binary variables or I/O signals. There are two states (logical 0 or logical 1).
CHAR: char TEXT: message	applies as of Version TO01E	ASCII characters in accordance with DIN 66003 Character string, e.g. 'SCHOOL'
FILE: danadat	applies as of Version TO01E	This is where the names of the files with extension DAT are declared. Values can be read from or written to DAT files. (See FILES I/O.)
SEMAPHORE: sema_var	applies as of Version TO01E	Variables of type SEMAPHORE are required for the EXCLUSIVE statement.



POINT DECLARATIONS

DEF POINT: d_pnt	applies as of Version TO01E	DEFine points are points stored in a point file. They can be influenced in operating mode 'DEFINE', 'TEACH' and by the BAPS program.
DEF JC_POINT: @d_jcp	applies as of Version TO01E	DEFine joint coordinate points. (see above)
DEF ma_1.POINT: d_pnt DEF ma_1.JC_POINT: @d_pnt	applies as of Version TO01E	Ditto with kinematic assignment.
DEF ARRAY [1..6] POINT:ap	applies as of Version TO01E	DEFine world coordinate points via an array with lower limit and upper limit.
DEF ARRAY [1..6] JC_POINT: @ap	applies as of Version TO01E	DEFine joint coordinate points via an array with lower limit and upper limit.
DEF ARRAY [1..6] ma_1.POINT: ap DEF ARRAY [1..6] ma_2.JC_POINT: @ap	applies as of Version TO01E	Ditto with kinematic assignment.

GLOBAL VARIABLES

Global variables permit simple data exchange between several independent BAPS2 user programs (processes). The underlying idea is that of combining programs operating with the same global variables to form one program group. One program can export data within this group while the other programs of this group may only import these data. Any number of such program groups can be created on the control (restricted only by the available memory space).

Example program

```

;Exporting program
PROGRAM exp_var

;global data
PUBLIC DEF POINT: start_pos
PUBLIC INTEGER: index
PUBLIC
SEMAPHORE: writeprotect

REAL: mvalue

BEGIN
;BAPS statements
EXCLUSIVE writeprotect
start_pos =POS
index=5
EXCLUSIVE_END
;...
;... further statements
;...
PROGRAM_END

;Importing program
PROGRAM imp_var

;global data
EXTERNAL exp_var: start_pos
EXTERNAL exp_var: index
EXTERNAL exp_var: writeprotect

;local data
POINT: end_pos

BEGIN
;BAPS statements
EXCLUSIVE writeprotect
RPT index TIMES

MOVE TO start_pos
MOVE TO end_pos
RPT_END
EXCLUSIVE_END
;
PROGRAM_END

```

applies as of
Version
TO02F

Declaration part in the **exporting program**:

Global variables are declared by adopting the reserved word **PUBLIC** in the type declaration of these variables. The data range for these variables is reserved in the IRD file. Teach points (e.g. identified by the keyword **DEF**) are stored in the PNT file.

Declaration part in the **importing program**:

The variables can be accessed by other BAPS programs if the variables are declared with **EXTERNAL** and the name of the exporting program.

Restrictions

The following restrictions must be taken into consideration when using global data:

1. The exporting program of a program group must have been compiled before the importing programs of this group (because of the type checking of the compiler), i.e. the user must ensure that the importing programs are 'more recent' than the exporting program. If this is not the case, an error message or a warning is issued at the start of the program.
2. In a program, it is not possible to import and export data simultaneously.
3. Data may be imported only from one program.
4. Global data may be exported or imported only in the declaration part of the main program, and not in the subroutines.
5. Access to the variables must be prevented by use of the **EXCLUSIVE** statement before interruption in order to guarantee data consistency. The consistency of simple standard types such as **BINARY**, **INTEGER**, **REAL**, **CHAR** is provided by the operating system.

ARRAY DECLARATIONS

Arrays are data structures consisting of a fixed number of elements of the same type. The lower and upper limits are specified in square brackets. The data type is specified after the square brackets. The array limits are monitored for the following range when declaring arrays of any element type: [– 8388608... 8388607].

ARRAY [1..6] POINT: ap ARRAY [1..6] JC_POINT: @ap	applies as of Version TO01E	Array of type POINT/JC_POINT
ARRAY [1..6] ma_2.POINT: ap ARRAY [1..6] ma_1.JC_POINT: @ap	applies as of Version TO01E	Ditto with kinematic assignment
ARRAY [1..6] CHAR: az ARRAY [21..36] TEXT: at	applies as of Version TO01E	Array of type CHAR and TEXT
ARRAY [1..6] INTEGER: ai ARRAY [21..36] REAL: ar	applies as of Version TO01E	Array of type INTEGER and REAL
ARRAY [1..6] BINARY: ab	applies as of Version TO01E	Array of type BINARY
ARRAY [1..4] ARRAY [1..2] INTEGER: a2dimi a2value = a2dimi [1] [2]	applies as of Version TO01E	Two–dimensional array of type INTEGER Access to the field components

I/O ARRAY DECLARATIONS

<p>ARRAY [1..2] OUTPUT BINARY: (1,32) = o_sen_F1</p>	<p>applies as of Version TO01E</p>	<p>Array of type OUTPUT BINARY</p>
<p>ARRAY [11..14] INPUT BINARY: (5,6,7,22) = i_sen_F2</p>	<p>applies as of Version TO01E</p>	<p>Array of type INPUT BINARY</p>
<p>ARRAY [1..3] OUTPUT INTEGER: (401,402,403) = oi_sen_F3</p>	<p>applies as of Version TO01E</p>	<p>Array of type OUTPUT INTEGER</p>
<p>ARRAY [11..13] INPUT INTEGER: (401,404,408) = ii_sen_F4</p>	<p>applies as of Version TO01E</p>	<p>Array of type INPUT INTEGER</p>
<p>ARRAY [1..2] OUTPUT REAL: (201,202) = or_sen_F5</p>	<p>applies as of Version TO01E</p>	<p>Array of type OUTPUT REAL</p>
<p>ARRAY [11..12] INPUT REAL: (201,203) = ir_sen_F6</p>	<p>applies as of Version TO01E</p>	<p>Array of type INPUT REAL</p>

I/O arrays may be declared only in one dimension.



CHANNEL DECLARATIONS


INPUT BINARY: 2 = gr_force
OUTPUT BINARY: 9 = magnet

applies as of
Version
TO01E

The names of the USER INPUTS/OUTPUTS are declared. The names may not be BAPS keywords. Entry "BINARY" may be omitted since BINARY is the default type.
(Permitted channel number: 1..120, 6xy with high speed inputs)

Structure of the high speed input number:

6 x y



INPUT INTEGER:
 401 = decade
OUTPUT INTEGER:
 403 = lcd_display

applies as of
Version
TO01E

The names of the INTEGER USER INPUTS/OUTPUTS are declared. These are output on the interface with a width of 8 BITS (significance 0–255).
(Permitted channel number: 401..408)

INPUT REAL: 201 = poti_1
OUTPUT REAL: 203 = v_pressure

applies as of
Version
TO01E

The names of the REAL USER INPUTS/OUTPUTS are declared.
(Permitted channel number: 201..299)

BELT: 501 = belt1_ma1
 ma_2.BELT: 502 = belt2_ma2

applies as of
Version
TO01E

The names of the belts are declared.
(Permitted channel number: 501..508)

Asynchronous inputs:

The declaration of asynchronous inputs is made by adding an offset of **1000** to the channel number.

INPUT BINARY:1002 = gr_force

applies as of
Version
TO01E

The names of the asynchronous INPUTS are declared. The names may not be BAPS keywords. Entry "BINARY" may be omitted since BINARY is the default type.

(Permitted channel number: 1001..1020)

INPUT INTEGER:1401 = decade

applies as of
Version
TO01E

The names of the integer-asynchronous INPUTS are declared.

(Permitted channel number: 1401..1408)

INPUT REAL:1201 = poti_1

applies as of
Version
TO01E

The names of the real-asynchronous INPUTS are declared.

(Permitted channel number: 1201..1299)

PROGRAM FLOW CONTROL

WAIT 5.5	applies as of Version TO01E	Program execution is stopped for the specified period. The constant (5.5) indicates the time in seconds.
REAL: dwell_time dwell_time = 5.5 WAIT dwell_time	applies as of Version TO01E	A variable may also be used instead of a constant. This variable must have been declared beforehand as a REAL or INTEGER variable. This variable must be assigned a value before it is used.
INPUT: 4 = part_there WAIT UNTIL part_there = 1	applies as of Version TO01E	WAIT for a condition to occur. (Only scanning inputs is permitted in the condition.)
INPUT: 5 = sig WAIT UNTIL sig = 0 MAX_TIME = 5.6 ERROR statement1	applies as of Version TO01E	WAIT for a condition to occur with a time limit. If the time has elapsed, the instruction ERROR statement1 is executed. If the condition is fulfilled in the max. time, the error is skipped and the next BAPS instruction is executed.
PAUSE	applies as of Version TO01E	Program execution is stopped. The program is continued with the interfacesignal "RC-START"
REPEAT 5 TIMES . . REPEAT_END	applies as of Version TO01E	A fixed number of program runs is executed between the two instructions.
INTEGER: number number = 5 REPEAT number TIMES ... REPEAT_END	applies as of Version TO01E	A fixed number of program runs is executed between the two instructions.
IF condition THEN statement1 ELSE statement2	applies as of Version TO01E	CONDITIONAL STATEMENT If the condition is fulfilled, the control executes statement 1. If the condition is not fulfilled, statement 2 is executed (after ELSE).



```

IF in1 = 1 THEN
  BEGIN
    out36 = 0
    out01 = 1
  .
  END
ELSE BEGIN
  .
  END

```

applies as of
Version
TO01E

BEGIN ... END compound
Several statements can be combined by means of compound statements at points at which only one single statement may occur.

```

JUMP label_1
.
.
label_1:

```

applies as of
Version
TO01E

It is possible to jump to labels within main programs or subroutines. Forward and backward jumps are possible.

```

INTEGER: magnitude,offset
BEGIN
  magnitude=0
  offset=0

  READ magnitude
  CASE magnitude
    EQUAL 9,10 : offset=0
    EQUAL 11,12 : offset=1
    EQUAL 13 : offset=2
    DEFAULT offset=5
  CASE_END
.
.
PROGRAM_END

```

applies as of
Version
TO03B

Using the branch statement "CASE", it is possible to implement a selection from several alternatives. Nested "IF – THEN" scans can thus be avoided and the program execution time can be shortened.

LOGIC – ARITHMETIC OPERATIONS

+ - * /	applies as of Version TO01E	Arithmetic operations (addition, subtraction, multiplication, division)
SIN COS	applies as of Version TO01E	Standard functions (Sine, cosine)
ATAN	applies as of Version TO01E	Standard functions (arc tangent)
SQRT	applies as of Version TO01E	Standard functions (\sqrt{x})
MOD	applies as of Version TO01E	Arithmetic operations (Modulo calculation corresponds to: dividing a number and using only the remainder)
AND OR NOT	applies as of Version TO01E	Logic operations
< , > <= , >= <> =	applies as of Version TO01E	Comparison operations (less than, greater than, equal to or less than, equal to or greater than not equal to, equal to)

VALUE ASSIGNMENTS

<p>variable = expression</p>	<p>applies as of Version TO01E</p>	<p>An assignment assigns a new value to a variable. This value must have a type compatible with the variable type.</p>
<p>p1 = (0,0,-50.123,0) @p1 = @(0,0,-19.4,0)</p>	<p>applies as of Version TO01E</p>	<p>POSITION ASSIGNMENT. Complete value assignment of a world and joint coordinate point. The number of components is equal to the number of axes of the kinematic.</p>
<p>REAL: z_value z_value = -50.0 p1 = (0,0,z_value,0)</p>	<p>applies as of Version TO01E</p>	<p>Value assignment of a point via variables.</p>
<p>z_axis.Z_C = 31.2 p1 = (0,0,z_axis.Z_C,0)</p>	<p>applies as of Version TO01E</p>	<p>AXIS ASSIGNMENT The axis name is used for the component value assignment.</p>
<p>INTEGER: i i = 0 i = i+1</p>	<p>applies as of Version TO01E</p>	<p>The value assignment can be used for all data types (e.g. REAL, INTEGER, etc.) and for all standard variables (e.g. V_PTP, A, VFACTOR, AFACTOR etc.).</p>
<p>CONST: yellow = 0, white = 1, blue = 4, red = 3 INTEGER : color</p>	<p>applies as of Version TO03B</p>	<p>CONSTANTS. Constants are defined before the variables of a program.</p>

STANDARD FUNCTIONS

INTEGER: i1 REAL: r1 r1 = TRUNC (12.58) i1 = TRUNC (1.32)	applies as of Version TO01E	Truncating the positions after the decimal point with assignment of an INTEGER number or variable or REAL number or variable.
INTEGER: i1, it REAL: r1, rt rt = ABS (r1) rt = ABS (i1) rt = ABS (i1)	applies as of Version TO01E	Absolute value generation of INTEGER or REAL variables or numbers.
REAL: r1 INTEGER: i1 r1 = ROUND (10.51) i1 = ROUND (1.32)	applies as of Version TO01E	Assignment of a REAL number or variable to an INTEGER or REAL variable with rounding. (> 0.5 is rounded up, < = 0.5 is rounded down).
INTEGER: varo1 varo1 = ORD ('a')	applies as of Version TO02A	Standard function ORD converts an ASCII character to an INTEGER value (in this example: varo1 = 97).
INTEGER: varo2, varo3 CHAR: c_var ARRAY[1..8] CHAR: txt txt = 'pRima__' varo2 = ORD (txt [2]) c_var = 'a' varo3 = ORD (c_var)	applies as of Version TO02A	ORD with arrays (in this example: txt[2] = 'R' varo2 = 82). ORD with character (in this example: varo3 = 97).
INTEGER: varc1 varc1 = CHR (97) varc1 = CHR (80 + 17)	applies as of Version TO02A	Standard function CHR converts an INTEGER value to an ASCII character. The displayable character depends on the character set used (in this example: varc1 = 'a').
CHAR: c_varc2 ARRAY[1..3] INTEGER: ainteger ainteger [2] = 97 c_varc2 = CHR(ainteger[2])	applies as of Version TO02A	The value range of CHR (X) should be between 0 and 255. No range check is conducted. The function argument is converted as follows internally for values outside this range: $X = (X \text{ MOD } 256)$ (in this example: c_varc2 = 'a')

```

INTEGER: int_number
INTEGER: index_ca
INTEGER: length_char
INTEGER: error_rue
ARRAY[1..10]
    CHAR: ascii_array
    
```

```

int_number = -1234
index_ca = 1
length_char = 5
    
```

```

INT_ASC
(int_number,
ascii_array,
index_ca,
length_char,
error_rue)
    
```

```

IF
  error_rue <> 0
THEN
  WRITE 'error in
  INTEGER-ASCII conversion'
ELSE
  WRITE ascii_array
    
```

applies as of
Version
TO02A

The standard procedure **INT_ASC** converts an integer number to an array of characters.

Note:

The format is right justified with leading blanks.

If an error is detected during conversion process, the 'character array' remains unchanged and the corresponding error code is returned.

```

----- PRESET -----
int_number = number to be converted
              ( only type INTEGER permitted
              | int_number | < =2147483647)
    
```

```

----- RESULT ACKNOWLEDGMENT -----
ascii_array = Result array of
              Type ARRAY [ ] char
              (The destination area is initialized
              with blanks before conversion)
    
```

```

----- PRESET -----
index_ca = Start index in the character array
    
```

```

----- PRESET -----
length_char = Maximum number of charac
              ters reserved for the number to be
              converted
    
```

```

----- RESULT ACKNOWLEDGMENT -----
error_rue = Error number output
    
```

0	No errors
-1	Start index outside array limits
-2	End index (start index + length) outside array limits
-3	Reserved length too small
-4	Range transgression (value too big)
-5	Array length < 0
-6	Array length = 0

```

INTEGER: int_number
INTEGER: index_ca
INTEGER: length_char
INTEGER: error_rue
ARRAY [1..10]
CHAR: ascii_array

ascii_array = 'AaBc'
index_ca = 1
length_char = 5

ASC_INT
(ascii_array,
int_number,
index_ca,
length_char,
error_rue)

IF
error_rue <> 0
THEN
WRITE 'error in
ASCII-INTEGER conver
sion'
ELSE
WRITE int_number
    
```

applies as of
Version
TO02A

The standard procedure **ASC_INT** converts an array of characters to an integer. The procedure reads in characters as of the start position until:

- a character which is not a digit is detected
- the maximum number of characters has been read
- the end of the character array is reached

----- PRESET -----
 ascii_array = array of type ARRAY [] char
 to be converted

---- RESULT ACKNOWLEDGMENT ----
 integer_number = converted number
 (only type INTEGER permitted)

----- PRESET -----
 index_ca = Position in the array as of which
 the number is to be read

----- PRESET -----
 length_char = Maximum number of
 characters to be read

---- RESULT ACKNOWLEDGMENT ----
 error_rue = Error number output

0	No errors
-1	Start index outside the array limits
-2	End index (start index + length) lies outside the array limits
-3	-----
-4	Range transgression (value too high)
-5	Array length < 0
-6	Array length = 0
-7	Character string does not start with a number or sign

<p>@pa = JC (ph) @p1 = JC (22) + @p3</p>	<p>applies as of Version TO01E</p>	<p>Conversion from world coordinates to joint coordinates.</p>
<p>pos_a = WC (@pal) pos_1 = p3 + WC (@p4)</p>	<p>applies as of Version TO01E</p>	<p>Conversion from joint coordinates to world coordinates.</p>
<p>R = 50 MOVE LINEAR TO p1</p>	<p>applies as of Version TO02F</p>	<p>Global passing radius. "R" acts in the case of LINEAR interpolation (acts kinematic-specifically)</p>
<p>MOVE LINEAR WITH R= 20 TO p1</p>	<p>applies as of Version TO02F</p>	<p>Statement-specific passing radius "R" acts in the case of LINEAR interpolation (acts kinematic-specifically)</p>
<p>R_PTP= 1.4 ;(or R_PTP=140%) MOVE PTP VIA p2</p>	<p>applies as of Version TO02F</p>	<p>Global passing factor "R_PTP" acts in the case of PTP interpolation (acts kinematic-specifically) R_PTP is multiplied with the value of P213</p>
<p>R_PTP= 1.4 ;(or R_PTP=140%) MOVE PTP WITH R_PTP =0.5 VIA p2</p>	<p>applies as of Version TO02F</p>	<p>Statement-specific passing factor. "R_PTP" acts in the case of PTP interpolation (acts kinematic-specifically)</p>

If R = 0 or R_PTP = 0 is programmed, Spatial passing movement is deactivated.

```

PROGRAM io_test

EXTERNAL: procname
INTEGER: index,number,
         status
FILE: fina

CONST:
    textconst = 'I85.7'
    txbyconst = 'I13'

BEGIN

number=0
READ V24_1, index
IF CONDITION(V24_1)
  < 0 THEN
WRITE 'Read error'

status=
  CONDITION(fina)

status=
  CONDITION(procname)

status=
  CONDITION('I0.0')

status=
  CONDITION('I0')

status=
  CONDITION(textconst)

status=
  CONDITION(txbyconst)

PROGRAM_END

```

applies as of
Version
TO02F

Standard function CONDITION permits:

1a. The status of an interface to be determined.

V24_1 ... V24_4,PHG,TTY are supported

Function value:

0	no errors
-1	Interface not found
-2	Interface blocked
-3	Timeout
-4	Parity error
-5	Overrun error
-6	Framing error
-7	Interface error
-8	Wrong string length
-9	Protocol error
-10	Illegal REAL value
-11	Point not defined

1b. The status of a file to be determined.

CONDITION (*filename*) checks, if the specified file exists.

Function value:

0	specified file does not exist
1	specified file exists

applies as of
Version
TO04J

2. To get the status of processes.

The name of the process must be declared with EXTERNAL 'processname'.

Function value:

-1	process does not exist
0	process is holding
1	process is running
2	process is waiting
3	process is ready
11	1 sub process of main process procname is active
12	2 subprocesses are active
13	3 sub processes are active
10+n	n sub proc. active (n=1..90)
>100	process error error code=func.-value -100

applies as of
Version
TO04J

3. To get the status of system signals (inputs and outputs).

There are two ways possible:

1. The address of the signal to be test can be used directly as parameter. Example:
'Ox.y', 'Ix.y'

2. The address of the signal is a CONST (of type text). Same for an input byte.

Function value:

0/1	status of a signal "0" or "1"
0..255	status of a byte
-1	invalid signal group
-2	invalid bit address
-3	invalid character
-4	invalid signal address



```

PROGRAM progname
FILE:filevar
TEXT:filename,one_line,
channel_var

BEGIN
WRITE PHG,CLS
WRITE PHG,'file name:'
READ PHG, filename
ASSIGNfilevar,filename

READ_BEGIN filevar
READ filevar,one_line
WRITE one_line
CLOSE filevar

channel_var = 'V24_2.'
ASSIGN PHG, channel_var
WRITE PHG, one_line
ASSIGN PHG,'PHG.'

PROGRAM_END

```

applies as of
Version
TO04J

The BAPS command ASSIGN makes it possible to change the names of files or to change the assignment of standard channels (V24_1..V24_4, SER_1..SER_4, PHG) at the runtime of a BAPS program.

Clears display of PHG

Read *filename* from the PHG
Assign the contents of *filename* to *filevar*. Following file I/O uses the file specified by *filevar*.

Open file for read
Read a line from the file and writes it on the PHG, then close the file.

note:
when ASSIGN is used with files, it is necessary to close the files before using **ASSIGN** with these files

assigns channel PHG to the content of channel_var (V24_2), writes *one_line* to channel V24_2 and assigns PHG back to channel PHG

note:
it is important to write the character '.' as limitation of channel names. If you omit the point '.', assignment is done to a filename (extension DAT), e.g. PHG.DAT

MOVEMENT INSTRUCTIONS

REF_PNT (3) REF_PNT (1,2,3,...)	applies as of Version TO01E	REFERENCE POINT TRAVEL Those axes that are to travel simultaneously to the reference point are specified in brackets. This should be the first command used in the INIT program. The default kinematic is moved.
REF_PNT ma_1 (3) REF_PNT ma_2 (1,2,3,...)	applies as of Version TO01E	REFERENCE POINT TRAVEL with kinematic entry
MOVE fetchpos MOVE @fetchpos	applies as of Version TO01E	MOVE ABSOLUTE This movement instruction traverses the robot in world or joint coordinates (default kinematic).
MOVE ma_2 fetchpos MOVE ma_1 @fetchpos	applies as of Version TO01E	MOVE ABSOLUTE with kinematic entry.
MOVE fetch + up MOVE @fetch + @up	applies as of Version TO01E	As for Move absolute, but the position is computed beforehand and, only then, the system moves.
MOVE ma_2 fetch + up MOVE ma_1 @fetch + @up	applies as of Version TO01E	Ditto with kinematic entry.
MOVE_REL down MOVE_REL @down	applies as of Version TO01E	MOVE INCREMENTAL The robot can be advanced by a distance (in mm) or an angular distance (in degrees) from the current position (default kinematic).
MOVE_REL ma_2 down MOVE_REL ma_2 @down	applies as of Version TO01E	Ditto with kinematic entries
MOVE_REL down + distance_z MOVE_REL @down + @distance_z	applies as of Version TO01E	As for Move incremental, but the position is computed beforehand, and only then, the system moves. (default kinematic)

MOVE_REL ma_2 down + distance_z MOVE_REL ma_2 @down + @distance_z	applies as of Version TO01E	Ditto with kinematic entries
MOVE TO pos1 MOVE_REL EXACT stre	applies as of Version TO01E	Move to points EXACT (with brief axis stop).
MOVE p1,p2,p3	applies as of Version TO01E	Move EXACT to several points (with brief axis stop).
MOVE VIA @palpos MOVE_REL APPROX home	applies as of Version TO01E	Move to points WITHOUT EXACT HALT.
MOVE UNTIL force = 1 TO hole_5	applies as of Version TO01E	ABORT MOVEMENT Movement occurs in direction hole_5 until hole_5 is reached or until condition (FORCE=1) is fulfilled.
MOVE UNTIL force = 1 ERROR pause TO hole_5	applies as of Version TO01E	ABORT MOVEMENT Movement occurs in direction hole_5 until the condition (FORCE=1) is fulfilled. If the destination position is reached and the condition is not fulfilled, the instruction after ERROR is executed
MOVE PTP @pos_door MOVE_REL PTP palpos	applies as of Version TO01E	MOVE POINT-TO-POINT in joint or world coordinates. The control moves synchronously PTP, i.e. all axes start and finish at the programmed point at the same instant.
MOVE LINEAR TO a_z MOVE_REL LINEAR APPROX up	applies as of Version TO01E	LINEAR INTERPOLATION The points are connected by an exact straight line (path), if the working area permits.
MOVE CIRCULAR (hi_put,end_put) MOVE_REL CIRCULAR (@pos1,@pos2)	applies as of Version TO01E	CIRCULAR INTERPOLATION Circular interpolation permits movement in circular arcs. One pair of points is always required so that the control can compute the circular arc size.



ACTUAL POSITION

```

posi = POS
IF posi.X_C > 300
THEN posi.X_C = 300
MOVE TO posi

```

applies as of
Version
TO01E

ACTUAL POSITION

The current position of the robot can be read with the aid of POS, and it is thus available to the program for further evaluation (default kinematic)

```

posi = ma_2.POS
IF posi.X_C > 300
THEN posi.X_C = 300
MOVE TO posi

```

applies as of
Version
TO01E

ACTUAL POSITION

Ditto with kinematic entries

```

@current = @POS

```

applies as of
Version
TO01E

The actual position can also be read in JC (joint coordinates). (Default kinematic)

```

@current = ma_1.@POS

```

applies as of
Version
TO01E

The actual position can also be read in JC with kinematic entries.



MEASUREMENT POSITION

@p1 = @MPOS

@p1 = ma_1.@MPOS
p1 = WC(ma_1.@MPOS)

applies as of
Version
TO02A

The component @MPOS contains the measurement position which can be determined with the high-speed inputs on the servo card with high accuracy. @MPOS acts only in the joint coordinate system but may be converted with the standard function WC.

SPEEDS

V_PTP = 80% V_PTP = 0.8	applies as of Version TO01E	POINT-TO-POINT SPEED The global PTP speed is written in one block on its own. It acts until it is overwritten by another speed (acts on the default kinematic).
ma_1.V_PTP = 80% ma_2.V_PTP = 0.8	applies as of Version TO01E	Ditto with kinematic entries. Acts only on the specified kinematic
V = 800	applies as of Version TO01E	PATH SPEED The global path speed acts on linear and circular movements of the default kinematic.
ma_1.V = 800	applies as of Version TO01E	Ditto with kinematic entries
A = 765	applies as of Version TO01E	PATH ACCELERATION The path acceleration acts only on linear and circular movements and not on PTP movements.
ma_1.A = 765	applies as of Version TO01E	Ditto with kinematic entries
MOVE PTP WITH V_PTP = 30% TÖ home	applies as of Version TO01E	LOCAL PTP SPEED The local PTP speed acts only in a MOVE (or Move_REL.) block. After this the global speed becomes active again.
MOVE ma_2 PTP WITH V_PTP = 30% TÖ home	applies as of Version TO01E	Ditto with kinematic entries
MOVE LINEAR WITH V = 2000 TO edge	applies as of Version TO01E	LOCAL PATH SPEED The local path speed acts only in this block. It must be entered in mm/s.

<p>MOVE ma_2 LINEAR WITH V = 2000 TO edge</p>	<p>applies as of Version TO01E</p>	<p>Ditto with kinematic entries</p>
<p>MOVE PTP WITH VFIX_PTP = 0.8 TO @pos_up</p>	<p>applies as of Version TO01E</p>	<p>Local point-to-point speed (block-by-block) without VFACTOR active (i.e. VFACTOR = 100%).</p>
<p>MOVE ma_1 PTP WITH VFIX_PTP = 0.8 TO @pos_up</p>	<p>applies as of Version TO01E</p>	<p>Ditto with kinematic entries.</p>
<p>MOVE LINEAR WITH VFIX = 300 VIA pal_pos_down</p>	<p>applies as of Version TO01E</p>	<p>Local path speed (block-by-block) without effect of the VFACTOR (i.e. VFACTOR = 100%).</p>
<p>MOVE ma_2 LINEAR WITH VFIX = 300 VIA pal_pos_down</p>	<p>applies as of Version TO01E</p>	<p>Ditto with kinematic entries.</p>
<p>AFIX = 300</p>	<p>applies as of Version TO01E</p>	<p>PATH ACCELERATION without AFACTOR ac- tive (= 100%). This statement is also possible only locally in the MOVE instruction for LIN- EAR and CIRCULAR (as VFIX above).</p>
<p>MOVE WITH T = 2.35 TO destpos</p>	<p>applies as of Version TO01E</p>	<p>TIME INPUT (in seconds) The next position is to be approached within a specific period. (Only local programming pos- sible.)</p>
<p>MOVE ma_2 WITH T = 2.35 TO destpos</p>	<p>applies as of Version TO01E</p>	<p>Ditto with kinematic entries.</p>



V / A / D FACTORS

VFACTOR = 100% VFACTOR = 1	applies as of Version TO01E	SPEED-FACTOR The PTP speed and the tool path feedrate can be influenced with the VFACTOR. The VFACTOR can also be modified via the PHG (acts on the default kinematic).
ma_1.VFACTOR = 100% ma_2.VFACTOR = 1	applies as of Version TO01E	Ditto with kinematic entries. Acts only on the specified kinematic.
AFACTOR = 100% AFACTOR = 1 DFACTOR = 100% DFACTOR = 1	applies as of Version TO01E	ACCELERATION and DECELERATION These factors influence the tool path accelerations and the stored PTP axis accelerations. (Only above the slope point in the case of ramp slope.)
ma_1.AFACTOR = 100% ma_2.DFACTOR = 1	applies as of Version TO01E	Ditto with kinematic entries. Acts only on the specified kinematic.

SLOPE MODES

MOVE WITH TFIX = 2.35 TO destpos	applies as of Version TO01E	Time input without VFACTOR active (=100%).
MOVE ma_2 WITH TFIX = 2.35 TO destpos	applies as of Version TO01E	Ditto with kinematic entries
PROGR_SLOPE	applies as of Version TO01E	Global switchover to the program slope. No downslope (setpoint = 0 V) is executed between several 'MOVE VIA' blocks. A 'MOVE TO' statement executes a down- slope (acts on the default kinematic).
;; KINEMATICS = ma_2 PROGR_SLOPE	applies as of Version TO01E	Ditto. If a kinematic other than the default ki- nematic is to be switched over, this must be set beforehand as the default kinematic.
BLOCK_SLOPE	applies as of Version TO01E	Global switchover to the block slope. A down- slope (setpoint = 0 V) is also executed bet- ween 'MOVE VIA' blocks.
;; KINEMATICS = ma_2 BLOCK_SLOPE	applies as of Version TO01E	Ditto with kinematic entry (see above). See rho3 machine parameters

BELT SYNCHRONIZATION

The synchronization statements ensure that the controlled machine assumes the correct position and orientation with respect to the belt. The belt may move forwards and backwards, change its speed or stop as required.

The belt must be a "straight line". This line may be arbitrarily positioned in space.

ma_1.BELT: 501 = belt_kin1	applies as of Version TO01E	DECLARATION OF THE BELT VARIABLES. Several belts can be declared for a kinematic. The belt names must be different. The same belt can be used for several kinematics.
SYNC belt_kin1 >= 10.0 SYNC BELT, light = 1	applies as of Version TO01E	Belt counter is reset. Resetting may be dependent upon the current value of the belt variables themselves or upon a condition (see SPC_FCT 28).
SYNCHRON ma_1 belt_kin1	applies as of Version TO01E	Instruction SYNCHRON activates belt synchronization. From this point on, the programmed movements are synchronized with the belt as regards position and orientation. The kinematic entry is optional.
SYNCHRON_END ma_1 belt_kin1	applies as of Version TO01E	Instruction SYNCHRON_END deactivates belt synchronization. The kinematic entry is optional; if it is omitted, the default kinematic is used.

WORKING AREA LIMITS

```
LIMIT_MIN =  
  (x_value, ..., u_value)  
  
LIMIT_MAX =  
  (x_value, ..., u_value)  
  
LIMIT_OFF
```

applies as of
Version
TO01E

Minimum and maximum values for working area limits. These values are always world coordinate positions.

Cancellation of the working area limits.

```
ma_1.LIMIT_MIN =  
  (x_value, ..., u_value)  
  
ma_1.LIMIT_MAX =  
  (x_value, ..., u_value)  
  
LIMIT_OFF ma_1
```

applies as of
Version
TO01E

Working area limits with kinematic entries.

WRITE / READ INTERFACES

The WRITE/READ operations in BAPS2 are performed on so-called logical devices to which specific transmission protocols are assigned by default and by machine parameters. Assignment to a physical interface is also performed via machine parameters. This permits flexible use of the interfaces on the control.

PHG	applies as of Version TO01E	SERIAL INTERFACE. Permanently assigned to the hand-held programming unit PHG3.
V24_1 V24_2 V24_3 V24_4	applies as of Version TO01E	SERIAL INTERFACES. See Default via PHG/machine parameters for the logical and physical assignment.

Various communication protocols are available for communication. These can be selected via machine parameter (default) or via mode 9.1 using the PHG.

P- No.	Protocol structure	Read Echo
1 a	<DATA> followed by <CR><LF>	yes
1 b	<DATA> followed by <CR> oder <LF>	
2	<DATA>	yes
3	<SOH><STX><DATA><ETX> followed by <SOH><STX><CR><LF><ETX>	no
4	<SOH><STX><DATA><ETX>	no
5	<DATA>	no
6	PHG – Protocol	yes
7	rho1 / rho2 compatible with P.No. 3	no
8	Data protection layer of the Siemens-Protocol 3964/R	no

1a = Data-Input
 1b = Data-Output

<p>WRITE V24_1,POS WRITE PHG, 'Number', i</p>	<p>applies as of Version TO01E</p>	<p>It is possible to write variables and texts from the BAPS program to the interface V24_1, V24_2, V24_3, V24_4 and PHG.</p>
<p>ARRAY[1..70] CHAR: F1_CHAR WRITE F1_CHAR ARRAY[1..4] ARRAY[1..50] CHAR: F2_CHAR WRITE F2_CHAR [1]</p>	<p>applies as of Version TO02C</p>	<p>It is possible to write variables, texts and one-dimensional arrays from the BAPS program to the interface V24_1, V24_2, V24_3, V24_4 and PHG. Note: If a BAPS program has to communicate via an interface which is used by ROPS3, the ROPS3-rho3 communication has to be deactivated before.</p>
<p>WRITE PHG, '<-[J', ...</p>	<p>applies as of Version TO01E</p>	<p>Clear PHG display <- corresponds to the control character of ESC (See chapter STANDARD CONSTANTS "CLS")</p>
<p>WRITE PHG, '<-[K', ...</p>	<p>applies as of Version TO01E</p>	<p>Clear to end of line on the PHG display (<- corresponds to the control character of ESC)</p>
<p>WRITE PHG, '<-[line;columnH', ...</p>	<p>applies as of Version TO01E</p>	<p>Position the cursor to line and column on the PHG display. (The H is required as the end character for the column) (<- corresponds to control character of ESC)</p>
<p>READ M READ V24_2, M</p>	<p>applies as of Version TO01E</p>	<p>It is possible to read variables and texts from the interfaces V24_1, V24_2, V24_3, V24_4 and PHG, starting from the BAPS program.</p>

FILES – I/O (READ)

FILE: fina	applies as of Version TO01E	Type declaration for ASCII files which are to permit read and/or write access within a BAPS program. (E.g. in this case, access to FINA.DAT)
FILE: fina READ_BEGIN fina, 5	applies as of Version TO01E	Positioning the READ pointer to the start of a defined line of the given file (in this case, the fifth line in file FINA.DAT). The pointer is positioned to line 1 if the line entry is omitted.
FILE: fina INTEGER: otto READ fina, otto	applies as of Version TO01E	The first value is read from the file (in this case: FINA.DAT) as of the positioned line, and is stored into the variable (e.g. OTTO). The invisible READ pointer is advanced by one position.
FILE: fina IF END_OF_FILE (fina) THEN_JUMP finished finished: ...	applies as of Version TO01E	This function permits interrogation of whether the file end has been reached (e.g. FINA.DAT).
BNR_FILE: fina	applies as of Version TO05G	Type declaration of BINARY-files which are to permit read and/or write access within a BAPS program. (E.g. in this case, access to FINA.BIN)

FILES – I/O (WRITE)

```
FILE: danadat
INTEGER: number

number = 1

WRITE_BEGIN
  danadat, 1

WRITE_BEGIN
  danadat, number
```

applies as of
Version
TO01E

The write pointer is positioned to the start of a specific line in the specified file (e.g. danadat.DAT).

note:

old data, existing behind the declared line number are deleted

```
FILE: danadat
REAL: rslt
TEXT: display

display = 'the result:'

WRITE danadat,
  display, rslt
```

applies as of
Version
TO01E

The contents of the variables are written to the specified file. The write position is the position to which the write pointer is pointing.

note:

data behind the write pointer are deleted

```
FILE: danadat

WRITE_END
  danadat
```

applies as of
Version
TO01E

The write pointer is set to the end of the file. The file is extended (appended) at the end with the next WRITE instruction.

```
FILE: danadat

CLOSE danadat
```

applies as of
Version
TO01E

A DAT file must always be closed after writing before it can be read. (The DAT file is closed automatically at the end of the program).

PARALLEL PROCESSES

PARALLEL PROCESSES (EXTERNAL)

```

..
EXTERNAL: gripper
.
START gripper
.
START gripper PRIO=100
.
.
STOP gripper
.
.

```

applies as of Version TO01E *(no synchronized end with parallel processes)*

External program with name must be defined in the declaration part.

The main program (HP) and external program (in this case: GRIPPER) are run in parallel.

A priority scale from 100 (highest) to 150 (lowest) can be assigned.

Parallel program Gripper is stopped and only the main program continues to run.

PARALLEL PROCESSES (INTERNAL)

```

.
..
PARALLEL
  MOVE pal_pos_1
  I = 5
.
.
ALSO
  MOVE ma_2 TO pal_corner_1
.
.
  ALSO
.
.
PARALLEL_END
.
.
MOVE TO home

```

(synchronized end in the case of parallel processes)

1st process

2nd process

3rd process
run simultaneously.

When all processes are finished, the system continues in the program after PARALLEL_END.

```

SEMAPHORE:sema_var
EXCLUSIVE
  sema_var
.
EXCLUSIVE_END

```

applies as of Version TO01E

If it is intended to access exclusively to common resources (e.g. printers), this can be achieved with the Exclusive statement. The semaphore variable must have been declared beforehand in the declaration part and acts globally in the operating system, i.e. an interlock function can be performed by all programs.

If another parallel-running process is using the semaphore, the second process remains in "wait" state until the semaphore is released again.

EXCLUSIVE – uses the semaphore
EXCLUSIVE_END – releases the semaphore
If the parallel running process is not using the semaphore, the interlock has no effect.

SPECIAL FUNCTIONS

<p>SPC_FCT:</p>	<p>applies as of Version TO01E</p>	<p>Functions to which no BAPS keywords are assigned are declared as SPECIAL FUNCTIONS. All special functions are listed in order of number below.</p>
<p>1 = eal (VALUE INTEGER: eal_no VALUE INTEGER: kin_no VALUE INTEGER: coordno VALUE REAL: outp_pos VALUE REAL: para_outp VALUE INTEGER: rate time)</p>	<p>applies as of Version TO01E</p>	<p>Exact–position switching of digital signals on the path with rate time. Up to 8 channels can be used for the function.</p>
<p>2 = ppa (VALUE INTEGER: ppa_no VALUE INTEGER: kin_no VALUE INTEGER: coord_no VALUE REAL: outp_pos VALUE REAL: param VALUE INTEGER: rate)</p>	<p>applies as of Version TO01E</p>	<p>Exact–position output of process parameters output with rate time. SPC2 includes 8 functions for output of 8 bit–wide outputs (value range 0..255) on the interface to the control or any decimal value via a free analog value output on the servo card.</p>
<p>3 = mach_pos (VALUE INTEGER : kin_no kin_name.JC_POINT : @p_name)</p> <p>3 = mach_pos (VALUE INTEGER : kin_no JC_POINT : @p_name)</p>	<p>applies as of Version TO03D</p>	<p>Special function 3 sets the internal machine position to the values specified in the point variables @p_name.</p> <p>If no kinematic is entered when declaring the special function, the point relates to the default kinematic.</p> <p>The special function must be declared separately for each kinematic to which it is intended to assign machine positions.</p>

IMPORTANT :

The kinematic selected with the variable **kin_no** and kinematic defined in the declaration must be the same.
The operating system of the rho3 control does **not** check for correct assignment.

CAUTION ! (Special function 3) :

Note that if machine positions are activated due to incorrect programming, the controller will no longer 'know' where the machine actually is.

4= command
 (VALUE INTEGER: com
 TEXT: src,dest
 INTEGER: status)

This special function permits to use rho3 system functions in a BAPS2 program.

command = name of special function for use in BAPS

com = selects the system function
 1= COMPILE (QLL-file)
 2= COPY (any file)
 3= DELETE (any file)
 4= START (user process)
 5= STOP (active user process)

src,dest = parameters for selected system function

status + result of the function as an integer value:

- 0 = no error
- 1 = invalid command
- 2 = error in source file name if COPY or error in file name if DELETE or error in file name if COMPILE was selected
- 3 = file extension is not QLL if COMPILE
- 4 = error in QLL file name if COMPILE
- 5 = file not closed if DELETE or destination file is not closed if COPY
- 6 = error if COPY, e.g. out of memory
- 7 = compiler is already active if COMPILE
- >0= number of error and warnings if COMPILE or error number if START:
 - 1051: user process already exist
 - 1057: file too much open
 - 1073: process is an ext. sub program
 - 1079: sub process tries to stop its own main process
 - 1085: invalid PKT file
 - 1092: selected process not available
 - 1112: sequent. of IRD- and PKT- file is not possible because there's not enough memory available

17 = mirroring
 (VALUE BINARY: X_INV
 Y_INV
 Z_INV)
 mirror, (1,1,0)
 MOVE @(50,120,-25.21)

applies as of
 Version
 TO01E

Axes 1 and 2 are mirrored in this example.

21 = belt_mode
 (VALUE INTEGER:belt_no
 VALUE INTEGER:mode_belt)

applies as of
 Version
 TO03D

This special function permits the required mode of belt synchronization to be selected. The following synchronization modes are currently implemented:

mode_belt = **1** Belt synchronization with belt-parallel traversing of the kinematic
 mode_belt = **2** Belt synchronization without belt-parallel traversing of the kinematic.
 mode_belt = **3** cam plate interpolation

<p>23 = time_date (INTEGER: hours, minutes, day, month, year)</p>	<p>applies as of Version TO01E</p>	<p>Access to the time and date of the system clock in the rho3.</p>
<p>24 = sys_time (INTEGER:start_time)</p>	<p>applies as of Version TO01E</p>	<p>Access to an internal system counter (real-time counter).</p>
<p>27 = wc_mainarea (INTEGER: kin_no)</p>	<p>applies as of Version TO01E</p>	<p>Coordinate transformation may lead to excess rotation of the world orientation angles in WC. Special function 27 serves to eliminate this excess rotation.</p>
<p>28 = set_belt (VALUE INTEGER: belt_no VALUE REAL: reset_value)</p>	<p>applies as of Version TO03D</p>	<p>Calling special function 28 assigns the value of variable reset_value to the internal belt reset value for the corresponding belt. The internal belt counter is set to the reset value with signal RESET BELT COUNTER.</p>
<p>29 = pnt_store_on (VALUE INTEGER: kin_no VALUE INTEGER: ms_no VALUE REAL: distance)</p>		<p>Calling special function 29 activates storing of internal "commanded positions". Stores positions as WC and JC points.</p> <p>kin_no = number of selected kinematic ms_no = number of measuring system (axis, belt or analogous input) which is related to the parameter 'distance'</p> <p>distance = stores actual "commanded position" when distance is reached</p> <p><u>note:</u> Storing of position after every 'distance' will be done on default (option byte 36 = "0", but it's also possible to store positions at every transformation clock by setting the option byte 36 = "1".</p>
<p>30 = pnt_store_off (VALUE INTEGER: kin_no INTEGER: no_points)</p>		<p>Calling special function 30 terminates storing of "commanded positions". The stored values are saved until the next call of special function 29 with the same kinematic.</p> <p>kin_no = number of selected kinematic no_points = returns the quantity of stored points since call of special function 29.</p>

31 = pnt_st_read
 (VALUE INTEGER: kin_no
 VALUE INTEGER: index
 JC-POINT: @position
 POINT: position)

Calling special function 31 makes it possible to read the values stored by special function 29 in a ring buffer.

kin_no = number of selected kinematic
 index = ring buffer index of selected
 value

@position = stored position in JC
 position = stored position in WC

note:

To get valid positions it's necessary to call up SPC_FCT 29 and 30 before calling SPC_FCT 31.

The size of the ring buffer is fixed to 50 points independent of the number of axes.

41 = poti_modify
 (VALUE INTEGER: kin_no
 VALUE REAL: poti_value)

applies as of
 Version
 TO05G

Calling special function 41 "Asynchronous speed preselection" permits the modification of the Vfactor of a kinematics during movement.

kin_no = number of selected kinematics
 poti_value = asynchronous Vfactor

42 = move_dist
 (VALUE INTEGER: kin_no
 VALUE REAL: m_distance)

applies as of
 Version
 TO05G

Opposite to the normal "MOVE UNTIL" –statement the movement by this special function is not directly aborted if the condition is true (probe input).

The distance in parameter *m_distance* is moved before the movement is ended.

kin_no = number of selected kinematics
 m_distance = distance to move after active
 probe input

note:

This modified "MOVE UNTIL" –statement acts only with probe inputs.

The base of this inputs is "700".

43 = probe_on
(VALUE INTEGER: kin_no
VALUE INTEGER: flank
INPUT: channel_no)

applies as of
Version
TO05G

Special function 43 permits to store the actual position by a minimum reaction time of 0,01 ms. The measured value is stored in the standard variable "MPOS". The parameter *flank* is used to select the trigger condition (starting the measurement).

The *channel_no* identifies, if a measurement has occurred.

kin_no = number of selected kinematics
flank = positive flank = 0
negative flank = 1

channel_no = measurement occurs = 1
no measurement = 0

note:

The probe input acts only with incremental measuring systems.

The base of the probe inputs is "600".

44 = probe_off
(VALUE INTEGER: kin_no
INPUT: channel_no)

applies as of
Version
TO05G

Calling special function 44 disables an active special function 43.

kin_no = number of selected kinematics
channel_no = input number of probe input

45 = move_file
(VALUE INTEGER: kin_no
BNR_FILE: curve_x
VALUE INTEGER: base
JC_POINT:@mod_flag
VALUE ARRAY[1..6]
INTEGER: reserve)

applies as of
Version
TO05G

Calling SPC_FCT 45 "MOVE_FILE" a curve chart stored in a binary file is moved by reading the actual values in this file. The output takes place in the interpolation raster or positioning control raster of the servo board clock. The issued values are position values.

kin_no = number of selected kinematics
curve_x = name of the BNR_FILE

base = selects the output of the position values.

1 = interpolation raster
2 = positioning control raster

mod_flag = The modulo flag is used by end-less axes. Other axes types must be initialized with "0.0" in the BAPS-program.

The following REAL-values are possible:

0.0 = no modulo calculation

1.0 = modulo calculation at the end of the block. The last axes value in the BNR_FILE is the modulo value.

2.0 = modulo calculation at the end of the block. The value stored in machine parameter P311 is used as modulo value.

reserve = reserved for future expansions of the operating system

restrictions:

This special function doesn't work with the rho 3.2 control.

46 = block_prep
(VALUE INTEGER: kin_no
VALUE INTEGER: number)

applies as of
Version
TO05G

Calling special function 46 "reduced block preparation with MOVE-statements" permits to reduce the internal block preparation. The use of this special function is recommended in connection with "MOVE_FILE" and "Asynchronous Inputs".

Especially with applications of asynchronous inputs it could be necessary to reduce the block preparation to ensure faster recognition of the inputs.

kin_no = number of selected kinematics
number = This value is an upper limit of prepared blocks of a kinematics. The range of this parameter is between 1..11.
Values < 1 are set internal to 1, values > 11 are set to 11.

TOOL – DAT

Coordinate transformation for determining the TOOL center point (TCP) is adjusted in two parts in order to permit different grippers/tools to be used during a processing run.

- a) Transformation as far as the flange.
The robot-specific data are defined via the machine parameters.
- b) Transformation as of the flange
The individual gripper parameters are stored in the file. Three translations (G_X, G_Y, G_Z) and three rotations (G_D1, G_D2, G_D3), each referring to the flange, are used for general definition.

<u>TOOL.DAT</u>					
gripper_l	=	10	2.5	5	1 2 3
gripper_r	=	0	50.0	1.3	5.4 0 0
gripper_1	=	-20	0	120	5 0 6
off	=	0	0	0	0 0

The order of the individual coordinates (first G_X, then G_Y, ... and last, G_D3) must always be observed. Zeroes must be set explicitly for values omitted. The gripper name must start in the first column and may have a maximum length of 12 characters.

```
TOOL
ma_1 gripper_l
```

applies as of
Version
TO01E

A gripper is selected in the BAPS program via command TOOL.
e.g.: The gripper coordinate system "gripper_1" from the file is offset.

```
TOOL
ma_1 off
```

applies as of
Version
TO01E

There is no TOOL_END. However, this can be obtained by a gripper coordinate system padded with zeroes.
(see example).

FIXED FILES

EXPROG.DAT

```
00 = init
01 = pal1
.
FF = basicpos
```

EXTERNAL PROGRAM SELECTION.

The interface input numbers are assigned to the program names (IRD) in file EXPROG.DAT.

MZA.DAT

```
01 = 'slide forward'
.
99 = 'end mza'
```

MACHINE STATUS DISPLAY.

The interface input numbers are assigned to the texts in file MZA.DAT. These selected texts can be displayed via the PHG in mode 7, 12, 1/2.

TEXTE.DAT

```
00 = 'text1'
.
FF = 'text256'
```

SELECTION OF TEXTS VIA THE INTERFACE.

The interface input numbers are assigned to the texts in file TEXTE.DAT.

TOOL.DAT

gripper_l	=	10	2.5	5	1	2	3
gripper_r	=	0	50.0	1.3	5.4	0	0
gripper_1	=	-20	0	120	5	0	6
off	=	0	0	0	0	0	0

TOOL COORDINATE description

The order of the individual coordinates must always be observed (zeros must be set explicitly for values omitted). The gripper name must start in the first column and may have a maximum length of 12 characters. (See Tool.)

BAPSPIC – SYNTAX

1. Declaration part

All variables used in a BAPSPIC – program may have a maximum length of 12 characters. The first character must be a letter. As special character only the underline “_” is permitted. Upper – and lower letters are equivalent.

Compiler instructions like **CONTROL** and **VERSION** must be declared before **PROGRAM**.

Lines containing compiler instructions should have no other characters following the statement.

```
::CONTROL = PIC250
```

COMPILER INSTRUCTION “PIC250”.
Indicates that the current program is a PIC – program (file extension “QLS”).

```
::VERSION = 200
```

COMPILER INSTRUCTION “VERSION”.
Indicates which compiler version is used compiling this PIC – program (from ROPS3 – Version W2C the new BAPSPIC – compiler version 2.00 is available).
The default setting is compiler version 1.00

```
PROGRAM pic_io
```

PROGRAM NAME.
The program name may have a maximum length of 8 characters. The name should agree with the file name, otherwise a warning is reported during compilation of this file.

```
::INCLUDE pic_sym
```

COMPILER INSTRUCTION “INCLUDE”.
Like in QLL – programs there is the possibility to include other files in the program.
This allows to create the symbol file in a separate file which can be included in the PIC – program by the *INCLUDE* statement.
From compiler version 2.00 the file extension is of your own choice. If there is no extension indicated, the compiler uses “QLS”.

```
PROGRAM pic_io
```

```
INPUT:
```

```
0 = permiss_phg,
```

```
.
```

```
.
```

```
767 = user_24_di
```

```
OUTPUT:
```

```
16 = emerg_n_rci,
```

```
.
```

```
.
```

```
743 = user_24_do
```

Declaration of IN– and OUTPUTS.

All inputs and outputs used in the PIC–program must be declared.

The symbol names are separated by a comma. After the last symbol name in a group, the comma is omitted (see example).

```
PROGRAM pic_io
```

```
.
```

```
.
```

```
BINARY:
```

```
0 = c0_decrem_m,
```

```
.
```

```
.
```

```
191 = c31_reset_m
```

```
TEMP BINARY:
```

```
marker_1, marker_2, marker_3
```

Declaration of REMANENT and NON–REMANENT MARKER.

All marker used in a PIC–program must be declared.

Remanent marker are declared as "BINARY", temporary marker as "TEMP BINARY".

The symbol names are separated by a comma. After the last symbol name in a group, the comma is omitted (see example).

2. Program part

```
PROGRAM pic_io
BEGIN
    ;instructions
PROGRAM_END
```

INSTRUCTION PART.

From compiler version 2.00 the syntactical construction of a BAPSPIC-program is adapted to the BAPS2-Syntax. This means that the instruction part is now separated from the declaration part by the keyword "BEGIN".

The end of the program is indicated by the keyword "PROGRAM_END".

```
feede_aa_rci = feeden_aa_di
cyclrun_do = proc_act_rco
              OR
              permpr_a_rco
user_10_do = feedhd_n_di
             AND
             contr_aa_di
```

ASSIGNMENTS.

With the "="-character the value of the variable or expression right of the sign of equality is assigned to the variable on the left.

The keyword "OR" permits a logic OR-combination of several variables (*var1 OR var2 OR var3*).

The keyword 'AND' permits a logic AND-combination of several variables (*var1 AND var2 AND var3*).

```
IFauto_mn_di
THEN
auto_mn_rci = 0
```

```
IF NOTuser_1_di
THEN
user_1_do = 1
```

IF-THEN INSTRUCTION.

The IF-THEN instruction permits the build of conditional instructions. This means the instruction is executed if the condition is true.

The keyword "NOT" permits the examination of a variable or expression of logic 0.

```
IF NOT auto_mn_di
THEN
auto_mn_rci = 0
ELSE
user_1_do = 1
```

IF-THEN-ELSE INSTRUCTION.

This instruction permits the execution of several instructions depending on the input condition.

```
IF NOT auto_mn_di
THEN BEGIN
    auto_mn_rci = 0
    user_2_do = 1
END
ELSE BEGIN
    user_2_do = 1
    user_3_do = 0
END
```

COMPOUND INSTRUCTION.

The compound instruction is used to clamp several instructions.

Thereby it is possible to execute several instructions where normally only one instruction is permitted.

```
feede_aa_rci = feeden_aa_di
               AND
               (marker_1 OR marker_2)
               OR
               marker_3
```

BUILDING COMPONENT EXPRESSIONS.
Using the parentheses "(" and ")" permits the construction of one expression of several variables.

```
IF NOT auto_mn_di
THEN
JUMP automatic
.
.
automatic:
IF marker_3 THEN user_11_do = 1
```

JUMP INSTRUCTION.
The jump instruction permits jumps to several positions in the PIC-program.
The instruction consists of a jump instruction (JUMP) and a destination (*mark:*).

INDEX

Symbols

@, 19, 26
@MPOS, 29
@POS, 28
+, 18, 26
-, 18
*, 18
/, 18
=, 18
<, 18
<=, 18
<>, 18
>, 18
>=, 18

A

A, 30
ABS, 20
AFACTOR, 32
AFIX, 31
ALSO, 40
AND, 18, 51
APPROX, 27
ARRAY, 12, 13, 37
ARRAY BINARY, 12, 13
ARRAY CHAR, 12
ARRAY INPUT INTEGER, 13
ARRAY INPUT REAL, 13
ARRAY INTEGER, 12
ARRAY JC_POINT, 12
ARRAY OUTPUT, 13
ARRAY OUTPUT INTEGER, 13
ARRAY OUTPUT REAL, 13
ARRAY POINT, 12
ARRAY REAL, 12
ARRAY TEXT, 12

ARRAY,Two-dimensional, 12
ASC_ARRAY, 22
ASSIGN, 25
Assignment, 51
Asynchronous inputs, 15
ATAN, 18
AXIS ASSIGNMENT, 19

B

BAPSPIC Compiler instruction
CONTROL, 49
INCLUDE, 49
VERSION, 49
BAPSPIC Declaration part, 49
BAPSPIC instruction part, 51
BAPSPIC Program part, 51
BEGIN, 6, 7, 17
BELT, 14, 34
BINARY, 9
BLOCK_SLOPE, 33
BNR_FILE, 38

C

CASE, 17
CASE_END, 17
CHANNEL NUMBERS, 14
CHAR, 9, 37
CHR, 20
CIRCULAR, 27
CLOSE, 39
CLS, 8
COMPOUND Instruction, 51
CONDITION, 24
CONST, 19
CONTROL, 4
COS, 18

D

DEBUGINFO, 4
DEF, 10

DEF ARRAY JC_POINT , 10
DEF ARRAY POINT, 10
DEF JC_POINT, 10
DEF POINT, 10
DEFAULT, 17
DFACTOR, 32
DRIVE_TYPE, 5

E

ELSE, 16, 51
END, 17
END_OF_FILE, 38
EQUAL , 17
ERROR, 4, 16, 27
EXACT, 27
EXCLUSIVE, 11, 40
EXCLUSIVE_END, 11
EXPROG.DAT, 48
EXTERNAL, 6, 11, 40

F

FILE, 9, 38

H

HALT, 6

I

IF, 16, 51
IF NOT, 51
IF THEN ELSE, 16
INCLUDE, 5
INPUT BINARY, 14
INPUT REAL, 14
INPUTER INTEGER, 14
INT, 5
INT_ASC, 21
INTEGER, 9, 19

J

JC, 23
JC_NAMES, 4
JC_POINT, 9
JUMP, 17, 52

K

KINEMATICS, 4

L

LIMIT_MAX, 35
LIMIT_MIN, 35
LIMIT_OFF, 35
LINEAR, 27

M

MAX_TIME, 16
MOD, 18
MOVE, 26
MOVE_REL, 26
MZA.DAT, 48

N

NOT, 18

O

OR, 18, 51
ORD, 20
OUTPUT BINARY, 14
OUTPUT INTEGER, 14
OUTPUT REAL, 14

P

PARALLEL, 40
PARALLEL_END, 40
PAUSE, 16
PERMANENT, 4

PHG, 37
POINT, 9
POS, 28, 37
PRIO, 40
PROCESS_KIND, 4
PROGR_SLOPE, 33
PROGRAM, 6
PROGRAM_END, 6
PTP, 27
PUBLIC, 11

R

R, 23
R_PTP, 23
READ, 37
READ_BEGIN, 38
REAL, 9, 19
REF_PNT, 26
REPEAT, 16
REPEAT_END, 16
RETURN, 7
ROUND, 20

S

SEMAPHORE, 9, 11
SER_IO_STOP, 5
SERIAL INTERFACES, 36
SIN, 18
SPC_FCT, 41
 1 = exact-position switching, 41
 17 = mirroring, 42
 2 = exact-position parameter output, 41
 21 = Belt mode selection, 42
 23 = System time and date, 43
 24 = System counter, 43
 27 = wc_mainarea, 43
 28 = set belt counter, 43
 29 = store command position "on", 43
 3 = set machine position, 41
 30 = store command position "off", 43
 31 = read stored command positions, 44
 4 = command, 42

41 = asynchronous speed preselection, 44
42 = asynchronous "MOVE UNTIL", 44
43 = fast measurement on, 45
44 = fast measurement off, 45
45 = MOVE_FILE, 45
46 = reduced block preparation, 46

SQRT, 18
START, 40
STOP, 40
SUB_END, 7
SUBROUTINE, 7
SYNC, 34
SYNCHRON, 34
SYNCHRON_END, 34

T

T, 31
TEXT, 9
TEXTE.DAT, 48
TFIX, 33
THEN, 16, 51
TIMES, 16
TO, 27
TOOL, 47
TRUNC, 20

U

UNTIL, 27

V

V, 30
V_PTP, 30
V24_1, 37
VALUE, 6
VERSION, 8
VFACTOR, 32
VFIX, 31
VFIX_PTP, 31
VIA, 27

W

WAIT, 16

WAIT UNTIL, [16](#)

WAIT UNTIL MAX_TIME, [16](#)

WARNING, [4](#)

WC, [23](#)

WC_NAMES, [4](#)

WITH, [30](#)

WRITE, [37](#)

WRITE_BEGIN, [39](#)

WRITE_END, [39](#)

Bosch-Automationstechnik

Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Industriehydraulik
Postfach 30 02 40
D-70442 Stuttgart
Telefax (07 11) 8 11-18 57

Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Fahrzeughydraulik
Postfach 30 02 40
D-70442 Stuttgart
Telefax (07 11) 8 11-17 98

Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Pneumatik
Postfach 30 02 40
D-70442 Stuttgart
Telefax (07 11) 8 11-89 17

Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Montagetchnik
Postfach 30 02 07
D-70442 Stuttgart
Telefax (07 11) 8 11-77 12

Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Antriebs- und Steuerungstechnik
Postfach 11 62
D-64701 Erbach
Telefax (0 60 62) 78-4 28

Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Schraub- und Einpreßsysteme
Postfach 11 61
D-71534 Murrhardt
Telefax (0 71 92) 22-1 81

Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Entgrattechnik
Postfach 30 02 07
D-70442 Stuttgart
Telefax (07 11) 8 11-34 75

Technische Änderungen vorbehalten

Ihr Ansprechpartner

BOSCH



Robert Bosch GmbH
Geschäftsbereich
Automationstechnik
Antriebs- und Steuerungstechnik
Postfach 11 62
D-64701 Erbach
Telefax (0 60 62) 78-4 28