

# Rexroth MKE synchronous motors for potentially hazardous areas

R911274804  
Edition 01

Project Planning Manual



**Title** MKE Digital AC Motors for potentially-explosive areas

**type of documentation** Project Planning Manual

**Document code** DOK-MOTOR\*-MKE\*\*\*\*\*-PRJ1-EN-E1,44

**Internal file reference**

- Drawing number: 209-0078-4301-00

**Reference**  
 This electronic document is based on the hardcopy document with document design.: DOK-MOTOR\*-MKE\*\*\*\*\*-PRJ1-EN-P

**The purpose of the documentation:** This document assists in
 

- familiarization with MKE AC motors
- mechanical integration into the machine
- planning of the electrical connections
- connecting the motor
- ordering or identifying a motor
- determining the required motor cables and connectors

**Editing sequence**

Document designations of previous editions	Status	Comments
DOK-MOTOR*-MKE*****-PRJ1-EN-P	06.97	1st edition
DOK-MOTOR*-MKE*****-PRJ1-EN-E1,44	06.97	1 st E- Dok

**Copyright** © INDRAMAT GmbH, 1997

Copying this document, and giving it to others and the use or communication of the contents thereof without express authority are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).

The electronic documentation (E-Doc) may be copied as often as needed if such are to be used by the customer for the purpose intended.

**Validity** All rights are reserved with respect to the contents of this documentation and the availability of the product.

**Published by** INDRAMAT GmbH • Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main  
 Telefon 09352/40-0 • Tx 689421 • Fax 09352/40-4885  
 Abt. ENS (JW)

# Contents

<b>1 Introduction to MKE digital AC motors</b>	<b>1-1</b>
1.1 General features .....	1-1
1.2 Versions .....	1-3
1.3 Motor feedback .....	1-3
<b>2 Mechanical integration into the machine</b>	<b>2-1</b>
2.1 Using the drive in potentially explosive areas .....	2-1
2.2 Conditions of Use.....	2-2
Maximum installation elevation and ambient temperature .....	2-2
Maximum vibration and shock requirements .....	2-3
Primary coat and housing finish .....	2-4
2.3 Type of construction and mounting orientation.....	2-5
2.4 Drive shaft.....	2-5
Available versions .....	2-5
Shaft loads .....	2-5
2.5 Holding brake.....	2-8
2.6 Connection variants and cable output directions .....	2-9
2.7 Speed and Torque .....	2-10
<b>3 Electrical connections</b>	<b>3-1</b>
3.1 Overview of connections.....	3-1
3.2 Connections for motors with terminal boxes .....	3-2
Terminal diagram .....	3-2
Thermal cutout connection.....	3-3
Power cable .....	3-3
Feedback cable.....	3-5
Technical data of the power and feedback cables.....	3-6
Minimum temperature resistance of the connecting leads .....	3-7
Individual parts .....	3-7
<b>4 MKE 035</b>	<b>4-1</b>
4.1 Technical data.....	4-1
4.2 Speed/torque characteristics .....	4-2
4.3 Determining maximum shaft load .....	4-3
4.4 Dimensions .....	4-4
4.5 Available versions and type codes.....	4-5
<b>5 MKE 045</b>	<b>5-1</b>
5.1 Technical data.....	5-1

5.2 Speed/torque characteristics .....	5-2
5.3 Determining maximum shaft load .....	5-3
5.4 Dimensions .....	5-4
5.5 Available versions and type codes.....	5-5
<b>6 MKE 096</b>	<b>6-1</b>
6.1 Technical data.....	6-1
6.2 Speed/torque characteristics .....	6-2
6.3 Determining maximum shaft load .....	6-3
6.4 Dimensions .....	6-4
6.5 Available versions and type codes.....	6-5
<b>7 Condition at delivery</b>	<b>7-1</b>
7.1 General information .....	7-1
7.2 Removing the bands .....	7-1
7.3 Shipping papers .....	7-1
<b>8 Identifying the merchandise</b>	<b>8-1</b>
8.1 Delivery slip.....	8-1
8.2 Barcode sticker .....	8-1
8.3 Type plate .....	8-2
<b>9 Storage , Transport and Handling</b>	<b>9-1</b>
9.1 Notes on the packaging .....	9-1
9.2 Storage .....	9-1
9.3 Transport and Handling .....	9-2
<b>10 Safety Guidelines for electrical drives</b>	<b>10-1</b>
10.1 General information .....	10-1
10.2 Note on protection against contact with live parts.....	10-1
10.3 Notes on "safely-isolated low voltages....."	10-2
10.4 Notes on handling and mounting .....	10-3
10.5 Notes on protection against dangerous movements .....	10-3
<b>11 Mounting and Installation</b>	<b>11-1</b>
11.1 Qualified personnel .....	11-1
11.2 General notes on mounting.....	11-1
11.3 Mounting the motor .....	11-1
11.4 Connecting the motor.....	11-2
Connecting guidelines for MKE 035 and MKE 045.....	11-3
Connecting guidelines for MKE 096.....	11-5
EExd cable screwed joints .....	11-7
11.5 Refinishing the holding brake.....	11-8
<b>12 Service Notes</b>	<b>12-1</b>
12.1 Changing the battery.....	12-1
12.2 Maintenance work.....	12-2

12.3 Contacting Customer Service ..... 12-2

**13 Index****13-1**



# 1 Introduction to MKE digital AC motors

## 1.1 General features

**Applications** In conjunction with digital intelligent INDRAMAT drive controllers, MKE digital AC motors create cost-effective drive systems with a broad range of functionalities for use in potentially explosive areas.

**Overview of performance** Motors with the following continuous standstill torques and nominal speeds are available:




Fig. 1-1: Continuous torque at standstill of the available MKE motors

**Advantages** The salient advantages of MKE motors are as follows:

- motors designed with „pressure-resistant housing“ as per EN 50014 ff
- extreme operating reliability
- maintenance-free operation (due to the brushless design and use of lifetime lubricated bearings)
- implementation even under adverse environmental conditions (due to the completely sealed motor design with protection category IP 65)
- overload protection (accomplished with motor temperature monitoring)
- high power data
- high dynamics (as a result of favorable power to weight ratio)
- high overload capacities (due to favorable heat conduction from the stator winding to the outside wall of the motor)
- peak torque which can be used over a broad rotational speed range (accomplished with electronic commutation)
- continuous start-stop operations with high repetitive frequencies is possible (accomplished with electronic commutation)
- easy mounting to the machine (with a flange as per DIN 42948)
- any mounting orientation
- pinions and belt pulleys can be directly mounted (the design of the bearing shaft accomodates high radial loads)
- simple cabling (accomplished with ready-made cables available in various designs)
- simple and rapid commissioning (as a result of data storage capabilities in the motor feedback)

**Structure and components**

MKE motors are permanent magnet-excited motors with electronic commutation. Special magnetic materials perwith a design with low inertia. The following illustrates the principle structure of MKE motors.




Fig. 1-2: The structure of MKE motors



MKE motors are intended for use with the following drive controllers:

Drive controller family	DIAX04	ECODRIVE
Drive controller	HDS HDD	DKC

Fig. 1-2: Drive controllers for MKE motors

## 1.2 Versions

MKE motors are available in different versions:

### Motor feedback

They are available with

- relative rotor position evaluation (standard) or
- absolute rotor position evaluation (optional).

For details see section 1.3.

### Holding brakes

Optional. For a safe holding of the axes at standstill when power to the motor is shutdown. See section 2.5 for details.

### Output shaft

They are available with

- plain shaft (standard) or
- shaft with keyway (optional).

For details see section 2.4.

### Electrical connections

These are motor-specific implementing either

- a terminal box

For details see section 11.4., „Connecting the motor“, Page 11-2.

## 1.3 Motor feedback

The drive controller requires the current position of the motor to regulate motor speed or when positioning the motor. The integrated motor feedback makes available to the drive controller such signals as are needed to perform this function. The drive controllers are, in turn, equipped to transmit the thus determined position value to a superordinate CNC or PLC.

**Feedback data storage**

Feedback electronics are equipped with data memory in which motor type designations, control loops and motor parameters are stored. The digital intelligent drive controllers from INDRAMAT can read this data thus guaranteeing

- an easy and quick startup
- an automatic adjustment between motor and drive controllers, avoiding any damage to the motor.

MKE motors are available with two position evaluation options, viz.,

- relative position evaluation and
- absolute position evaluation.

**Technical data of the motor feedback**

Designation	Resolver feedback (RSF)	Resolver feedback (RSF) with integrated multiturn absolute encoder
measuring principle	inductive	
position resolution at the motor	MKE035, 045: $3 \times 2^{13} = 24\,576$ MKE096: $4 \times 2^{13} = 32\,768$ information/rotations	
system accuracy	±8 angle minutes	
position detection type	relative	absolute (within 4096 motor rotations)

Fig. 1-3: Technical data - motor feedback

**Resolver feedback (RSF)**

For relative indirect position evaluation. Replaces a separate incremental encoder on the motor.

Features of the digital resolver feedback: Given a power failure or after the initial POWER ON, it is necessary to first run the axis to its reference point before work can begin.

⇒ When placing the reference point switches and during the referencing procedure itself, it must be taken into account that during the course of a mechanical motor revolution, several zero pulses are generated. This is the result of the operating principle of the resolver. Therefore note:

- there are 3 zero pulses per revolution with the MKE 035 and MKE 045
- there are 4 zero pulses per revolution with the MKE 096

⇒ For this reason, avoid transmission ratios that are too large or feed constants that are too small.

**Resolver feedback (RSF) with integrated multiturn absolute encoder**

For absolute indirect position detection within a range of 4096 motor revolutions. Replaces a separate absolute encoder on the motor.

The absolute axis position of this feedback variant is retained even after power has been shutdown because of the battery backup it is equipped with. The battery has a lifespan of approximately ten years.

## 2 Mechanical integration into the machine

### 2.1 Using the drive in potentially explosive areas

The figure below illustrates how to mount the drive in potentially explosive areas. The following components must meet the demands made for explosion protection:

- motor with mountable components
- circuits which lead into the potentially explosive areas

Explosive area




Fig. 2-1: Potentially explosive area

MKE motors are prototype tested as per EN 50014 ff (European standards) and have been released for use in potentially explosive areas. The relevant drive controllers and any plugin connectors for the lines (power and feedback connections) must be situated outside of the potentially dangerous area.



**DANGER**

#### **Danger of explosion**

Danger to life, severe injury and property damage

- ⇒ Do not install drive controllers and plugin connectors within the hazardous area.
- ⇒ Make sure that plugin connectors do not end up in the hazardous area.
- ⇒ Do not pull plugin connectors when machine is live!
- ⇒ Make sure that sparks cannot be generated in the hazardous area.

## 2.2 Conditions of Use

### Maximum installation elevation and ambient temperature

- Nominal data** The power data of the motor apply to
- an ambient temperature range of 0° to +40° C
  - and an installation elevation of 0 to 1000 meters above sea level.

**Exceeding nominal data** If the motor is to be used above this range, then the "load factors" must be taken into consideration. This derates the output data.

⇒ In cases like this, check whether the output data still suffice for your application. To determine the load factors, see Fig. 2-2. Values higher than those depicted are not permitted!



**WARNING**

#### Motor damage and forfeiture of guarantee!

Motors used outside of the specified conditions could be damaged. Such use also results in forfeiture of guarantee.

⇒ Please therefore note the following instructions!




Fig. 2-2: Load factors as dependent on ambient temperature and installation elevation

If **either** ambient temperature **or** installation elevation exceed nominal ratings then:

⇒ Multiply the continuous standstill torque listed in the selection data with the determined load factor .

⇒ Make sure that the derated torque is not exceeded by your application.

If **both** ambient temperature **and** installation elevation exceed nominal ratings then:

⇒ Multiply the determined load factors  $f_T$  and  $f_H$ .

⇒ Multiple the determined value by the continuous standstill torque of the motor indicated in the selection data.

⇒ Make sure that the derated torque is not exceeded by your application.

**Protection category** The design of MKE motors meets the protection category requirements as described in DIN VDE 0470, section 1, edition 11/1992:

Area of the motor	Protection category
Motor housing, drive shaft, power & feedback connections (only with proper mounting)	IP 65

Fig. 2-3: Protection category of MKE motors

The protection category is defined with the letters IP (International Protection) and two digits for the protection category.

The **first digit** denotes the protection level against contact and penetration of extrinsic objects. Thus,

a 6 means

- protection against penetration by dust (dust-proof)
- and complete contact protection.

The **second digit** denotes the protection level against water. Thus,

a 5 means

- protection against a jet of water ejected out of a nozzle, sprayed at the housing from all directions (jet of water).



**WARNING**

**Danger to personnel or damage to property!**

Improperly mounted power and feedback connections can injure personnel or damage the motor!

- ⇒ Make sure that the power and feedback connections are mounted by properly trained personnel.
- ⇒ Use MKE motors only in an environment where the indicated protection categories can be ensured.

## Maximum vibration and shock requirements

**Note:** MKE motors may be used in areas with excessive vibrations and shocks as per IEC 721-3-3, edition 1987 or EN 60721-3-3, edition 06/1994 as per the following table. All mounting should be shock absorbent. The structure of mountable components depends on the application, whereby testing may be necessary.



**WARNING**

**Motor damage and forfeiture of guarantee!**

Motors operated outside of specified ambient conditions could be damaged. The guarantee is also forfeited.

- ⇒ Please therefore note the following instructions!

According to IEC 721-3-3, edition 1987 or EN 60721-3-3, edition 06/1994, MKE motors may be operated in a stationary and weather protected manner under the following conditions:

- longitudinal axis of the motor as per class 3M1
- lateral axis of the motor as per class 3M4

⇒ Make sure that, in terms of storage, transport and operation, MKE motors do not exceed values as depicted in Fig. 2-4: Limit data for sinusoidal oscillations and Fig. 2-5: Limit data of shock loads.

Influencing variable	Unit	Maximum value of longitudinal axis	Maximum value in Lateral axis
Amplitude of the displacement at 2 to 9 Hz	mm	0.3	3.0
Amplitude of acceleration at 9 to 200 Hz	m/s <sup>2</sup>	1	10

Fig. 2-4: Limit data for sinusoidal oscillations

Influencing variable	Unit	Maximum value of longitudinal axis	Maximum value of lateral axis
Total shock-response spectrum (per IEC721-1 ed. 1990; table 1, section 6)		type L	type I
Reference accel (in IEC 721 peak acceleration given)	m/s <sup>2</sup>	40	100
Duration	ms	22	11

Fig. 2-5: Limit data of shock loads

## Primary coat and housing finish

Condition at delivery: primary coat, black (RAL 9005)

Resistance: against weathering, yellowing, chalking, diluted acids and lyes.

An additional coat may be applied to the housing (maximum thickness equals 40 µm).

## 2.3 Type of construction and mounting orientation

Type of construction: B05 for flange mounting

Orientation: any

Per DIN IEC 34-7, edition 12/1992, the following orientations are permitted:

- IM B5 (horizontal)
- IM V1 (vertical, drive shaft downward)
- IM V3 (vertical, drive shaft upward)



**CAUTION**

### Seeping of liquids!

Motors mounted as per IM V3 are susceptible to seeping liquids that collect over extended periods at the shaft and then penetrate the motor causing damage.

⇒ Make sure that liquids cannot collect at the drive shaft.

## 2.4 Drive shaft

### Available versions

#### Plain drive shaft

For a backlash free and non-positive transmission of torque.

⇒ Use clamping sets, tension sleeves or other tension elements for coupling pinions, pulleys or other similar drive elements.

#### Drive shaft with keyway

(Per DIN 6885, sheet 1, edition 08/1968). For a form-fitting transmission of torque with low demands at the shaft/hub joint.



**CAUTION**

### Damage to the shaft!

During powerful reverse operations, the bottom of the key can turn out and reduce the quality of concentricity. Ever-increasing deformations can cause fractures.

⇒ The use of plain shafts is thus recommended.

## Shaft loads

Radial and axial forces affect the shaft:




Fig. 2-6: Shaft load forces

**WARNING****Motor damage and forfeiture of guarantee!**

Excessive shaft loads can damage the motor and shorten bearing life span considerably. The guarantee is also forfeited.

⇒ Please therefore note the following instructions!

**Maximum permissible  
radial force  $F_{\text{radial}}$**

Maximum permissible radial force  $F_{\text{radial\_max}}$  depends on shaft/force load. It is determined in terms of distance  $x$  of the point of application of force and the design of the drive shaft (plain shaft or with keyway).

Sections 4 to 6 contain information on „Determining maximum shaft load“.

⇒ Using the characteristics specified, determine the maximum permissible radial force  $F_{\text{radial\_max}}$  for your application.

⇒ Make sure that the radial force thus determined is not exceeded during actual operations.

**Permissible radial force  $F_{\text{radial}}$**

The permissible radial force  $F_{\text{radial}}$  depends on the bearing lifespan desired. It is dependent on the arithmetic average rotational speed of the motor  $n_{\text{mittel}}$  and distance  $x$  of application point of force (see Fig. 2-6: Shaft load forces).

Sections 4 to 6 contain information on „Determining maximum shaft load“.

⇒ Using the characteristics specified, determine the permissible radial force  $F_{\text{radial\_max}}$  for your application.

⇒ Make sure that the radial force thus determined is not exceeded during actual operations.




Fig. 2-7: Example to illustrate maximum permissible or permissible radial force



**Permissible axial force  $F_{axial}$**

It is proportional to the permissible radial force  $F_{radial}$ .

The factor of proportionality can be found in sections 4 to 6 in section "Determining maximum shaft load".

⇒ Using the given formula, determine maximum permissible axial force  $F_{axial}$  for your application.

⇒ Make sure that the determined axial force is not exceeded during operations. Please note the following on this!

**Note:**

Thermal effects can shift the flanged end of the drive shaft to the motor housing by up to 0.6 mm. If helical toothed drive pinions or bevel gear pinions are used and mounted directly to the output shaft, then these changes in the length can lead to the shifting

- of position of the axis, if the drive pinions are not axially fixed to the machine, or
- a thermally-dependent component of the axial force if the drive pinions are axially fixed machine side. There is the danger, in this case, that the maximum permissible axial force can be exceeded or that the clearance within the toothing is unacceptably increased.

The use of drive elements with bearings which are connected to the motor shaft via an axial compensating coupling is thus recommended.

**Bearing lifespan  $L_{10h}$**

If permissible radial and axial forces are not exceeded, then the following applies to nominal bearing lifespan:

$L_{10h} = 30,000$  operating hours (calculated per ISO 281, edition 12/1990).

Bearing lifespan otherwise drops to:

$$L_{10h} = \left( \frac{F_{radial}}{F_{radial\_ist}} \right)^3 \cdot 30000$$

$L_{10h}$ : bearing lifespan (per ISO 281, edition 12/1990) in hours  
 $F_{radial}$ : determined permissible radial force in N  
 $F_{radial\_ist}$ : actual effective radial force in N

Fig. 2-8: Calculating bearing lifespan  $L_{10h}$  if permissible radial force  $F_{radial}$  is exceeded

**Note:**

The actually effective radial force  $F_{radial\_ist}$  may at no time exceed maximum permissible radial force  $F_{radial\_max}$ .

**Mounting drive elements**

**Note:**

When mounting drive elements to the motor shaft, do not use fixed supported bearings, but rather bearings that are simply supported. The indispensable and existing tolerances generate the application of additional forces to the bearings of the motor shaft and possibly lead to a drop in service life. If a fixed type of mounting cannot be avoided, please contact INDRAMAT!

## 2.5 Holding brake

Optional. Holds the servo axis when no power is being supplied to the machine.

The holding brake works with the "electrically-released" principle. At zero current, a magnetic force acts on the brake armature disc. This means that the brake is locked and holding off the axis.

With the application of 24 V DC, the electrical field cancels the permanent magnetic field and the brake opens.

The drive controller regulates the holding brake. This ensures the correct on and off sequence in all operating states.



**DANGER**

### Falling axes!

Danger to personnel. Body parts could be pinched or severed.

⇒ The holding brake itself does not guarantee personnel safety. Personnel safety must be secured by other measures such as protective bars or an additional brake in the machine.



**CAUTION**

### Premature wear of the holding brake is possible!

The holding brake wears down after approximately 20,000 motor revolutions in a closed state.







⇒ Do not use the holding brake to stop a moving axis. This is only permitted in an emergency stop (E-stop) situation!

**Note:** If motors are stored for extended periods, then the transferrable torque of the holding brakes must be checked before the motor can be used. If the torque specified in the data sheets is not achieved, then it becomes necessary to refinish the holding brake prior to use.

⇒ Note the guidelines in section 11.5, Refinishing the holding brake, page 11-8.

## 2.6 Connection variants and cable output directions

A cable connection box is generally used for the MKE motor power and feedback connections. The desired cable output direction can be set at the time of mounting by turning the cable connection box.

Connection options	Possible output directions	
<b>Terminal box (can be turned by 180°) MKE 035, MKE 045</b>	 <p>Power cable</p> <p>Feedback cable</p>	 <p>Feedback cable</p> <p>Power cable</p> <p>(State at delivery)</p>
<b>Terminal box (can be turned in 90° increments) MKE 096</b>	 <p>Power cable</p> <p>Feedback cable</p>	 <p>Feedback cable</p> <p>Power cable</p> <p>(State at delivery)</p>  <p>Feedback cable</p> <p>Power cable</p>  <p>Power cable</p> <p>Feedback cable</p>

E02ME82P.fh5

Fig. 2-9: Possible cable output directions

**Note:** The cable output direction set at the factory can be altered at the time of mounting. Please see section, 11.4 „Connecting the motor“, page 11-2.

## 2.7 Speed and Torque

The rotational speed/torque characteristics depict

- the torque limit data
- the rotational speed limit data and
- operating characteristics

A diagram for each motor can be found in sections 4 to 6 under the topic „Speed/torque characteristics“.

⇒ Use this diagram to:

- Determine maximum usable speed with known torque requirements.
- Check whether the thermal limits of the motor are maintained. The RMS torque for a critical cycle must be below the S1 continuous operating curve ( $M_{dN}$ ) of the averaged speed (arithmetic average).
- Record information from the selection documentation.




Fig. 2-10: Example diagram to illustrate speed/torque characteristics

$M_{max}$  Corresponds to the theoretically possible maximum torque of the motor. The drive controller can limit it.

**Note:** The maximum torque of a motor/controller **combination** is always specified in the selection lists.

$M_{KB}$  S6 intermittent operating curve with 25% ON time of the motor cooled with natural convection or 56% ON time of the motor with surface cooling as per DIN VDE 0530, edition 07/1991. Maximum duty cycle time for

- MKE 035: equals 10 minutes
- MKE 045 and 096: equals 15 minutes.

$M_{dN}$  S1 continuous operating curve of the motor (as per DIN VDE 0530, edition 07/1991).

**Characteristics (1) to (5)** As of "peak-torque" speed, maximum achievable, usable speed depends on the torque required. Since maximum motor speed is fixed by the DC bus voltage used, separate characteristics result for the individual drive controllers in terms of their supply voltage or the power supply unit used:

- (1) **HDS or HDD attached to supply units HVR**
- (2) **HDS or HDD with power supply unit HVE with a mains connection of 3 x AC 480 V -or- DKC.....-7 with 3 x AC 480 V**
- (3) **HDS or HDD with power supply unit HVE with a mains connection of 3 x AC 440 V -or- DKC.....-7 with 3 x AC 440 V**
- (4) **HDS or HDD with power supply unit HVE with a mains connection of 3 x AC 400 V -or- DKC.....-7 with 3 x AC 400 V**
- (5) **HDS or HDD with power supply unit HVE with a mains connection of 3 x AC 380 V -or- DKC.....-7 with 3 x AC 380 V**



## 3 Electrical connections

### 3.1 Overview of connections

The electrical connections of INDRAMAT drives are standardized. On MKE AC motors there are

- a power connection - includes connections for temperature sensors and holding brake - and
- a feedback connection.

Depending on the motor, both connections are conducted into the cable connection box with the use of EExd-cable leadthroughs, where they are mounted with a plug contact (see section 11.4 „Connecting the motor“, page11-2).




Fig. 3-1: Schematic terminal plan of MKE motors

### 3.2 Connections for motors with terminal boxes

#### Terminal diagram

**Note:** Only direct connections between motor and drive controller are depicted. The terminal diagrams, however, also apply to all other types, e.g., with intermediate connector, as the allocation of the connections of motor and drive controller never change.




Fig. 3-2: Terminal diagram of MKE motor with terminal box



## Thermal cutout connection

The use of an integrated motor temperature evaluation circuit in INDRAMAT drive controllers is urgently recommended to evaluate motor temperature in MKE motors used in areas where explosions represent a risk.

The PTC resistor connection for motor temperature evaluation is illustrated in the terminal diagram of the relevant drive controller.



**Attention!**

Temperature evaluation of the motors **must** implement INDRAMAT drive controllers!

⇒ Connections [1] and [2] of the PTC resistor must be connected with the temperature cutout circuit [TM+; TM-] of the drive controller!

---

The temperature class of INDRAMAT MKE motors is T4 as per EN 50014/ 3.77 (European standard). This makes a highly reliable surface temperature of the equipment with  $\leq 135$  °C possible. The PTC thermistor, made up of three thermistors, built into the MKE motors, guarantees, in conjunction with the evaluation circuits of the drive controller, a reliable and safe overtemperature cutout.

## Power cable

Motors with terminal boxes are preferably equipped with ready-made power cables.

These power cables are available in various versions:

- direct connection of motor to drive controller
- direct connection of motor to terminal strip
- direct connection of motor to flanged socket
- motor connected via pluggable isolating point




Fig. 3-3: Different types of connecting cables

- ⇒ Please find the type that suits your motor/controller combination in the table below.
- ⇒ If type designations are specified for two cables or a cable and a flanged socket, then order both.

**Connecting drive controller  
DIAX04 or ECODRIVE**

Motor type	Direct connection motor to						Connected via pluggable isolating point motor to				
	DKC 40A	DKC 100A	HDD/HDS 40A	HDS 75/100A	Terminal strip	Flanged socket	DKC 40A	DKC 100A	HDD/HDS 40A	HDS 75/100A	Terminal strip
035B-144	IKG-0307	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.
045B-144	IKG-0307	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.
096B-047	IKG-0307	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.	in prep.

Fig. 3-4: Ready-made power cables to connect MKE motors with terminal boxes to drive controller family DIAX 04 or ECODRIVE

**Selecting the length**

Available cable lengths: 5, 10, 15, 20, 30m. All other lengths available upon request.

⇒ When ordering, just enter the cable type and desired length. Example: IKG 0307 (= power cable for DKC, length 5m).

**Note:** Maximum total length of the cable connection from motor to drive controller with two intermediate plugin locations equals 75 m. With more plugin locations, the maximum total length drops. This may also necessitate testing.

**Feedback cable**

Motors with terminal boxes are generally preferably equipped with ready-made feedback cables.

These feedback cables are available in various versions:

- direct connection of motor to drive controller




Fig. 3-5: Versions of connecting cables

⇒ Locate the cable which suits your motor/controller combination in the table below.

Motor type	Direct connection of motor to drive controller	Connected via pluggable isolating point motor to drive controller
all motor types with terminal box	IKS0203	in prep.

Fig. 3-6: Ready-made feedback cable to connect to MKE motors with terminal box

#### Selecting the length

Available cable length: 5, 10, 15, 20, 30m. Other lengths available upon request.

⇒ When ordering, just enter the cable type and desired length. Example: IKS 0203 / 5 (= feedback cable, length 5 meters).

**Note:** Maximum total length of the cable connection from motor to drive controller with two intermediate plugin locations equals 75 m. With more plugin locations, the maximum total length drops. This may also necessitate testing.

## Technical data of the power and feedback cables

Name	Unit	Data		
		Power cables		Feedback cables
Ready-made cable type designation		IKG0307	IKG0308	IKS0203
Type designation of cable (cable parts)		INK0653	INK0650	INK0448
Diameter of power or supply strands	mm <sup>2</sup>	4 x 1.0	4 x 1.5	2 x 0.5
Control strand diameter (holding brake, temperature monitor or control voltage)	mm <sup>2</sup>	2 x (2 x 0.75)	2 x (2 x 0.75)	4 x (2 x 0.25)
Diameter	mm	12.5 ±0.3	12.2 ±0.4	8.5 ±0.3
Minimum bend radius fixed routing flexible routing (≥ 1 000 000 bend loads)	mm mm	75 120	80 120	50 90
Protection category (transition cable/terminal box) with expert mounting		IP 65		
Chemical features		absolute resistance to mineral oils and greases, hydrolysis resistant, silicone and halogen free		
Permissible ambient temperature for operation and storage	°C	-30 to +80		
Cable surface		Poor adhesion, prevents sticking in drag chains		
Specific cable weight	kg/m	0.25	0.39	0.10

Fig. 3-7: Technical data of power and feedback cables for MKE motors with terminal box

## Minimum temperature resistance of the connecting leads

To use MKE motors in potentially explosive areas, cables with a minimum temperature resistance of **80°C (176° F)** must be used. The cables listed in the INDRAMAT cable selection lists meet these requirements.

## Individual parts

---

**Note:** INDRAMAT cables can be put together by the customer. The parts needed in this case are listed in the document „Connecting accessories for INDRAMAT drives“, doc. no. 209-0050-4399.

---



## 4 MKE 035

### 4.1 Technical data

Designation	Symbol	Unit	Data
Motor type			MKE035B-144
to run with drive controller family			DIAX04, ECODRIVE
drive controllers			HDS, HDD, DKC
nominal motor speed <sup>1)</sup>	n	min <sup>-1</sup>	9000
continuous torque at standstill	M <sub>dN</sub>	Nm	0.9 (0.8) <sup>8)</sup>
continuous current at standstill	I <sub>dN</sub>	A	5.1 (4.5) <sup>8)</sup>
theoretical maximum torque <sup>2)</sup>	M <sub>max</sub>	Nm	4.0
peak current	I <sub>max</sub>	A	23.0
rotor inertia <sup>3)</sup>	J <sub>M</sub>	kgm <sup>2</sup>	0.3 x 10 <sup>-4</sup>
torque constant at 20°C	K <sub>m</sub>	Nm/A	0.20
voltage constant at 20°C <sup>4)</sup>	K <sub>Eeff</sub>	V/1000 min <sup>-1</sup>	18.5
winding resistance at 20°C	R <sub>A</sub>	Ohm	2.7
winding inductance	L <sub>A</sub>	mH	3.7
thermal time constant	T <sub>th</sub>	min	15
mass <sup>3)</sup>	m <sub>M</sub>	kg	2.0
electrical connection			terminal box
permissible ambient temperature <sup>5)</sup>	T <sub>um</sub>	°C	0 to +40
permissible storage and transport temperature	T <sub>L</sub>	°C	-20 to +80
maximum installation elevation <sup>6)</sup>		m	1000 above sea level
Protection category <sup>7)</sup>			IP 65
insulation class DIN VDE 0530 section 1			F
ignition protection category per EN 50014 / 3.77			EExd II C T4
PTB no.:			Ex - 97.D.1010
housing coat			black primary coat (RAL 9005)
<p>1) Depends on torque requirements of the application. For standard applications see n<sub>max</sub> in the selection lists of the motor/controller combination. For other applications, determine usable speed using the required torque as seen in the speed/torque characteristics.</p> <p>2) Achievable maximum torque depends on drive controller used. <b>Only the</b> in the selection lists of the motor/controller combination specified maximum torques M<sub>max</sub> are binding.</p> <p>3) Without holding brake.</p> <p>4) With 1000 min<sup>-1</sup>.</p> <p>5) With deviating ambient temperatures, see section 2.2.</p> <p>6) With deviating installation elevations, see section 2.2.</p> <p>7) With proper mounting of power and feedback cables.</p> <p>8) Parenthetical value applies to motor with holding brake.</p>			

Fig. 4-1: Technical data MKE035

Designation	Symbol	Unit	Holding brake data
Holding torque	$M_H$	Nm	1.0
Nominal voltage	$U_N$	V	DC 24 ±10%
Nennstrom	$I_N$	A	0.4
Moment of inertia	$J_B$	kgm <sup>2</sup>	$0.08 \times 10^{-4}$
Release delay	$t_i$	ms	4
Clamping delay	$t_k$	ms	3
Mass	$m_B$	kg	0.25

Fig. 4-2: Technical data - holding brake - MKE035 (Optional)

## 4.2 Speed/torque characteristics

For details see section 2.7, Speed and Torque, page 2-10.




Fig. 4-3: Rotational speed - torque characteristics - MKE035B-144



### 4.3 Determining maximum shaft load

For details see section 2.4, section Shaft loads , page 2-5.

Permissible maximum radial force  $F_{\text{radial\_max}}$  and permissible radial force  $F_{\text{radial}}$




Fig. 4-4: MKE035: permissible maximum radial force  $F_{\text{radial\_max}}$  and permissible radial force  $F_{\text{radial}}$

Permissible axial force  $F_{\text{axial}}$

$F_{\text{axial}} = 0,58 \cdot F_{\text{radial}}$

$F_{\text{axial}}$ : permissible axial force in N  
 $F_{\text{radial}}$ : permissible radial force in N

Fig. 4-1: MKE035: permissible axial force

### 4.4 Dimensions




Fig. 4-5: Dimensional data MKE035

## 4.5 Available versions and type codes




Fig. 4-6: Type codes MKE035



## 5 MKE 045

### 5.1 Technical data

Designation	Symbol	Unit	Data
Motor type			MKE045B-144
to run with drive controller family			DIAX04, ECODRIVE
drive controllers			HDS, HDD, DKC
nominal motor speed <sup>1)</sup>	n	min <sup>-1</sup>	6000
continuous torque at standstill	M <sub>dN</sub>	Nm	2.7
continuous current at standstill	I <sub>dN</sub>	A	7.5
theoretical maximum torque <sup>2)</sup>	M <sub>max</sub>	Nm	11.3
peak current	I <sub>max</sub>	A	34.0
rotor inertia <sup>3)</sup>	J <sub>M</sub>	kgm <sup>2</sup>	1.7 x 10 <sup>-4</sup>
torque constant at 20°C	K <sub>m</sub>	Nm/A	0.40
voltage constant at 20°C <sup>4)</sup>	K <sub>Eeff</sub>	V/1000 min <sup>-1</sup>	36.3
winding resistance at 20°C	R <sub>A</sub>	Ohm	1.8
winding inductance	L <sub>A</sub>	mH	5.0
thermal time constant	T <sub>th</sub>	min	30
mass <sup>3)</sup>	m <sub>M</sub>	kg	4.4
electrical connection			terminal box
permissible ambient temperature <sup>5)</sup>	T <sub>um</sub>	°C	0 to +40
permissible storage and transport temperature	T <sub>L</sub>	°C	-20 to +80
maximum installation elevation <sup>6)</sup>		m	1000 above sea level
Protection category <sup>7)</sup>			IP 65
insulation class DIN VDE 0530 section 1			F
ignition protection category per EN 50014 / 3.77			EExd II B+H2 T4
PTB no.:			Ex - 97.D.1010
housing coat			black primary coat (RAL 9005)
<p>1) Depends on torque requirements of the application. For standard applications see n<sub>max</sub> in the selection lists of the motor/controller combination. For other applications, determine usable speed using the required torque as seen in the Speed/torque characteristics ermittelt werden.</p> <p>2) Achievable maximum torque depends on drive controller used. <b>Only the</b> in the selection lists of the motor/controller combination specified maximum torques M<sub>max</sub> are binding.</p> <p>3) Without holding brake.</p> <p>4) With 1000 min<sup>-1</sup>.</p> <p>5) With deviating ambient temperatures, see section 2.2.</p> <p>6) With deviating installation elevations, see section 2.2.</p> <p>7) With proper mounting of power and feedback cables.</p>			

Fig. 5-1: Technical data MKE045

Designation	Symbol	Unit	Holding brake data
Holding torque	$M_H$	Nm	2.2
Nominal voltage	$U_N$	V	DC 24 $\pm$ 10%
Nominal current	$I_N$	A	0.35
Moment of inertia	$J_B$	kgm <sup>2</sup>	$0.16 \times 10^{-4}$
Release delay	$t_l$	ms	28
Clamping delay	$t_k$	ms	14
mass	$m_B$	kg	0.25

Fig. 5-2: Technical data - holding brake - MKE045 (Optional)

## 5.2 Speed/torque characteristics

For details see section 2.7, Speed and Torque, page 2-10.




Fig. 5-3: Speed/torque characteristics MKE045B-144

### 5.3 Determining maximum shaft load

For details see section 2.4, Shaft loads , page 2-5.

Permissible maximum radial force  $F_{\text{radial\_max}}$  and permissible radial force  $F_{\text{radial}}$




Fig. 5-4: MKE045: Permissible maximum radial force  $F_{\text{radial\_max}}$  and permissible radial force  $F_{\text{radial}}$

Permissible axial force  $F_{\text{axial}}$




Fig. 5-5: MKE045: permissible axial force  $F_{\text{axial}}$

### 5.4 Dimensions




Fig. 5-6: Dimensional data - MKE045



## 5.5 Available versions and type codes




Fig. 5-7: Type codes MKE045



## 6 MKE 096

### 6.1 Technical data

Designation	Symbol	Unit	Data
Motor type			MKE096B-047
to run with drive controller family			DIAX04, ECODRIVE
drive controllers			HDS, HDD, DKC
nominal motor speed <sup>1)</sup>	n	min <sup>-1</sup>	3200
continuous torque at standstill	M <sub>dN</sub>	Nm	12.0
continuous current at standstill	I <sub>dN</sub>	A	13.2
theoretical maximum torque <sup>2)</sup>	M <sub>max</sub>	Nm	43.5
peak current	I <sub>max</sub>	A	59.4
rotor inertia <sup>3)</sup>	J <sub>M</sub>	kgm <sup>2</sup>	41.5 x 10 <sup>-4</sup>
torque constant at 20°C	K <sub>m</sub>	Nm/A	1.0
voltage constant at 20°C <sup>4)</sup>	K <sub>Eeff</sub>	V/1000 min <sup>-1</sup>	91.0
winding resistance at 20°C	R <sub>A</sub>	Ohm	1.2
winding inductance	L <sub>A</sub>	mH	10.1
thermal time constant	T <sub>th</sub>	min	60
mass <sup>3)</sup>	m <sub>M</sub>	kg	14
electrical connection			terminal box
permissible ambient temperature <sup>5)</sup>	T <sub>um</sub>	°C	0 to +40
permissible storage and transport temperature	T <sub>L</sub>	°C	-20 to +80
maximum installation elevation <sup>6)</sup>		m	1000 above sea level
Protection category <sup>7)</sup>			IP 65
insulation class DIN VDE 0530 section 1			F
ignition protection category per EN 50014 / 3.77			EEx d IIB T4
PTB no.:			Ex-97.D.1036
housing coat			black primary coat (RAL 9005)
<p>1) Depends on torque requirements of the application. For standard applications see n<sub>max</sub> in the selection lists of the motor/controller combination. For other applications, determine usable speed using the required torque as seen in the Speed/torque characteristics ermittelt werden.</p> <p>2) Achievable maximum torque depends on drive controller used. <b>Only the</b> in the selection lists of the motor/controller combination specified maximum torques M<sub>max</sub> are binding.</p> <p>3) Without holding brake.</p> <p>4) With 1000 min<sup>-1</sup>.</p> <p>5) With deviating ambient temperatures, see section 2.2.</p> <p>6) With deviating installation elevations, see section 2.2.</p> <p>7) With proper mounting of power and feedback cables.</p>			

Fig. 6-1: Technical data MKE096

Designation	Symbol	Unit	Holding brake data
Holding torque	$M_H$	Nm	11.0
Nominal voltage	$U_N$	V	DC 24 $\pm$ 10%
Nominal current	$I_N$	A	0.5
Moment of inertia	$J_B$	kgm <sup>2</sup>	$1.1 \times 10^{-4}$
Release delay	$t_i$	ms	29
Clamping delay	$t_k$	ms	20
mass	$m_B$	kg	0.65

Fig. 6-2: Technical data - holding brake - MKE096 (Optional)

## 6.2 Speed/torque characteristics

For details see section 2.7, Speed and Torque, page 2-10.




Fig. 6-3: Rotational speed - torque characteristics - MKE096B-047

### 6.3 Determining maximum shaft load

For details see section 2.4, Shaft loads , page 2-5.

Permissible maximum radial force  $F_{\text{radial\_max}}$  and permissible radial force  $F_{\text{radial}}$




Fig. 6-4: MKE096: Permissible maximum radial force  $F_{\text{radial\_max}}$  and permissible radial force  $F_{\text{radial}}$  .

Permissible axial force  $F_{\text{axial}}$




Fig. 6-5: MKE096: Permissible axial force  $F_{\text{axial}}$

## 6.4 Dimensions




Fig. 6-6: Dimensional data MKE096

## 6.5 Available versions and type codes




Fig. 6-7: Type codes MKE096





## 7 Condition at delivery

### 7.1 General information

The motor and accessories, such as cables, are loaded into cartons at delivery. Depending on number or size of these cartons, they may be loaded onto a pallet and then fixed into place with metal bands. For protection against adverse weather, an additional carton may be placed over the pallet and affixed into place with metal bands attached to the pallet.

### 7.2 Removing the bands



CAUTION

#### **Uncontrolled movements of the metal bands upon removal!**

Mechanical injuries are possible.

⇒ Metal bands must be carefully removed!

⇒ Sufficient distance must be maintained!

### 7.3 Shipping papers

The entire delivery is accompanied by one copy of the shipping papers in an envelope. This lists merchandise by name and order designation. In the event that the listed contents are distributed over all cartons, (transport containers), such will be noted on the papers or freight papers.

The packaging on each motor lists the following information:

- type designation of the motor
- customer
- delivery slip number
- consignment
- freight company

(See section 8 "Identifying the merchandise".)



## 8 Identifying the merchandise

### 8.1 Delivery slip

The entire delivery is accompanied by one slip in an envelope. The merchandise is listed here by name and order number. In the event that the contents are distributed over several cartons (transport containers), such will be noted in the delivery slip or the freight papers.

### 8.2 Barcode sticker

There is a barcode sticker on each motor package will lists the following information:

- type designation of the motor
- customer
- delivery slip number
- consignment
- freight company

The barcode sticker serves to identify the contents at the time of order completion.




Fig. 8-1: Barcode sticker (Example)

## 8.3 Type plate

**Motors** The motor is delivered with a type plate. It is attached to the motor housing. There is a second type plate placed over the original type plate with two-sided tape. This can be removed and placed elsewhere at a visible spot on the machine if the original type plate on the motor is somehow covered or not visible due to the contours of the machine.




Fig. 8-2: Type plate (Example)

The type plate serves

- the identification of the motor
- to obtain replacement parts in the event of a breakdown
- service information, in general

**Cable parts** Type designations are printed on the cable sheath.

**Individual plugin connectors** Type designations are on the plastic bag.

**Ready-made cables** Label (at cable end) with type designations.

---

**Note:** Type designations of the motor are also listed in the feedback data memory.

---

## 9 Storage , Transport and Handling

### 9.1 Notes on the packaging

Notes on storage, transport and handling are on the packaging. Please comply with the instructions.




Fig. 9-1: Notes on storage, transport and handling on the packaging

### 9.2 Storage



**WARNING**

#### **Motor damage and forfeiture of guarantee!**

Motors not properly stored could be damaged. The guarantee is also forfeited in this case.

⇒ Please therefore note the following instructions.

Maintain the following conditions during storage:

- ⇒ permissible temperature range: -20° C to +80° C.
- ⇒ motors must be stored dry, dust-free and shock-free
- ⇒ motors must be stored horizontally
- ⇒ Protective cover of plastic on the drive shaft must not be removed. It protects against moisture and mechanical damage.

## 9.3 Transport and Handling



### WARNING

#### Motor damage and forfeiture of guarantee!

Improper transport and handling can damage the motor.


The guarantee is also forfeited in this case.

⇒ Please therefore follow the instructions below.

Maintain the following conditions during transport and when handling:

- ⇒ Use suitable transport devices. Note the weight of the components (weights are listed in the individual sections with the technical data of the motor or on the type plates of the motor).
- ⇒ Shock damping should be used if excessive shocks are expected during transport. Note the limit data as outlined in section „2.2 Maximum vibration and shock requirements, page 2-3“.
- ⇒ Transport in horizontal position only.
- ⇒ When picking up the motor, use a crane or lifting belts
- ⇒ Motor flange and drive shaft must not be damaged!
- ⇒ Avoid impacts to drive shaft.
- ⇒ Protective cover made of plastic is on the drive shaft and must not be removed until shortly before the motor is mounted.

**Note:** If the motor is also equipped with a holding brake and, if prior to mounting the holding torque listed in the data sheets is not achieved, then refinish the holding brakes. Note the instructions in section 11.5 „Refinishing the holding brake“, page 11-8.



O01ME82P.fh5

Fig. 9-2: Lifting and transporting the motors with the use of lifting belts

## 10 Safety Guidelines for electrical drives

### 10.1 General information

- The safety instructions outlined in this document must always be complied with. Improper handling of this machinery and non-compliance with the warnings can cause property damage, injury and possibly even death. INDRAMAT assumes no responsibility for detrimental conditions ensuing from non-compliance with the warnings.
- There can only be a safe and trouble-free operation of these drives if they have been correctly transported, stored, mounted and installed as well as if they are carefully operated and maintained.
- Only duly qualified personnel is permitted to work at, on or near them. Personnel is defined as qualified if it is familiar with mounting, installation and operation as well as with all warnings and precautionary measures as outlined in this document. Personnel is also trained if it has been instructed or if it may switch electric circuits on and off, ground and label them. Trained personnel must also have appropriate safety equipment and be instructed in first aid.
- Use only those replacement parts designated as acceptable.
- Safety guidelines and regulations must be complied with.
- The motors are intended for mounting into machines that will be used commercially.
- Commissioning is not permitted until it has been determined that the machine meets the EG directives 89/392/EEG for its application as per the corresponding machine guidelines.
- It may only be operated if it maintains the national EMC requirements for the particular application. The EMC guideline 89/336/EEG applies within the EU.

### 10.2 Note on protection against contact with live parts

If parts carrying in excess of 50 volts are touched, then this could be dangerous for human beings. When operating electrical components, they unavoidably become live and conduct dangerous voltage levels.

**DANGER****High voltage!**

DANGER to life or severe injury!

- ⇒ Comply with general setup and safety guidelines when working on high voltage facilities.
- ⇒ After installation, check the permanent connection of the protective conductor at all electrical components for compliance with the terminal diagram.
- ⇒ Operation, even for quick measuring and testing purposes, is only permitted with permanently attached protective conductors of all electrical components.
- ⇒ Prior to accessing electrical parts with voltages greater than 50 volts, remove them from the mains or the voltage source. Secure against being switched back on.
- ⇒ Wait the discharge time of five minutes after switching off before accessing the motor.
- ⇒ Points of electrical connections of the components are not to be touched when on.
- ⇒ Before switching the machine on, cover live parts to prevent contact.
- ⇒ Make sure that there is also sufficient against indirect contact (as per DIN EN 50178/edition 11.94, 5.3.2.3).

**WARNING****High leakage current!**

DANGER to life or severe injury!

- ⇒ Prior to switching on, connect the electrical devices of each drive controller, supply unit and the motor with the protective device to the grounding point.
- ⇒ The leakage current is greater than 3.5 mA. This necessitates a permanent connection to the power supply system (as per DIN EN 50178/edition 11.94, 5.3.2.3).
- ⇒ Before starting up, even for test purposes, always connect the protective conductor. High voltages could otherwise occur on the housing.

## 10.3 Notes on "safely-isolated low voltages"

The connections and interfaces on the drive components intended for signal voltages range from 5 to 30 volts. These electrical circuits are part of the safely-isolated electrical circuits (safely-isolated low voltages).



**WARNING****High electrical voltages from improper connections!****DANGER** to life or severe injury!

⇒ Only those devices, electrical components or lines may be connected to the signal voltages of these components if they are sufficiently and safely isolated from the connected electrical circuits as complying with set standards (as per DIN EN 50178/edition 11.94, section 5.3.2.3).

## 10.4 Notes on handling and mounting

**CAUTION****DANGER when handling!**

Injury from pinching, shearing, cutting and poking!

- ⇒ Comply with the general setup and safety guidelines on handling and mounting.
- ⇒ Use suitable mounting and transport devices and special tools, if necessary.
- ⇒ Squeezing and pinching can be prevented with the proper measures.
- ⇒ If necessary, wear suitable protective clothing (for example, protective eyewear, shoes and gloves).
- ⇒ Do not stand under hanging loads.
- ⇒ Spilled liquids must be wiped up immediately to avoid slipping.

## 10.5 Notes on protection against dangerous movements

The causes of dangerous motions can be various:

- faulty control
- software error
- component failure
- faulty wiring and cabling
- error in encoder for signals and measured values
- error causes by improper use of components

These errors can occur either directly after powering up or any time thereafter.

**DANGER****Dangerous movements!**

Danger to life, severe injury or property damage!

- ⇒ The monitoring devices within the drive components largely exclude malfunctions. This alone should not be relied upon for personnel safety. Until the built-in monitors are activated, it should be assumed that a faulty drive motion can occur, the extent of which depends on the nature of the problem and the operating mode. Personnel protection is therefore dependent on and must be secured with monitoring devices or measures that are superordinate in the machine. These are instituted in the machine by the manufacturer after a danger and error analysis has been complied with which takes the safety measures for the machine into consideration as well.
- ⇒ Personnel may not remain within the motional range of the machine. Possible measures against accidental accessing of personnel are:
  - protective fences
  - protective railings
  - protective covers
  - and photosensors.
- ⇒ Make sure that fencing and covers are strong enough to absorb maximum motional energy.
- ⇒ E-stop switches must be easily accessible and in close proximity to the user. Check the E-stop prior to commissioning to make sure it is operating properly.
- ⇒ Secure against unintentional startups of the drive via the E-stop loop or use a starting lockout mechanism.
- ⇒ Prior to accessing or entering the danger zone, bring the drives to a standstill.
- ⇒ Switch electrical equipment off via the main switch and secure it against being switched back on in the event of
  - maintenance and service work
  - when clearing
  - prior to long operational breaks
- ⇒ The operation of high frequency, remote control and radio equipment in the proximity of the machine's electronics and leads is to be avoided. If such must be used, then check, prior to initial start, both system and machine for possible malfunctions in all situations. It may be necessary to run a special EMC check on the machine.

# 11 Mounting and Installation

## 11.1 Qualified personnel

All work on the machines and drives, or work within proximity of such, must be performed by trained and qualified personnel only. The user of machine or plant must ascertain that all personnel performing

- installation or
- maintenance work
- or those who operate them

are familiar with the contents, the warnings and the guidelines as specified in this documentation. Qualified personnel is trained, instructed and authorized to switch electric circuits and equipment on and off as per safety guidelines. They may also ground and label these. This personnel is equipped with appropriate safety equipment and is trained in first aid.

## 11.2 General notes on mounting

- ⇒ Comply with all the warnings and safety guidelines outlined in section 10 „Safety Guidelines for electrical drives“. This minimizes the risk of an accident and avoids damage to the plant or motor.
- ⇒ Follow all instructions carefully. This guarantees a problem-free assembly and disassembly of all components.

## 11.3 Mounting the motor

- ⇒ Obtain lifting devices, auxiliary aids, measuring and testing equipment.
- ⇒ Check the transferrable holding torque of the holding brake.  
If the holding torque listed in the dimensional data sheets is not achieved, then go to section 11.5, page 11-7 first before taking the following steps.
- ⇒ Check all the components for cleanliness.
- ⇒ Check whether the components have visible damage. Do not mount damaged parts.
- ⇒ Make sure that the mounting procedure itself takes place in a dry, dust-free environment.
- ⇒ Make sure that the motor flange is free of burrs.
- ⇒ Mount the motor. Maintain all dimensions and tolerances of the motor on the machine. For relevant data, see section "MKE ...", section „“.
- ⇒ If the motor is equipped with a "resolver feedback", then note, when allocating the reference point switches, that, due to the operating principle of the resolver, several zero pulses are generated during the course of an entire motor rotation (see section 1.3 "Motor feedback").
- ⇒ If the motor is equipped with a "resolver feedback with integrated multi-turn absolute encoder", then make sure that the battery of the feedback electronics is in order. Empty or used batteries must be properly disposed of. If the battery needs to be replaced, then please follow the instructions outlined in section 12.1 „Changing the battery“.

---

**Note:** In the event the motor must be replaced, the connecting cable may remain in the lid of the terminal box. Only the motor needs to be replaced and attached to the connector on the new motor. This translates into a simple, service-friendly and quick replacement of MKE motors!

---

## 11.4 Connecting the motor

Once the motor has been properly mechanically mounted, then it can be connected.

---



**DANGER**

### **DANGER from electrical voltage!**

Working in the area of live parts can be perilous. Thus:

- ⇒ All work on the electrical components may only be performed by trained electrical personnel. Electrical tools are absolutely necessary.
  - ⇒ Before starting work, switch power to the machine off. Secure the power switch against being unintentionally and accidentally switched back on.
  - ⇒ Prior to starting work, check, using suitable equipment, whether components are still under any residual voltage (e.g., from capacitors or similar). Wait until completely discharged.
- 



**WARNING**

### **Injury to personnel or damage to property possible!**

Interrupting or connecting live leads can cause unanticipated dangerous situations or property damage. Therefore:

- ⇒ Plugin connectors may only be connected or separated when these are dry and dead.
  - ⇒ All plugin connectors must be firmly screwed into place while the machine is running.
- 



**WARNING**

### **Danger of short-circuits from coolant or lubricants!**

A short-circuit in live lines can cause unanticipated dangerous situations or property damage. Therefore:

- ⇒ Cover the exposed connector side of power plugin connectors both during installation or when replacing drive components, if the possibility exists that these could come into contact with either coolants or lubricants.
-

Indramat's terminal diagrams should be exclusively used for developing the wiring diagrams of the machine!

⇒ connect the motor as per the machine wiring diagrams of the manufacturer of the machine! Use the relevant terminal diagram as depicted in Fig. 3-2: Terminal diagram of MKE motor with terminal box.

⇒ Note the instructions in the following section when mounting and routing the cables.

## Connecting guidelines for MKE 035 and MKE 045



**WARNING**

### Possible damage to terminal box or cables!

High tightening torques can damage screwed joints or pinch cables. If screwed joints are damaged, then the protection category IP 65 at the terminal box can no longer be guaranteed!

⇒ Do not, therefore, use automatic screwdrivers such as an electrical, pneumatic or hydraulic screwdriver!

MKE motors are equipped with a terminal box. Use ready-made INDRAMAT cables to mount them. Mount the cables as depicted below:




Fig. 11-1: Drawing of EExd screwed joint with terminal box

⇒ Release lid screws (8) and remove terminal box lid (9).

⇒ The EExd cable screwed joints are mounted at the factory. Sealing ring (1) is screwed to the screwed joints (2) in the terminal box lid. Tightening torque equals 50 Nm.

⇒ Cap nut (5) and washer (4) must be removed.

- ⇒ Cap nut (5) and washer (4) must be guided over power cable (7) or feedback cable (6).
- ⇒ Check cable sealing ring (3) in screwed joint (2).
- ⇒ Feed cable end (6) and (7) through screwed joints (2) through terminal box lid (9).




Fig. 11-2: Mounting power and feedback cables

- ⇒ Pull cable back to the point where the shrink sleeve extends into the inside of the terminal box by about 16 mm.
- ⇒ Screw down cap nut (5) onto screwed joint (2) with a tightening torque of about 15 Nm. This torque is achieved if the cable screwed joint is manually tightened and then turned twice using a suitable tool.
- ⇒ The connecting plugs X1, X2 and X3 must be mounted as per MKE motor plans (see Fig. 3-2: Terminal diagram of MKE motor with terminal box).

**Note:** Crimping pliers are available from INDRAMAT to mounting connector X3, part no. 262 293

- ⇒ The ground ring terminals (10) and (11) must be screwed to the terminal box lid (9) with 1.3 Nm.
- ⇒ X1, X2 and feedback connector X3 must be placed into position on the motor mounting panel.
- ⇒ The 4 connecting screws (plugin bushing of power cable connector part no.: 259698) of X1, must be firmly screwed into place.
- ⇒ The sealing ring (12) must be well greased, then inserted into nut on motor housing (13).
- ⇒ Make sure that no cable strands are pinched or damaged.
- ⇒ Tighten terminal box lid (9) into place with TFL coated lid screws (8) and 6.1 Nm.

**i** If the lid screws (8) must be replaced, then only use screws, as per DIN 912 with a firmness of at least 8.8!

**Note:** If the terminal box must be repeatedly mounted, or has been repeatedly remounted, then it is recommended that the fastening screws (8) are additionally secured with Loctite 243.

## Connecting guidelines for MKE 096



### WARNING

#### Terminal box or cables could be damaged!

Excessive tightening torques could damage screwed joints or pinch cables. If screwed joints are damaged then the protection category IP 65 for the terminal box can no longer be guaranteed!

⇒ Therefore, do not use automatic screwdrivers such as electrical, pneumatic or hydraulic screwdrivers!

MKE motors are equipped with terminal boxes. Cables which correspond to ready-made INDRAMAT cables must be used for connections. Mount the cables in the following order:




Fig. 11-3: EExd screwed joints with terminal box lid for MKE 096

- ⇒ Release lid screws (8) and remove terminal box lid (9).
- ⇒ The EExd cable screwed joints are mounted at the factory. Sealing ring (1) is screwed to the screwed joints (2) in the terminal box lid. Tightening torque equals 50 Nm.
- ⇒ Cap nut (5) and washer (4) must be removed.
- ⇒ Cap nut (5) and washer (4) must be guided over power cable (7) or feedback cable (6).
- ⇒ Check cable sealing ring (3) in screwed joint (2).
- ⇒ Guide cable ends (6) and (7) through the screwed joints (2) into the terminal box lid (9).




Fig. 11-4: Feeding in power and feedback cables of MKE 096

- ⇒ Pull cables back to the point where the shrink sleeve extends into the interior of the terminal box starting from the end of the screwed joint for a length of about 35 mm (up to about the middle of the terminal box lid) (see Fig. 11-4: Feeding in power and feedback cables of MKE 096).
- ⇒ Screw down cap nut (5) onto screwed joint (2) with a tightening torque of about 15 Nm. This torque is achieved if the cable screwed joint is manually tightened and then turned twice using a suitable tool.
- ⇒ The connectors X1, X2 and X3 must be mounted as per MKE motor plans (see Fig. 3-2: Terminal diagram of MKE motor with terminal box).

**Note:** Crimping pliers are available from INDRAMAT to mounting connector X3, part no. 262 293

- ⇒ The ground ring terminals (10) and (11) must be screwed to the terminal box lid (9) with 1.3 Nm.
- ⇒ X1, X2 and feedback connector X3 must be placed into position on the motor mounting panel.
- ⇒ The 4 connecting screws (plugin bushing of power cable connector part no.: 259698) of X1, must be firmly screwed into place.
- ⇒ The sealing ring (12) must be well greased and inserted into nut on motor housing (13).
- ⇒ Make sure that no cable strands are pinched or damaged.
- ⇒ Tighten terminal box lid (9) into place with TFL coated lid screws (8) and 6.1 Nm.

**i** If the lid screws (8) must be replaced, then use only screws, as per DIN 912 with a firmness of at least 8.8!

**Note:** If the terminal box is repeatedly mount, then it is recommended that the screws (8) are additionally secured with Loctite 243.



## EExd cable screwed joints

To meet the explosion requirements, it is necessary to tighten the cable screwed joints after power and feedback cables are in place.

Tightening torque: 15 Nm

A tightening torque of approximately 15 Nm is achieved if the cable screwed joints are manually tightened and then followed by two more turns of a suitable tool (spanner or wrench).

The EExd screwed joints are only permitted with specific cable diameters. The table below specifies these diameters for screwed joints of the power and feedback cables.

EExd screwed joint	Screwed joint type	Permitted cable diameters in mm	
		Min.	Max.
Power cable	VERSCHR-M*20,0-GER-EX-11,0*14,3-MS-C4N-6	11.0	14.3
Feedback cable	VERSCHR-M*20,0-GER-EX-07,5*11,9-MS-C4N-6	7.5	11.9

Fig. 11-5: Permissible cable diameter of EExd screwed joints

If MKE motors are not mounted using the cable screwed joints supplied by INDRAMAT, then the following must be noted.

**Note:** MKE motors must be mounted with cable screwed joints that have a special test certificate complying with the B generation of EN 50014 and EN 50018.

## 11.5 Refinishing the holding brake

Check if the holding brake is functioning properly before mounting the motor. How to check the holding brake is described below as well as procedures to follow if any refinishing of such could be necessary.



**CAUTION**

**Premature wear of the holding brake is possible!**

The holding brake wears down after approx. 20000 motor revolutions when closed.

⇒ Please therefore note the following instructions!

**Prerequisite:** The motor is equipped with a holding brake and has been stored for an extended period.

⇒ Check the transferrable holding torque of the holding brake.

If the holding torque listed in the dimensional data sheets is not achieved, then refinish the holding brake.

The following preconditions must be set before the holding brake can be refinished.

**Prerequisite:** No electrical connection of motor and drive controller.

⇒ Electrical connection between motor and drive controller must be separated.

⇒ Turn motor manually with holding brake closed approximately 50 times.

The holding brake is now refinished and ready to operate.

## 12 Service Notes

### 12.1 Changing the battery

If the motor is equipped "with integrated multiturn absolute encoder", then the battery must be included in regular maintenance scheduling. The nominal lifespan of the battery equals approximately 10 years.

#### How to change the battery

⇒ The following tools and aids must be handy:

- Allen screw driver for  
MKE 035 Size 2,5  
MKE 045 Size 3  
MKE 096 Size 4
- pointed pliers
- torque key with a range of 1.3 - 6.8 Nm
- New, ready-made batters for  
MKE 035 and MKE 045 INDRAMAT part no. 257 101  
MKE 096 INDRAMAT part no. 265 187



**DANGER**

#### **Danger to life and limb from electrical voltage!**

When changing the batter, the control voltage must be left on. Therefore:

- ⇒ only trained electricans must work on the machine.
- ⇒ switch power supply to machines off and secure them against being switched back on!



**DANGER**

#### **Dangerous movements!**

Danger to life and limb and serious property damage!

- ⇒ Switch power supply to drive controllers off and secure against being switched back on.
- ⇒ Replace batteries only with control voltage on. If control voltage is switched off with the battery removed, then the reference dimension will be lost and faulty movement could occur once the machine is switched back on.

#### Removing the battery

- ⇒ Allen screws (1) must be released and removed with Allen screwdriver size 2.5, 3 or 4
- ⇒ Remove motor feedback lid.
- ⇒ Pull battery connector (2) out.
- ⇒ Release screw (4) of the clamping device (3) of battery and remove it.

#### Mounting the battery

- ⇒ Insert ready-made battery as per motor type (part no. 257101 or 265187) and screw clamping device (3) with screws (4) back on (tightening torque max. 1.0 Nm).

**Note:** Do not pinch battery cable!

- ⇒ Place battery connector (2) back in place.
- ⇒ Close the motor feedback lid.
- ⇒ Allen screws (1) must be screwed back into place with toque key for MKE 035 with 3.1 Nm, MKE 045 with 1.3 Nm or 6.1 Nm with the MKE 096.




Fig. 12-1: Changing the battery

- Powering machine/plant up**
- ⇒ Switch power supply to drive controllers back on.
  - ⇒ Run an axis test.

## 12.2 Maintenance work

The motors should be regularly cleaned (no later than one year after assuming operations)

- of dust, chips or similar dirt.

## 12.3 Contacting Customer Service

To rapidly and effectively eliminate and deal with all problems, our Service-Hotline is available.

⇒ Prior to calling, please note the following information

- type designations of drive controllers and motors not functioning
- the state of the problem
- disturbance or diagnostic displays (if machine is thus equipped)

Our Service-Hotline can be reached as follows:

Monday - Friday	7 - 23 CET
Saturday	8 - 20 CET
Sundays and holidays	9 - 19 CET



at the following telephone numbers

0171 - 333 882 6 **or** 0172 - 660 040 6.

⇒ If the decision has been made to return the motors, then please make a copy of the following fault report, fill it out and include it in the shipment.

⇒ Add a copy of the fault report to the machine documents for the user in the event such is needed.

This will facilitate processing of repairs and in determining application-specific problems.

INDRAMAT		<b>Fault Report</b> for digital DKC and MKE AC servo drives	
<p>This fault report serves to clarify problems and their causes. It is absolutely necessary in order to detect and eliminate even hidden, sporadica or applicat-specific problems.</p> <p>- Always include fault report when returning parts for repair.</p> <p>- Otherwise send fault reports to relevant INDRAMAT office or the address of INDRAMAT's Quality Assurance department printed in the address field.</p> <p>INDRAMAT appreciates your cooperation in this matter and will respond as quickly as possible.</p>			
<b>Fault report dated:</b>	Co.:	Loc	Date:
	Dept.:	Name:	Tel.:
<p><b>Data on problem drive:</b></p> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Data on type plate of basic unit</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">FWA _____</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">DKC .- .- .- .- .- .-</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">SN: _____</div> <p>Mains connection: single <input type="checkbox"/> three phase <input type="checkbox"/></p> </div> <div style="width: 10%; text-align: center;">  <p>Display at time problem occurred</p> </div> <div style="width: 40%;"> <p>Motor data</p> <p>Motor _____</p> <p>S. No.: _____</p>  </div> </div>			






	<h2 style="margin: 0;">Fault Report</h2> <h3 style="margin: 0;">for HDS and HDD digital AC drives</h3>									
<p>This fault report serves to clarify problems and their causes. It is absolutely necessary in order to detect and eliminate even hidden, sporadica or application-specific problems.</p> <p>- Always include fault report when returning parts for repair.</p> <p>- Otherwise send fault reports to relevant INDRAMAT office or the address of INDRAMAT's Quality Assurance department printed in the address field.</p> <p>INDRAMAT appreciates your cooperation in this matter and will respond as quickly as possible.</p>										
<p><b>Fault report dated:</b></p>	<p>Co.: _____ Loc _____ Date: _____</p> <p>Dept.: _____ Name: _____ Tel.: _____</p>									
<p><b>Data on problem drive:</b></p> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p><b>Type plate of basic unit</b></p> <p>basic unit type designation: _____</p> <p>coded serial number: </p> <p>Serial number: SN _____ internal marker: A _____</p> <p><b>Firmware type plate</b></p> <p>Firmware type designation: FWA- _____ V _____ K _____</p> <p>coded serial number: </p> <p>serial number: SN _____ internal marker: _____</p> </div> <div style="width: 45%;"> <p><b>Configuration type plate</b></p> <p>SYSTEMCONFIGURATION</p> <p>_____ -2- _____ -FW</p> <p>_____ -2- _____</p> <p>U 1 _____</p> <p>U 2 _____</p> <p>U 3 _____</p> <p>U 4 _____</p> <p>U 5 _____</p> <p>K_ / _</p> </div> </div> <div style="text-align: center; margin-top: 10px;">  <p>H1 and H2 display (note display at time problem occurred)</p> </div> <div style="margin-top: 10px;">  <p>Motor data _____</p> <p>Motor _____</p> <p>S. No.: _____</p> </div>										
<p><b>Data on machine with problem:</b></p> <p>Manufacturer: _____ Type: _____ Operating hours: _____</p> <p>Machine number: _____ Startup date: _____</p> <p>Manufacturer and machine control type: _____</p> <p>Machine axis designation with problem: _____</p> <p><b>Please explain the problem:</b></p> <p>_____</p> <p>_____</p> <p>_____</p>										
<p><b>Additional data:</b></p> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="width:25%;">Status:</th> <th style="width:25%;">Causes:</th> <th style="width:25%;">Accompanying</th> <th style="width:25%;"></th> </tr> </thead> <tbody> <tr> <td> <input type="checkbox"/> is steady  <input type="checkbox"/> at startup  <input type="checkbox"/> occurs sporadically  <input type="checkbox"/> occurs after <input type="checkbox"/> hours  <input type="checkbox"/> occurs with shocks  <input type="checkbox"/> is temperature dependent   <input type="checkbox"/> Additional comments: _____                      _____                      _____                 </td> <td> <input type="checkbox"/> unknown  <input type="checkbox"/> faulty connection  <input type="checkbox"/> external causes  <input type="checkbox"/> mechanical damage  <input type="checkbox"/> loose cable connection  <input type="checkbox"/> moisture in unit  <input type="checkbox"/> extrinsic object in unit                 </td> <td> <input type="checkbox"/> Problem in mechanics  <input type="checkbox"/> power section failure (24 V<sub>ext.</sub>)  <input type="checkbox"/> control failure  <input type="checkbox"/> motor failure  <input type="checkbox"/> cable break  <input type="checkbox"/> blower defective  <input type="checkbox"/> feedback defective                 </td> <td>                     Is there an air conditioner in the cabinet ?                      Y / N <input type="checkbox"/> <p>Have there been similar problems previously ?</p> <p>How often: _____</p> <p>Did problems always occur in specific days or specific times of the day?</p>                     _____                      _____                 </td> </tr> </tbody> </table>			Status:	Causes:	Accompanying		<input type="checkbox"/> is steady <input type="checkbox"/> at startup <input type="checkbox"/> occurs sporadically <input type="checkbox"/> occurs after <input type="checkbox"/> hours <input type="checkbox"/> occurs with shocks <input type="checkbox"/> is temperature dependent  <input type="checkbox"/> Additional comments: _____ _____ _____	<input type="checkbox"/> unknown <input type="checkbox"/> faulty connection <input type="checkbox"/> external causes <input type="checkbox"/> mechanical damage <input type="checkbox"/> loose cable connection <input type="checkbox"/> moisture in unit <input type="checkbox"/> extrinsic object in unit	<input type="checkbox"/> Problem in mechanics <input type="checkbox"/> power section failure (24 V <sub>ext.</sub> ) <input type="checkbox"/> control failure <input type="checkbox"/> motor failure <input type="checkbox"/> cable break <input type="checkbox"/> blower defective <input type="checkbox"/> feedback defective	Is there an air conditioner in the cabinet ? Y / N <input type="checkbox"/> <p>Have there been similar problems previously ?</p> <p>How often: _____</p> <p>Did problems always occur in specific days or specific times of the day?</p> _____ _____
Status:	Causes:	Accompanying								
<input type="checkbox"/> is steady <input type="checkbox"/> at startup <input type="checkbox"/> occurs sporadically <input type="checkbox"/> occurs after <input type="checkbox"/> hours <input type="checkbox"/> occurs with shocks <input type="checkbox"/> is temperature dependent  <input type="checkbox"/> Additional comments: _____ _____ _____	<input type="checkbox"/> unknown <input type="checkbox"/> faulty connection <input type="checkbox"/> external causes <input type="checkbox"/> mechanical damage <input type="checkbox"/> loose cable connection <input type="checkbox"/> moisture in unit <input type="checkbox"/> extrinsic object in unit	<input type="checkbox"/> Problem in mechanics <input type="checkbox"/> power section failure (24 V <sub>ext.</sub> ) <input type="checkbox"/> control failure <input type="checkbox"/> motor failure <input type="checkbox"/> cable break <input type="checkbox"/> blower defective <input type="checkbox"/> feedback defective	Is there an air conditioner in the cabinet ? Y / N <input type="checkbox"/> <p>Have there been similar problems previously ?</p> <p>How often: _____</p> <p>Did problems always occur in specific days or specific times of the day?</p> _____ _____							

Fig. 12-3: MKE on HDS, HDD

# 13 Index

## A

Advantages 1-2  
Ambient temperature 2-2  
Applications 1-1  
Available cable lengths 3-5  
Axial force Faxial 2-7

## B

Barcode sticker 8-1  
Bearing lifespan 2-7

## C

Changing the battery 12-1  
Condition at delivery 7-1  
Conditions of Use 2-2  
Continuous torque at standstill 1-1  
Customer Service 12-2

## D

Danger of explosion 2-1  
Delivery slip 8-1  
Drawing of EExd screwed joint with terminal box 11-3  
Drive shaft  
    Drive shaft with keyway 2-5  
    Plaint drive shaft 2-5  
    Shaft loads 2-5

## E

EExd cable screwed joints 11-7  
Electrical connections 1-3  
    Connection variants and cable output directions 2-9  
    Overview of connections 3-1  
    Terminal box 3-2  
    Terminal diagram 3-2  
    Thermal cutout 3-3  
Explosive area 2-1

## F

Feedback cable 3-5  
Feedback data storage 1-4

## G

General features 1-1

## H

Handling 9-1

Holding brake 2-8  
Holding brakes 1-3  
Housing finish 2-4

## I

Identification 7-1  
Individual parts 3-7  
Installation elevation 2-2

## L

Lifting belts 9-2  
Load factor 2-2  
Load factors 2-2

## M

Maintenance work 12-2  
Metal bands 7-1  
Minimum temperature resistance 3-7  
MKE 035

    Available versions and type codes 4-5  
    Determining maximum shaft load 4-3  
    Dimensions 4-4  
    Speed/torque characteristics 4-2  
    Technical data 4-1

### MKE 045

    Available versions and type codes 5-5  
    Determining maximum shaft load 5-3  
    Dimensions 5-4  
    Speed/torque characteristics 5-2  
    Technical data 5-1

### MKE 096

    Available versions and type codes 6-5  
    Determining maximum shaft load 6-3  
    Dimensions 6-4  
    Speed/torque characteristics 6-2  
    Technical data 6-1

### Motor feedback 1-3

### Mounting 11-1

### Mounting drive elements 2-7

### Mounting orientation 2-5

### Mounting the battery 12-1

### Multiturn absolute encoder 1-4

## N

Nominal data 2-2

## O

Output shaft 1-3  
Overview of performance 1-1

## P

Packaging 9-1  
Placing power and feedback cables 11-4

Position evaluation 1-4  
Power cable 3-3  
Primary coat 2-4  
Protection category 2-3

## Q

Qualified personnel 11-1

## R

Radial force Fradial 2-6  
Refinishing the holding brake 11-8  
Removing the battery 12-1  
Resolver feedback (RSF) 1-4  
Rotational speed 2-10, 4-2

## S

### Safety Guidelines

Connecting the motor 11-2  
General information 10-1  
Protecting "safely-isolated low voltages 10-2  
Protection against contact with live parts 10-1  
Protection against dangerous movements 10-3  
Protection when handling and mounting 10-3  
Selection data 2-2  
Shipping papers 7-1  
Shock damping 9-2  
Storage 9-1  
Structure and components 1-2

## T

Torque 2-10  
Transport 9-1  
Type of construction 2-5  
Type plate 8-2

## V

Versions 1-3  
Vibration and shock requirements 2-3



# Directory of Customer Service Locations

## Germany

<p>Sales region central</p> <p>INDRAMAT GmbH D-97816 Lohr am Main Bgm.-Dr.-Nebel-Str. 2</p> <p>Telefon: 09352/40-0 Telefax: 09352/40-4885</p>	<p>Sales region east</p> <p>INDRAMAT GmbH D-09120 Chemnitz Beckerstraße 31</p> <p>Telefon: 0371/3555-0 Telefax: 0371/3555-230</p>	<p>Sales region west</p> <p>INDRAMAT GmbH D-40849 Ratingen Hansastraße 25</p> <p>Telefon: 02102/4318-0 Telefax: 02102/41315</p>	<p>Sales region north</p> <p>INDRAMAT GmbH D-22085 Hamburg Fährhausstraße 11</p> <p>Telefon: 040/227126-16 Telefax: 040/227126-15</p>
<p>Sales region south</p> <p>INDRAMAT GmbH D-80339 München Ridlerstraße 75</p> <p>Telefon: 089/540138-30 Telefax: 089/540138-10</p>	<p>Sales region southwest</p> <p>INDRAMAT GmbH D-71229 Leonberg Böblinger Straße 25</p> <p>Telefon: 07152/972-6 Telefax: 07152/972-727</p>		<p>INDRAMAT Service-Hotline</p> <p>INDRAMAT GmbH Telefon: D-0172/660 040 6 -or- Telefon: D-0171/333 882 6</p>

Customer service locations in Germany

## Europe

<p>Austria</p> <p>G.L.Rexroth Ges.m.b.H. Geschäftsbereich INDRAMAT A-1140 Wien Hägelingasse 3</p> <p>Telefon: 1/9852540-400 Telefax: 1/9852540-93</p>	<p>Austria</p> <p>G.L.Rexroth Ges.m.b.H. Geschäftsbereich INDRAMAT A-4061 Pasching Randlstraße 14</p> <p>Telefon: 07229/64401-36 Telefax: 07229/64401-80</p>	<p>Belgium</p> <p>Mannesmann Rexroth N.V.-S.A. Geschäftsbereich INDRAMAT B-1740 Ternat Randlstraße 8</p> <p>Telefon: 02/5823180 Telefax: 02/5824310</p>	<p>Denmark</p> <p>BEC Elektronik AS DK-8900 Randers Zinkvej 6</p> <p>Telefon: 086/447866 Telefax: 086/447160</p>
<p>England</p> <p>Mannesmann Rexroth Ltd. INDRAMAT Division Cirencester, Glos GL7 1YG 4 Esland Place, Love Lane</p> <p>Telefon: 01285/658671 Telefax: 01285/654991</p>	<p>Finnland</p> <p>Rexroth Mecman OY SF-01720 Vantaa Riihimiehentie 3</p> <p>Telefon: 0/848511 Telefax: 0/846387</p>	<p>France</p> <p>Rexroth - Sigma S.A. Division INDRAMAT F-92632 Gennevilliers Cedex Parc des Barbanniers 4, Place du Village</p> <p>Telefon: 1/41475430 Telefax: 1/47946941</p>	<p>France</p> <p>Rexroth - Sigma S.A. Division INDRAMAT F-69634 Venissieux - Cx 91, Bd 1 Joliot Curie</p> <p>Telefon: 78785256 Telefax: 78785231</p>
<p>France</p> <p>Rexroth - Sigma S.A. Division INDRAMAT F-31100 Toulouse 270, Avenue de l'ardenne</p> <p>Telefon: 61499519 Telefax: 61310041</p>	<p>Italy</p> <p>Rexroth S.p.A. Divisione INDRAMAT I-20063 Cernusco S/N.MI Via G. Di Vittoria, 1</p> <p>Telefon: 02/92365-270 Telefax: 02/92108069</p>	<p>Italy</p> <p>Rexroth S.p.A. Divisione INDRAMAT Via Borgomanero, 11 I-10145 Torino</p> <p>Telefon: 011/7712230 Telefax: 011/7710190</p>	<p>Netherlands</p> <p>Hydraudyne Hydrauliek B.V. Kruisbroeksestraat 1a P.O. Box 32 NL-5280 AA Boxtel</p> <p>Telefon: 04116/51951 Telefax: 04116/51483</p>
<p>Spain</p> <p>Rexroth S.A. Centro Industrial Santiago Obradors s/n E-08130 Santa Perpetua de Mo- goda (Barcelona)</p> <p>Telefon: 03/718 68 51 Telex: 591 81 Telefax: 03/718 98 62</p>	<p>Spain</p> <p>Goimendi S.A. División Indramat Jolastokieta (Herrera) Apartado 11 37 San Sebastian, 20017</p> <p>Telefon: 043/40 01 63 Telex: 361 72 Telefax: 043/39 93 95</p>	<p>Sweden</p> <p>AB Rexroth Mecman INDRAMAT Division Varuvägen 7 S-125 81 Stockholm</p> <p>Telefon: 08/727 92 00 Telefax: 08/64 73 277</p>	<p>Switzerland</p> <p>Rexroth SA Département INDRAMAT Chemin de l'Ecole 6 CH-1036 Sullens</p> <p>Telefon: 021/731 43 77 Telefax: 021/731 46 78</p>
<p>Switzerland</p> <p>Rexroth AG Geschäftsbereich INDRAMAT Gewerbestraße 3 CH-8500 Frauenfeld</p> <p>Telefon: 052/720 21 00 Telefax: 052/720 21 11</p>	<p>Russia</p> <p>Tschudnenko E.B. Arsenia 22 153000 Ivanovo Rußland</p> <p>Telefon: 093/22 39 633</p>		

European customer service locations without Germany

## Outside of Europe

<p><b>Argentina</b></p> <p>Mannesmann Rexroth S.A.I.C. Division INDRAMAT Acassusso 48 41/7 1605 Munro (Buenos Aires) Argentina</p> <p>Telefon: 01/756 01 40 01/756 02 40 Telex: 262 66 rexro ar Telefax: 01/756 01 36</p>	<p><b>Argentina</b></p> <p>Nakase Asesoramiento Tecnico Diaz Velez 2929 1636 Olivos (Provincia de Buenos Aires) Argentina Argentina</p> <p>Telefon 01/790 52 30</p>	<p><b>Australia</b></p> <p>Australian Industrial Machinery Services Pty. Ltd. Unit 3/45 Horne ST Campbellfield VIC 2061 Australia</p> <p>Telefon: 03/93 59 0228 Telefax: 03/93 59 02886</p>	<p><b>Brazil</b></p> <p>Mannesmann Rexroth Automação Ltda. Divisão INDRAMAT Rua Georg Rexroth, 609 Vila Padre Anchieta BR-09.951-250 Diadema-SP Caixa Postal 377 BR-09.901-970 Diadema-SP</p> <p>Telefon: 011/745 90 65 011/745 90 70 Telefax: 011/745 90 50</p>
<p><b>Canada</b></p> <p>Basic Technologies Corporation Burlington Division 3426 Mainway Drive Burlington, Ontario Canada L7M 1A8</p> <p>Telefon: 905/335-55 11 Telefax: 905/335-41 84</p>	<p><b>China</b></p> <p>Rexroth (China) Ltd. Shanghai Office Room 206 Shanghai Intern. Trade Centre 2200 Yanan Xi Lu Shanghai 200335 P.R. China</p> <p>Telefon: 021/627 55 333 Telefax: 021/627 55 666</p>	<p><b>China</b></p> <p>Rexroth (China) Ltd. Shanghai Parts &amp; Service Centre 199 Wu Cao Road, Hua Cao Minhang District Shanghai 201 103 P.R. China</p> <p>Telefon: 021/622 00 058 Telefax: 021/622 00 068</p>	<p><b>China</b></p> <p>Rexroth (China) Ltd. 1430 China World Trade Centre 1, Jianguomenwai Avenue Withjing 100004 P.R. China</p> <p>Telefon: 010/50 50 380 Telefax: 010/50 50 379</p>
<p><b>China</b></p> <p>Rexroth (China) Ltd. A-5F., 123 Lian Shan Street Sha He Kou District Dalian 116 023 P.R. China</p> <p>Telefon: 0411/46 78 930 Telefax: 0411/46 78 932</p>	<p><b>Honkong</b></p> <p>Rexroth (China) Ltd. 19 Cheung Shun Street 1st Floor, Cheung Sha Wan, Kowloon, Honkong</p> <p>Telefon: 741 13 51/-54 and 741 14 30 Telex: 3346 17 GL REX HX Telefax: 786 40 19 786 07 33</p>	<p><b>India</b></p> <p>Mannesmann Rexroth (India) Ltd. INDRAMAT Division Plot. 96, Phase III Peenya Industrial Area Bangalore - 560058</p> <p>Telefon: 80/839 21 01 80/839 73 74 Telex: 845 5028 RexB Telefax: 80/839 43 45</p>	<p><b>Japan</b></p> <p>Rexroth Co., Ltd. INDRAMAT Division I.R. Building Nakamachidai 4-26-44 Tsuzuki-ku, Yokohama 226 Japan</p> <p>Telefon: 045/942-72 10 Telefax: 045/942-03 41</p>
<p><b>Korea</b></p> <p>Rexroth-Seki Co Ltd. 1500-12 Da-Dae-Dong Saha-Gu, Pusan, 604-050</p> <p>Telefon: 051/264 90 01 Telefax: 051/264 90 10</p>	<p><b>Korea</b></p> <p>Seo Chang Corporation Ltd. Room 903, Jail Building 44-35 Yoido-Dong Youngdeungpo-Ku Seoul, Korea</p> <p>Telefon: 02/780-82 07 -9 Telefax: 02/784-54 08</p>	<p><b>Mexico</b></p> <p>Motorización y Diseño de Controles, S.A. de C.V. Av. Dr. Gustavo Baz No. 288 Col. Parque Industrial la loma Apartado Postal No. 318 54060 Tlalnepantla Estado de Mexico</p> <p>Telefon: 5/397 86 44 Telefax: 5/398 98 88</p>	
<p><b>USA</b></p> <p>Rexroth Corporation INDRAMAT Division 5150 Prairie Stone Parkway Hoffman Estates, Illinois 60192</p> <p>Telefon: 847/645-36 00 Telefax: 857/645-62 01</p>	<p><b>USA</b></p> <p>Rexroth Corporation INDRAMAT Division 2110 Austin Avenue Rochester Hills, Michigan 48309</p> <p>Telefon: 810/853-82 90 Telefax: 810/853-82 90</p>		

Customer service locations outside of Europe



Bosch Rexroth AG  
Electric Drives and Controls  
P.O. Box 13 57  
97803 Lohr, Germany  
Bgm.-Dr.-Nebel-Str. 2  
97816 Lohr, Germany  
Phone +49 (0)93 52-40-50 60  
Fax +49 (0)93 52-40-49 41  
service.svc@boschrexroth.de  
www.boschrexroth.com

