

Programming with IndraStep SFCs with Mode Control and Diagnosis

Application Manual

SYSTEM200

Title	Programming with IndraStep SFCs with Mode Control and Diagnosis
Type of Documentation	Application Manual
Document Typecode	DOK-CONTRL-SPS*ISTEP02-AW02-EN-P
Internal File Reference	Document Number, 120-0400-B374-02/EN
Purpose of Documentation	This documentation serves to adjust to the possibilities of the mode control with IndraStep on the basis of a continuous example. Diagnosis and criteria analysis are shown for the different mode controls.

Record of Revisions

Description	Release Date	Notes
120-0400-B374-02/EN	01/03	First English issue

Copyright	© 2003 Rexroth Indramat GmbH Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).
Validity	The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.
Published by	Rexroth Indramat GmbH Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main Telephone +49 (0)93 52/40-0 • Tx 68 94 21 • Fax +49 (0)93 52/40-48 85 http://www.boschrexroth.de/ Dept. BRC/EPY (NH)
Note	This document has been printed on chlorine-free bleached paper.

Contents

1	General Information	1-1
1.1	Documentation Contents.....	1-1
1.2	Additional Documentations	1-2
1.3	Differences Between Standard SFC and IndraStep	1-3
2	Important Directions for Use	2-1
2.1	Appropriate Use	2-1
	Introduction	2-1
	Areas of Use and Application.....	2-2
2.2	Inappropriate Use.....	2-2
2.3	Delivery Stipulations for Computer Programs.....	2-3
3	Safety Instructions for Electric Drives and Controls	3-1
3.1	Introduction.....	3-1
3.2	Explanations.....	3-1
3.3	Hazards by Improper Use	3-2
3.4	General Information	3-3
3.5	Protection Against Contact with Electrical Parts.....	3-4
3.6	Protection Against Electric Shock by Protective Low Voltage (PELV).....	3-5
3.7	Protection Against Dangerous Movements.....	3-5
3.8	Protection Against Magnetic and Electromagnetic Fields During Operation and Mounting	3-7
3.9	Protection Against Contact with Hot Parts	3-8
3.10	Protection During Handling and Mounting	3-8
3.11	Battery Safety.....	3-9
3.12	Protection Against Pressurized Systems	3-9
4	Creating an IndraStep Example Project	4-1
4.1	Preparing the Root Program in WinPCL.....	4-1
4.2	Example Project: Drilling Station.....	4-9
4.3	Incorporating the Example in the “Root Program”	4-11
	Extending the Declaration by the Variables of the Example.....	4-11
	Completing the SFC (Automatic Mode) According to the Example.....	4-11
	Principles of Entering Actions and Switch-On Conditions (Automatic Mode).....	4-14
	Entering Actions and Transitions	4-18
	SetStep in the Automatic Mode	4-34
	Instructions on Starting the Program Example	4-35

- 4.4 Possibilities of Error Monitoring 4-35
 - Action Errors 4-35
 - Time Errors 4-36
 - Error Monitoring 4-39
- 4.5 Diagnosis Options 4-43
 - Diagnosis Options in WinPCL..... 4-43
 - Advanced Diagnosis in WinHMI 4-43
- 4.6 AutoStep Mode 4-61
- 4.7 Manual Mode 4-61
 - Supplementing the Manual Mode to the Example SFC..... 4-62
 - Activating Outputs by Forcing Steps and/or Actions in the Manual Mode..... 4-68
 - Activating Outputs via Operating Screens in the Manual Mode 4-69
 - Activating Outputs via Compact Operator Terminals in the Manual Mode..... 4-81
 - Activating Outputs by ManualForce in the Manual Mode 4-82
 - SetStep on Changing from the Manual Mode to the Automatic Mode 4-84
- 4.8 ProVi Messages Used for Diagnosis 4-85
- 4.9 Updating IndraStep Files..... 4-89

5 System Variables of Steps, Transitions, Actions and Sequences (Overview) 5-1

- 5.1 Modes for Sequential Function Charts..... 5-1
- 5.2 System Variables of Steps 5-2
- 5.3 System Variables of Transitions 5-3
- 5.4 System Variables of Actions 5-3
- 5.5 Overview of Action Qualifiers 5-4
- 5.6 System Variables of Sequences 5-5
 - Notes on the Control_a, Control_b and Control_c Flags..... 5-6
 - Control Signals “i” 5-7
 - Status Signals “q” 5-7

6 ProVi Messages (Overview) 6-1

- 6.1 ProVi Messages (Diagnosis in LD / IL Rungs)..... 6-1
 - General Information 6-1
 - Programming a ProVi Message 6-2
 - ProVi Message, Input Dialog 6-3
 - Output of ProVi Messages..... 6-5
 - ProVi Criteria Analysis 6-5
- 6.2 Sequential Function Chart Diagnosis..... 6-7
 - General Information 6-7
 - Programming a Sequential Function Chart Diagnosis..... 6-7
 - Output of Sequential Function Chart Diagnosis Messages 6-9
 - Programming Instructions 6-9
- 6.3 Diagnosis Display of I/O Addresses in PRs and FBs 6-11
- 6.4 Module Assignment (Multiple Use of POUs)..... 6-12

7	Instructions	7-1
7.1	Criteria Analysis	7-1
	Which Elements can be Processed by the Criteria Analysis?	7-1
	How Many Rungs are Covered by the Criteria Analysis?	7-2
	Using FBs, FNs and OPs	7-3
	Displayed Status Values of a Criteria Analysis	7-3
7.2	Motion Signal with IndraStep	7-4
8	Glossary	8-1
9	List of Figures	9-1
10	Index	10-1
11	Service & Support	11-1
11.1	Helpdesk	11-1
11.2	Service-Hotline	11-1
11.3	Internet	11-1
11.4	Vor der Kontaktaufnahme... - Before contacting us	11-1
11.5	Kundenbetreuungsstellen - Sales & Service Facilities	11-2

1 General Information

1.1 Documentation Contents

These programming instructions contain a description of the operating mode support provided by “IndraStep” within the WinPCL programming system for the programmable logic controllers (PLC) of Messrs. Bosch Rexroth, illustrated by a general example.

This documentation should be filed between the **Description of the User Interface for High-Volume-Production Machines /2/** and the PLC programming instructions **Programming with WinPCL 04VRS /1/**.

This documentation contains the following chapters:

- Creating a root program (chapter 4.1)

This chapter provides the IndraStep beginner with information on how to create a resource with a program in a variant. The program contains an IndraStep sequential function chart. Please note that this root program is initially independent of the example.

The root program is filed in the IndraStep_Demo_00.APV archive in ... \Basic Data\TEMPLATES.

- Description of an example and extension of the root program by this example in the automatic mode (chapters ,4.2, 4.3).

- Options of error control (chapter 4.4).

The options of error control are presented on the basis of the IndraStep example.

- Diagnosis options - criteria analysis (chapter 4.5).

This chapter shows that the WinPCL features permit minimum diagnosis in the startup phase which should, however, be extended by the WinHMI diagnosis features for practical use.

The example is used to describe the various error types and the associated diagnosis messages.

- For the IndraStep sequences, the automatic mode is extended by the AutoStep mode (chapter 4.6). This does not result in any changes to the sequential function chart used in the example.

- The functions possible in the manual mode are explained. The automatic sequential function chart of the example is extended by the manual mode (chapter 4.7).

- The possibilities of activating the outputs in the manual mode are discussed:

- Activating the outputs by forcing
- Activating the outputs by operating screens

Creation of operating screens is explained in detail. The connection between the operating screen and the diagnosis is shown by means of the example.

- Activating the outputs by compact operator panels
- Activating the outputs while overriding the locking mechanism (ManualForce)
- The diagnosis options are shown by means of ProVi messages (chapter 4.8).
- Instructions on how to update IndraStep files (chapter 4.9).

The following chapters complete the documentation by

- an overview of system variables of steps, transitions, actions, and sequences (chapter 5),
- an overview of ProVi messages (excerpt from /1/ and /2/) (chapter 6),
- FAQs, which are constantly updated in chapter 7.

1.2 Additional Documentations

Number	Title	Contents	Documentation code
/1/	Programming with WinPCL 04VRS	- Description of the Menu Structure - Editor Description - Description of the Standard and Firmware Types / Functions / Function Blocks	DOK-CONTRL-WINPCL*4VRS-AW..-EN-P
/2/	MTC200/ISP200/MTA200 WinHMI User Interface	Description of the User Interface for High-Volume-Production Machines	DOK-CONTRL-WIN*HMI*V22-AW..-EN-P
/3/	PC Compound	- Description of the actions required for establishing a PC network - Requirements for remote programming	DOK-CONTRL-PC**NET*V21-AW..-EN-P
/4/	ScreenManager for Miniature Control Panels Application Description	- Compact operator terminals	DOK_SUPPL* SCM*BEDIEN*AW..-EN-P

Fig. 1-1: Additional documentations

1.3 Differences Between Standard SFC and IndraStep

The sequential function charts defined in EN 61131-3 do not provide any support on mode control and diagnosis. As a result, this support must be completely programmed by the programmer.

This can be avoided by using IndraStep. Contrary to standard SFCs, IndraStep provides full mode and diagnosis support. This support is automatically added to each element to be controlled. This automatic support also increases the operational reliability, since no element will ever be forgotten. Each sequential function chart is provided with its own closed mode and diagnosis evaluation with first-error analysis.

In the action shown in Fig. 1-2, the user utilizes the features provided by IndraStep in order to configure the following rungs:

- monitoring rung for an error condition,
- activation of an output in the automatic mode and in the manual mode.




Fig. 1-2: Rungs with IndraStep features

The contacts resulting in the desired functionality are highlighted in yellow in the following equivalent circuit diagram (Fig. 1-3). This part is not applicable in the input and startup phases.




Fig. 1-3: Completed rungs according to the desired function (additional contacts are highlighted in yellow)

2 Important Directions for Use

2.1 Appropriate Use

Introduction

Rexroth products represent state-of-the-art developments and manufacturing. They are tested prior to delivery to ensure operating safety and reliability.

The products may only be used in the manner that is defined as appropriate. If they are used in an inappropriate manner, then situations can develop that may lead to property damage or injury to personnel.

Note: Bosch Rexroth AG, as manufacturer, is not liable for any damages resulting from inappropriate use. In such cases, the guarantee and the right to payment of damages resulting from inappropriate use are forfeited. The user alone carries all responsibility of the risks.

Before using Rexroth products, make sure that all the prerequisites for appropriate use of the products are satisfied:

- Personnel that in any way, shape or form uses our products must first read and understand the relevant safety instructions and be familiar with appropriate use.
- If the product takes the form of hardware, then they must remain in their original state, in other words, no structural changes are permitted. It is not permitted to decompile software products or alter source codes.
- Do not mount damaged or faulty products or use them in operation.
- Make sure that the products have been installed in the manner described in the relevant documentation.

Areas of Use and Application

IndraStep serves to support the mode control within the programming system WinPCL for programmable logic controls of Rexroth.

Note: Operation is only permitted in the specified configurations and combinations of hardware components using the software and firmware as specified in this documentation.

2.2 Inappropriate Use

Using IndraStep outside of the above-referenced areas of application or under operating conditions other than described in the document and the technical data specified is defined as "inappropriate use".

IndraStep may not be used if it is subject to operating conditions that do not meet the above specified ambient conditions. Furthermore, IndraStep must not be used for applications that the manufacturer has not specifically released for that intended purpose. Please note the specifications outlined in the general Safety Instructions!

2.3 Delivery Stipulations for Computer Programs

The copyrights, present and future commercial proprietary rights of all kinds, as well as all the rights of exploitation to delivered computer programs -- in equipment or separate from it -- belong exclusively to the Supplier.

A computer program may only be used in one single piece of equipment. Exceptions are commissioning software, which are marked with the designation -COPY at the end. These can be copied freely within the context of regular product usage by the customer.

Every act exceeding the minimum use outlined in the proprietary rights requires the consent of the Supplier. If a computer program delivered by the Supplier is not protected by proprietary rights, then the minimum use stated in the proprietary rights laws is declared as agreed upon.

If the Orderer transfers a computer program then he must completely surrender the program carrier and all copies in their entirety to the Acquiring Party, or these must be erased. A limitation of use corresponding to these stipulations (1 through 6) must be agreed upon with the Acquiring Party.

The Supplier will eliminate any fault in the computer program either by a circumvention of the fault, which is agreeable to the Orderer, or by delivering a new program.

All documents and information needed to reconstruct a fault must accompany the notification of a fault in the computer program.

Otherwise, the general delivery stipulations outlined by Bosch Rexroth apply.

3 Safety Instructions for Electric Drives and Controls

3.1 Introduction

Read these instructions before the initial startup of the equipment in order to eliminate the risk of bodily harm or material damage. Follow these safety instructions at all times.

Do not attempt to install or start up this equipment without first reading all documentation provided with the product. Read and understand these safety instructions and all user documentation of the equipment prior to working with the equipment at any time. If you do not have the user documentation for your equipment, contact your local Bosch Rexroth representative to send this documentation immediately to the person or persons responsible for the safe operation of this equipment.

If the equipment is resold, rented or transferred or passed on to others, then these safety instructions must be delivered with the equipment.



Improper use of this equipment, failure to follow the safety instructions in this document or tampering with the product, including disabling of safety devices, may result in material damage, bodily harm, electric shock or even death!

3.2 Explanations

The safety instructions describe the following degrees of hazard seriousness in compliance with ANSI Z535. The degree of hazard seriousness informs about the consequences resulting from non-compliance with the safety instructions.

Warning symbol with signal word	Degree of hazard seriousness according to ANSI
	Death or severe bodily harm will occur.
	Death or severe bodily harm may occur.
	Bodily harm or material damage may occur.

Fig. 3-1: Hazard classification (according to ANSI Z535)

3.3 Hazards by Improper Use



DANGER

**High voltage and high discharge current!
Danger to life or severe bodily harm by electric shock!**



DANGER

Dangerous movements! Danger to life, severe bodily harm or material damage by unintentional motor movements!



WARNING

High electrical voltage due to wrong connections! Danger to life or bodily harm by electric shock!



WARNING

Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electrical equipment!



CAUTION

Surface of machine housing could be extremely hot! Danger of injury! Danger of burns!



CAUTION

Risk of injury due to improper handling! Bodily harm caused by crushing, shearing, cutting and mechanical shock or incorrect handling of pressurized systems!



CAUTION

Risk of injury due to incorrect handling of batteries!

3.4 General Information

- The Bosch Rexroth AG is not liable for damages resulting from failure to observe the warnings provided in this documentation.
- Read the operating, maintenance and safety instructions in your language before starting up the machine. If you find that you cannot completely understand the documentation for your product, please ask your supplier to clarify.
- Proper and correct transport, storage, assembly and installation as well as care in operation and maintenance are prerequisites for optimal and safe operation of this equipment.
- Only persons who are trained and qualified for the use and operation of the equipment may work on this equipment or within its proximity.
 - The persons are qualified if they have sufficient knowledge of the assembly, installation and operation of the equipment as well as an understanding of all warnings and precautionary measures noted in these instructions.
 - Furthermore, they must be trained, instructed and qualified to switch electrical circuits and equipment on and off in accordance with technical safety regulations, to ground them and to mark them according to the requirements of safe work practices. They must have adequate safety equipment and be trained in first aid.
- Only use spare parts and accessories approved by the manufacturer.
- Follow all safety regulations and requirements for the specific application as practiced in the country of use.
- The equipment is designed for installation in industrial machinery.
- The ambient conditions given in the product documentation must be observed.
- Use only safety features and applications that are clearly and explicitly approved in the Project Planning Manual.

For example, the following areas of use are not permitted: construction cranes, elevators used for people or freight, devices and vehicles to transport people, medical applications, refinery plants, transport of hazardous goods, nuclear applications, applications sensitive to high frequency, mining, food processing, control of protection equipment (also in a machine).
- The information given in the documentation of the product with regard to the use of the delivered components contains only examples of applications and suggestions.

The machine and installation manufacturer must

 - make sure that the delivered components are suited for his individual application and check the information given in this documentation with regard to the use of the components,
 - make sure that his application complies with the applicable safety regulations and standards and carry out the required measures, modifications and complements.
- Startup of the delivered components is only permitted once it is sure that the machine or installation in which they are installed complies with the national regulations, safety specifications and standards of the application.
- Technical data, connections and operational conditions are specified in the product documentation and must be followed at all times.

- Operation is only permitted if the national EMC regulations for the application are met.
The instructions for installation in accordance with EMC requirements can be found in the documentation "EMC in Drive and Control Systems".
The machine or installation manufacturer is responsible for compliance with the limiting values as prescribed in the national regulations.

3.5 Protection Against Contact with Electrical Parts

Note: This section refers to equipment and drive components with voltages above 50 Volts.

Touching live parts with voltages of 50 Volts and more with bare hands or conductive tools or touching ungrounded housings can be dangerous and cause electric shock. In order to operate electrical equipment, certain parts must unavoidably have dangerous voltages applied to them.



DANGER

High electrical voltage! Danger to life, severe bodily harm by electric shock!

- ⇒ Only those trained and qualified to work with or on electrical equipment are permitted to operate, maintain or repair this equipment.
 - ⇒ Follow general construction and safety regulations when working on high voltage installations.
 - ⇒ Before switching on power the ground wire must be permanently connected to all electrical units according to the connection diagram.
 - ⇒ Do not operate electrical equipment at any time, even for brief measurements or tests, if the ground wire is not permanently connected to the points of the components provided for this purpose.
 - ⇒ Before working with electrical parts with voltage higher than 50 V, the equipment must be disconnected from the mains voltage or power supply. Make sure the equipment cannot be switched on again unintended.
 - ⇒ The following should be observed with electrical drive and filter components:
 - ⇒ Wait five (5) minutes after switching off power to allow capacitors to discharge before beginning to work. Measure the voltage on the capacitors before beginning to work to make sure that the equipment is safe to touch.
 - ⇒ Never touch the electrical connection points of a component while power is turned on.
 - ⇒ Install the covers and guards provided with the equipment properly before switching the equipment on. Prevent contact with live parts at any time.
 - ⇒ A residual-current-operated protective device (RCD) must not be used on electric drives! Indirect contact must be prevented by other means, for example, by an overcurrent protective device.
 - ⇒ Electrical components with exposed live parts and uncovered high voltage terminals must be installed in a protective housing, for example, in a control cabinet.
-

To be observed with electrical drive and filter components:



DANGER

**High electrical voltage on the housing!
High leakage current! Danger to life, danger of
injury by electric shock!**

- ⇒ Connect the electrical equipment, the housings of all electrical units and motors permanently with the safety conductor at the ground points before power is switched on. Look at the connection diagram. This is even necessary for brief tests.
- ⇒ Connect the safety conductor of the electrical equipment always permanently and firmly to the supply mains. Leakage current exceeds 3.5 mA in normal operation.
- ⇒ Use a copper conductor with at least 10 mm² cross section over its entire course for this safety conductor connection!
- ⇒ Prior to startups, even for brief tests, always connect the protective conductor or connect with ground wire. Otherwise, high voltages can occur on the housing that lead to electric shock.

3.6 Protection Against Electric Shock by Protective Low Voltage (PELV)

All connections and terminals with voltages between 0 and 50 Volts on Rexroth products are protective low voltages designed in accordance with international standards on electrical safety.



WARNING

**High electrical voltage due to wrong
connections! Danger to life, bodily harm by
electric shock!**

- ⇒ Only connect equipment, electrical components and cables of the protective low voltage type (PELV = Protective Extra Low Voltage) to all terminals and clamps with voltages of 0 to 50 Volts.
- ⇒ Only electrical circuits may be connected which are safely isolated against high voltage circuits. Safe isolation is achieved, for example, with an isolating transformer, an opto-electronic coupler or when battery-operated.

3.7 Protection Against Dangerous Movements

Dangerous movements can be caused by faulty control of the connected motors. Some common examples are:

- improper or wrong wiring of cable connections
- incorrect operation of the equipment components
- wrong input of parameters before operation
- malfunction of sensors, encoders and monitoring devices
- defective components
- software or firmware errors

Dangerous movements can occur immediately after equipment is switched on or even after an unspecified time of trouble-free operation.

The monitoring in the drive components will normally be sufficient to avoid faulty operation in the connected drives. Regarding personal safety, especially the danger of bodily injury and material damage, this alone cannot be relied upon to ensure complete safety. Until the integrated monitoring functions become effective, it must be assumed in any case that faulty drive movements will occur. The extent of faulty drive movements depends upon the type of control and the state of operation.



DANGER

Dangerous movements! Danger to life, risk of injury, severe bodily harm or material damage!

- ⇒ Ensure personal safety by means of qualified and tested higher-level monitoring devices or measures integrated in the installation. Unintended machine motion is possible if monitoring devices are disabled, bypassed or not activated.
- ⇒ Pay attention to unintended machine motion or other malfunction in any mode of operation.
- ⇒ Keep free and clear of the machine's range of motion and moving parts. Possible measures to prevent people from accidentally entering the machine's range of motion:
 - use safety fences
 - use safety guards
 - use protective coverings
 - install light curtains or light barriers
- ⇒ Fences and coverings must be strong enough to resist maximum possible momentum, especially if there is a possibility of loose parts flying off.
- ⇒ Mount the emergency stop switch in the immediate reach of the operator. Verify that the emergency stop works before startup. Don't operate the machine if the emergency stop is not working.
- ⇒ Isolate the drive power connection by means of an emergency stop circuit or use a starting lockout to prevent unintentional start.
- ⇒ Make sure that the drives are brought to a safe standstill before accessing or entering the danger zone. Safe standstill can be achieved by switching off the power supply contactor or by safe mechanical locking of moving parts.
- ⇒ Secure vertical axes against falling or dropping after switching off the motor power by, for example:
 - mechanically securing the vertical axes
 - adding an external braking/ arrester/ clamping mechanism
 - ensuring sufficient equilibration of the vertical axes

The standard equipment motor brake or an external brake controlled directly by the drive controller are not sufficient to guarantee personal safety!

- ⇒ Disconnect electrical power to the equipment using a master switch and secure the switch against reconnection for:
 - maintenance and repair work
 - cleaning of equipment
 - long periods of discontinued equipment use
 - ⇒ Prevent the operation of high-frequency, remote control and radio equipment near electronics circuits and supply leads. If the use of such equipment cannot be avoided, verify the system and the installation for possible malfunctions in all possible positions of normal use before initial startup. If necessary, perform a special electromagnetic compatibility (EMC) test on the installation.
-

3.8 Protection Against Magnetic and Electromagnetic Fields During Operation and Mounting

Magnetic and electromagnetic fields generated near current-carrying conductors and permanent magnets in motors represent a serious health hazard to persons with heart pacemakers, metal implants and hearing aids.



WARNING

Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electrical equipment!

- ⇒ Persons with heart pacemakers, hearing aids and metal implants are not permitted to enter the following areas:
 - Areas in which electrical equipment and parts are mounted, being operated or started up.
 - Areas in which parts of motors with permanent magnets are being stored, operated, repaired or mounted.
 - ⇒ If it is necessary for a person with a heart pacemaker to enter such an area, then a doctor must be consulted prior to doing so. Heart pacemakers that are already implanted or will be implanted in the future, have a considerable variation in their electrical noise immunity. Therefore there are no rules with general validity.
 - ⇒ Persons with hearing aids, metal implants or metal pieces must consult a doctor before they enter the areas described above. Otherwise, health hazards will occur.
-

3.9 Protection Against Contact with Hot Parts



CAUTION

**Housing surfaces could be extremely hot!
Danger of injury! Danger of burns!**

- ⇒ Do not touch housing surfaces near sources of heat! Danger of burns!
 - ⇒ After switching the equipment off, wait at least ten (10) minutes to allow it to cool down before touching it.
 - ⇒ Do not touch hot parts of the equipment, such as housings with integrated heat sinks and resistors. Danger of burns!
-

3.10 Protection During Handling and Mounting

Under certain conditions, incorrect handling and mounting of parts and components may cause injuries.



CAUTION

Risk of injury by incorrect handling! Bodily harm caused by crushing, shearing, cutting and mechanical shock!

- ⇒ Observe general installation and safety instructions with regard to handling and mounting.
 - ⇒ Use appropriate mounting and transport equipment.
 - ⇒ Take precautions to avoid pinching and crushing.
 - ⇒ Use only appropriate tools. If specified by the product documentation, special tools must be used.
 - ⇒ Use lifting devices and tools correctly and safely.
 - ⇒ For safe protection wear appropriate protective clothing, e.g. safety glasses, safety shoes and safety gloves.
 - ⇒ Never stand under suspended loads.
 - ⇒ Clean up liquids from the floor immediately to prevent slipping.
-

3.11 Battery Safety

Batteries contain reactive chemicals in a solid housing. Inappropriate handling may result in injuries or material damage.



CAUTION

Risk of injury by incorrect handling!

- ⇒ Do not attempt to reactivate discharged batteries by heating or other methods (danger of explosion and cauterization).
- ⇒ Never charge non-chargeable batteries (danger of leakage and explosion).
- ⇒ Never throw batteries into a fire.
- ⇒ Do not dismantle batteries.
- ⇒ Do not damage electrical components installed in the equipment.

Note: Be aware of environmental protection and disposal! The batteries contained in the product should be considered as hazardous material for land, air and sea transport in the sense of the legal requirements (danger of explosion). Dispose batteries separately from other waste. Observe the legal requirements in the country of installation.

3.12 Protection Against Pressurized Systems

Certain motors and drive controllers, corresponding to the information in the respective Project Planning Manual, must be provided with pressurized media, such as compressed air, hydraulic oil, cooling fluid and cooling lubricant supplied by external systems. Incorrect handling of the supply and connections of pressurized systems can lead to injuries or accidents. In these cases, improper handling of external supply systems, supply lines or connections can cause injuries or material damage.



CAUTION

Danger of injury by incorrect handling of pressurized systems !

- ⇒ Do not attempt to disassemble, to open or to cut a pressurized system (danger of explosion).
- ⇒ Observe the operation instructions of the respective manufacturer.
- ⇒ Before disassembling pressurized systems, release pressure and drain off the fluid or gas.
- ⇒ Use suitable protective clothing (for example safety glasses, safety shoes and safety gloves)
- ⇒ Remove any fluid that has leaked out onto the floor immediately.

Note: Environmental protection and disposal! The media used in the operation of the pressurized system equipment may not be environmentally compatible. Media that are damaging the environment must be disposed separately from normal waste. Observe the legal requirements in the country of installation.

Notes

4 Creating an IndraStep Example Project

The benefits of IndraStep are illustrated below by means of an example project:

- The first step is the development of a root program which can be reused irrespective of the particular application.
- Then an example project is presented illustrating essential features of the IndraStep mode control.
- The automatic sequential function chart of the example is integrated in the root program.
- The actions are extended by the necessary manual mode.

4.1 Preparing the Root Program in WinPCL

To prepare the root program, proceed as follows:

- Create the folder of the variant.
- Load the IndraStep structures.
- Create the IndraStep program and its resource.

Creating a New Variant

Using the *File/ Variant selection for control*** menu item, click the right mouse button in the left-hand field of the variant selection screen to create a new variant, rename it by “**IndraStep_Demo**” and select it as the current variant.




Fig. 4-1: Creating the variant

The IndraStep functionality can only be used if the IndraStep structures are present within the variant.

Creating the Program In the next step, create the program using the “File / New / Programs” menu item.




Fig. 4-2: Creating a new program

Initially, the blank program is adequate for the following steps.

Creating the Resource and Entering the Program

Then create the resource using the “File / New / Resource” menu item. A task which controls the program is defined.




Fig. 4-3: Creating a new resource

After the “RE_INDRA_DEMO” resource has been saved, all windows are closed.

The resource, the program and the IndraStep structures of the template are now available. Load the resource via *File / Open*. Press <Ctrl>+<Enter> or double-click the mouse on the program instance name (I_Step) to open the program (see Fig. 4-3).

The programming system opens the ladder diagram editor (implementation) of the program.

Entering of the variables, however, requires the declaration editor of the program. The declaration editor can be called via *View / Declaration* or <ALT>+<F2>.

Declaring the Variables for Mode Control

The names of the variables mentioned below have been selected such that they match the IndraStep structures.

In a real program, the mode control is controlled by a higher-order program part. In our programming example, the control of IndraStep is directly connected to the inputs and outputs of peripheral equipment.

For that reason, these variables must be entered in the declaration in the VAR...END_VAR area of the program.

Name	AT	TYPE	:=	Comment
(*Mode control=====*)				
i_Start	%I1.0.0	BOOL		(*Start SFC*)
i_Stop	%I1.0.1	BOOL		(*Stop SFC*)
i_AutoStep	%I1.0.2	BOOL		(*Single step mode (automatic)*)
i_Manual	%I1.0.3	BOOL		(*Manual mode*)
i_ManualForce	%I1.0.4	BOOL		(*Manual mode; force outputs controlled by Control_a*)
i_SetStep	%I1.0.5	BOOL		(*Steps with <step name>.SYNC = TRUE to activate when changing from manual to automatic mode*)
i_Reset	%I1.0.6	BOOL		(*Reset SFC; activate INITIAL_STEP of SFC*)
i_ClearError	%I1.0.7	BOOL		(*Delete error status*)
q_Run	%Q1.0.0	BOOL		(*SFC executes active steps or in manual mode at least one step is activated*)
q_Active	%Q1.0.1	BOOL		(*SFC is active - not in the INITIAL_STEP*)
q_Manual	%Q1.0.2	BOOL		(*Manual mode is active*)
q_Ready	%Q1.0.3	BOOL		(*Ready*)
q_Error	%Q1.0.4	BOOL		(*Error in SFC*)
q_ErrorStp	%Q1.0.5	BOOL		(*Unable to takeover the steps set with <step name>.SYNC in automatic mode*)
q_Stopped	%Q1.0.6	BOOL		(*SFC stopped*)
q_WaitOnTransition	%Q1.0.7	BOOL		(*At least one transition following the active step/s is clear*)

Fig. 4-4: "Mode control" area in the declaration of a program

Note: This variable block is required for each SFC with mode control (IndraStep). For that reason, it must be entered and checked only once, then copied and adjusted with regard to the absolute addresses.

You can now continue to create the sequential function chart. The declaration window can either be minimized or closed.

Mode control of the sequence (of the sequential function chart) requires that the folder (the variant) contains the IndraStep files.

Loading the IndraStep Files The *empty* SFC selection window in Fig. 4-6 indicates that there are no IndraStep structures. If not yet available, the IndraStep structures can be loaded via *File/Archive/Load archive*. The files are contained as **archives** for WinHMI or WinPCL in the following folders:

- *Mtgui\BasicData\TEMPLATES*
- *WinPCL\BasicData\TEMPLATES*

When loading the IndraStep_02 archive, make sure to select “Current variant” as the destination. Seven structure files and one SKD file are loaded.





Fig. 4-5: Loading the “IndraStep structures” archive to the “IndraStep_Demo” variant.

Creating a Sequential Function Chart An IndraStep SFC is created on the program or FB level via *View/SFCs* (<ALT>+<F3>).


Enter the name of the name of the SFC in the first column of this SFC editor. Move to the “TYPE” column using the <space bar> and select IndraStep using the footer command “3-IndraStep” or <ALT>+<3>.



Auswahl_Ablauftyp.bmp

Fig. 4-6: Selecting an SFC type, here IndraStep

The line for the SFC is completed by entering a comment.



Auswahl_Ablauftyp_komplett.bmp

Fig. 4-7: Defining the SFC type

The symbol indicates that the SFC is an IndraStep SFC with mode control. Press <Ctrl>+<Enter> or double-click on the name of the SFC (Demo_01) to open the SFC editor for entering the steps and transitions.

First, however, call only the SFC itself (i.e. without any content) in the implementation of the program. To achieve this, either minimize or close the SFC list editor (Fig. 4-7). Now, the still empty ladder diagram editor or IL editor is required.

Calling the SFC in the Ladder Diagram

In an empty ladder diagram rung, use the 4-SFC footer command or the <ALT>+<4> keys to call the selection window which displays the SFCs available.




Fig. 4-8: Selecting the desired "Demo_01" SFC

The right-hand field of the "SFCs" window shows a preview of all variables which are assigned to the "Demo_01" SFC.




Fig. 4-9: SFC selected from the ladder diagram

The variables of the "Demo_01" SFC (see Fig. 4-8) provided by IndraStep are now activated by the already declared variables for mode control (Fig. 4-4).

Here, the declared input variables are applied to the elements of the "<SFC name>.i.xxx" input structure and the output variables to the elements of the "<SFC name>.q.xxx" output structure of the SFC.

The SFC itself is positioned between these two assignment blocks.

Note: Up to that point, the program does not yet contain any user-specific information – with the exception of the <SFC name>. For that reason, the program should be saved to the archive at this point. The <SFC name> can be adjusted without any loss in the SFC list (Fig. 4-7).

Using the implementation editor, add the required rungs to the ladder diagram:




Fig. 4-10: Mode control in the ladder diagram

Calling the SFC in the Instruction List

As an alternative, the instruction list is shown with equal contents in the implementation editor. The call of the SFC (CAL Demo_01) is selected as a block.



Fig. 4-11: Mode control in the IL

Section	Component	Task
Implementation of LD rungs at the top		Assigning the variables to the SFC control signals
Demo_01 SFC	Transitions	Calculating the steps to be activated
	INTERN.aIN_USER	System action
	User actions	Execution of actions (order as specified in the SFC list)
	INTERN.aOUT_USER	System action
Implementation of LD rungs at the bottom		Assigning the SFC status signals to the variables

Fig. 4-12: Order of execution in Fig. 4-10 and Fig. 4-11

4.2 Example Project: Drilling Station

The example below is to be programmed. It has been simplified to a large degree.




Fig. 4-13: Example of the IndraStep mode control

The example to be programmed is a drilling station with supply and removal of material.

Sequence of Steps

- The material is supplied by a conveyor belt from the right with open safety door only.
- Once the workpiece has reached the transport position below the drilling station, the conveyor belt is stopped; after the safety door has been closed, the workpiece is clamped.
- The clamped workpiece is turned to its machining position.
- Then it is machined.
- After having been machined, the workpiece is turned back to the transport position.
- Now, the workpiece can be unclamped and the safety door opened.
- With open safety door, the workpiece is transported to the left. The machining cycle is completed when the workpiece has been removed.

The new machining cycle starts when the next workpiece is supplied.

Details of the workpiece machining cycle are not covered by the example. Only a possible tool breakage causing the work to be stopped will be considered.

Assigning Inputs and Outputs The following variables are declared in the declaration part of the programs for controlling the safety door, the clamping mechanism and the supply and removal of material.

Name	AT	TYPE	:=	Comment
(*Safety door=====*)				
iPB_CloseDoor	%I1.1.0	BOOL		(*Close safety door; jog*)
iPB_OpenDoor	%I1.1.1	BOOL		(*Open safety door; jog*)
iLS_DoorClosed	%I1.1.2	BOOL		(*Limit switch 'Safety door at the bottom'*)
iLS_DoorOpened	%I1.1.3	BOOL		(*Limit switch 'Safety door at the top'*)
qM_CloseDoor	%Q1.1.0	BOOL		(*Motor 'Close safety door'*)
qM_OpenDoor	%Q1.1.1	BOOL		(*Motor 'Open safety door'*)
(*Clamping=====*)				
iPB_Clamp	%I1.1.4	BOOL		(*Clamp piece, jog*)
iPB_Unclamp	%I1.1.5	BOOL		(*Unclamp piece, jog*)
iLS_Clamped	%I1.1.6	BOOL		(*Limit switch 'Clamping closed'*)
iLS_Unclamped	%I1.1.7	BOOL		(*Limit switch 'Clamping opened'*)
qM_Clamp	%Q1.1.4	BOOL		(*Motor 'Close clamping'*)
qM_Unclamp	%Q1.1.5	BOOL		(*Motor 'Open clamping'*)
(*Treatment=====*)				
iPB_ToPosProcess	%I1.2.0	BOOL		(*Turn in working position, jog*)
iPB_ToPosTransport	%I1.2.1	BOOL		(*Turn in transport position, jog*)
iLS_PosProcess	%I1.2.2	BOOL		(*Piece reached working position*)
iLS_PosTransport	%I1.2.3	BOOL		(*Piece is in transport direction*)
iLS_BrokenDie	%I1.3.0	BOOL		(*Piece breakage*)
iLS_NoCooling	%I1.3.1	BOOL		(*Breakdown of the cooling system*)
qM_ToPosProcess	%Q1.2.0	BOOL		(*Motor 'Turn piece in working position'*)
qM_ToPosTransport	%Q1.2.1	BOOL		(*Motor 'Turn piece in transport position'*)
ton_Pos		TON		(*Delay 'Limit switch monitoring'*)
(*Conveyor belts=====*)				
iPB_FeedRemove	%I1.2.4	BOOL		(*Conveyor belt 'Removal', jog*)
iPB_FeedLoad	%I1.2.5	BOOL		(*Conveyor belt 'Supply, jog*)
iLS_PieceRemoved	%I1.2.6	BOOL		(*Piece left conveyor belt*)
iLS_WorkFinished	%I1.2.7	BOOL		(*Treatment completed*)
qM_FeedLoad	%Q1.2.4	BOOL		(*Motor 'Conveyor belt, supply', jog*)
qM_FeedRemove	%Q1.2.5	BOOL		(*Motor 'Conveyor belt, removal', jog*)

Fig. 4-14: Input and output assignment of the example

4.3 Incorporating the Example in the “Root Program”

Extending the Declaration by the Variables of the Example

Enter the variables of the example (Fig. 4-14) in the declaration part of the program in the VAR...END_VAR area.





Fig. 4-15: Extending the declaration part by the variables of the example

Completing the SFC (Automatic Mode) According to the Example

The still empty SFC can be reached

- via the ladder diagram, implementation <Shift>+<F2> of the program, double-click or <Ctrl>+<Enter> on the yellow box of the call (Fig. 4-10);
- via the instruction list, implementation <Shift>+<F2> of the program, double-click or <Ctrl>+<Enter> on the “**Demo_01**” operand of the call (Fig. 4-11);
- via *View / SFCs* <Alt>+<F3>, double-click or <Ctrl>+<Enter> on the “**Demo_01**” name of the SFC (Fig. 4-7).

Enter the SFC as a sequence of steps and transitions, according to the verbal description of the example. Initially, the steps and transitions are blank.



Ablauf_Bsp.bmp

- wAAA: Waiting step (evaluation in the author's opinion)
- sBBB: General step
- tCCC: General transition

Fig. 4-16: SFC of the example

The “**sCloseDoor**” and “**sClamp**” or “**sUnclamp**” and “**sOpenDoor**” steps can be arranged in a sequence. Their arrangement in parallel steps that has been selected here is intended to show that IndraStep can also be used in parallel sequential function charts.

The steps and transitions entered are also displayed in the SFC list.




Fig. 4-17: Steps and transitions in the SFC list

“Self-explaining” names and a comment describing the task should be assigned to the steps and transitions. The names and/or comments can be changed in the SFC list without any loss of information.

Principles of Entering Actions and Switch-On Conditions (Automatic Mode)

The method of entering the complete SFC first (overview) and then completing the steps and transitions one after the other has the advantage that the user can focus on details now.

General Structure of an Action in the Manual and Automatic Modes

The mode support provides the following possibility of easily realizing the manual and automatic modes:




Fig. 4-18: Sample action with manual and automatic modes

The meaning of the elements in Fig. 4-18 is as follows:

Element	Meaning	
<SFC name>.Auto here: demo_01.Auto	Status contact which is closed as long as the SFC is in the automatic mode	
v1 Activation Auto	Contacts which assume the task of activating output qM1 in the automatic mode 0...n contacts	
v2 Activation in general	Contacts which assume the task of activating output qM1 in the all modes 0...m contacts	
<SFC name>.Control_* here: demo_01.Control_*	<SFC name>.Control_a	Status contact - opens on action end, stop, error, and in case of the AutoStep mode with AutoStepEnable
	<SFC name>.Control_b	Status contact - opens at the end of the action (in analogy with <action name>.Q)
	<SFC name>.Control_c	Status contact - function same as for Control_a, with additional diagnosis if the logic result before the contact is FALSE (starting with the second working cycle)
<SFC name>.Manual here: demo_01.Manual	Status contact which is closed as long as the SFC is in the manual mode	
v3 Activation Manual	Contacts which assume the task of activating output qM1 in the manual mode 0...p contacts	

Fig. 4-19: Elements of the sample action

Note: If the user needs a third branch for the “AutoStep” mode, then this branch must be generated **after** the “<SFC name>.Auto” contact. This is caused by the criteria analysis which can, up to now, only differentiate between automatic mode and manual mode.

Processing and Postprocessing of Actions

Chronological Coordination of Action Processing

Processing of actions has been fixedly bound to the graphical structure of the SFC. For that reason, the actions must be processed as specified by the steps. To achieve this, the following processing strategy is implemented by the structure interpreter:

- The steps of the SFC are processed line by line from left to right and from top to bottom.
- The action blocks are processed in the order resulting from the order of steps, i.e. from left to right and from top to bottom (cf. action list). This list can be resorted manually.
- If actions are entered repeatedly in one step (in parallel steps which are activated at the same time), they are still processed only once per cycle.

Chronological Coordination of Action Postprocessing

Postprocessing of all actions is achieved alternately with <action name>.Q and <action name>.A.

Since actions must be postprocessed only once, this is done independently of the graphical structure of the SFC. Actions are postprocessed in the order represented in the action list.

Examples are illustrated in the sections below.

Definition of the 'Step is active' Time

If the condition of the 'tOn' transition is fulfilled, the step is rated as being active in the same PLC cycle when the action is calculated.




Fig. 4-20: The step becomes active


Definition of the 'Step is inactive' Time

If the condition of the 'tOff' transition is fulfilled, the step is rated as being inactive in the same PLC cycle when the action is calculated.

When the step is becoming inactive, the Boolean variables and the negated variables are still calculated in the same PLC cycle, as specified above.

Results from Postprocessing of Actions – Example

Postprocessing of actions results in the question how the behavior of the outputs can be controlled when a step is exited.



I1: Input for enabling the output Q1

Fig. 4-21: Step 'sStep' with action 'aAction1' and an LD rung within

Processing of the action 'aAction1' is specified uniquely:

- Once the transition condition 'tOn' is fulfilled with active predecessor step, the step 'sStep' is activated (sStep.X: FALSE → TRUE).
- The action 'aAction1' is processed according to its action qualifier "N" (aAction1.Q and aAction1.A: FALSE → TRUE).
- The output Q1 follows the switch I1; we assume that the switch I1 is just TRUE and, thus, the output Q1 is also TRUE, if the transition condition for 'tOff' is fulfilled.
- Once 'tOff' is fulfilled, the step 'sStep' is inactive (sStep.X → FALSE) and the action 'aAction1' is not processed any longer (aAction.Q → FALSE). However, the action is postprocessed one more time (aAction.A is still TRUE).
- On postprocessing, all activities are completed.


From the user's view, there are two interesting situations with regard to output Q1:

- Q1 is to activate a **motor**. The transition 'tOFF' corresponds to the acknowledgement 'object has reached destination'. The user expects that the motor is turned off when the step and the action are becoming inactive.
- Q1 is to activate a **clamping device**. The transition 'tOFF' corresponds to the acknowledgement 'object is clamped'. The user expects that the clamping device is still activated when the step and the action are becoming inactive.

The different expected behaviors can be achieved only by a manipulation on the part of the user:

Motor case:

The output Q1 is to be deactivated when the step is exited.




Input I1: TRUE

Fig. 4-22: Modification for the motor case (forced turnoff)

When the step 'sStep' is exited, sStep.X and aAction1.Q are becoming FALSE. Postprocessing of the action results in that the output 'Q1' becomes FALSE independently of the input 'I1'.

Clamping device case:

The value of the output 'Q1' is to be preserved when the step is exited.



Input I1: TRUE

Fig. 4-23: Circuit for the **clamping device** case

When the step 'sStep' is exited, the action is not processed any longer; postprocessing does not cause any modification of the value of output 'Q1' either; the clamping device remains activated.

Hence, the position highlighted in yellow is suited to cause a behavior defined by the user, when components are turned off or in relation to the operating mode.

This task is assumed by the contacts <SFC name>.Control_a, <SFC name>.Control_b or <SFC name>.Control_c according to Fig. 4-18 / Fig. 4-19.

Entering Actions and Transitions

The automatic mode is entered
 → irrespective of the manual mode and
 → without error monitoring.

For that reason,

- the <step name>,
- the actions of the step, and
- the ladder diagrams required for implementing the actions are entered thereafter.

If transitions are concerned,

- the <transition name> and
- the switch-on condition are entered as a ladder diagram.

wPiece: _INDRASTEP_02_SCHRITT – (Initial Step)

Name	Comment	Remark
wPiece	(*Waiting for next piece*)	The workpiece is conveyed if the safety door is open and the transport position is unused.

Fig. 4-24: “wPiece” step (initial step)

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises both windows:




Fig. 4-25: Details on step “wPiece”

The contact sequence is to be provided with a comment:

The first contact **“Demo_01.Auto”** (<SFC name>.Auto) permits enabling for the automatic mode only. The user can be sure that this branch will be active in this mode only, without his further doing anything.

The following contacts **“iLS_DoorOpened”** (safety door is open) and **“iLS_PosTransport”** (no more workpieces in the supply unit) are normal switch-on conditions.

The contact **“Demo_01.Control_a”** assumes the task of deactivating the output in case of a regular action end, stop and error.

The coil **“qM_FeedLoad”** activates the motor of the supply conveyor belt.

tPiece_in_Pos: _INDRASTEP_02_TRANSITION

Name	Comment	How to continue
tPiece_in_Pos	Did the piece reach the transport position?	Workpiece in position; clamping can start.

Fig. 4-26: **“tPiece_in_Pos”** transition

The step **“wPiece”** is exited when the transition **“tPiece_in_Pos”** is fulfilled.




Fig. 4-27: Details on the transition **“tPiece_in_Pos”**

The step **“wPiece”** is exited when the workpiece has reached the transport position. The action **“aMovePiece”** is postprocessed; the conveyor belt is turned off.

sCloseDoor: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
sCloseDoor	(*Close safety door*)	Close the safety door when the workpiece has reached the transport position

Fig. 4-28: “sCloseDoor” step

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises both windows:




Fig. 4-29: Details on step “sCloseDoor”

The contact sequence is to be provided with a comment:

The first contact “**Demo_01.Auto**” (<SFC name>.Auto) permits enabling for the automatic mode only.

The contact “**iLS_PosTransport**” permits closing of the door when a workpiece waits for being processed inside the safety door.

The contact “**iLS_DoorClosed**” locks the door in the closed state (preventing it from being lowered further).

The contact “**Demo_01.Control_a**” assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.

The coil “**qM_CloseDoor**” activates the motor for closing the safety door.

sClamp: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
sClamp	(*Piece clamping*)	Clamp as soon as the workpiece is in its position and the safety door is closed.

Fig. 4-30: “sClamp” step

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises both windows:




Fig. 4-31: Details on step “sClamp”

The contact sequence is to be provided with a comment:

The first contact “**Demo_01.Auto**” (<SFC name>.Auto) permits enabling for the automatic mode only.

The contact “**iLS_PosTransport**” permits clamping when a workpiece waits for being machined inside the safety door.

The contact “**iLS_DoorClosed**” confirms that the door is closed.

The contact “**Demo_01.Control_a**” assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.

The coil “**qM_Clamp**” controls the motor for clamping the workpiece.


When the step “sClamp” is exited, the action “aClamp” is postprocessed and the motor “qM_Clamp” turned off. Since this is not desired, clamping must again be activated in the next step. This is done without any interruption.

tClamped_Closed: _INDRASTEP_02_TRANSITION

Name	Comment	How to continue
tClamped_Closed	Piece clamped and door closed?	The workpiece is clamped; the door is closed; turning of the workpiece can start

Fig. 4-32: “tClamped_Closed” transition

The steps “sClosedDoor” and “sClamped” are exited once the transition “tClamped_Closed” is fulfilled. Now, the safety door is closed and the workpiece is clamped.



Details_tClamped_Close.bmp

Fig. 4-33: Details on transition “tClamped_Closed”

sOrient: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
sOrient	(*Turn clamped piece in working position*)	Turn the clamped workpiece to the machining position.

Fig. 4-34: “sOrient” step

The step “sOrient” requires that the workpiece must remain clamped. This also applies to its successors “sWorkOn” and “sOrientBack”. For that reason, activation of clamping is separated into the action “aClampContinue”.




Fig. 4-35: Details on step “sOrient”

The step “sOrient” contains the actions “aClampContinue” and “aClampOrient”.

Action “aClampContinue”:

The first contact “**Demo_01.Auto**” (<SFC name>.Auto) permits enabling for the automatic mode only.

The following contact “**iLS_DoorClosed**” (safety door closed) is a normal switch-on condition.

The contact “**Demo_01.Control_a**” assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.

The coil “**qM_Clamp**” activates clamping of the workpiece. It assumes this task without any interruption from the preceding step “sClamp”.

Action “aClampOrient”:

The first contact “Demo_01.Auto” (<SFC name>.Auto) permits enabling for the automatic mode only. The user can be sure that this branch will be active in this mode only, without his further doing anything.

The following contact “iLS_DoorClosed” (safety door closed) is a normal switch-on condition.

“iLS_Clamped” confirms that the workpiece is clamped.

The contact “Demo_01.Control_a” assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.

The coil “qM_ToPosProcess” activates the turning movement to the machining position.

tOriented: _INDRASTEP_02_TRANSITION

Name	Comment	How to continue
tOriented	Piece turned in working position?	The workpiece has been turned to the machining position; machining can start.

Fig. 4-36: “tOriented” transition

The step “sOrient” is exited once the transition “tOriented” is fulfilled.




Fig. 4-37: Details on transition “tOriented”

If the step “sOrient” were exited, the action “aClampOrient” would be postprocessed and the motor “qM_Clamp” would be turned off. Since this is not desired, clamping must again be activated in the next step. This is done without any interruption.

sWorkOn: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
sWorkOn	(*Treatment enable for drilling station')	The clamped workpiece is enabled for machining.

Fig. 4-38: "sWorkOn" step

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises the windows:




Fig. 4-39: Details on step "sWorkOn"

The action "aClampContinue" continues to activate the clamping process without any interruption.

Note: Since they are of no interest here, details on machining will not be described in this program example.

tReady: _INDRASTEP_02_TRANSITION

Name	Comment	How to continue
tReady	Working process completed?	Machining is completed; unclamp the workpiece; open the door.

Fig. 4-40: “tReady” transition

The step “sWorkOn” is exited once the transition “tReady” is fulfilled.




Fig. 4-41: Details of transition “tReady”

If the step “sWorkOn” were exited, the action “aClampContinue” would be postprocessed and the motor “qM_Clamp” would be turned off. Since this is not desired, clamping must again be activated in the next step. This is done without any interruption.

sOrientBack: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
sOrientBack	(*Turn clamped piece in working position*)	Turn the clamped workpiece to the machining position.

Fig. 4-42: “sOrientBack” step

The step “sOrientBack” requires that the workpiece must remain clamped. This also applies to its predecessors “sWorkOn” and “sOrient”. For that reason, activation of clamping is separated into the action “aClampContinue”.

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises the windows:




Fig. 4-43: Details on step “sOrientBack”

The step “sOrientBack” contains the actions “aClampContinue” and “aClampBack”.

Action “aClampContinue”:

The first contact “Demo_01.Auto” (<SFC name>.Auto) permits enabling for the automatic mode only.

The following contact “iLS_DoorClosed” (safety door closed) is a normal switch-on condition.

The contact “Demo_01.Control_a” assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.

The coil “qM_Clamp” activates clamping of the workpiece. It assumes this task without any interruption from the preceding step “sClamp”.

Action “aOrientBack”:

The first contact “Demo_01.Auto” (<SFC name>.Auto) permits enabling for the automatic mode only.

The following contact “iLS_DoorClosed” (safety door closed) is a normal switch-on condition.

“iLS_Clamped” confirms that the workpiece is closed.

The contact “Demo_01.Control_a” assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.


The coil “qM_ToPosTransport” activates the turning movement to the transport position.

tOrientedBack: _INDRASTEP_02_TRANSITION

Name	Comment	How to continue
tOrientedBack	Turning back completed?	Turning back of the workpiece is completed; unclamp the workpiece; open the safety door.

Fig. 4-44: “tOrientedBack” transition

The step “sOrientBack” is exited once the transition “tOrientedBack” is fulfilled.



Detail_tOrientedBack.bmp

Fig. 4-45: Details on transition “tOrientedBack”

When the step “sOrientBack” is exited, the action “aClampContinue” is postprocessed and the motor “qM_Clamp” turned off.

sUnClamp: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
sUnClamp	(*Unclamp piece*)	Unclamp the workpiece with closed safety door

Fig. 4-46: "sUnClamp" step

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises both windows:




Fig. 4-47: Details of step "sUnClamp"

The contact sequence is to be provided with a comment:

The first contact "Demo_01.Auto" (<SFC name>.Auto) permits enabling for the automatic mode only.

The contact "iLS_DoorClosed" confirms that the door is closed.

The contact "iLS_UnClamped" limits unclamping of the workpiece.

The contact "Demo_01.Control_a" assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.

The coil "qM_Unclamp" activates the motor for clamping the workpiece.

sOpenDoor: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
sOpenDoor	(*Open safety door*)	Open the safety door after having unclamped the workpiece.

Fig. 4-48: “sOpenDoor” step

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises both windows:




Fig. 4-49: Details on step “sOpenDoor”

The contact sequence is to be provided with a comment:

The first contact “**Demo_01.Auto**” (<SFC name>.Auto) permits enabling for the automatic mode only.

The contact “**iLS_UnClamped**” indicates that the workpiece is unclamped.

The contact “**iLS_DoorOpened**” locks the door in the open state (preventing it from being opened further).

The contact “**Demo_01.Control_a**” assumes the task of deactivating the output if the step becomes inactive on a regular action end, in case of a stop, an error or a positive starting edge in the AutoStep mode.

The coil “**qM_OpenDoor**” activates the motor for opening the safety door.

tUnClamped_Opened: _INDRASTEP_02_TRANSITION

Name	Comment	How to continue
tUnClamped_Opened	Piece unclamped and door opened?	The workpiece is unclamped; the door is open; eject the workpiece.

Fig. 4-50: “tUnClamped_Opened” transition

The steps “sUnClamped” and “sDoorOpened” are exited once the transition “tUnClamped_Opened” is fulfilled. Now, the safety is door open and the workpiece is unclamped. It can be ejected.

However, removal of the workpiece is prevented in the event of a tool breakage.




Fig. 4-51: Detail on transition “tUnClampedOpened”

wRemove: _INDRASTEP_02_SCHRITT

Name	Comment	Remark
wRemove	(*Eject piece*)	The workpiece is ejected; if necessary, use Demo_01.Control_c for diagnosis purposes to detect whether the safety door is open.

Fig. 4-52: “wRemove” step

Open the step by double-clicking on it or by pressing <Ctrl>+<Enter>. Now a comment and the action block can be entered.

Press <Ctrl>+<Enter> or double-click on the name of the action to move to the ladder diagram.

The following figure comprises both windows:




Fig. 4-53: Details on step “wRemove”

The contact sequence is to be provided with a comment:

The first contact “**Demo_01.Auto**” (<SFC name>.Auto) permits enabling for the automatic mode only.

The following contact “**iLS_DoorOpened**” (safety door open) is a normal switch-on condition.

The contact “**Demo_01.Control_c**” assumes the task of deactivating the output on a regular action end, in case of a stop and an error with additional diagnosis, if the logic result before the contact is FALSE.

The coil “**qM_FeedRemove**” activates the motor of the removal conveyor belt.

Note: The safety door must be opened, because otherwise “**Demo_01.Control_c**” would react with stopping the SFC and setting the error signal “**Demo_01.q.Error**”.

tQuit: _INDRASTEP_02_TRANSITION

Name	Comment	How to continue
tQuit	Piece removed?	The workpiece has been removed; the SFC can be restarted.

Fig. 4-54: “tQuit” transition

The step “wRemove” is exited once the transition “tQuit” is fulfilled.




Fig. 4-55: Detail on transition “tQuit”

The step “wRemove” is exited when the workpiece has left the conveyor belt. The action “aRemovePiece” is postprocessed; the conveyor belt is turned off.

SetStep in the Automatic Mode

In the automatic mode, a jump to a different step assignment of the SFC can be prepared and, if necessary, executed.

This jump is prepared by setting the SYNC variables of the desired steps and the SetStep flag of the SFC. If a non-implementable step combination prevents the jump from being executed, the SFC stops (<SFC name>.q.Stop) with an error message (<SFC name>.q.ErrorStp).

In the example, this situation is present in the step “sWorkOn”. In this case, it is only possible to stop machining, unclamp the workpiece and open the safety door after a tool breakage.




Fig. 4-56: Jump of “sWorkOn” in case of a tool breakage

The action “aBrokenDieHead” is also processed in the step “sWorkOn”. If there is a tool breakage “iLSBrokenDie=TRUE” in the automatic mode, the variables “sUnClamp.SYNC” and “sOpenDoor.SYNC” are set; at the same time, the jump to the step assignments “sUnClamp” and “sOpenDoor” is initiated via “Demo_01.SetStep”.

Since this is a valid following assignment, the jump is executed and the step “sOrientBack” is skipped without processing. Continued transport of the workpiece is prevented by the condition in “tUnClamped_Opened”. This problem must, at any rate, be solved manually.

Note: Before the new step assignment is set, it is checked for being suitable for an SFC.

In case of an error, the jump is not executed and, with the SFC stopped, “<SFC name>.q.ErrorStp=TRUE” is set.

- Problem Solution**
- Eliminate the error cause.
 - Enter the correct step assignment (possible in the online-edit mode).
 - Acknowledge the error.
 - Acknowledge “**Demo_01.i.ClearError**”. The error message “**Demo_01.q.ErrorStp=FALSE**” disappears, but the SFC is still stopped.
 - Enable continued processing of the SFC.
 - Press “**Demo_01.i.Start**”. “**Demo_01.q.Stopped= FALSE**”, “**Demo_01.q.Run**” and “**Demo_01.q.Active**” are becoming TRUE.

The SFC jumps to the desired step assignment.

Instructions on Starting the Program Example

To be able to start the program example, load the resource file once more.. Depending on their availability, establish the connections to the input and output elements in the IO editor. A DEA box, which can be activated by means of the IO modules of any bus, was used as input/output device.

At this point, we recommend to put the programmed level into operation. This permits an immediate test of the following steps.

4.4 Possibilities of Error Monitoring

Action Errors

Diagnoses from action errors represent the easiest possibility of detecting an incorrect behavior..

It is initiated by the contact “<SFC name>.Control_c”, if the logic result before the contact is FALSE longer than one machining cycle with the step and the action being active.

The contact “<SFC name>.Control_c” is used instead of the contact “<SFC name>.Control_a”. Please replace by the action “**aMovePiece**”!




Fig. 4-57: Action error initiated by “<SFC name>.Control_c” (yellow)

The SFC is started after the resource has been downloaded.

The safety door (“**iLS_DoorOpened**”) is not opened, thus preventing the conveyor belt motor from being activated.

“Demo_01.Control_c” initiates an error:

“Demo_01.q.Error= TRUE”; “Demo_01.q.Stopped= TRUE”.

Refer to the status display of the SFC – display of the active step, the active actions and/or their contents – for more information.

Problem Solution

- Eliminate the error cause
 - Open the safety door (manual mode) until “iLS_DoorOpened=True”.
- Acknowledge the error.
 - Acknowledge “Demo_01.i.ClearError”. The error message “Demo_01.q.Error=FALSE” disappears, but the SFC is still stopped.
- Enable continued processing of the SFC.
 - Press “Demo_01.i.Start”. “Demo_01.q.Stopped= FALSE”, “Demo_01.q.Run” and “Demo_01.q.Active” are becoming TRUE.

Note: An action error is not evaluated for the first processing cycle of the action.

Purpose: If the following transition is directly fulfilled after a step, an action diagnosis (error message) is not executed even if the action is not fulfilled.

Time Errors

IndraStep permits to monitor steps with regard to their maximum and minimum processing time as well as to monitor signals over time.

Enter the times in the SFC as follows: Position the cursor on the desired step, click the right mouse button or press the <Shift>+<F10> keys, Step time.




Fig. 4-58: Pop-up menu, step time

Maximum Processing Time (Example)

The step “**sOrientBack**” has proven to be susceptible to faults, owing to the chips produced during machining. For that reason, the time required for turning the workpiece from the working position back to the transport position is to be monitored.

This time can be specified as absolute time or as a variable of type TIME.




Fig. 4-59: Specifying the maximum step time in the step “**sOrientBack**”

If the maximum set time is exceeded, the SFC stops:

“**Demo_01.q.Error = TRUE**”; “**Demo_01.q.Stopped = TRUE**”.

Problem Solution

- Eliminate the error cause.
 - The switch-on condition of “**tOrientBack**” must be fulfilled.
- Acknowledge the error.
 - Acknowledge “**Demo_01.i.ClearError**”. The error message “**Demo_01.q.Error=FALSE**” disappears, but the SFC is still stopped.
- Enable continued processing of the SFC.
 - Press “**Demo_01.i.Start**”. “**Demo_01.q.Stopped= FALSE**”, “**Demo_01.q.Run**” and “**Demo_01.q.Active**” are becoming TRUE.

Time Errors with TimeErrorStepDiagnosis

In contrast to the maximum step time, this feature can be used to check a monitoring condition. The desired signal is applied to the input of a time stage. If the time is exceeded, the variable (<SFC name>.TimeErrorStepDiag) is set.

The step “sCloseDoor” is used in the example. If the safety door “iLS_DoorClosed” fails to be closed within 5 sec, the SFC must be stopped and an error message emitted.




Fig. 4-60: Monitoring the down movement of the safety door

This monitoring measure is appropriate if the step remains active for a longer time than the activity to be monitored may be running. Here, the step remains active for a longer time because of the parallelity with “sClamp” and the subsequent clamping cycle.

The time stage is not applicable in case of immediate reactions.

If the maximum set time is exceeded, the SFC enters the stop state:

“Demo_01.q.Error = TRUE”; “Demo_01.q.Stopped = TRUE”.

Problem Solution

- Eliminate the error cause
 - Close the safety door until “iLS_DoorClosed=TRUE”.
- Acknowledge the error.
 - Acknowledge “Demo_01.i.ClearError”. The error message “Demo_01.q.Error=FALSE” disappears, but the SFC is still stopped.
- Enable continued processing of the SFC.
 - Press “Demo_01.i.Start”. “Demo_01.q.Stopped= FALSE”, “Demo_01.q.Run” and “Demo_01.q.Active” are becoming TRUE.

Minimum Processing Time

The minimum processing time has weaker effects on processing of the SFC. Here, the set minimum processing time of a step is ensured even if the transition condition is fulfilled beforehand. Example: Workpiece cleaning should take 15 seconds. An error cannot occur.




Fig. 4-61: Equivalent circuit diagram “Minimum processing time”, Tmin in green color

Error Monitoring

The monitoring function permits to check monitoring conditions globally for all steps or locally in the active steps immediately or delayed. If such an error occurs, the SFC stops and indicates an error (<SFC name>.q.Stop) with error message (<SFC name>.q.Error).

Error Monitoring (Global)

If the global limit switch monitoring function is used, the state or mode of the SFC is irrelevant.

To achieve this, a stored action incorporating the limit switches to be monitored must be entered in the initial step.




Fig. 4-62: Global limit switch monitoring

The following items are monitored in Fig. 4-62:

- Safety door: “**iLS_DoorClosed**” versus “**iLS_DoorOpened**”
- Clamping state: “**iLS_Clamped**” versus “**iLS_Unclamped**”
- Workpiece positions: “**iLS_PosProcess**” and “**iLS_PosTransport**”

An overlap of no more than 2 sec is tolerated for the workpiece positions.

Note: Although all rungs feed the variable <SFC name>.MonError, the rung can be localized in case of an error.

If an error message is emitted, the SFC stops:

“**Demo_01.q.Error=TRUE**”; “**Demo_01.q.Stopped=TRUE**”.

Problem Solution

- Eliminate the error cause
- Acknowledge the error.
 - Acknowledge “**Demo_01.i.ClearError**”. The error message “**Demo_01.q.Error=FALSE**” disappears, but the SFC is still stopped.
- Enable continued processing of the SFC.
 - Press “**Demo_01.i.Start**”. “**Demo_01.q.Stopped= FALSE**”, “**Demo_01.q.Run**” and “**Demo_01.q.Active**” are becoming TRUE.

Error Monitoring (Local)

If an error can occur within the SFC in a specific step only, the monitoring function can be executed in this step by means of a non-stored action.

The error is exactly localized for the particular rung. The same action can be called in several steps. In case of an error, the step causing the error is also determined.




Fig. 4-63: Local error monitoring

If the cooling unit fails, the SFC is stopped and an error message is displayed.

If an error message is emitted, the SFC enters the stop state:

“Demo_01.q.Error= TRUE”; “Demo_01.q.Stopped= TRUE”.

Problem Solution

- Eliminate the error cause.
- Acknowledge the error.
 - Acknowledge **“Demo_01.i.ClearError”**. The error message **“Demo_01.q.Error=FALSE”** disappears, but the SFC is still stopped.
- Enable continued processing of the SFC.
 - Press **“Demo_01.i.Start”**. **“Demo_01.q.Stopped= FALSE”**, **“Demo_01.q.Run”** and **“Demo_01.q.Active”** are becoming TRUE.

Dynamic Error Monitoring (MonErrorFE)

IndraStep permits to monitor output signals for being interrupted briefly.




Fig. 4-64: Dynamic monitoring of an output signals

The action “**aClampContinue**” organizes the permanent activation of the clamping state over several steps. If the activation of “**qM_Clamp**” is interrupted briefly, then this is registered by the parallel contact <SFC name>.MonErrorFE, with emission of an error message.

Note: Each action can be monitored only **once**. The step, in which the interruption occurred, is determined.

If an error message is emitted, the SFC enters the stop state:

“**Demo_01.q.Error= TRUE**”; “**Demo_01.q.Stopped= TRUE**”.

Problem Solution

- Eliminate the error cause.
- Acknowledge the error.
 - Acknowledge “**Demo_01.i.ClearError**”. The error message “**Demo_01.q.Error=FALSE**” disappears, but the SFC is still stopped.
- Enable continued processing of the SFC.
 - Press “**Demo_01.i.Start**”. “**Demo_01.q.Stopped= FALSE**”, “**Demo_01.q.Run**” and “**Demo_01.q.Active**” are becoming TRUE.

4.5 Diagnosis Options

Diagnosis Options in WinPCL

The present diagnosis function in WinPCL permits

- to display the status information of the SFC,
- to eliminate the errors occurred,
- to acknowledge the error message, and
- to restart the SFC.

Action error example:

The SFC is started after the resource has been downloaded.

The safety door (“iLS_DoorOpened”) is not opened, thus preventing the conveyor belt motor from being activated.

“Demo_01.Control_c” initiates an error:

- “Demo_01.q.Error=TRUE”
- “Demo_01.q.Stopped=TRUE”

Refer to the status display of the SFC (display of the active step) and the active actions and/or their contents for more information.

Problem Solution

- Eliminate the error cause.
 - Open the safety door until “iLS_DoorOpened=TRUE”.
- Acknowledge the error.
 - Confirm “Demo_01.i.ClearError”. Thereafter, the error message “Demo_01.q.Error=FALSE” disappears, but the SFC is still in the stop state.
- Enable continued processing of the SFC.
 - Confirm “Demo_01.i.Start”. “Demo_01.q.Stopped=FALSE”, “Demo_01.q.Run” and “Demo_01.q.Active” become TRUE, unless the SFC is in the initial step.

Advanced Diagnosis in WinHMI

In WinHMI /2/, there are eight different display areas:

- System error messages: Error messages causing a stop of the complete control. Operation can only be continued after the control has been reset.
- Start requirements: Switch-on conditions of the entire machine.
- Warnings: Instructions on a control; user guide for bottlenecks in the near future.
- Setup diagnosis: Diagnosis for operating screens (OP4-Manual).
- CNC failures and/or mechanism faults of a module.
- **Processing faults**
 - **IndraStep SFC faults of a module**
 - General faults: PLC faults of a module
 - Messages: PLC operating and CNC status messages of a module

The sections below describe the advanced diagnosis functions for processing faults.

Preparing the Use of the Diagnosis Functions in WinHMI

Remark:

Working with WinHMI requires a BTV, because it permits easy handling via the function keys (<F2>...<F9>), operation keys (<OP2>...<OP9>) and machine function keys (<L1>...<L8> as well as <R1>...<R8>).

The WinHMI and WinPCL screens can be toggled with <ALT>+<TAB> /2/. However, we recommend to operate the BTV with "remote control". In this case, the WinHMI screens can be viewed on the BTV screen, while the WinPCL screens can be displayed on the remote PC (notebook or the like) without toggling being necessary.

Make the following preparations:

Loading the Archive "HMI_SPS.APV"

All data types and function blocks required for implementing the process connection between WinHMI and the PLC are comprised in the PLC archive "HMI_SPS.APV".

The archive must be loaded once to the WinPCL programming system using "File / Archive / Load archive...".

The archive resides in the

Drive:\Programme\Indramat\Mtgui\Basicdata\templates

folder.

Defining the Module Configuration

The "Module" structuring instrument is available for extending the existing control structure. The module definition is called module configuration and exists once per PC.

In contrast to the control structure described above, the module configuration is primarily made under aspects of machine construction and operation.

Note: WinHMI requires the configuration of at least one module. Optionally, further modules can be configured.

Creating the file ModulDef.ini

Modules permit to comprise and group processes, SFCs and diagnoses in relation to the application.

After a new WinHMI user interface has been set up, a template file "ModulDef.ini" is generated.

The file must be adjusted before WinHMI is called because, otherwise, it is not possible to assign devices, modules, processes, etc. to the display areas.

The template file ModulDef.ini contains several commented entries. The machine manufacturer has to define the final assignment and adjust the file to the software structure. ",," must be removed accordingly.

The file ModulDef.ini exists once per PC, e.g. in the BTV20. At present, the file must be edited directly with an editor, e.g. NotePad.

The following figure shows the file ModulDef.ini for our example:

Moduldef.ini	Remark
;Default Module definition MUI/GUI version 20V01	
[ModulGeneral]	General definition for the modules
[ModulGeneral\ModulDescription]	Designation of the module level in the various languages
DE = Einheit EN = Unit	German name English name
[DeviceAddr0]	Device (control) assignment with device address, e.g. device 0
[DeviceAddr0\Modul1] ModulName = Modul 1 Drilling Station	Assignment of module 1 of device 0 Name of module 1
:[DeviceAddr0\Modul1\Process] ;Entry1 =	Assignment of the processes (no.) to module 1 of device 0 number of the process assigned: Still empty

Fig. 4-65: ModulDef.ini for our example

Assigning the module definition in the SFC editor

To be able to use the advanced diagnosis options, you must assign a module number to the SFC.

The assignment can be made with the pop-up menu of the editor, which is opened by clicking the right mouse button or pressing the <Shift>+<F10> keys.




Fig. 4-66: Enabling the diagnosis




Fig. 4-67: Entering the module number

After the assignment has been completed, the SFC concerned is marked with **i**.




Fig. 4-68: "Entry of module number executed" marked in the SFC




Fig. 4-69: "Entry of module number executed" marked in the SFC list

Starting WinHMI on the BTV and WinPCL in the Remote Mode

After WinHMI has been started and Diagnosis / Diagnosis Overview has been activated, the monitor of the BTV shows the following screen, provided no failure has occurred:








Fig. 4-70: Diagnosis in WinHMI, faultless operation

Note: If the "No diagnosis" message is displayed instead of the "SFC Faults" message, the module number is not assigned to the SFC.

This screen changes if an error occurs.

Action Errors

Diagnoses caused by action errors have been described in the section on diagnosis options in WinPCL. They are initiated by the contact "<SFC name>.Control_c", if the logic result before the contact is FALSE with the step and the action being active.

Component	Representation
WinPCL, step "wPiece", "Waiting for next piece"	
Action "aMovePiece" in the step "wPiece"	
Error description	<p>The safety door is not open, the contact "iLS_DoorOpened" is not closed. For that reason, the motor "qM_FeedLoad" is not activated. There is no workpiece. "iLS_PosTransport" (neg.) is closed. The contact "Demo_01.Control_c" signals an SFC fault.</p>
WinHMI, SFC fault	
	<p>Selection of the fault displayed; <Enter></p>
WinHMI, criteria analysis The rung is reduced to the contact which prevents the activation.	





Fig. 4-71: Advanced diagnosis up to the criteria analysis

The criteria analysis can provide further information.

The default setting is represented in **bold** letters below:

- <F2>: Toggling of IL and **ladder diagram**
- <F3>: All contacts of the automatic branch in the rung are displayed; the manual branch is suppressed. / **Only the missing contacts** are displayed.
- <F4>: All non-closed contacts are displayed in the online mode / **Error**: The rung is frozen when the error occurs and is preserved for evaluation.
- <F5>: Absolute address / **symbolic name**.
- <F6>: Selection of transitions / **actions** pertaining to the step. Additional information can be obtained from the remaining actions of the step or the following transitions. In the selection list, the action/transition causing the error is displayed with a red background, the currently selected one with a blue background. The display shows contacts which are not fulfilled.

Note: The  symbol in the criteria analysis window indicates additional information. This information can be called by pressing the “Info” key of the BTV.




	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	ACTION ERROR	ACTION ERROR
Step:	Comment on the step	<Step name>
		Minimum step time
		Maximum step time
Action:	Name of the action	Name of the action
Qualifier		Action qualifier of the actions selected

Fig. 4-72: Additional information after the Info key of the BTV has been pressed

Maximum Processing Time

If the set maximum time is exceeded, the SFC enters the stop state (<SFC name>.q.Stop) with the error being displayed (<SFC name>.q.Error).

This time can be specified as absolute time or as a variable of type TIME.

Component	Representation
WinPCL, step "sOrientBack", "Turn back clamped piece" Dwell time of the step	
Error description	The step sOrientBack has proven to be susceptible to faults, owing to the chips produced during machining. For that reason, the time required for turning the workpiece from the machining position back to the transport position is to be monitored.
WinHMI, time error	
	Selection of the fault displayed; <Enter>
WinHMI, criteria analysis The rung is reduced to the contact which has interrupted the activation.	




Fig. 4-73: Advanced diagnosis up to the criteria analysis




	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	TIME ERROR	TIME ERROR
Step:	Comment on the step	<Step name>
Transition	Comment on the transition	<Transition name>
		Minimum step time
		Maximum step time
Action:	Name of the action	Name of the action

Fig. 4-74: Additional information after the Info key of the BTV has been pressed

Time Error – Resulting from TimeErrorStepDiag

In contrast to the maximum step time, this feature can be used to check a monitoring condition. The desired signal is applied to the input of a time stage. If the time is exceeded, the variable (<SFC name>.TimeErrorStepDiag) is set.

The step “sCloseDoor” is used in the example.

Component	Representation
WinPCL, step “sCloseDoor”, “Close safety door”	
Action “aCloseDoor” in the step “sCloseDoor”	
Error description	<p>If the safety door “iLS_DoorClosed” fails to be closed within 5 sec, the SFC must be stopped and an error message emitted. The contact “Demo_01.TimeErrorStepDiag” signalizes a time error.</p>
WinHMI, time error	
	<p>Selection of the fault displayed; <Enter></p>




Fig. 4-75: Advanced diagnosis up to the criteria analysis




	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	TIME ERROR	TIME ERROR
Step:	Comment on the step	<Step name>
		Minimum step time
		Maximum step time
Transition:	Comment on the transition	<Transition name>

Fig. 4-76: Additional information after the Info key of the BTV has been pressed

Undelayed Error Monitoring (Global)

If the global limit switch monitoring function is used, the state or mode of the SFC is irrelevant.

To achieve this, a stored action incorporating the limit switches to be monitored must be entered in the initial step.

Component	Representation
<p>WinPCL, The initial step "wPiece" includes the stored action "aMonitoringGlobal", which incorporates all limit switch monitoring functions.</p>	
<p>Error description</p>	<p>Monitoring for limit switch breakage, "iLS_DoorClosed"/"iLS_DoorOpened"</p>
<p>WinHMI, monitoring</p>	
<p></p>	<p>Selection of the fault displayed; <Enter></p>
<p>WinHMI, criteria analysis</p> <p>The rung is reduced to the contacts which have interrupted the activation.</p>	




Fig. 4-77: Advanced diagnosis up to the criteria analysis



	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	MON ERROR	MON ERROR
Step:	Comment on the step	<Step name>
		Minimum step time
		Maximum step time
Monitor NW:	Name of the action	Name of the action

Fig. 4-78: Additional information after the Info key of the BTV has been pressed

Delayed Error Monitoring (Global)

If the global limit switch monitoring function is used, the state or mode of the SFC is irrelevant.

To achieve this, a **stored** action incorporating the limit switches to be monitored must be entered in the **initial step**.

Component	Representation
<p>WinPCL, The initial step "wPiece" includes the stored action "aMonitoringGlobal", which incorporates all limit switch monitoring functions.</p>	
<p>Error description</p>	<p>Monitoring for limit switch breakage, "iLS_PosProcess"/"iLS_PosTransport" with delay time (limit switch ranges are intersecting)</p>
<p>WinHMI, monitoring</p>	
	<p>Selection of the fault displayed; <Enter></p>




Fig. 4-79: Advanced diagnosis up to the criteria analysis

	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	MON ERROR	MON ERROR
Step:	Comment on the step	<Step name>
		Minimum step time
		Maximum step time
Monitor NW:	Name of the action	Name of the action

Fig. 4-80: Additional information after the Info key of the BTV has been pressed

Note: FBs with the respectively topmost Boolean input and output can be removed from the display in connection with




- <SFC name>.MonError
- <SFC name>.MonErrorFE

Error Monitoring (Local)

If an error can occur within the SFC in a specific step only, the monitoring function can be executed in this step by means of a non-stored action.

The error is exactly localized for the particular rung. The same action can be called in several steps. In case of an error, the step causing the error is also determined.

It is possible to program a time delay (also see the section on delayed error monitoring (global)).

Component	Representation
WinPCL, step "sWorkOn", "Treatment enable for drilling station"	
Action "aMonitoringCooling" in the step "sWorkOn"	
Error description	If the cooling unit fails, the SFC is stopped and an error message is displayed.
WinHMI, monitoring	
	Selection of the fault displayed; <Enter>







Fig. 4-81: Advanced diagnosis up to the criteria analysis

	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	MON ERROR	MON ERROR
Step:	Comment on the step	<Step name>
		Minimum step time
		Maximum step time
Monitor NW:	Name of the action	Name of the action

Fig. 4-82: Additional information after the Info key of the BTV has been pressed

Dynamic Error Monitoring (MonErrorFE)

IndraStep permits to monitor output signals for being interrupted briefly.

Component	Representation
<p>WinPCL, step "sOrient", "Turn clamped piece in working position"</p>	 <p>The screenshot shows a step editor window titled '8FC00 SFC Demo_01 [PR INDRA_DEMO.I_Step:INDRA_PRG]'. It displays a state transition diagram with step 1 containing 'sOrient' and transition 'tOriented' leading to step 2. Below the diagram, there is a text field for 'sCloseDoor: _INDRASTEP_02_SCHRITT (*Close safety door / Schutztür sch...' and a 'STATUS' button. The bottom toolbar includes '1 T/S', '9', and '0 edit'.</p>
<p>Action "aClampContinue" in the step "sOrient"</p> <p>The action is used in other steps; objective: Detecting the step where the problem occurred.</p>	 <p>The screenshot shows an action editor window titled 'Impl00 Action aClampContinue [PR INDRA_DEMO.I_Step:INDRA_PRG]'. It displays a logic diagram with six rungs. Rung 2 contains '(*Continue clamping, safety door closed; monitoring if interruption / Weiter Klemmen, Schutztür gesc...'. Rung 3 contains '(*Status cont...'. Rung 4 contains 'iLS_DoorClosed'. Rung 5 contains 'Demo_01.Control_a'. Rung 6 contains 'qM_Clamp'. A 'STATUS' button is visible at the bottom right. The bottom toolbar includes '1', '2', '3', '4 NOT', '5 FB', '6 FN', '7 OP', '8', '9', and '0 edit'.</p>
<p>Error description</p>	<p>The safety door briefly opened "iLS_DoorClosed"; then the signal was stable again. Nevertheless, an error is generated and qM_Clamp is prevented from closing again.</p>
<p>WinHMI, falling edge error</p>	 <p>The screenshot shows a WinHMI interface with a blue header displaying '16:30:12 WinHMI 08.10.02' and 'Rexroth Indramat mtc200p_00 Modul 1 Drilling Station'. Below the header is a red 'SFC Faults' section with a message: '08.10.2002 16:22:16 F_EDGE ERROR: SFC: Drilling station / Bohrwerk STEP: Turn clamped piece in working posi...'. At the bottom is a navigation menu with buttons for 'Diagnosis Overview', 'Preparation', 'ZOOM CNC fault', 'ZOOM SFC fault', 'ZOOM Faults', 'ZOOM Messages', 'Fault Logbook', 'Maintenance', 'Select Control', 'Program-ming', and 'Special Screens'.</p>
	<p>Selection of the fault displayed; <Enter></p>




Fig. 4-83: Advanced diagnosis up to the criteria analysis

	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	FALLING EDGE ERROR	FALLING EDGE ERROR
Step:	Comment on the step	<Step name>
		Minimum step time
		Maximum step time
Monitor NW:	Name of the action	Name of the action

Fig. 4-84: Additional information after the Info key of the BTV has been pressed

4.6 AutoStep Mode

General Function The **automatic single-step mode** is a special type of the **automatic mode** and is different in that switch-on from step to step must be enabled manually, in addition to the transition condition that must be fulfilled.

On actuation of “**i.AutoStep**”, the automatic mode changes to the AutoStep mode.

If a “*transition condition*” following an active step is “*fulfilled*” and the transition variable *<transition name>.JOG = True*, “**q.WatiOnTrans**” is set without the old active step being left.

The following step is reached only, if “**i.Start**” is also actuated.

In this manner, the SFC can be run through step by step.

Note: The transition condition must, of course, still be fulfilled, if “**i.Start**” is to become effective.

Using *<transition name>.JOG = FALSE*

The initial value of the system variable “*<transition name>.JOG*” of all transitions is TRUE.

Hence, all transitions must be confirmed manually for switch-on.

The AutoStep mode can be accelerated if the JOG flags of those transitions which are to be run through without being confirmed manually are set to FALSE in the first action of their preceding step. In this case, the message “**q.WaitOnTrans**” and activation of the start signal are not applicable.

4.7 Manual Mode

Activation and Deactivation of the Manual Mode from the Automatic Mode

The automatic mode can be changed to the manual mode at any time by activating the signal “*<SFC name>.i.Manual*”.

- The current step assignment is saved. The steps are deactivated.
- Actions with non-stored call are deactivated.
- Actions with stored call are still processed (limit switch monitoring in “**aMonitoringGlobal**”).

If the signal “*<SFC name>.i.Manual*” is deactivated again, the old step assignment is restored.

Changing the Step Assignment before Returning to the Automatic Mode

The step assignment can be changed if, in the manual mode, the desired steps are set (forced) with their variable *<step name>.SYNC = TRUE* and the variable *<SFC name>.i.SetStep = TRUE* is set. If the “*<SFC name>.i.Manual*” is now deactivated and the step assignment was valid, the automatic mode is continued at the desired assignment.

Supplementing the Manual Mode to the Example SFC

The actions which have been activated in the automatic mode before must be extended by the manual mode for the output elements to be controlled in the manual mode.

General Structure of an Action in the Manual and Automatic Modes

The mode support provides the following possibility of easily implementing the manual and automatic modes:




Fig. 4-85: Sample action with manual and automatic modes

The meaning of the elements in Fig. 4-85 is as follows:

Element	Meaning
<SFC name>.Auto here: demo_01.Auto	Status contact which is closed as long as the SFC is in the automatic mode
v1 Activation Auto	Contacts which assume the task of activating output qM1 in the automatic mode 0...n contacts
v2 Activation in general	Contacts which assume the task of activating output qM1 in all modes 0...m contacts
<SFC name>.Control_* here: demo_01.Control_*	<SFC name>.Control_a Status contact - opens on action end, stop, error, and in case of the AutoStep mode with AutoStepEnable
	<SFC name>.Control_b Status contact - opens at the end of the action (analogously <action name>.Q)
	<SFC name>.Control_c Status contact - function same as for Control_a, with additional diagnosis if the logic result before the contact is FALSE
<SFC name>.Manual here: demo_01.Manual	Status contact which is closed as long as the SFC is in the manual mode
v3 Activation Manual	Contacts which assume the task of activating output qM1 in the manual mode 0...p contacts

Fig. 4-86: Elements of the sample action

Note: If the user needs a third branch for the “AutoStep” mode, then this branch must be generated *after* the “<SFC name>.Auto” contact. This is caused by the criteria analysis which can, up to now, only differentiate between automatic mode and manual mode.

These elements can be determined by means of the cross-reference list:




Fig. 4-87: Cross-reference list for determining the assignment of outputs

The actions are now extended by the necessary contacts:

aMovePiece - qM_FeedLoad




Fig. 4-88: Extension of "aMovePiece" - "qM_FeedLoad"

"iPB_FeedLoad" - enabling the supply conveyor belt

aClamp - qM_Clamp




Fig. 4-89: Extension of “aClamp” - “qM_Clamp”

“iPB_Clamp” - enable signal for “qM_Clamp”

“iLS_Clamped” - limit switch if the workpiece is clamped.

aCloseDoor - qM_CloseDoor




Fig. 4-90: Extension of “aCloseDoor” - “qM_CloseDoor”

“iPB_CloseDoor” - enable signal for “qM_CloseDoor”

aClampOrient - qM_ToPosProcess




Fig. 4-91: Extension of “aClampOrient” - “qM_ToPosProcess”

“iPB_ToPosProcess” - enable signal for “qM_ToPosProcess”

“iLS_PosProcess” - limitation of the movement (machining position)

aOrientBack - qM_ToPosTransport




Fig. 4-92: Extension to “aOrientBack” - “qM_ToPosTransport”

“iPB_ToPosTransport” - enable signal for “qM_ToPosTransport”

“iLS_PosTransport” - limitation of the movement (transport position)

aRemovePiece - qM_FeedRemove




Fig. 4-93: Extension to “aRemovePiece” - “qM_FeedRemove”

“iPB_FeedRemove” - enabling the removal conveyor belt

“iLS_PieceRemoved” - workpiece not yet removed

aOpenDoor - qM_OpenDoor




Fig. 4-94: Extension to “aOpenDoor” - “qM_OpenDoor”

“iPB_OpenDoor” - enable signal for “qM_OpenDoor”

aUnclamp - qM_Unclamp




Fig. 4-95: “aUnclamp” - “qM_Unclamp”

“iPB_Unclamp” - enable signal for “qM_Unclamp”

Activating Outputs by Forcing Steps and/or Actions in the Manual Mode

Variables, steps and actions are always activated by the user in the manual mode.

Processing, however, is still pending as long as the step has neither been forced (setting of the <step name>.F) nor been activated otherwise for the manual mode. Setting the <step name>.ManEnable initiates setting of the <step name>.F.




Fig. 4-96: Forcing the step “sClamp” via “sClamp.ManEnable”

Now, activation of the motor “qM_Clamp” only depends on enabling “iPB_Clamp”.

Note: “sClamp.ManEnable” can be enabled by:

- forcing the variables (do not forget deactivation after having used them!),
- activation by pressing an M-key using an operator terminal,
- activation via a compact operator terminal.

Activating Outputs via Operating Screens in the Manual Mode

WinHMI permits to design operating screens which can be used in connection with machine function keys to control the output signals.



- L2: Safety door Open safety door (transparent), motor not activated; Is open (green); limit switch in end position.
- L3: Clamping Motion instruction (blue) for clamping open (transparent), motor not activated; is open (transparent); limit switch open.
- L6: Conveyor belt Motion instruction (blue) given for transport; Removal Material transport (red) pressed via M-key L6.

Fig. 4-97: Operating screen for controlling the example in the manual mode

Preparing the Use of the Operating Screens in WinHMI

Loading the Archive "HMI_SPS.APV"

All data types and function blocks required for implementing the process connection between WinHMI and the PLC are comprised in the PLC archive "HMI_SPS.APV".

The archive must be loaded once to the WinPCL programming system using "File / Archive / Load archive...". The archive resides in the

Drive:\Programme\Indramat\Mtgui\Basicdata\templates

folder.

Note: This step is, of course, not applicable, if it has already been implemented in connection with the diagnosis functions (preparing the use of the diagnosis functions in WinHMI)!

Supplementing the Declaration by the Necessary Variables / Instances for Activation of the Operating Screens

The connections to the machine function keys (M-keys) must be entered in the IO table of the resource.

Connection	I/Q	StartPos	Length	Log. No.	from	to	Program	Log. No.	Byte	Length
Interbus/M	%I	0.0	4.0	1	0.0	3.7	INDRA_PRG	1	0	1
							INDRA_PRG	1	1	1
							INDRA_PRG	1	2	1
							INDRA_PRG	1	3	1
M-Keys	%I	0.0	1.0	20	0.0	0.7	INDRA_PRG	20	0	1
							INDRA_PRG	20	1	1
Interbus/M	%Q	0.0	4.0	1	0.0	3.7	INDRA_PRG	1	0	1
							INDRA_PRG	1	1	1
							INDRA_PRG	1	2	1

Interbus-M: Inputs and outputs of the DEA box via Interbus modules
 M-keys: Connection of the machine function keys to the left and right

Fig. 4-98: IO table of the resource of the example

The declaration part is the next to be extended.

Name	AT	TYPE	:=	Comment
qM_FeedLoad	%Q1.2.4	BOOL	FALSE	(*Motor 'Conveyor belt, supply' / Motor Transportband Zu
qM_FeedRemove	%Q1.2.5	BOOL	FALSE	(*Motor 'Conveyor belt, removal' / Motor Transportband,
(*Gui_Sk16=====				
gui		GUI_SK16		(*Addressing of the machine function keys / Anschaltun
indGLMKEY		INST3A00		(*Data type for Mkey/ image mode / Datentyp für MKey/ E
TL_01	%I20.0.0	BOOL	FALSE	(*Machine function key 1 on the left / Maschinenfunktion
TL_02	%I20.0.1	BOOL	FALSE	(*Machine function key 2 on the left / Maschinenfunktion
TL_03	%I20.0.2	BOOL	FALSE	(*Machine function key 3 on the left / Maschinenfunktion
TL_04	%I20.0.3	BOOL	FALSE	(*Machine function key 4 on the left / Maschinenfunktion
TL_05	%I20.0.4	BOOL	FALSE	(*Machine function key 5 on the left / Maschinenfunktion
TL_06	%I20.0.5	BOOL	FALSE	(*Machine function key 6 on the left / Maschinenfunktion
TL_07	%I20.0.6	BOOL	FALSE	(*Machine function key 7 on the left / Maschinenfunktion
TL_08	%I20.0.7	BOOL	FALSE	(*Machine function key 8 on the left / Maschinenfunktion
TR_01	%I20.1.0	BOOL	FALSE	(*Machine function key 1 on the right / Maschinenfunctio
TR_02	%I20.1.1	BOOL	FALSE	(*Machine function key 2 on the right / Maschinenfunctio
TR_03	%I20.1.2	BOOL	FALSE	(*Machine function key 3 on the right / Maschinenfunctio
TR_04	%I20.1.3	BOOL	FALSE	(*Machine function key 4 on the right / Maschinenfunctio
TR_05	%I20.1.4	BOOL	FALSE	(*Machine function key 5 on the right / Maschinenfunctio
TR_06	%I20.1.5	BOOL	FALSE	(*Machine function key 6 on the right / Maschinenfunctio
TR_07	%I20.1.6	BOOL	FALSE	(*Machine function key 7 on the right / Maschinenfunctio
TR_08	%I20.1.7	BOOL	FALSE	(*Machine function key 8 on the right / Maschinenfunctio

gui: GUI_SK16, FB instance for connecting the M-keys to the PLC
 indGLMKEY: INST3A00, memory cells for the operation modes of the screen
 TL_01..TL_08: Machine function keys, to the left of the operating screen
 TR_01..TR_08: Machine function keys, to the right of the operating screen

Fig. 4-99: Extension of the declaration part of the example program

The next step is to assign the M-keys in the implementation of the example program.




Fig. 4-100: Connection of the M-keys to the module for operating screens (1st rung in the program)

Note: The extensions in the IO table and in the declaration part as well as the entry of the GUI_SK16 instance and the connection of the M-keys are independent of the example and can be applied to the root program.

Creating the Operating Screen

The complete creation of the operating screen goes beyond the scope of this description. For that reason, only the “Clamping”, M-key “L3” “open” and “is opened” areas as well as the motion instruction will be treated here. Please refer to /2/ for a detailed description of screen creation.

The entered operating screen is always bound to a control number. It can be executed in one language by defined texts or in several languages via token number and text files.

The texts are residing in “HMI_Manual_en.text”,

Drive:\Programme\Indramat\MTGUI\Project_000\CustomData\TEXT\EN or the appropriate language folder.

“Clamping” Text




Fig. 4-101: “Clamping” entry

Enter the number of the control “00”.

Axis specifications are not applicable.

“Clamping” is entered as a defined text.

“Open” Text




Fig. 4-102: “Open” entry

Enter the number of the control “00”.

The name of the PLC variable “**:I_Step.qM_Unclamp**” consists of:

- ":" Delimiter
- I_Step Instance name of the program
- qM_Unclamp Drive for unclamping the workpiece

The IO address of the variable is not necessary; access is achieved via the name.

If the variable is active, the field to the left is red, else it is transparent.

“Open” is entered as a defined text.

“Is opened” Text




Fig. 4-103: “Is opened” entry

Enter the number of the control “00”.

The name of the PLC variable “**:I_Step.iLS_Unclamp**” consists of:

- ":" Delimiter
- I_Step Instance name of the program
- iLS_Unclamped Limit switch indicating that the workpiece is unclamped.

The IO address of the variable is not necessary; access is achieved via the name.

If the variable is active, the field to the left is green, else it is transparent.

“Is opened” is entered as a defined text.

Editing M-key L3




Fig. 4-104: Editing M-key L3

Enter the number of the control “00”.

Check the “Use IndraStep” checkbox.

The name of the PLC variable of the M-key

“**I_Step.sUnclamp.ManEnable**” consists of:

- ":" Delimiter (automatically entered here)
- I_Step Instance name of the program (POU name)
- Demo_01 Name of the sequential function chart
- sUnclamp Name of the step to be used for controlling the clamping state in the manual mode.

Executability is displayed in the manual mode only; the diagnosis lens (in case of non-executability) is activated for SFC variables.

If execution is possible, the field to the right of M-key L3 is blue, else it is transparent.

The other fields of the operating screen must be completed appropriately.

Using the Operating Screen

In the sequence, operation steps typical for the manual mode are initiated and represented in WinPCL, step “**sUnclamp**”, action “**aUnclamp**”, and on the operating screen in the vicinity of M-key L3.

Basic Manual Mode Setting




Fig. 4-105: Display of the operating screen in its basic setting

The basic setting is characterized by

- WinPCL, an inactive step, left-hand bus-bar gray;
- WinPCL, “**Demo_01.Manual**” active, manual mode active;
- WinPCL, “**iPB_Unclamp**” inactive;
- WinHMI, motion instruction transparent;
- WinHMI, drive for unclamping the workpiece is inactive, transparent;
- WinHMI, clamping-is-opened limit switch, inactive, transparent.

Enabling “iPB_Unclamp” On enabling “iPB_Unclamp”, the motion instruction is activated.




Fig. 4-106: Display of the operating screen with motion instruction

This setting is characterized by

- WinPCL, an inactive step, left-hand bus-bar gray;
- WinPCL, “**Demo_01.Manual**” active, manual mode active;
- WinPCL, “**iPB_Unclamp**” active;
- WinHMI, motion instruction blue;
- WinHMI, drive for unclamping the workpiece is inactive, transparent;
- WinHMI, clamping-is-opened limit switch, inactive, transparent.

Command for Unclamping the Workpiece via M-key L3

With active motion instruction, the step “**sUnclamp**” and, thus, the drive for unclamping the workpiece is activated, when the M-key L3 is actuated.




Fig. 4-107: Display of the operating screen with active drive

This setting is characterized by

- WinPCL, an inactive step, left-hand bus-bar blue;
- WinPCL, “**Demo_01.Manual**” active, manual mode active;
- WinPCL, “**iPB_Unclamp**” active;
- WinHMI, motion instruction blue;
- WinHMI, drive for unclamping the workpiece is active, red;
- WinHMI, clamping-is-opened limit switch, inactive, transparent.

Workpiece is Unclamped; iLS_Unclamped Responds Once the workpiece is unclamped, the limit switch “iLS_Unclamped” responds and interrupts activation of the drive.




Fig. 4-108: Display of the operating screen with responding limit switch

This setting is characterized by

- WinPCL, an inactive step, left-hand bus-bar blue;
- WinPCL, “**Demo_01.Manual**” active, manual mode active;
- WinPCL, “**iPB_Unclamp**” active;
- WinPCL, “**iLS_Unclamped**” negated interrupts the power flow;
- WinHMI, motion instruction inactive, transparent;
- WinHMI, drive for unclamping the workpiece is inactive, transparent;
- WinHMI, clamping-is-opened limit switch, active, green.

Opening is achieved until the limit switch responds and is interrupted by the locking mechanism.

Activation of the M-key *without* Motion Enable If the M-key is activated *without* motion enable signal, the diagnosis lens (criteria analysis) is activated after the M-key has been released.

Component	Representation
BTV with WinHMI lens without additional information	
BTV with WinHMI lens without additional information	

Fig. 4-109: Diagnosis lens without and with additional information (Info key on BTV)

	Without Info key	With Info key
SFC:	Comment on the SFC (instance name.<SFC name>)	Instance name.<SFC name>
Status:	MANUAL	MANUAL
Step:	Comment on the step	<Step name>
		Minimum step time
		Maximum step time
Action:	Name of the action	Name of the action
Qualifier:		Action qualifier

Fig. 4-110: Additional information by pressing the Info key

Using Auxiliary Flags in Case of Several Contacts

If the number of conditions before “<SFC name>.Control_*” exceeds the number that can be represented, the rung can be separated by means of auxiliary flags, as shown below:



Component	Representation
<p>Separation of rungs by means of the auxiliary “flag” in WinPCL</p>	
<p>BTV with WinHMI comprises separated rungs on the screen.</p>	

Fig. 4-111: Auxiliary flags for separating wide rungs

Note: The name of the auxiliary flag can be selected as desired.
 The auxiliary flag can be used as often as desired, in one rung or in several rungs or even in various actions.

Activating Outputs via Compact Operator Terminals in the Manual Mode

(This section can be skipped if it is not intended to connect a compact operator terminal.)

Since compact operator terminals are not provided with operating screens, activation must be achieved by means of a PLC program block

The program block must be entered in the action “INTERN.aIN_USER”.





Fig. 4-112: Access to “INTERN.aIN_USER” via View / SFCs

Branch down to the action by double-clicking the mouse or pressing <Ctrl>+<Enter>.

If a compact operator terminal is connected, this program block forces the particular step concerned (in the manual mode). If a compact operator terminal is not active, the force flags of the particular step concerned are reset.



“**I_CompactOperatorTerminal_active**”:

A compact operator terminal is connected.

“**I_sUnclamp_manu_enable**”:

Unclamping command (in analogy with the M-key on the operating screen)

Fig. 4-113: Preparing the “manual mode with compact operator terminal” in the action “INTERN.aIN_USER”

If a compact operator terminal is connected, forcing of the step “**sUnclamp.F**” preliminarily calculates the motion instruction. However, the contact “**Control_a**” is enabled only via “**ManEnable**” (“**sUnclamp.ManEnable**”) (also see Fig. 4-95).

Activating Outputs by ManualForce in the Manual Mode

If it is intended to force one of the outputs directly in the manual mode (without evaluation of the locking mechanism), the signal “**i.ManualForce**” can be used.

Note: The risk arising in connection with using this signal is reduced by

- separate programming in the action <SFC name>.INTERN.aIN_USER,
- locking with the key switch.




Fig. 4-114: **Equivalent circuit diagram**; the branch containing Demo_01-ManualForce (green) has been additionally highlighted

Signal transfer from the input switch “**I_ManualForce**” via the locking mechanism with the contact “**Key Switch**” to the control signal “**Demo_01.i.ManualForce**” is programmed in the action “**Demo_01.INTERN.aIN_USER**”.




Fig. 4-115: Access to “**INTERN.aIN_USER**” via View / SFCs

Branch down to the action by double-clicking the mouse or pressing <Ctrl>+<Enter>.




Fig. 4-116: Locking “ManualForce” in the action “INTERN.aIN_USER”

This activates the following window:




Fig. 4-117: “ManualForce” - forcing an output

Note:

In this manner, the switch “I_ManualForce” activates

- all “relays” of the action with forced action,
- all “relays” of the step with forced step,

which are preceded by a variable “Control_a”.

“<Step name>.ManEnable” or “<action name>.ManEnable” must be activated for the desired step or desired action respectively.

SetStep on Changing from the Manual Mode to the Automatic Mode

If , on changing from the manual mode to the automatic mode, it is intended to use a step selection differing from that used before the manual mode has been activated, the following steps must be taken:

- Setting the SYNC variables of the appropriate steps “<step name>.SYNC”
- Setting the variable “<SFC name>.i.SetStep”
- Deactivating the manual mode “<SFC name>.i.Manual = FALSE”

On deactivation of the manual mode, it is checked whether the desired step assignment can be implemented.

If yes, the steps selected are activated.

If the step selected cannot be activated, the variable “<SFC name>.q.ErrorSetStep” is set.

4.8 ProVi Messages Used for Diagnosis

With the PLC program taken as a basis, ProVi messages are an additional instrument for displaying information on the WinHMI interface. The message can be emitted independently of whether IndraStep SFCs have been used or not.

Types of ProVi Messages

There are the following categories of messages which can be defined by the user:

- Faults
- Messages
- Warnings
- Start requirements
- Setup diagnosis messages

The type of message determines the type of display on the WinHMI interface (see /2/ WinHMI documentation).

Entering the Messages in the PLC Program

Organization of entering and processing the ProVi messages is uniform throughout the PLC program. A message can always be assigned to an LD or IL rung with Boolean output. If the Boolean output is activated, the message is displayed; if the output is not activated any more, the message disappears.

Note: If the rung is not processed any longer, for instance because it is skipped, the messages get "stuck"!

Messages are entered via the pop-up menu (<Shift>+<F10> keys or right mouse button), menu item "ProVi message".

This opens a window of the Message Integrator (MI), see Fig. 4-118.


The following items can be selected:

- module number,
- message type,
- message number (if the message is already existing, else it is assigned automatically),
- with or without criteria analysis;

and, in addition, multilingually:

- the desired message text,
- an additional message text (optional), and
- an advanced HTML file.

The multilingual text can be translated either immediately or as a complete file in the Message Integrator.

The  symbol to the upper left of the rung indicates that a ProVi message exists in WinPCL.






Fig. 4-118: Entering a ProVi message

The ProVi message can be entered in the online edit mode. The HMI diagnosis window shown below displays the message, which can be seen in Fig. 4-119.

The two pictograms at the beginning of the line have the following meanings:

-  HMI info; indicates that an additional comment can be displayed by pressing the Info key on the BTM. The header of the “Further info” box contains the information A/B/[C]/D/E - message text.
 - A: name of the POU instance (PLC program)
 - B: variable name
 - C: detail name (for “action” and “transition” detail types only)
 - D: rung number
 - E: message number
-  HMI-Enter; indicates that the criteria analysis (diagnosis lens) has been selected in Fig. 4-118.




Fig. 4-119: HMI diagnosis window with display of the ProVi message

Pressing the <Enter> key activates the criteria analysis:




Fig. 4-120: Diagnosis lens (criteria analysis)




Fig. 4-121: Header of the diagnosis lens (criteria analysis) after pressing of the Info key

The display shows the entire rung having caused activation of the variables.

Depending on whether the Info key has been pressed or not, the header of the screen displays the following information:

	Without Info key	With Info key
Status message:	Number in the Message Integrator	Number in the Message Integrator
Modules:	Number in the Message Integrator / in the SFC_diagnosis	Number in the Message Integrator / in the SFC_diagnosis
Comment:	ProVi message	
		Instance name and type of program
		Rung number in the action
		Variable having initiated the message

Fig. 4-122: Additional information after pressing of the Info key

Removing Function Blocks from the Displays of ProVi Rungs

The following example shows that function blocks which have one Boolean input and one Boolean output each as topmost connections will be removed from the criteria analysis if the condition is fulfilled:

Comment	Example
The branch with iPB30 and fb_ea has been added for test purposes.	<p>The screenshot shows a ProVi rung editor window titled 'Imp 00 Action aClampContinue [PR INDRA_DEMO.I_Step:INDRA_PRG]'. The rung contains several contacts: 'Demo_01.Auto', 'iLS_DoorClosed', 'Demo_01.Control_a', and 'qM_Clamp'. A function block 'fb_ea' (FB_EA) is connected to the rung. The function block has two inputs labeled 'e1' and 'a1', both of which are set to 'TRUE'. Below the function block, there are two outputs labeled 'r1' and 's1', both set to '0'. A status bar at the bottom of the window reads 'Demo_01.Auto (*Status contact - SFC is in automatic mode / Statuskontakt - SFC ist im Automatikbetrieb*)'. The status bar also shows 'STATUS' and 'edit' buttons.</p>
FB removed.	<p>The screenshot shows the same ProVi rung editor window after the function block 'fb_ea' has been removed. The rung now contains the contacts 'Demo_01.Auto', 'iLS_DoorClosed', 'Demo_01.Control_a', and 'qM_Clamp'. The contact 'iPB30' is highlighted in orange. The status bar at the bottom of the window reads 'Demo_01.Auto (*Status contact - SFC is in automatic mode / Statuskontakt - SFC ist im Automatikbetrieb*)'. The status bar also shows 'STATUS' and 'edit' buttons.</p>

Fig. 4-123: Removing function blocks

4.9 Updating IndraStep Files

IndraStep files (SKD file and structures) should only be changed after consultation with the customer service.

The user should, in particular, inform himself about further developments, so as to come to more beneficial solutions by using these new possibilities.

The following steps should be taken:

1. Archive the complete project (without secondary files).
2. Read the archive back to a new folder (variant).
3. Open the resource.
4. Export the files from WinPCL starting with the resource (main file).
5. Load the text file (ANSI) to a simple text editor (e.g. NotePad).
6. Replace the character strings for all types of use, e.g. “_INDRASTEP_01” by “_INDRASTEP_02”, and save them.
7. Import the changed ANSI file. A great number of editor windows is opened, with the resource being the topmost one.
8. Save the imported files. The following files are of no relevance, i.e. actually they do not have to be saved:
 - _INDRASTEP_02,
 - _INDRASTEP_02_SCHRITT, _INDRASTEP_02_TRANSITION, _INDRASTEP_02_AKTION,
 - _INDRASTEP_02_INTERN, _INDRASTEP_02_STEUERST, _INDRASTEP_02_STATUS
9. Load the new IndraStep files from the archive.

The files are contained as **archives** for WinHMI or WinPCL in the following folders:

 - *Mtgui\BasicData\TEMPLATES*
 - *WinPCL\BasicData\TEMPLATES*

The new files bear the same names as those recorded under item 8, overwriting them.
10. Complete compilation starting with the resource (main file).

5 System Variables of Steps, Transitions, Actions and Sequences (Overview)

5.1 Modes for Sequential Function Charts

According to the standard EN 61131-3, 2nd edition, the properties of steps, transitions and actions should be capable of being read back and modified by assigning system variables (flags) in programs and function blocks.

These requirements are met by the programming system WinPCL which, going beyond the variables contained in the standard, also supports additional variables by assigning data types.

In this manner, the following modes are implemented by **IndraStep**:

- Automatic mode
- Manual mode
- AutoStep mode

Note: Here, several sequential function charts are supported in each program or function block.

Using the footer command “3 - IndraStep”, an SKD file (**SchrittKetten-Diagnose** = SFC diagnosis) containing a set of data types and the necessary scripts is assigned to each sequential function chart.

SFC element	Data type
SFC (sequential function chart)	_INDRASTEP_02
STEP	_INDRASTEP_02_SCHRITT
TRANSITION	_INDRASTEP_02_TRANSITION
ACTION	_INDRASTEP_02_AKTION

Fig. 5-1: Data types for the “IndraStep” mode control

System Actions Calling the SKD file also provides two actions with system support:

Name	Use
<SFC name>.INTERN.aIN_USER	Whenever the SFC is executed, the action is executed before the SFC.
<SFC name>.INTERN.aOUT_USER	Whenever the SFC is executed, the action is executed after the SFC.

Fig. 5-2: System actions for the “IndraStep” mode control

Any activities which are executed independently of the active steps and the current mode can be programmed in these actions. However, actions are included in the SFC and they are part of the yellow box in the implementation.

The actions can be reached via

- the *View / SFCs* menu item,
- the actual SFC,
- actions.

5.2 System Variables of Steps

Depending on the type that is assigned, the user has access to the following variables (<SFC name>.<variable name>):

EN 61131-3	Basis	IndraStep	Type	Remark
X	X	X	BOOL	Step flag; TRUE if the step is active; read only
	F	F	BOOL	Forcing of the step in the manual mode; r/w
	SYNC	SYNC	BOOL	If TRUE: the step to be set as active step is selected, r/w
T	T	T	TIME	Step-active time, time elapsed since the step has been set; read only
		T_min	BOOL	If TRUE: the minimum step time is active; read only
		T_max	BOOL	If TRUE: the maximum step time is active; read only
		Error	BOOL	If TRUE: step failure; read only
		ActionIn	BOOL	Internal; motion instruction; read only
		ManEnable	BOOL	Motion enabled in the manual mode; acts on Control_a/Control_c; write

Fig. 5-3: Overview of step system variables

Using the pop-up menu (<Shift>+<F10> or right mouse button), two time values, i.e. a minimum and a maximum step time, can be entered for each step. The times can be entered as constants (T#...) or variables of type "TIME".

If TIME variables are used for the minimum / maximum step time, their value is saved when the step is becoming active.

Note: Only if a time value has been entered will the appropriate code be generated. Entering T#0s causes unnecessary effort!

The **minimum step time** forces the system to remain in the step, even if the following transition has already been fulfilled. The error and T-min flags of the step as well as the MinTime flag of the following transition are set in the time interval between "Condition fulfilled" and "minimum step time not yet elapsed completely".

After this time has elapsed, the system moves to the following step, with the transition condition still fulfilled. The error and T_min flags of the step as well as the MinTime flag of the transition are reset.

The **maximum step time** permits to check whether the transition condition has been fulfilled rapidly enough, so that the step could be exited.

If this time is exceeded, the T_max and error flags are set. The entire SFC is stopped with set SFC error flag. If the condition is fulfilled thereafter, it is not possible to move to the following step. The error must be eliminated and the SFC restarted.

Note: If the minimum step time exceeds the maximum step time, the maximum step time and, thus, its error mechanism will become ineffective.

The **ManEnable** flag will be described in the section on forcing of actions in the manual mode.

5.3 System Variables of Transitions

Depending on the type that is assigned, the user has access to the following variables (<transition name>.<variable name>):

EN 61131-3	Basis	IndraStep	Type	Remark
	JOG	JOG	BOOL	Stop point in the jog mode; TRUE if the transition, with the condition fulfilled, is to switch on after confirmation only (initial value); write
		X	BOOL	Logic result of the transition rung; write
		MinTime	BOOL	TRUE - minimum step time is running; read only

Fig. 5-4: Overview of transition system variables

The MinTime flag indicates that the transition condition was fulfilled before the minimum step time had elapsed. It will be reset after the transition has been passed.


5.4 System Variables of Actions

Depending on the type that is assigned, the user has access to the following variables (<action name>.<variable name>):

EN 61131-3	Basis	IndraStep	Type	Remark
Q	Q	Q	BOOL	Action flag; regular action processing according to the action qualifier; read only
A	A	A	BOOL	Postprocessing flag Regular action processing + postprocessing; read only
	F	F	BOOL	If TRUE: forcing of the action in the manual mode; write
	JOG	JOG	BOOL	TRUE - in the JOG mode, if the following transition is fulfilled; read only
		Error	BOOL	If TRUE: error message; read only
		ActionIn	BOOL	TRUE, if the action conditions are fulfilled; read only
		ManEnable	BOOL	TRUE - permits action processing in the manual mode; write
		MonErrorFE	BOOL	Used internally; flag for indication of a falling edge (criteria analysis)

Fig. 5-5: Overview of action system variables

5.5 Overview of Action Qualifiers



- S_A : The step becomes active
- T_1 : The action time is between S_A and S_E
- S_E : The step becomes inactive
- T_2 : The action time is outside of S_E
- R : The action block is reset

Fig. 5-6: Time diagram for the action qualifiers

The bar is to be interpreted as follows:



- ?: No statement on processing
- Black: The action is being processed.
- Gray: The action is being postprocessed (once).

5.6 System Variables of Sequences

The sections below describe the data type “_INDRASTEP_02”.

- **INTERN** Mode management; for internal use only
- **i** Input signals for mode control of the sequence
- **q** Status signals for mode control of the sequence
- **Flags** which can be used to activate the mode-depending outputs.

_INDRASTEP_02	STRUCT	
INTERN	_INDRASTEP_02_INTERN	Internal control interface of the IndraStep sequential function chart
i	_INDRASTEP_02_STEUERST	Control Signals “i”
q	_INDRASTEP_02_STATUS	Status Signals “q”
Manual	BOOL	Contact which indicates the manual mode (read only)
Auto	BOOL	Contact which indicates the automatic mode (read only)
AutoStep	BOOL	Contact which indicates the AutoStep mode (read only)
Stopped	BOOL	Contact which indicates that the sequential function chart has stopped (read only)
Control_a	BOOL	Status contact - opens on a stop, error, and in case of the AutoStep mode with AutoStepEnable
Control_b	BOOL	Status contact - opens at the end of the action (in analogy with action.Q)
Control_c	BOOL	Status contact - function same as for Control_a, with additional diagnosis if the logic result before the contact is FALSE
Transition_OK	BOOL	Contact which is closed under the marginal condition “AutoStep mode”, “Action processing = TRUE”, and “Following transition condition fulfilled”.
WaitOnTransition	BOOL	Contact which indicates that <u>one</u> transition is fulfilled in the AutoStep mode. “Start” switches on to the next step (see AutoStep Mode on page 4-61)
MonError	BOOL	This flag can be used for monitoring purposes in a rung. If the flag is set to TRUE, the sequential function chart enters the failure mode. In this case, the IndraStep criteria analysis analyzes only this rung.
MonErrorFE	BOOL	Has the same effects as MonError, with the exception that, here, only the falling edge is evaluated. Can be used to diagnose falling conditions (interruptions).
TimeErrorStepDiag	BOOL	This contact can be used to monitor error conditions. If it responds, the possible error causes (inactive outputs with their control rungs) or, if these are not available, the non-fulfilled transition rung is searched from all actions of the active step.
SetStep	BOOL	Permits, in the automatic mode, further processing of the sequential function chart starting with that step assignment which has been selected by <step name>. Sync (see SetStep in the Automatic Mode on page 4-34)
ManualForce	BOOL	Permits to set variables in the manual mode, without taking the locking conditions into consideration. Beforehand, the signal must be applied in <SFC name>. INTERN.aIN_USER (see Activating Outputs by ManualForce in the Manual Mode on page 4-82)
END_STRUCT		

Fig. 5-7: Structure “_INDRASTEP_02” (flag highlighted in gray)

Notes on the Control_a, Control_b and Control_c Flags

- **Control_a**

Status contact - opens on action end, stop, error, and in case of the AutoStep mode with **AutoStepEnable**

Control_a is TRUE, if:	Control_a is FALSE, if:
SFC.AutoStepEnable = TRUE in the AutoStep mode	<SFC name>.Enable = FALSE in the AutoStep mode
Regular processing of actions	Postprocessing of actions
No error (e.g. MonError)	Error
Not stopped	Stopped

Fig. 5-8: **Control_a** conditions

- **Control_b**

Status contact - opens at the end of the action (in analogy with <action name>.Q)

- **Control_c**

Status contact - function same as for **Control_a**, with additional diagnosis if the logic result before the contact is FALSE

Note: An action error is not evaluated for the first processing cycle of the action.
Purpose: If the following transition is directly fulfilled after a step, an action diagnosis is not executed even if the action is not fulfilled.

Control Signals “i”

Input signals which can be used to change the operating modes and to manipulate the sequence.

_INDRASTEP_02_STEUERST	STRUCT	
Start	BOOL	Start signal for the sequential function chart after a stop
Stop	BOOL	The sequential function chart is stopped.
Revers	BOOL	Recommended for users: Using the <step name>.SYNC variables and SetStep , the user is able to program reverse processes.
AutoStep	BOOL	Selection of the AutoStep mode
Manual	BOOL	Selection of the manual mode
ManualForce	BOOL	Permits to activate an output controlled via Control_a in the manual mode, without taking the enable conditions into consideration. To achieve this, the ManualForce signal must be locked in the action INTERN.aIN_USER , by means of a key switch contact.
SetStep	BOOL	Unconditional jump to steps specified by <step name>.SYNC. Here, parallel steps must be taken into consideration.
Reset	BOOL	The sequential function chart is reset to the initial step und to the initial state.
ClearError	BOOL	An existing error is cleared.
END_STRUCT		

Fig. 5-9: Control signals for mode control

Status Signals “q”

Output signals indicating the current mode as well as its additional properties, such as error messages and the like.

_INDRASTEP_02_STATUS	STRUCT	
Error	BOOL	An error is existing; the sequential function chart is stopped.
ErrorSetStep	BOOL	Error in setting the steps which have been preselected by the <step name>.SYNC variables and whose processing has been initiated by setting i.SetStep . Note: Take note of parallel steps!
Stopped	BOOL	The sequential function chart is in the stop mode.
Manual	BOOL	The sequential function chart is in the manual mode.
AutoStepActive	BOOL	At least one step/transition is in the AutoStep mode.
WaitOnTransition	BOOL	At least one transition following an active step is fulfilled.
Revers	BOOL	Recommended for users: The sequential function chart is in the reverse mode.
Ready	BOOL	Recommended for users: The sequential function chart is ready for the start enable signal.
Active	BOOL	The SFC is active and has exited the initial step.
Run	BOOL	The SFC processes active steps, or at least one step is active in the manual mode.
END_STRUCT		

Fig. 5-10: Status signals of the mode control

6 ProVi Messages (Overview)

This section contains information on how to handle diagnosis messages in WinPCL:

- ProVi Messages (Diagnosis in LD / IL Rungs)
- Sequential Function Chart Diagnosis
- Module Assignment (Multiple Use of POUs)
- Diagnosis Display of I/O Addresses in PRs and FBs

A difference is made between diagnosis messages which are related to instruction-list or ladder-diagram rungs and diagnosis messages which are bound to sequential function charts.

Since a diagnosis message is always filed in the program code, it is necessary to assign modules, if several instances exist of one function block with diagnosis generation.

6.1 ProVi Messages (Diagnosis in LD / IL Rungs)

General Information

ProVi messages are messages which are emitted by the PLC and can be displayed on the WinHMI interface or on the compact operator terminals by means of the Screen Manager /3/.

ProVi messages comprise five different messages types:

- Errors
- Messages
- Warnings
- Start requirements
- Setup diagnosis messages

The type of message determines the type of display on the WinHMI interface (see /2/ WinHMI documentation).

The “warning, start requirement and setup diagnosis” message types are existing only once per control.

The “error and message” message types are existing only once per module. If several modules are provided in one control, the message types may also exist several times (for modules see /2/ WinHMI documentation).

The text to be displayed for a ProVi message must be entered in the **Message Integrator**. There the message can also be translated for the multilingual diagnosis function (also see /2/ WinHMI documentation).

Programming a ProVi Message

ProVi messages can be emitted in each program and in each instance of a function block.

In these programs and function blocks, a ProVi message can be assigned to each rung having a Boolean result.

Proceed as follows:

- Program the rung to initiate the ProVi message.
- Click the right mouse button (or press <Shift>+<F10>) to select the ProVi messages item.




Fig. 6-1: Assigning the network (rung) properties

- This opens a dialog where the message type (error, message, warning, etc.), the message number and the module number can be entered.




Fig. 6-2: Dialog for selecting the message type

ProVi Message, Input Dialog

This dialog (“Entry ProVi message”) can be used to enter the text to be displayed for a ProVi message in several languages. The data entered here will then be displayed in the Message Integrator and, in WinHMI, for the diagnosis message.

The dialog can also be used to select texts already existing in the Message Integrator and to assign these texts to a message in a rung.

Selecting an unused message number automatically

If the dialog is opened for a rung which does not contain any ProVi message, an unused message number is automatically suggested after a message type and a module number have been selected. This number corresponds to the highest existing message number + 1.

This message number can then be used to enter the message text, the further info text and the further info file in this dialog.

Selecting an unused message number manually

If the automatically selected message number fails to be the desired one, the message number can also be entered manually. If the **Message Integrator** contains data for this message number, this data is displayed in the dialog where it can also be edited.

Finding a message number

It is also possible to find an already existing message text and to apply its message number.

The find dialog can be called up by clicking the “Find” button.




Fig. 6-3: Find window entered from the “Entry ProVi message” window

Message numbers can be found in the message texts or in the further info texts. The search is always made in all existing languages.

Once the dialog is exited with OK, the message number selected is applied to the ProVi message input dialog.

- Any ProVi message assigned to the rung is indicated by the “i” to the left of the status bar of the rung.




Fig. 6-4: The “blue I” indicating a ProVi message

Output of ProVi Messages

If the Boolean result of a ProVi rung is TRUE, the message is emitted. The message remains active until the result of this rung becomes FALSE again.

Here, the status of the variable at the time of processing the rung is of relevance, and not the status of the variable at the end of the cycle. Hence, the same variable can be used in various ProVi rungs.

Note: If a rung is not processed any more, e.g. if it is skipped, or if the action is not active any longer, a change of the ProVi message is no longer possible. In other words: If the condition for output of a message is not fulfilled any more and the rung of this message is not processed any longer, the message still remains active.

ProVi Criteria Analysis

The default setting of ProVi messages is without criteria analysis. However, the **criteria analysis** can be activated for each single message.

In order to achieve a reasonable diagnosis, certain programming guidelines must be observed.

- The code in the sequential function chart may contain Boolean variables only.
- Operations with XOR are not permitted.
- Function or function block calls are not permitted.
- Temporary flags, i.e. an assignment within a rung, are not permitted.




Fig. 6-5: Impermissible use of the temporary flag "output_01" (yellow)

Permissible exceptions are the following:

- *Temporary flags* which are only used within their own action.
- *Variables whose rungs are not displayed in the diagnosis:*
If the IndraStep variables **TimeErrorStepDiag** and **SetStep** are used in rungs, these rungs are removed from the diagnosis.
- *Hiding function blocks from the diagnosis:*
Function blocks in rungs to be subjected to diagnosis are removed from the diagnosis if the first (topmost) input and the first (topmost) output of the function block are of the BOOL type.

Time stages (TON) are typical for this application.

The code at the first input and output is displayed (see example of the "output_03" variable).




Fig. 6-6: Hiding function blocks in the diagnosis by defined variables (yellow)

The diagnosis display is as follows:




Fig. 6-7: Hidden FB

In the ProVi criteria analysis, the I/O addresses of the variables are displayed (see Section 6.3, Diagnosis Display of I/O Addresses in PRs and FBs).

6.2 Sequential Function Chart Diagnosis

General Information

Each sequential function chart with operating modes is able to generate diagnosis messages on the WinHMI interface.

The **criteria analysis** can be called for this sequential function chart. The criteria analysis will then display one or several contacts having triggered the error of the sequential function chart.

The **criteria analysis** is activated automatically for each sequential function chart with diagnosis that has failed, without an additional code having to be programmed. The following section, Programming Instructions on page 6-3, contains a couple of restrictions which are required to obtain a reasonable criteria analysis.

By assigning a sequential function chart to a module, the place of display on the WinHMI interface is determined.

The diagnosis comments of the sequential function chart (sequence, action, transition, steps, variables, IL / LD) can be translated in the **Message Integrator** to provide a multilingual display of the diagnosis.

Programming a Sequential Function Chart Diagnosis

The assignment of a module to the sequential function chart results automatically in the diagnosis for this sequential function chart.

Proceed As Follows:

- Program the sequential function chart which is to trigger the diagnosis message.
- Click the right mouse button or press <Shift>+<F10> to select the Diagnosis properties item.




Fig. 6-8: Assigning the diagnosis properties

- This opens a dialog box for entering the module number.




Fig. 6-9: Dialog box for entering the module number

- The **i** to the left of the status bar of the sequence indicates that diagnosis information has been assigned to this sequential function chart.




Fig. 6-10: The "blue I" indicating a sequential function chart with diagnosis

Output of Sequential Function Chart Diagnosis Messages

If a sequential function chart enters the failure mode, a message is emitted.

This message contains the SFC name, the step that has failed and the error type of the sequential function chart. This message remains active until the error of the sequential function chart has been cleared.

For this failed sequential function chart, the criteria analysis can also be called on the WinHMI interface (see WinHMI documentation /2/).

Programming Instructions

These instructions are applicable to programming the sequential function chart, i.e. only those actions and transitions are concerned which are contained in a sequential function chart with diagnosis.

The implementation as well as the actions and transitions which are not used in the sequential function chart diagnosis are not displayed in the **criteria analysis**. As a consequence, these rules are not applicable to the code contained therein either.

- It is not permitted to use Boolean transitions or Boolean actions.
- The code in the sequential function chart may contain Boolean variables only.
- Operations with XOR are not permitted.
- Function or function block calls are not permitted.
- Temporary flags, i.e. assignments within a rung, are not permitted (see the example below).




Fig. 6-11: Impermissible use of the temporary flag "output_01" (yellow)

Permissible exceptions are the following:

- *Temporary flags* which are only used within their own action.
- *Variables whose rungs are not displayed in the diagnosis:*
If the IndraStep variables **TimeErrorStepDiag** and **SetStep** are used in rungs, these rungs are removed from the diagnosis.
- *Hiding function blocks from the diagnosis:*
Functions blocks in rungs to be subjected to diagnosis are removed from the diagnosis if the first (topmost) input and the first (topmost) output of the function block are of the BOOL type.

Time stages (TON) are typical for this application.

The code at the first input and output is displayed (see example of the "output_03" variable).




Fig. 6-12: Hiding function blocks in the diagnosis by defined variables (yellow)

The diagnosis display is as follows:




Fig. 6-13: Hidden FB

6.3 Diagnosis Display of I/O Addresses in PRs and FBs

In the **criteria analysis**, the I/O address and the related comment are displayed for those variables which are connected to absolutely addressed inputs and outputs.

This also functions under the following conditions, if the real I/O variable is not defined in the POU of the sequential function chart, but is only transferred to it:

1. The I/O variable is defined globally and is used as VAR_EXTERNAL variable in the POU.
2. The variable displayed is an input or output of the POU. An I/O variable is directly connected to this input or output. The variable may neither be negated nor be linked to other variables.

Note: A call of the POU must always be processed since, otherwise, the status of the internal variables is not the same as the status of the input or output.

Example:

The variable input_01 is used in the sequential function chart of the POU SfcFB. For this variable, the criteria analysis displays the address %I1.4.6 and the comment "test_input".




Fig. 6-14: Diagnosis display of absolute addresses in FBs

6.4 Module Assignment (Multiple Use of POU's)

If a function block or a program with diagnosis is provided with several instances, it is necessary to define the instance where the diagnosis should be displayed.

Example:

There is a function block (FB_DRILLING) which entirely controls a drill and also contains the diagnosis messages of the drill. One control is to control two modules each of which contains one drill. Instances of the same function block are used for the two drills.

VAR		
Drilling_Module1	FB_DRILLING	(*Drilling station 1*)
Drilling_Module2	FB_DRILLING	(*Drilling station 2*)
Diagnose_Bohrwerk_00.bmp		

Fig. 6-15: Declaration of two instances of FB_DRILLING

ProVi messages (errors and messages) and a sequential function chart (drilling station) are programmed in this function block.

During programming, module numbers had to be specified for these diagnosis messages (sequential function chart diagnosis). In our example, module number 1 has been programmed. The diagnosis for one of the drills, however, is to be displayed in module 1 and that of the other drill in module 2.

In the resource, each use of a diagnosis message can be provided with its own module number.

The dialog for the module assignment can only be called for the resource of the PLC program. It can be reached via the menu item *Tools / Diagnosis module assignment*.

This dialog contains an ASCII editor where the module assignments can be entered, with the appropriate syntax being observed.

Example:

The program where the two drills (see above) are declared is declared as unit_01 in the resource.

In this dialog, module number 1 is assigned to all diagnosis messages from Drilling_Module1 and module number 2 to all diagnosis messages from Drilling_Module2.




Fig. 6-16: Diagnosis module assignment

If no entry is made in this dialog, the original module number is assigned, i.e. the entry for Drilling_Module1 in the figure above is actually not necessary because the original module number is already 1.

Syntax:

- The various specifications are always separated by a dot.
- Defined keywords are **SFC, PROVI, ERROR, MESSAGE**.
- The complete instance must be entered for the POU. The various instances of the POU's are separated by a dot. Example: Unit_01.Drilling_Module1
- Sequential function charts are specified by **SFC.SfcName.ModuleNo.**
 - *SfcName* = name of the sequential function chart in the POU
 - *ModuleNo.* = originally programmed module number (sequential function chart diagnosis)
- ProVi messages are specified by **PORVI.MessageType.ModuleNo.**
 - *MessageType* = **ERROR** or **MESSAGE**
 - *ModuleNo.* = originally programmed module number (diagnosis in LD/IL rungs)

Since there is no module number for the other ProVi message types, they cannot be assigned here.

The assignment to the module number can be made at any point in the path. That is why it is not necessary to enter the entire character string:

Character string	Meaning
Unit_01.Drilling_Module2.PROVI.Error.1=3	Only this message type is displayed in module 3.
Unit_01.Drilling_Module2.PROVI.Error=3	All ProVi errors in this instance are displayed in module 3.
Unit_01.Drilling_Module2.PROVI=3	All ProVi messages in this instance are displayed in module 3.
Unit_01.Drilling_Module2.SFC.Drill=4	Only this sequential function chart is displayed in module 4.
Unit_01.Drilling_Module2.SFC=4	All sequential function charts of this instance are displayed in module 4.
Unit_01.Drilling_Module2=5	All diagnosis messages of this instance of the POU are displayed in module 5. This also applies to all instances of the POUs which are declared in this POU.
Unit_01=5	All diagnosis messages occurring in this program are displayed in module 5. This also applies to all instances of the POUs which are declared in this POU (in our example: Drilling_Module1 and Drilling_Module2).

Fig. 6-17: Examples for the assignment of module numbers

It is always the last module assignment in an instance path that transfers its value. If, for instance, the following assignments are made:

```
Unit_01.Drilling_Module2.SFC.Drill=4
Unit_01.Drilling_Module2=3
Unit_01=2
```

the diagnosis messages from the example are displayed in the following modules:

- Instance Unit_01.Drilling_Module1
 - ProVi error 1 in module 2
 - ProVi message 1 in module 1
 - Sequential function chart drill 1 in module 2
- Instance Unit_01.Drilling_Module2
 - ProVi message 1 in module 3
 - ProVi message 1 in module 3
- Sequential function chart drill 1 in module 4

7 Instructions

7.1 Criteria Analysis

ProVi messages and IndraStep sequential function charts can be **supplemented** by automatically generated diagnosis messages, which can be displayed directly on the HMI interface without requiring any additional configuration. In the case of ProVi networks, this is the network property with activated “criteria analysis”; in the case of IndraStep sequential function charts, it is the assignment to a module in the sequence overview. The criteria analysis is not necessarily activated in the case of IndraStep sequential function charts and ProVi messages. If it is used, however, certain rules must be followed. Should these rules not be observed, the syntax check or the compiler will not cause any errors, but the diagnosis may be incorrect or incomplete.

Which Elements can be Processed by the Criteria Analysis?

As a matter of principle, only operations of Boolean variables can be analyzed. These may be declared globally and locally. They may be part of multi-element variables (ARRAYs and structures as well as mixtures of these). Here, it is not permitted

- to determine an intermediate result within the rung,
- to use the XOR operation,
- to analyze operations, functions and function blocks.

If non-Boolean variables are existing in the rung, e.g. a comparison of two numerals, they are always considered to be faulty or, when the motion signal is calculated by IndraStep, to be fulfilled.

ProVi An exception here are function blocks whose topmost input is a Boolean input and whose topmost output is a Boolean output.

Such a function block is completely suppressed by the criteria analysis, i.e. the criteria analysis considers the topmost input to be connected to the topmost output. As a consequence, e.g. timers for delaying the message in case of limit-switch pair monitoring can be used. To generate a reasonable error display, the function block used must transfer a positive network result (logic result VKE = TRUE) from its topmost input to its topmost output in the event of an error.

To save the error state, a **latch** can be programmed. If a latch is provided in the rung, the complete OR branch is suppressed by the criteria analysis, even if it comprises still other contacts, thus not appearing on the display.

- IndraStep** Here as well, an exception are function blocks whose topmost input is a Boolean input and whose topmost output is a Boolean output.
- In the case of IndraStep, the output of the FB must, in addition, be assigned to specific IndraStep elements (MonError, MonErrorFe).
- Such a function block is completely suppressed by the criteria analysis, i.e. the criteria analysis considers the topmost input to be connected to the topmost output. As a consequence, e.g. timers for delaying the message in case of limit-switch pair monitoring can be used. To generate a reasonable error display, the function block used must transfer a positive network result (logic result VKE = TRUE) from its topmost input to its topmost output in the event of an error.
- In the case of IndraStep, a difference can be made between manual and automatic network branches (<SFC name>.Manual or <SFC name>.Auto), depending on the operating mode. If the automatic mode is activated, the branch in which the <SFC name>.Manual has been programmed is ignored, thus not appearing in the analysis.
- Complete networks, which activate a <SFC name>.SetStep or <SFC name>.TimeErrorStepDiag relay, are excluded from the diagnosis.
- These networks can also contain FBs and functions, etc.

How Many Rungs are Covered by the Criteria Analysis?

- ProVi** As far as ProVi is concerned, the criteria analysis covers only the particular rung to which the ProVi property has been assigned. In other words, all contacts involved in the error must be within the rung.
- IndraStep** As far as IndraStep is concerned, errors are covered by the criteria analysis within an action. For that reason, a dummy calculation can even be made within the failed action with IndraStep. If diagnosis is necessary, only an action or transition will be displayed as the error cause. If several actions are programmed in a step, the first action processed (order from the SFC list) will be signalled as the faulty action. If several rungs are contained in a failed action, the rungs are analyzed for non-compliance and, thus, displayed in the order of processing, in the event of an action or time error.
- If several rungs in one action are connected via dummies, the particular dummy is replaced by the rung above it.

Using FBs, FNs and OPs

With the exception of the simple FBs for delaying failures which are not displayed in the criteria analysis, it should be avoided to use FBs, FNs or OPs in rungs which can be subjected to the criteria analysis. If, however, it is necessary to use such functionalities nonetheless, they should not be used within the IndraStep sequential function chart or ProVi rungs with criteria analysis. If, for instance, an excess temperature is to be displayed, the temperature comparison must be programmed outside of the sequential function chart, before calling the sequence (the yellow box) or in the action **“alnUser”** or before the ProVi rung. The result of such a function is to be mapped on a Boolean flag which is used in the stead of the function in the rung to be analyzed. This has the advantage, that the operator of the machine receives a clear message (in our case a flag contact **“excess temperature (*excess temperature oil hydraulics assembly XYZ*)”**) which can usually be understood more easily than a comparison with values requiring interpretation.

Supplement of Future IndraStep Versions with FBs/FNs/OPs

To be able to use FBs/FNs/OPs directly within an action, a flag **“NoDiag”** must be added as relay to the operation result. If this flag name is used, the rung where it is used as relay will be excluded from diagnosis.

A second normal flag (e.g. **“excess temperature: BOOL; (*excess temperature at assembly XYZ*)”**) which has been switched in parallel can be used for diagnosis in the following rung.

Displayed Status Values of a Criteria Analysis

On the one hand, the criteria analysis displays the stored state of the variables used as it was when the error occurred and, on the other hand, the current status value corresponding to the usual online display of the editor.

The stored status value corresponds to the stored states of the involved variables immediately after the rung has been processed. As is the case with the normal status display, the current online variable values correspond to the variable values at the end of the PLC cycle.

7.2 Motion Signal with IndraStep

The motion signal is calculated by the HMI operating screen themselves, without the logic in the PLC being processed.

Steps and actions of the IndraStep sequential function chart are not processed in the manual mode. The logic of the step and its actions is only processed when the M-key is pressed.

To establish the motion signal without active processing, use is made of the functionality of the criteria analysis. The actions existing in a step, including their rungs, are checked for a positive rung result by the criteria analysis. As soon as at least one rung has a positive result (TRUE), the motion signal is signaled.

The calculation is functioning if only Boolean elements capable of analysis are used in the rungs.

In cases of doubt, i.e. if FBs, FNs or OPs are used, a positive result is assumed, i.e. a motion signal is displayed. In other words, it is possible that a motion and, thus, a diagnosis, is **not** initiated when the M-key is pressed.

8 Glossary

Criteria analysis

Tool for detecting error causes in the event of *monitor errors* or *time errors*.

Device

In WinHMI, a control or a unit is also called device.

Diagnosis lens

If execution is not possible, the *diagnosis lens* permits to determine the conditions which are not fulfilled, using the *criteria analysis*. The function of calling the diagnosis lens can be deactivated, can always be active or can be bound to the manual mode via an SFC variable.

Head-end control

Main operator panel of the system

IndraStep

Sequence (sequential function chart) in a PLC function block or a PLC program on the basis of the IndraStep data types.

Local control

Device in front of the operator.

Mode = operating mode

Automatic mode = Auto

Automatic single-step mode = AutoStep mode

Manual mode = Manual

Module

WinHMI provides the option of designing the structure of the user interface according to mechanical-engineering or operating units by means of so-called modules. A module represents such a mechanical-engineering or operating unit.

Monitor errors

The *criteria analysis* of WinHMI cause exactly those rungs to be displayed in which the error variables **MonError** and **MonErrorFE** are controlled.

Motion instruction

Summary of all conditions to the left of **Control_a**;

Its calculation requires that the step / the action is active (automatic mode) or forced (manual mode).

MTGUI

Graphical user interface for calling and managing or configuring the programming system for NC (WinMTC) and PLC (WinPCL) as well as the WinHMI user interface. It is also based on Windows.

PC compound

Name for the PC network at a machine (e.g. transfer machine).

Process

Name same as in the NC area, i.e. designation of a sequential function chart programmed in the NC control.

ProVi

System for the generation (in the PLC) or display (in WinHMI) of various types of messages and/or failures.

Time errors

Time errors are errors for which the *criteria analysis* initially searches the output that has caused the error in all actions of the currently active step(s). For this output or these outputs, the rungs are signalled for diagnosis.

If the criteria analysis fails to find such an output, the rung of the non-fulfilled transition is signalled for diagnosis.

9 List of Figures

- Fig. 1-1: Additional documentations 1-2
- Fig. 1-2: Rungs with IndraStep features 1-3
- Fig. 1-3: Completed rungs according to the desired function (additional contacts are highlighted in yellow) 1-4
- Fig. 3-1: Hazard classification (according to ANSI Z535) 3-1
- Fig. 4-1: Creating the variant 4-1
- Fig. 4-2: Creating a new program 4-2
- Fig. 4-3: Creating a new resource 4-2
- Fig. 4-4: "Mode control" area in the declaration of a program 4-3
- Fig. 4-5: Loading the "IndraStep structures" archive to the "IndraStep_Demo" variant. 4-4
- Fig. 4-6: Selecting an SFC type, here IndraStep 4-5
- Fig. 4-7: Defining the SFC type 4-5
- Fig. 4-8: Selecting the desired "Demo_01" SFC 4-6
- Fig. 4-9: SFC selected from the ladder diagram 4-6
- Fig. 4-10: Mode control in the ladder diagram 4-7
- Fig. 4-11: Mode control in the IL 4-8
- Fig. 4-12: Order of execution in Fig. 4-10 and Fig. 4-11 4-8
- Fig. 4-13: Example of the IndraStep mode control 4-9
- Fig. 4-14: Input and output assignment of the example 4-10
- Fig. 4-15: Extending the declaration part by the variables of the example 4-11
- Fig. 4-16: SFC of the example 4-12
- Fig. 4-17: Steps and transitions in the SFC list 4-13
- Fig. 4-18: Sample action with manual and automatic modes 4-14
- Fig. 4-19: Elements of the sample action 4-14
- Fig. 4-20: The step becomes active 4-15
- Fig. 4-21: Step 'sStep' with action 'aAction1' and an LD rung within 4-16
- Fig. 4-22: Modification for the motor case (forced turnoff) 4-17
- Fig. 4-23: Circuit for the **clamping device** case 4-17
- Fig. 4-24: "**wPiece**" step (initial step) 4-18
- Fig. 4-25: Details on step "**wPiece**" 4-18
- Fig. 4-26: "**tPiece_in_Pos**" transition 4-19
- Fig. 4-27: Details on the transition "**tPiece_in_Pos**" 4-19
- Fig. 4-28: "**sCloseDoor**" step 4-20
- Fig. 4-29: Details on step "**sCloseDoor**" 4-20
- Fig. 4-30: "**sClamp**" step 4-21
- Fig. 4-31: Details on step "**sClamp**" 4-21
- Fig. 4-32: "**tClamped_Closed**" transition 4-22
- Fig. 4-33: Details on transition "**tClamped_Closed**" 4-22
- Fig. 4-34: "**sOrient**" step 4-23
- Fig. 4-35: Details on step "**sOrient**" 4-23

- Fig. 4-36: “**tOriented**” transition 4-24
- Fig. 4-37: Details on transition “**tOriented**” 4-24
- Fig. 4-38: “**sWorkOn**” step 4-25
- Fig. 4-39: Details on step “**sWorkOn**” 4-25
- Fig. 4-40: “**tReady**” transition 4-26
- Fig. 4-41: Details of transition “**tReady**” 4-26
- Fig. 4-42: “**sOrientBack**” step 4-26
- Fig. 4-43: Details on step “**sOrientBack**” 4-27
- Fig. 4-44: “**tOrientedBack**” transition 4-28
- Fig. 4-45: Details on transition “**tOrientedBack**” 4-28
- Fig. 4-46: “**sUnClamp**” step 4-29
- Fig. 4-47: Details of step “**sUnClamp**” 4-29
- Fig. 4-48: “**sOpenDoor**” step 4-30
- Fig. 4-49: Details on step “**sOpenDoor**” 4-30
- Fig. 4-50: “**tUnClamped_Opened**” transition 4-31
- Fig. 4-51: Detail on transition “**tUnClampedOpened**” 4-31
- Fig. 4-52: “**wRemove**” step 4-32
- Fig. 4-53: Details on step “**wRemove**” 4-32
- Fig. 4-54: “**tQuit**” transition 4-33
- Fig. 4-55: Detail on transition “**tQuit**” 4-33
- Fig. 4-56: Jump of “**sWorkOn**” in case of a tool breakage 4-34
- Fig. 4-57: Action error initiated by “<SFC name>.Control_c” (yellow) 4-35
- Fig. 4-58: Pop-up menu, step time 4-36
- Fig. 4-59: Specifying the maximum step time in the step “**sOrientBack**” 4-37
- Fig. 4-60: Monitoring the down movement of the safety door 4-38
- Fig. 4-61: Equivalent circuit diagram “Minimum processing time”, T_{min} in green color 4-39
- Fig. 4-62: Global limit switch monitoring 4-40
- Fig. 4-63: Local error monitoring 4-41
- Fig. 4-64: Dynamic monitoring of an output signals 4-42
- Fig. 4-65: ModulDef.ini for our example 4-45
- Fig. 4-66: Enabling the diagnosis 4-45
- Fig. 4-67: Entering the module number 4-46
- Fig. 4-68: “Entry of module number executed” marked in the SFC 4-46
- Fig. 4-69: “Entry of module number executed” marked in the SFC list 4-46
- Fig. 4-70: Diagnosis in WinHMI, faultless operation 4-46
- Fig. 4-71: Advanced diagnosis up to the criteria analysis 4-48
- Fig. 4-72: Additional information after the Info key of the BTV has been pressed 4-48
- Fig. 4-73: Advanced diagnosis up to the criteria analysis 4-50
- Fig. 4-74: Additional information after the Info key of the BTV has been pressed 4-50
- Fig. 4-75: Advanced diagnosis up to the criteria analysis 4-52

- Fig. 4-76: Additional information after the Info key of the BTV has been pressed 4-52
- Fig. 4-77: Advanced diagnosis up to the criteria analysis 4-54
- Fig. 4-78: Additional information after the Info key of the BTV has been pressed 4-54
- Fig. 4-79: Advanced diagnosis up to the criteria analysis 4-56
- Fig. 4-80: Additional information after the Info key of the BTV has been pressed 4-56
- Fig. 4-81: Advanced diagnosis up to the criteria analysis 4-58
- Fig. 4-82: Additional information after the Info key of the BTV has been pressed 4-58
- Fig. 4-83: Advanced diagnosis up to the criteria analysis 4-60
- Fig. 4-84: Additional information after the Info key of the BTV has been pressed 4-60
- Fig. 4-85: Sample action with manual and automatic modes 4-62
- Fig. 4-86: Elements of the sample action 4-62
- Fig. 4-87: Cross-reference list for determining the assignment of outputs 4-63
- Fig. 4-88: Extension of **“aMovePiece”** - **“qM_FeedLoad”** 4-63
- Fig. 4-89: Extension of **“aClamp”** - **“qM_Clamp”** 4-64
- Fig. 4-90: Extension of **“aCloseDoor”** - **“qM_CloseDoor”** 4-64
- Fig. 4-91: Extension of **“aClampOrient”** - **“qM_ToPosProcess”** 4-65
- Fig. 4-92: Extension to **“aOrientBack”** - **“qM_ToPosTransport”** 4-65
- Fig. 4-93: Extension to **“aRemovePiece”** - **“qM_FeedRemove”** 4-66
- Fig. 4-94: Extension to **“aOpenDoor”** - **“qM_OpenDoor”** 4-66
- Fig. 4-95: **“aUnclamp”** - **“qM_Unclamp”** 4-67
- Fig. 4-96: Forcing the step **“sClamp”** via **“sClamp.ManEnable”** 4-68
- Fig. 4-97: Operating screen for controlling the example in the manual mode 4-69
- Fig. 4-98: IO table of the resource of the example 4-70
- Fig. 4-99: Extension of the declaration part of the example program 4-70
- Fig. 4-100: Connection of the M-keys to the module for operating screens (1st rung in the program) 4-71
- Fig. 4-101: **“Clamping”** entry 4-72
- Fig. 4-102: **“Open”** entry 4-72
- Fig. 4-103: **“Is opened”** entry 4-73
- Fig. 4-104: Editing M-key L3 4-74
- Fig. 4-105: Display of the operating screen in its basic setting 4-75
- Fig. 4-106: Display of the operating screen with motion instruction 4-76
- Fig. 4-107: Display of the operating screen with active drive 4-77
- Fig. 4-108: Display of the operating screen with responding limit switch 4-78
- Fig. 4-109: Diagnosis lens without and with additional information (Info key on BTV) 4-79
- Fig. 4-110: Additional information by pressing the Info key 4-79
- Fig. 4-111: Auxiliary flags for separating wide rungs 4-80
- Fig. 4-112: Access to **“INTERN.aIN_USER”** via View / SFCs 4-81

- Fig. 4-113: Preparing the “manual mode with compact operator terminal” in the action “**INTERN.aIN_USER**” 4-81
- Fig. 4-114: **Equivalent circuit diagram**; the branch containing Demo_01-ManualForce (green) has been additionally highlighted 4-82
- Fig. 4-115: Access to “**INTERN.aIN_USER**” via View / SFCs 4-82
- Fig. 4-116: Locking “**ManualForce**” in the action “**INTERN.aIN_USER**” 4-83
- Fig. 4-117: “**ManualForce**” - forcing an output 4-83
- Fig. 4-118: Entering a ProVi message 4-86
- Fig. 4-119: HMI diagnosis window with display of the ProVi message 4-87
- Fig. 4-120: Diagnosis lens (criteria analysis) 4-87
- Fig. 4-121: Header of the diagnosis lens (criteria analysis) after pressing of the Info key 4-87
- Fig. 4-122: Additional information after pressing of the Info key 4-88
- Fig. 4-123: Removing function blocks 4-88
- Fig. 5-1: Data types for the “IndraStep” mode control 5-1
- Fig. 5-2: System actions for the “IndraStep” mode control 5-1
- Fig. 5-3: Overview of step system variables 5-2
- Fig. 5-4: Overview of transition system variables 5-3
- Fig. 5-5: Overview of action system variables 5-3
- Fig. 5-6: Time diagram for the action qualifiers 5-4
- Fig. 5-7: Structure “_INDRASTEP_02” (flag highlighted in gray) 5-5
- Fig. 5-8: **Control_a** conditions 5-6
- Fig. 5-9: Control signals for mode control 5-7
- Fig. 5-10: Status signals of the mode control 5-7
- Fig. 6-1: Assigning the network (rung) properties 6-2
- Fig. 6-2: Dialog for selecting the message type 6-3
- Fig. 6-3: Find window entered from the “Entry ProVi message” window 6-4
- Fig. 6-4: The “blue I” indicating a ProVi message 6-4
- Fig. 6-5: Impermissible use of the temporary flag “output_01” (yellow) 6-5
- Fig. 6-6: Hiding function blocks in the diagnosis by defined variables (yellow) 6-6
- Fig. 6-7: Hidden FB 6-6
- Fig. 6-8: Assigning the diagnosis properties 6-7
- Fig. 6-9: Dialog box for entering the module number 6-8
- Fig. 6-10: The “blue I” indicating a sequential function chart with diagnosis 6-8
- Fig. 6-11: Impermissible use of the temporary flag “output_01” (yellow) 6-9
- Fig. 6-12: Hiding function blocks in the diagnosis by defined variables (yellow) 6-10
- Fig. 6-13: Hidden FB 6-10
- Fig. 6-14: Diagnosis display of absolute addresses in FBs 6-11
- Fig. 6-15: Declaration of two instances of FB_DRILLING 6-12
- Fig. 6-16: Diagnosis module assignment 6-13
- Fig. 6-17: Examples for the assignment of module numbers 6-14

10 Index

—
 _INDRASTEP_02 5-5
 _INDRASTEP_02_ACTION 5-3
 _INDRASTEP_02_STATUS 5-7
 _INDRASTEP_02_STEP 5-2
 _INDRASTEP_02_STEUERST 5-7
 _INDRASTEP_02_TRANSITION 5-3

>

>Step is active< time 4-15
 >Step is inactive< time 4-15

A

Activating outputs by forcing steps and/or actions in the manual mode 4-68
 Activating outputs by ManualForce in the manual mode 4-82
 Activating outputs via compact operator terminals in the manual mode 4-81
 Activating outputs via operating screens
 Creating the operating screen 4-71
 Preparatory measures 4-69
 Preparatory measures, loading the archive HMI_SPS.APV 4-69
 Preparatory measures, supplementing the declaration by the necessary variables /
 instances for activation of the operating screens 4-70
 Activating outputs via operating screens in the manual mode 4-69
 Appropriate use
 Introduction 2-1
 Uses 2-2
 Automatic mode
 SetStep 4-34
 AutoStep mode 4-61
 AutoStep mode of an IndraStep SFC 4-61
 Auxiliary flags 4-80

C

Control_a 4-14, 5-6
 Control_b 4-14, 5-6
 Control_c 4-14, 5-6
 Creating an IndraStep example project 4-1

D

Diagnosis
 Action errors 4-47
 Delayed error monitoring (global) 4-55
 Dynamic error monitoring (MonErrorFE) 4-59
 Error monitoring (local) 4-57
 Maximum processing time 4-49
 Time error – resulting from TimeErrorStepDiag 4-51
 Undelayed error monitoring (global) 4-53
 Diagnosis display of I/O addresses in PRs and FBs 6-11
 Diagnosis options 4-43
 Diagnosis options in WinHMI 4-43
 Assigning the module definition in the SFC editor 4-45
 Creating the file ModulDef.ini 4-44
 Defining the module configuration 4-44
 Loading the archive HMI_SPS.APV 4-44
 Diagnosis options in WinPCL 4-43
 Diagnosis options, ProVi messages 4-85

E

Error monitoring 4-39

- Action errors 4-35
- Dynamic 4-42
- Global 4-39
- Local 4-41
- Possibilities 4-35
- Time errors 4-36
- Time errors, maximum processing time 4-37
- Time errors, minimum processing time 4-39
- Time errors, TimeErrorStepDiagnosis 4-38

Example

- Assigning inputs and outputs 4-10
- Completing the SFC in the root program 4-11
- Drilling station 4-9
- Entering actions and switch-on conditions (automatic mode) in the root program 4-14
- Extending the declaration by the variables of the example 4-11
- Incorporating the example in the root program 4-11
- Sequence of steps 4-9
- supplementing the manual mode to the automatic mode 4-62

F

Flag, mode control

- Control_a 5-6
- Control_a 4-14, 4-62
- Control_b 4-14, 4-62, 5-6
- Control_c 4-14, 4-62, 5-6

G

- General processing of actions 4-15
- General structure of an action in the manual and automatic modes 4-14, 4-62
- GUI_SK16, , FB instance for connecting the M-keys to the PLC 4-71

H

- HMI_SPS.APV 4-44, 4-69

I

- Inappropriate use 2-2
 - Consequences, Discharge of liability 2-1
- Instructions on starting the program example 4-35

M

- Manual mode 4-61
 - Activation and deactivation of the manual mode from the automatic mode 4-61
 - Changing the step assignment before returning to the automatic mode 4-61
 - SetStep 4-84
- Manual operation of an IndraStep SFC 4-61
- ModulDef.ini 4-44
- Module assignment (multiple use of POU) 6-12
- Module assignment (syntax) 6-13

O

- Operating screen
 - Using the operating screen 4-75
- Operating screens
 - Creating the operating screen 4-71
- Order of execution 4-8
- Output of ProVi messages 6-5
- Output of sequential function chart diagnosis messages 6-9

P

- Postprocessing of actions 4-15
- Programming a ProVi message 6-2
- Programming a sequential function chart diagnosis 6-7
- Programming Instructions for Sequential Function Chart Diagnosis Messages 6-9
- ProVi messages 6-1
- ProVi messages (overview) 6-1
- ProVi messages used for diagnosis 4-85
- ProVi messages, removing FBs 6-6
- ProVi messages, removing of FBs 4-88

R

- Results from postprocessing of actions – example 4-16
- Root program 4-1
 - Calling the SFC in the instruction list 4-8
 - Calling the SFC in the ladder diagram 4-6
 - Creating a new variant 4-1
 - Creating a sequential function chart 4-4
 - Creating the program 4-2
 - Creating the resource and entering the program 4-2
 - Declaring the variables for mode control 4-3
 - Loading the IndraStep files 4-4

S

- Safety Instructions for Electric Drives and Controls 3-1
- Sequential function chart diagnosis 6-7
- SetStep
 - In the automatic mode 4-34
 - In the manual mode 4-84
- SKD file 4-4, 5-1
- System action <sfc_name>.INTERN.aIN_USER 5-1
- System action <sfc_name>.INTERN.aOUT_USER 5-1
- System variables of steps, transitions, actions 5-1
- Sytem action <sfc_name>.INTERN.aIN_USER 4-8
- Sytem action <sfc_name>.INTERN.aOUT_USER 4-8

T

TEMPLATES

- _IndraStep_xx.apv 4-4, 4-89
- HMI_SPS.apv 4-44, 4-69
- IndraStep_Demo_00.APV 1-1

U

- Updating IndraStep files 4-89
- Use *See appropriate use and inappropriate use*
- Using auxiliary flags in case of several contacts 4-80

11 Service & Support

11.1 Helpdesk

Unser Kundendienst-Helpdesk im Hauptwerk Lohr am Main steht Ihnen mit Rat und Tat zur Seite. Sie erreichen uns

- telefonisch - by phone:
über Service Call Entry Center
- via Service Call Entry Center
- per Fax - by fax:
- per e-Mail - by e-mail:

Our service helpdesk at our headquarters in Lohr am Main, Germany can assist you in all kinds of inquiries. Contact us

49 (0) 9352 40 50 60

Mo-Fr 07:00-18:00
Mo-Fr 7:00 am - 6:00 pm

+49 (0) 9352 40 49 41

service@boschrexroth.de

11.2 Service-Hotline

Außerhalb der Helpdesk-Zeiten ist der Service direkt ansprechbar unter

After helpdesk hours, contact our service department directly at

+49 (0) 171 333 88 26

oder - or

+49 (0) 172 660 04 06

11.3 Internet

Unter www.boschrexroth.de finden Sie ergänzende Hinweise zu Service, Reparatur und Training sowie die **aktuellen** Adressen *) unserer auf den folgenden Seiten aufgeführten Vertriebs- und Servicebüros.



Verkaufsniederlassungen



Niederlassungen mit Kundendienst

Außerhalb Deutschlands nehmen Sie bitte zuerst Kontakt mit unserem für Sie nächstgelegenen Ansprechpartner auf.

*) Die Angaben in der vorliegenden Dokumentation können seit Drucklegung überholt sein.

At www.boschrexroth.de you may find additional notes about service, repairs and training in the Internet, as well as the **actual** addresses *) of our sales- and service facilities figuring on the following pages.



sales agencies



offices providing service

Please contact our sales / service office in your area first.

*) Data in the present documentation may have become obsolete since printing.

11.4 Vor der Kontaktaufnahme... - Before contacting us...

Wir können Ihnen schnell und effizient helfen wenn Sie folgende Informationen bereithalten:

1. detaillierte Beschreibung der Störung und der Umstände.
2. Angaben auf dem Typenschild der betreffenden Produkte, insbesondere Typenschlüssel und Seriennummern.
3. Tel./Faxnummern und e-Mail-Adresse, unter denen Sie für Rückfragen zu erreichen sind.

For quick and efficient help, please have the following information ready:

1. Detailed description of the failure and circumstances.
2. Information on the type plate of the affected products, especially type codes and serial numbers.
3. Your phone/fax numbers and e-mail address, so we can contact you in case of questions.

11.5 Kundenbetreuungsstellen - Sales & Service Facilities

Deutschland – Germany

vom Ausland:

(0) nach Landeskennziffer weglassen!

from abroad:

don't dial (0) after country code!

Vertriebsgebiet Mitte Germany Centre Rexroth Indramat GmbH Bgm.-Dr.-Nebel-Str. 2 / Postf. 1357 97816 Lohr am Main / 97803 Lohr Kompetenz-Zentrum Europa Tel.: +49 (0)9352 40-0 Fax: +49 (0)9352 40-4885	SERVICE CALL ENTRY CENTER MO – FR von 07:00 - 18:00 Uhr from 7 am – 6 pm Tel. +49 (0) 9352 40 50 60 service@boschrexroth.de	SERVICE HOTLINE MO – FR von 17:00 - 07:00 Uhr from 5 pm - 7 am + SA / SO Tel.: +49 (0)172 660 04 06 oder / or Tel.: +49 (0)171 333 88 26	SERVICE ERSATZTEILE / SPARES verlängerte Ansprechzeit - extended office time - ♦ nur an Werktagen - only on working days - ♦ von 07:00 - 18:00 Uhr - from 7 am - 6 pm - Tel. +49 (0) 9352 40 42 22
Vertriebsgebiet Süd Germany South Rexroth Indramat GmbH Landshuter Allee 8-10 80637 München Tel.: +49 (0)89 127 14-0 Fax: +49 (0)89 127 14-490	Vertriebsgebiet West Germany West Bosch Rexroth AG Regionalzentrum West Borsigstrasse 15 40880 Ratingen Tel.: +49 (0)2102 409-0 Fax: +49 (0)2102 409-406	Gebiet Südwest Germany South-West Bosch Rexroth AG Service-Regionalzentrum Süd-West Siemensstr.1 70736 Fellbach Tel.: +49 (0)711 51046-0 Fax: +49 (0)711 51046-248	Gebiet Südwest Germany South-West Bosch Rexroth AG Regionalzentrum Südwest Ringstrasse 70 / Postfach 1144 70736 Fellbach / 70701 Fellbach Tel.: +49 (0)711 57 61-100 Fax: +49 (0)711 57 61-125
Vertriebsgebiet Nord Germany North Bosch Rexroth AG Walsroder Str. 93 30853 Langenhagen Tel.: +49 (0) 511 72 66 57-0 Service: +49 (0) 511 72 66 57-256 Fax: +49 (0) 511 72 66 57-93 Service: +49 (0) 511 72 66 57-95	Vertriebsgebiet Mitte Germany Centre Bosch Rexroth AG Regionalzentrum Mitte Waldecker Straße 13 64546 Mörfelden-Walldorf Tel.: +49 (0) 61 05 702-3 Fax: +49 (0) 61 05 702-444	Vertriebsgebiet Ost Germany East Bosch Rexroth AG Beckerstraße 31 09120 Chemnitz Tel.: +49 (0)371 35 55-0 Fax: +49 (0)371 35 55-333	Vertriebsgebiet Ost Germany East Bosch Rexroth AG Regionalzentrum Ost Walter-Köhn-Str. 4d 04356 Leipzig Tel.: +49 (0)341 25 61-0 Fax: +49 (0)341 25 61-111

Europa (West) - Europe (West)

vom Ausland: (0) nach Landeskennziffer weglassen, **Italien:** 0 nach Landeskennziffer mitwählen
from abroad: don't dial (0) after country code, **Italy:** dial 0 after country code

<p>Austria - Österreich</p> <p>Bosch Rexroth GmbH Bereich Indramat Stachegasse 13 1120 Wien</p> <p>Tel.: +43 (0)1 985 25 40 Fax: +43 (0)1 985 25 40-93</p>	<p>Austria – Österreich</p> <p>Bosch Rexroth GmbH Gesch.ber. Rexroth Indramat Industriepark 18 4061 Pasching</p> <p>Tel.: +43 (0)7221 605-0 Fax: +43 (0)7221 605-21</p>	<p>Belgium - Belgien</p> <p>Bosch Rexroth AG Electric Drives & Controls Industrielaan 8 1740 Ternat</p> <p>Tel.: +32 (0)2 5830719 - service: +32 (0)2 5830717 Fax: +32 (0)2 5830731 indramat@boschrexroth.be</p>	<p>Denmark - Dänemark</p> <p>BEC A/S Zinkvej 6 8900 Randers</p> <p>Tel.: +45 (0)87 11 90 60 Fax: +45 (0)87 11 90 61</p>
<p>Great Britain – Großbritannien</p> <p>Bosch Rexroth Ltd. Rexroth Indramat Division Broadway Lane, South Cerney Cirencester, Glos GL7 5UH</p> <p>Tel.: +44 (0)1285 863000 Fax: +44 (0)1285 863030 sales@boschrexroth.co.uk service@boschrexroth.co.uk</p>	<p>Finland - Finnland</p> <p>Bosch Rexroth Oy Rexroth Indramat division Ansatie 6 017 40 Vantaa</p> <p>Tel.: +358 (0)9 84 91-11 Fax: +358 (0)9 84 91-13 60</p>	<p>France - Frankreich</p> <p>Bosch Rexroth S.A. Division Rexroth Indramat Avenue de la Trentaine (BP. 74) 77503 Chelles Cedex</p> <p>Tel.: +33 (0)164 72-70 00 Fax: +33 (0)164 72-63 00 Hotline: +33 (0)608 33 43 28</p>	<p>France - Frankreich</p> <p>Bosch Rexroth S.A. Division Rexroth Indramat ZI de Thibaud, 20 bd. Thibaud (BP. 1751) 31084 Toulouse</p> <p>Tel.: +33 (0)5 61 43 61 87 Fax: +33 (0)5 61 43 94 12</p>
<p>France - Frankreich</p> <p>Bosch Rexroth S.A. Division Rexroth Indramat 91, Bd. Irène Joliot-Curie 69634 Vénissieux – Cedex</p> <p>Tel.: +33 (0)4 78 78 53 65 Fax: +33 (0)4 78 78 53 62</p>	<p>Italy - Italien</p> <p>Bosch Rexroth S.p.A. Via G. Di Vittoria, 1 20063 Cernusco S/N.MI</p> <p>Tel.: +39 02 92 365 1 +39 02 92 365 326 Fax: +39 02 92 365 500 +39 02 92 365 516378</p>	<p>Italy - Italien</p> <p>Bosch Rexroth S.p.A. Via Paolo Veronesi, 250 10148 Torino</p> <p>Tel.: +39 011 224 88 11 Fax: +39 011 224 88 30</p>	<p>Italy - Italien</p> <p>Bosch Rexroth S.p.A. Via del Progresso, 16 (Zona Ind.) 35020 Padova</p> <p>Tel.: +39 049 8 70 13 70 Fax: +39 049 8 70 13 77</p>
<p>Italy - Italien</p> <p>Bosch Rexroth S.p.A. Via Mascia, 1 80053 Castellammare di Stabia NA</p> <p>Tel.: +39 081 8 71 57 00 Fax: +39 081 8 71 68 85</p>	<p>Italy - Italien</p> <p>Bosch Rexroth S.p.A. Viale Oriani, 38/A 40137 Bologna</p> <p>Tel.: +39 051 34 14 14 Fax: +39 051 34 14 22</p>	<p>Netherlands – Niederlande/Holland</p> <p>Bosch Rexroth B.V. Kruisbroeksestraat 1 (P.O. Box 32) 5281 RV Boxtel</p> <p>Tel.: +31 (0)411 65 19 51 Fax: +31 (0)411 65 14 83 www.boschrexroth.nl</p>	<p>Netherlands - Niederlande/Holland</p> <p>Bosch Rexroth Services B.V. Technical Services Kruisbroeksestraat 1 (P.O. Box 32) 5281 RV Boxtel</p> <p>Tel.: +31 (0)411 65 19 51 Fax: +31 (0)411 67 78 14 services@boschrexroth.nl</p>
<p>Norway - Norwegen</p> <p>Bosch Rexroth AS Rexroth Indramat Division Berghagan 1 or: Box 3007 1405 Ski-Langhus 1402 Ski</p> <p>Tel.: +47 (0)64 86 41 00 Fax: +47 (0)64 86 90 62 jul.ruud@rexroth.no</p>	<p>Spain - Spanien</p> <p>Bosch Rexroth S.A. Divisiòn Rexroth Indramat Centro Industrial Santiga Obradors s/n 08130 Santa Perpetua de Mogoda Barcelona</p> <p>Tel.: +34 9 37 47 94 00 Fax: +34 9 37 47 94 01</p>	<p>Spain – Spanien</p> <p>Goimendi S.A. Divisiòn Rexroth Indramat Parque Empresarial Zuatzu C/ Francisco Grandmontagne no.2 20018 San Sebastian</p> <p>Tel.: +34 9 43 31 84 21 - service: +34 9 43 31 84 56 Fax: +34 9 43 31 84 27 - service: +34 9 43 31 84 60 sat.indramat@goimendi.es</p>	<p>Sweden - Schweden</p> <p>Rexroth Mecman Svenska AB Rexroth Indramat Division - Varuvägen 7 (Service: Konsumentvägen 4, Älfsjö) 125 81 Stockholm</p> <p>Tel.: +46 (0)8 727 92 00 Fax: +46 (0)8 647 32 77</p>
<p>Sweden - Schweden</p> <p>Rexroth Mecman Svenska AB Indramat Support Ekvändan 7 254 67 Helsingborg</p> <p>Tel.: +46 (0) 42 38 88 -50 Fax: +46 (0) 42 38 88 -74</p>	<p>Switzerland West - Schweiz West</p> <p>Bosch Rexroth Suisse SA Département Rexroth Indramat Rue du village 1 1020 Renens</p> <p>Tel.: +41 (0)21 632 84 20 Fax: +41 (0)21 632 84 21</p>	<p>Switzerland East - Schweiz Ost</p> <p>Bosch Rexroth Schweiz AG Geschäftsbereich Indramat Hemrietstrasse 2 8863 Buttikon</p> <p>Tel. +41 (0) 55 46 46 111 Fax +41 (0) 55 46 46 222</p>	

Europa (Ost) - Europe (East)

vom Ausland: (0) nach Landeskenziffer weglassen
from abroad: don't dial (0) after country code

Czech Republic - Tschechien Bosch -Rexroth, spol.s.r.o. Hviezdoslavova 5 627 00 Brno Tel.: +420 (0)5 48 126 358 Fax: +420 (0)5 48 126 112	Czech Republic - Tschechien DEL a.s. Strojírenská 38 591 01 Zdar nad Sázavou Tel.: +420 566 64 3144 Fax: +420 566 62 1657	Hungary - Ungarn Bosch Rexroth Kft. Angol utca 34 1149 Budapest Tel.: +36 (1) 422 3200 Fax: +36 (1) 422 3201	Poland – Polen Bosch Rexroth Sp.zo.o. ul. Staszica 1 05-800 Pruszków Tel.: +48 22 738 18 00 – service: +48 22 738 18 46 Fax: +48 22 758 87 35 – service: +48 22 738 18 42
Poland – Polen Bosch Rexroth Sp.zo.o. Biuro Poznan ul. Dabrowskiego 81/85 60-529 Poznan Tel.: +48 061 847 64 62 /-63 Fax: +48 061 847 64 02	Romania - Rumänien East Electric S.R.L. B-dul Basarabie, nr.250, sector 3 73429 Bucuresti Tel./Fax:: +40 (0)21 255 35 07 +40 (0)21 255 77 13 Fax: +40 (0)21 725 61 21 est@mb.roknet.ro	Romania - Rumänien Bosch Rexroth Sp.zo.o. Str. Drobety nr. 4-10, app. 14 70258 Bucuresti, Sector 2 Tel.: +40 (0)1 210 48 25 +40 (0)1 210 29 50 Fax: +40 (0)1 210 29 52	Russia - Russland Bosch Rexroth OOO Wjatskaja ul. 27/15 127015 Moskau Tel.: +7-095-785 74 78 +7-095 785 74 79 Fax: +7 095 785 74 77 laura.kanina@boschrexroth.ru
Russia - Russland ELMIS 10, Internationalnaya 246640 Gomel, Belarus Tel.: +375/ 232 53 42 70 +375/ 232 53 21 69 Fax: +375/ 232 53 37 69 elmis_ltd@yahoo.com	Turkey - Türkei Bosch Rexroth Otomasyon San & Tic. A..S. Fevzi Cakmak Cad No. 3 34630 Sefaköy Istanbul Tel.: +90 212 541 60 70 Fax: +90 212 599 34 07	Slovenia - Slowenien DOMEL Otoki 21 64 228 Zelezniki Tel.: +386 5 5117 152 Fax: +386 5 5117 225 brane.ozebek@domel.si	

Africa, Asia, Australia – incl. Pacific Rim

<p>Australia - Australien</p> <p>AIMS - Australian Industrial Machinery Services Pty. Ltd. 28 Westside Drive Laverton North Vic 3026 Melbourne</p> <p>Tel.: +61 3 93 243 321 Fax: +61 3 93 243 329 Hotline: +61 4 19 369 195 terryobrien@aimservices.com.au</p>	<p>Australia - Australien</p> <p>Bosch Rexroth Pty. Ltd. No. 7, Endeavour Way Braeside Victoria, 31 95 Melbourne</p> <p>Tel.: +61 3 95 80 39 33 Fax: +61 3 95 80 17 33 mel@rexroth.com.au</p>	<p>China</p> <p>Shanghai Bosch Rexroth Hydraulics & Automation Ltd. Waigaoqiao, Free Trade Zone No.122, Fu Te Dong Yi Road Shanghai 200131 - P.R.China</p> <p>Tel.: +86 21 58 66 30 30 Fax: +86 21 58 66 55 23 richard.yang_sh@boschrexroth.com.cn gf.zhu_sh@boschrexroth.com.cn</p>	<p>China</p> <p>Shanghai Bosch Rexroth Hydraulics & Automation Ltd. 4/f, Marine Tower No.1, Pudong Avenue Shanghai 200120 - P.R.China</p> <p>Tel.: +86 21 68 86 15 88 Fax: +86 21 58 40 65 77</p>
<p>China</p> <p>Bosch Rexroth China Ltd. 15/F China World Trade Center 1, Jianguomenwai Avenue Beijing 100004, P.R.China</p> <p>Tel.: +86 10 65 05 03 80 Fax: +86 10 65 05 03 79</p>	<p>China</p> <p>Bosch Rexroth China Ltd. Guangzhou Repres. Office Room 1014-1016, Metro Plaza, Tian He District, 183 Tian He Bei Rd Guangzhou 510075, P.R.China</p> <p>Tel.: +86 20 8755-0030 +86 20 8755-0011 Fax: +86 20 8755-2387</p>	<p>China</p> <p>Bosch Rexroth (China) Ltd. A-5F., 123 Lian Shan Street Sha He Kou District Dalian 116 023, P.R.China</p> <p>Tel.: +86 411 46 78 930 Fax: +86 411 46 78 932</p>	<p>China</p> <p>Melchers GmbH BRC-SE, Tightening & Press-fit 13 Floor Est Ocean Centre No.588 Yanan Rd. East 65 Yanan Rd. West Shanghai 200001</p> <p>Tel.: +86 21 6352 8848 Fax: +86 21 6351 3138</p>
<p>Hongkong</p> <p>Bosch Rexroth (China) Ltd. 6th Floor, Yeung Yiu Chung No.6 Ind Bldg. 19 Cheung Shun Street Cheung Sha Wan, Kowloon, Hongkong</p> <p>Tel.: +852 22 62 51 00 Fax: +852 27 41 33 44 alexis.siu@boschrexroth.com.hk</p>	<p>India - Indien</p> <p>Bosch Rexroth (India) Ltd. Rexroth Indramat Division Plot. A-58, TTC Industrial Area Thane Turbhe Midc Road Mahape Village Navi Mumbai - 400 701</p> <p>Tel.: +91 22 7 61 46 22 Fax: +91 22 7 68 15 31</p>	<p>India - Indien</p> <p>Bosch Rexroth (India) Ltd. Rexroth Indramat Division Plot. 96, Phase III Peenya Industrial Area Bangalore - 560058</p> <p>Tel.: +91 80 41 70 211 Fax: +91 80 83 94 345 mohanvelu.t@boschrexroth.co.in</p>	<p>India - Indien</p> <p>Bosch Rexroth (India) Ltd. 1st Floor, S-10 Green Park ext. Market New Delhi – 110016</p> <p>Tel.: +91 1 16 56 68 88 Fax: +91 1 16 56 68 87</p>
<p>Indonesia - Indonesien</p> <p>PT. Rexroth Wijayakusuma Building # 202, Cilandak Commercial Estate Jl. Cilandak KKO, Jakarta 12560</p> <p>Tel.: +62 21 7891169 (5 lines) Fax: +62 21 7891170 - 71</p>	<p>Japan</p> <p>Bosch Rexroth Automation Corp. Service Center Japan Yutakagaoka 1810, Meito-ku, NAGOYA 465-0035, Japan</p> <p>Tel.: +81 52 777 88 41 +81 52 777 88 53 +81 52 777 88 79 Fax: +81 52 777 89 01</p>	<p>Japan</p> <p>Bosch Rexroth Automation Corp. Rexroth Indramat Division 1F, I.R. Building Nakamachidai 4-26-44, Tsuzuki-ku YOKOHAMA 224-0041, Japan</p> <p>Tel.: +81 45 942 72 10 Fax: +81 45 942 03 41</p>	<p>Korea</p> <p>Bosch Rexroth-Korea Ltd. Electric Drives and Controls Bongwoo Bldg. 7FL, 31-7, 1Ga Jangchoong-dong, Jung-gu Seoul, 100-391</p> <p>Tel.: +82 234 061 813 Fax: +82 222 641 295</p>
<p>Korea</p> <p>Bosch Rexroth-Korea Ltd. 1515-14 Dadae-Dong, Saha-Ku Rexroth Indramat Division Pusan Metropolitan City, 604-050</p> <p>Tel.: +82 51 26 00 741 Fax: +82 51 26 00 747 gyhan@rexrothkorea.co.kr</p>	<p>Malaysia</p> <p>Bosch Rexroth Sdn.Bhd. 11, Jalan U8/82, Seksyen U8 40150 Shah Alam Selangor, Malaysia</p> <p>Tel.: +60 3 78 44 80 00 Fax: +60 3 78 45 48 00 hockhwa@hotmail.com rexroth1@tm.net.my</p>	<p>Singapore - Singapur</p> <p>Bosch Rexroth Pte Ltd 15D Tuas Road Singapore 638520</p> <p>Tel.: +65 68 61 87 33 Fax: +65 68 61 18 25 sanjay.nemade@boschrexroth.com.sg</p>	<p>South Africa - Südafrika</p> <p>TECTRA Automation (Pty) Ltd. 71 Watt Street, Meadowdale Edenvale 1609</p> <p>Tel.: +27 11 971 94 00 Fax: +27 11 971 94 40 Hotline: +27 82 903 29 23 georgv@tectra.co.za</p>
<p>Taiwan</p> <p>Rexroth Uchida Co., Ltd. No.17, Alley 24, Lane 737 Cheng Bei 1 Rd., Yungkuang Tainan Hsien</p> <p>Tel.: +886 6 25 36 565 Fax: +886 6 25 34 754 indra.charlie@msa.hinet.net</p>	<p>Thailand</p> <p>NC Advance Technology Co. Ltd. 59/76 Moo 9 Ramintra road 34 Tharang, Bangkokhen, Bangkok 10230</p> <p>Tel.: +66 2 943 70 62 +66 2 943 71 21 Fax: +66 2 509 23 62 sonkawin@hotmail.com</p>		

Nordamerika – North America

USA Headquarters - Hauptniederlassung Bosch Rexroth Corporation Rexroth Indramat Division 5150 Prairie Stone Parkway Hoffman Estates, IL 60192-3707 Tel.: +1 847 6 45 36 00 Fax: +1 847 6 45 62 01 servicebrc@boschrexroth-us.com repairbrc@boschrexroth-us.com	USA Central Region - Mitte Bosch Rexroth Corporation Rexroth Indramat Division Central Region Technical Center 1701 Harmon Road Auburn Hills, MI 48326 Tel.: +1 248 3 93 33 30 Fax: +1 248 3 93 29 06	USA Southeast Region - Südwest Bosch Rexroth Corporation Rexroth Indramat Division Southeastern Technical Center 3625 Swiftwater Park Drive Suwanee, Georgia 30124 Tel.: +1 770 9 32 32 00 Fax: +1 770 9 32 19 03	USA SERVICE-HOTLINE - 7 days x 24hrs - +1-800-860-1055
USA East Region – Ost Bosch Rexroth Corporation Rexroth Indramat Division Charlotte Regional Sales Office 14001 South Lakes Drive Charlotte, North Carolina 28273 Tel.: +1 704 5 83 97 62 +1 704 5 83 14 86	USA Northeast Region – Nordost Bosch Rexroth Corporation Rexroth Indramat Division Northeastern Technical Center 99 Rainbow Road East Granby, Connecticut 06026 Tel.: +1 860 8 44 83 77 Fax: +1 860 8 44 85 95	USA West Region – West Bosch Rexroth Corporation 7901 Stoneridge Drive, Suite 220 Pleasant Hill, California 94588 Tel.: +1 925 227 10 84 Fax: +1 925 227 10 81	
Canada East - Kanada Ost Bosch Rexroth Canada Corporation Burlington Division 3426 Mainway Drive Burlington, Ontario Canada L7M 1A8 Tel.: +1 905 335 55 11 Fax: +1 905 335-41 84 michael.moro@boschrexroth.ca	Canada West - Kanada West Bosch Rexroth Canada Corporation 5345 Goring St. Burnaby, British Columbia Canada V7J 1R1 Tel.: +1 604 205-5777 Fax: +1 604 205-6944 david.gunby@boschrexroth.ca	Mexico Bosch Rexroth Mexico S.A. de C.V. Calle Neptuno 72 Unidad Ind. Vallejo 07700 Mexico, D.F. Tel.: +52 5 754 17 11 +52 5 754 36 84 +52 5 754 12 60 Fax: +52 5 754 50 73 +52 5 752 59 43 mariofelipe.hernandez@boschrexroth.com.mx	Mexico Bosch Rexroth S.A. de C.V. Calle Argentina No 3913 Fracc. las Torres 64930 Monterrey, N.L. Tel.: +52 8 333 88 34...36 +52 8 349 80 91...93 Fax: +52 8 346 78 71 mario.quiroga@boschrexroth.com.mx

Südamerika – South America

Argentina - Argentinien Bosch Rexroth S.A.I.C. "The Drive & Control Company" Acassusso 48 41/47 1605 Munro Provincia de Buenos Aires Tel.: +54 11 4756 01 40 Fax: +54 11 4756 01 36 victor.jabif@boschrexroth.com.ar	Argentina - Argentinien NAKASE Servicio Tecnico CNC Calle 49, No. 5764/66 B1653AOX Villa Balester Provincia de Buenos Aires Tel.: +54 11 4768 36 43 Fax: +54 11 4768 24 13 nakase@usa.net nakase@nakase.com gerencia@nakase.com (Service)	Brazil - Brasilien Bosch Rexroth Ltda. Av. Tégula, 888 Ponte Alta, Atibaia SP CEP 12942-440 Tel.: +55 11 4414 56 92 +55 11 4414 56 84 Fax sales: +55 11 4414 57 07 Fax serv.: +55 11 4414 56 86 alexandre.wittwer@rexroth.com.br	Brazil - Brasilien Bosch Rexroth Ltda. R. Dr.Humberto Pinheiro Vieira, 100 Distrito Industrial [Caixa Postal 1273] 89220-390 Joinville - SC Tel./Fax: +55 47 473 58 33 Mobil: +55 47 9974 6645 prochnow@zaz.com.br
Columbia - Kolumbien Refflutec de Colombia Ltda. Calle 37 No. 22-31 Santafé de Bogotá, D.C. Colombia Tel.: +57 1 368 82 67 +57 1 368 02 59 Fax: +57 1 268 97 37 reflutec@neutel.com.co reflutec@007mundo.com			



Printed in Germany