

Rexroth BTA20.4

296393
Edition 01

Project Planning Manual



Title	Rexroth BTA20.4
Type of Documentation	Project Planning Manual
Document Typecode	DOK-SUPPL*-BTA20.4****-PR01-EN-P
Internal File Reference	Document Number, 120-2100-B344-01/EN.
Purpose of Documentation	This documentation serves <ul style="list-style-type: none"> • to describe the hardware functions of the BTA20.4, • to specify the technical data of the BTA20.4, • to describe the connection and installation of the BTA20.4.

Record of Revisions	Description	Release Date	Notes
	120-2100-B344-01/EN	09/03	First edition

Copyright © 2003 Bosch Rexroth AG

Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).

Validity The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

Published by Bosch Rexroth AG
 Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main
 Telephone +49 (0)93 52/40-0 • Tx 68 94 21 • Fax +49 (0)93 52/40-48 85
<http://www.boschrexroth.com/>
 Dept. BRC/EPY (NH)

Note This document has been printed on chlorine-free bleached paper.

Contents

1	System Presentation	1-1
1.1	Brief Description	1-1
1.2	Special Features of the BTA20.4	1-1
1.3	Product-Specific Safety Instructions	1-2
2	Important Directions for Use	2-1
2.1	Appropriate Use	2-1
	Introduction	2-1
	Areas of Use and Application.....	2-2
2.2	Inappropriate Use.....	2-2
3	Safety Instructions for Electric Drives and Controls	3-1
3.1	Introduction	3-1
3.2	Explanations.....	3-1
3.3	Hazards by Improper Use	3-2
3.4	General Information	3-3
3.5	Protection Against Contact with Electrical Parts.....	3-4
3.6	Protection Against Electric Shock by Protective Low Voltage (PELV)	3-5
3.7	Protection Against Dangerous Movements	3-6
3.8	Protection Against Magnetic and Electromagnetic Fields During Operation and Mounting	3-7
3.9	Protection Against Contact with Hot Parts	3-8
3.10	Protection During Handling and Mounting	3-8
3.11	Battery Safety.....	3-9
3.12	Protection Against Pressurized Systems.....	3-9
4	Module Layout, Address Assignment	4-1
4.1	Basic Module.....	4-1
	Instruction for Installing Additional Switches.....	4-1
	Main Board Configuration	4-3
	Address Assignment	4-4
	Interface Converter	4-5
4.2	Emergency Stop Module, Type NA.....	4-6
	Address Assignment when Installing on the Left Module Slot.....	4-6
	Address Assignment when Installing on the Right Module Slot	4-6
4.3	Emergency Stop Module, Type ND/NE	4-7
	Switching Positions of the Key Switch	4-8
	Address Assignment when Installing on the Left Module Slot.....	4-9
	Address Assignment when Installing on the Right Module Slot	4-9

4.4	Emergency Stop Module, Type NG	4-10
	Address Assignment when Installing on the Left Module Slot.....	4-10
	Address Assignment when Installing on the Right Module Slot	4-10
4.5	Feed / Spindle Module, Type VB	4-11
	Address Assignment when Installing on the Left Module Slot.....	4-11
	Address Assignment when Installing on the Right Module Slot	4-11
4.6	Feed Module, Type VD	4-13
	Address Assignment when Installing on the Left Module Slot.....	4-13
	Address Assignment when Installing on the Right Module Slot	4-13
4.7	Feed Module, Type VE	4-15
	Switching Positions of the Key Switch	4-15
	Address Assignment when Installing on the Left Module Slot.....	4-16
	Address Assignment when Installing on the Right Module Slot	4-16
4.8	Interface Switch-over for the Left / Right Module Slot	4-17
5	Bus Systems	5-1
5.1	Overview	5-1
5.2	INTERBUS	5-2
	Special Features of the INTERBUS.....	5-2
	Status Indicators	5-2
5.3	BT Bus	5-3
	Addressing	5-3
6	Technical Data	6-1
6.1	General Technical Data	6-1
6.2	Interface Converter	6-1
7	Connections	7-1
7.1	Position of the Plug-in Connector	7-1
7.2	24 V Outputs X4 (Isolated).....	7-1
7.3	24 V Inputs X5 (Isolated)	7-2
7.4	INTERBUS Interface IN (X6)	7-2
7.5	INTERBUS Interface OUT (X7)	7-2
7.6	Interface RS232 IN (X8).....	7-3
7.7	Interface RS422 IN (X8A)	7-3
7.8	Interface RS422 OUT (X9).....	7-3
7.9	Terminal Strips X1...X3	7-4
7.10	Terminal Strips X4 and X5	7-5
7.11	E-STOP and Enabling Circuits.....	7-6
	Using the Standard Modules.....	7-6
8	Dimensions	8-1
8.1	Housing Dimensions	8-1
8.2	Mounting Dimensions.....	8-3

9	Application Examples	9-1
9.1	INTERBUS Connections	9-1
9.2	General Notes on the BT Bus	9-2
9.3	RS422 Wiring with BTV20.3 (MTS-P0x.2), BTC06.2 and Several BTA10.1s	9-3
	Device Arrangement	9-3
	Wiring of the Application	9-4
10	Ordering Information	10-1
10.1	Type Code.....	10-1
10.2	Accessories.....	10-2
	Connectors and Ready-Made Cables.....	10-2
11	List of Figures	11-1
12	Index	12-1
13	Service & Support	13-1
13.1	Helpdesk	13-1
13.2	Service-Hotline.....	13-1
13.3	Internet	13-1
13.4	Vor der Kontaktaufnahme... - Before Contacting Us...	13-1
13.5	Kundenbetreuungsstellen - Sales & Service Facilities	13-2

1 System Presentation

1.1 Brief Description




Fig. 1-1: BTA20.4 – Front view

The BTA20.4 was specially designed for use in conjunction with the BTV20.3 or the BTV40. Thus, the user is provided with a suitable freely configurable operator panel. The panel consists of three units and can be ordered according to the project requirements.

1.2 Special Features of the BTA20.4

Minimum Wiring Combined with High Flexibility

As the slots for the 22,5 mm standard built-in components of series ZB4 of Telemecanique can be equipped as required, wiring is reduced to a minimum. Subsequently mounted switching elements are directly connected to the INTERBUS. If required, the right auxiliary contact can be potential-free wired by jumpers (see Fig. 4-4).

30-pin Terminal Strip

All contacts for the hard-wired connections are on the 10-pin terminal strip (X1-X3). These are:

- Emergency stop,
- enabling circuits and
- an isolated contact of each standard built-in element that can be connected from the bus to this terminal strip via jumper.

Freely Configurable Modules

Two emergency stop and three enabling circuits (for mobile operator terminals) are available on both module slots. Each module can be mounted on the left or right side.

Integrated INTERBUS Connection

The built-in INTERBUS adapter contains the entire, active electronics on a single printed circuit board. The BTA20.4 uses an I/O width of three words. Eight isolated 24 V inputs and outputs are available for external connections (e.g. for signal lamps etc.).

Isolated Interface Converter

The integrated interface converter connects the serial RS232 interface of a control with the RS422 interface of the compact operator terminal BTV05.2 or the mobile operator terminal BTC06.2 without the need to equip this control with an additional interface board.

1.3 Product-Specific Safety Instructions

The information given in this documentation with regard to the use of the delivered components contains only examples of applications and suggestions.

The machine and installation manufacturer must ensure, that

- the delivered components are suited for this individual application and check the information given in this documentation with regard to the used components,
- his application complies with the applicable safety regulations and standards and carry out the required measures, modifications and complements.

Startup of the delivered components is only permitted once it is sure that the machine or installation, in which they are installed, complies with the national regulations, safety specifications and standards of the application (according to machine regulation 98/37/EG, appendix II B).

2 Important Directions for Use

2.1 Appropriate Use

Introduction

Products of Bosch Rexroth represent state-of-the-art developments and manufacturing. They are tested prior to delivery to ensure operating safety and reliability.

The products may only be used in the manner that is defined as appropriate. If they are used in an inappropriate manner, then situations can develop that may lead to property damage or injury to personnel.

Note: Bosch Rexroth, as manufacturer, is not liable for any damages resulting from inappropriate use. In such cases, the guarantee and the right to payment of damages resulting from inappropriate use are forfeited. The user alone carries all responsibility of the risks.

Before using products of Bosch Rexroth, make sure that all the prerequisites for appropriate use of the products are satisfied:

- Personnel that in any way, shape or form uses our products must first read and understand the relevant safety instructions and be familiar with appropriate use.
- If the product takes the form of hardware, then they must remain in their original state, in other words, no structural changes are permitted. It is not permitted to decompile software products or alter source codes.
- Do not mount damaged or faulty products or use them in operation.
- Make sure that the products have been installed in the manner described in the relevant documentation.

Areas of Use and Application

The BTA20.4 is a freely configurable operator panel, which can be ordered in product-specific design. The operator panel BTA20.4 produced by Bosch Rexroth is designed for use in the following cases:

- to operate control units at a machine,
- in certain designs, to provide the connections for a mobile operator terminal BTV06.2.

Note: The BTA20.4 may only be used with the accessories and parts specified in this document. If a component has not been specifically named, then it may not be either mounted or connected. The same applies to cables and lines.

Operation is only permitted in the specified configurations and combinations of components using the software and firmware as specified in the relevant function descriptions.

For an application-specific use of the operator panel unit types with differing equipment are available.

Typical areas of application of a BTA20.4 are:

- lathes
- milling machines and
- machining centers

The BTA20.4 may only be operated under the assembly, installation and ambient conditions as described here (temperature, system of protection, humidity, EMC requirements, etc.) and in the position specified.

2.2 Inappropriate Use

Using the operator panels outside of the above-referenced areas of application or under operating conditions other than described in the document and the technical data specified is defined as "inappropriate use".

The operator panels may not be used if

- they are subject to operating conditions that do not meet the above specified ambient conditions. This includes, for example, operation under water, in the case of extreme temperature fluctuations or extreme maximum temperatures or if
- Bosch Rexroth has not specifically released them for that intended purpose. Please note the specifications outlined in the general Safety Instructions!

3 Safety Instructions for Electric Drives and Controls

3.1 Introduction

Read these instructions before the initial startup of the equipment in order to eliminate the risk of bodily harm or material damage. Follow these safety instructions at all times.

Do not attempt to install or start up this equipment without first reading all documentation provided with the product. Read and understand these safety instructions and all user documentation of the equipment prior to working with the equipment at any time. If you do not have the user documentation for your equipment, contact your local Bosch Rexroth representative to send this documentation immediately to the person or persons responsible for the safe operation of this equipment.

If the equipment is resold, rented or transferred or passed on to others, then these safety instructions must be delivered with the equipment.



Improper use of this equipment, failure to follow the safety instructions in this document or tampering with the product, including disabling of safety devices, may result in material damage, bodily harm, electric shock or even death!

3.2 Explanations

The safety instructions describe the following degrees of hazard seriousness in compliance with ANSI Z535. The degree of hazard seriousness informs about the consequences resulting from non-compliance with the safety instructions.

Warning symbol with signal word	Degree of hazard seriousness according to ANSI
	Death or severe bodily harm will occur.
	Death or severe bodily harm may occur.
	Bodily harm or material damage may occur.

Fig. 3-1: Hazard classification (according to ANSI Z535)

3.3 Hazards by Improper Use



DANGER

**High voltage and high discharge current!
Danger to life or severe bodily harm by electric shock!**



DANGER

Dangerous movements! Danger to life, severe bodily harm or material damage by unintentional motor movements!



WARNING

High electrical voltage due to wrong connections! Danger to life or bodily harm by electric shock!



WARNING

Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electrical equipment!



CAUTION

Surface of machine housing could be extremely hot! Danger of injury! Danger of burns!



CAUTION

Risk of injury due to improper handling! Bodily harm caused by crushing, shearing, cutting and mechanical shock or incorrect handling of pressurized systems!



CAUTION

Risk of injury due to incorrect handling of batteries!

3.4 General Information

- Bosch Rexroth AG is not liable for damages resulting from failure to observe the warnings provided in this documentation.
- Read the operating, maintenance and safety instructions in your language before starting up the machine. If you find that you cannot completely understand the documentation for your product, please ask your supplier to clarify.
- Proper and correct transport, storage, assembly and installation as well as care in operation and maintenance are prerequisites for optimal and safe operation of this equipment.
- Only persons who are trained and qualified for the use and operation of the equipment may work on this equipment or within its proximity.
 - The persons are qualified if they have sufficient knowledge of the assembly, installation and operation of the equipment as well as an understanding of all warnings and precautionary measures noted in these instructions.
 - Furthermore, they must be trained, instructed and qualified to switch electrical circuits and equipment on and off in accordance with technical safety regulations, to ground them and to mark them according to the requirements of safe work practices. They must have adequate safety equipment and be trained in first aid.
- Only use spare parts and accessories approved by the manufacturer.
- Follow all safety regulations and requirements for the specific application as practiced in the country of use.
- The equipment is designed for installation in industrial machinery.
- The ambient conditions given in the product documentation must be observed.
- Use only safety features and applications that are clearly and explicitly approved in the Project Planning Manual.

For example, the following areas of use are not permitted: construction cranes, elevators used for people or freight, devices and vehicles to transport people, medical applications, refinery plants, transport of hazardous goods, nuclear applications, applications sensitive to high frequency, mining, food processing, control of protection equipment (also in a machine).
- The information given in the documentation of the product with regard to the use of the delivered components contains only examples of applications and suggestions.

The machine and installation manufacturer must

 - make sure that the delivered components are suited for his individual application and check the information given in this documentation with regard to the use of the components,
 - make sure that his application complies with the applicable safety regulations and standards and carry out the required measures, modifications and complements.
- Startup of the delivered components is only permitted once it is sure that the machine or installation in which they are installed complies with the national regulations, safety specifications and standards of the application.
- Technical data, connections and operational conditions are specified in the product documentation and must be followed at all times.

- Operation is only permitted if the national EMC regulations for the application are met.
The instructions for installation in accordance with EMC requirements can be found in the documentation "EMC in Drive and Control Systems".
The machine or installation manufacturer is responsible for compliance with the limiting values as prescribed in the national regulations.

3.5 Protection Against Contact with Electrical Parts

Note: This section refers to equipment and drive components with voltages above 50 Volts.

Touching live parts with voltages of 50 Volts and more with bare hands or conductive tools or touching ungrounded housings can be dangerous and cause electric shock. In order to operate electrical equipment, certain parts must unavoidably have dangerous voltages applied to them.



DANGER

High electrical voltage! Danger to life, severe bodily harm by electric shock!

- ⇒ Only those trained and qualified to work with or on electrical equipment are permitted to operate, maintain or repair this equipment.
 - ⇒ Follow general construction and safety regulations when working on high voltage installations.
 - ⇒ Before switching on power the ground wire must be permanently connected to all electrical units according to the connection diagram.
 - ⇒ Do not operate electrical equipment at any time, even for brief measurements or tests, if the ground wire is not permanently connected to the points of the components provided for this purpose.
 - ⇒ Before working with electrical parts with voltage higher than 50 V, the equipment must be disconnected from the mains voltage or power supply. Make sure the equipment cannot be switched on again unintended.
 - ⇒ The following should be observed with electrical drive and filter components:
 - ⇒ Wait five (5) minutes after switching off power to allow capacitors to discharge before beginning to work. Measure the voltage on the capacitors before beginning to work to make sure that the equipment is safe to touch.
 - ⇒ Never touch the electrical connection points of a component while power is turned on.
 - ⇒ Install the covers and guards provided with the equipment properly before switching the equipment on. Prevent contact with live parts at any time.
 - ⇒ A residual-current-operated protective device (RCD) must not be used on electric drives! Indirect contact must be prevented by other means, for example, by an overcurrent protective device.
 - ⇒ Electrical components with exposed live parts and uncovered high voltage terminals must be installed in a protective housing, for example, in a control cabinet.
-

To be observed with electrical drive and filter components:



DANGER

**High electrical voltage on the housing!
High leakage current! Danger to life, danger of
injury by electric shock!**

- ⇒ Connect the electrical equipment, the housings of all electrical units and motors permanently with the safety conductor at the ground points before power is switched on. Look at the connection diagram. This is even necessary for brief tests.
- ⇒ Connect the safety conductor of the electrical equipment always permanently and firmly to the supply mains. Leakage current exceeds 3.5 mA in normal operation.
- ⇒ Use a copper conductor with at least 10 mm² cross section over its entire course for this safety conductor connection!
- ⇒ Prior to startups, even for brief tests, always connect the protective conductor or connect with ground wire. Otherwise, high voltages can occur on the housing that lead to electric shock.

3.6 Protection Against Electric Shock by Protective Low Voltage (PELV)

All connections and terminals with voltages between 0 and 50 Volts on Rexroth products are protective low voltages designed in accordance with international standards on electrical safety.



WARNING

**High electrical voltage due to wrong
connections! Danger to life, bodily harm by
electric shock!**

- ⇒ Only connect equipment, electrical components and cables of the protective low voltage type (PELV = Protective Extra Low Voltage) to all terminals and clamps with voltages of 0 to 50 Volts.
- ⇒ Only electrical circuits may be connected which are safely isolated against high voltage circuits. Safe isolation is achieved, for example, with an isolating transformer, an opto-electronic coupler or when battery-operated.

3.7 Protection Against Dangerous Movements

Dangerous movements can be caused by faulty control of the connected motors. Some common examples are:

- improper or wrong wiring of cable connections
- incorrect operation of the equipment components
- wrong input of parameters before operation
- malfunction of sensors, encoders and monitoring devices
- defective components
- software or firmware errors

Dangerous movements can occur immediately after equipment is switched on or even after an unspecified time of trouble-free operation.

The monitoring in the drive components will normally be sufficient to avoid faulty operation in the connected drives. Regarding personal safety, especially the danger of bodily injury and material damage, this alone cannot be relied upon to ensure complete safety. Until the integrated monitoring functions become effective, it must be assumed in any case that faulty drive movements will occur. The extent of faulty drive movements depends upon the type of control and the state of operation.



Dangerous movements! Danger to life, risk of injury, severe bodily harm or material damage!

- ⇒ Ensure personal safety by means of qualified and tested higher-level monitoring devices or measures integrated in the installation. Unintended machine motion is possible if monitoring devices are disabled, bypassed or not activated.
- ⇒ Pay attention to unintended machine motion or other malfunction in any mode of operation.
- ⇒ Keep free and clear of the machine's range of motion and moving parts. Possible measures to prevent people from accidentally entering the machine's range of motion:
 - use safety fences
 - use safety guards
 - use protective coverings
 - install light curtains or light barriers
- ⇒ Fences and coverings must be strong enough to resist maximum possible momentum, especially if there is a possibility of loose parts flying off.
- ⇒ Mount the emergency stop switch in the immediate reach of the operator. Verify that the emergency stop works before startup. Don't operate the machine if the emergency stop is not working.
- ⇒ Isolate the drive power connection by means of an emergency stop circuit or use a starting lockout to prevent unintentional start.

Make sure that the drives are brought to a safe standstill before accessing or entering the danger zone. Safe standstill can be achieved by switching off the power supply contactor or by safe mechanical locking of moving parts.

- ⇒ Secure vertical axes against falling or dropping after switching off the motor power by, for example:
 - mechanically securing the vertical axes
 - adding an external braking/ arrester/ clamping mechanism
 - ensuring sufficient equilibration of the vertical axes
 The standard equipment motor brake or an external brake controlled directly by the drive controller are not sufficient to guarantee personal safety!
- ⇒ Disconnect electrical power to the equipment using a master switch and secure the switch against reconnection for:
 - maintenance and repair work
 - cleaning of equipment
 - long periods of discontinued equipment use
- ⇒ Prevent the operation of high-frequency, remote control and radio equipment near electronics circuits and supply leads. If the use of such equipment cannot be avoided, verify the system and the installation for possible malfunctions in all possible positions of normal use before initial startup. If necessary, perform a special electromagnetic compatibility (EMC) test on the installation.

3.8 Protection Against Magnetic and Electromagnetic Fields During Operation and Mounting

Magnetic and electromagnetic fields generated near current-carrying conductors and permanent magnets in motors represent a serious health hazard to persons with heart pacemakers, metal implants and hearing aids.



WARNING

Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electrical equipment!

- ⇒ Persons with heart pacemakers, hearing aids and metal implants are not permitted to enter the following areas:
 - Areas in which electrical equipment and parts are mounted, being operated or started up.
 - Areas in which parts of motors with permanent magnets are being stored, operated, repaired or mounted.
- ⇒ If it is necessary for a person with a heart pacemaker to enter such an area, then a doctor must be consulted prior to doing so. Heart pacemakers that are already implanted or will be implanted in the future, have a considerable variation in their electrical noise immunity. Therefore there are no rules with general validity.
- ⇒ Persons with hearing aids, metal implants or metal pieces must consult a doctor before they enter the areas described above. Otherwise, health hazards will occur.

3.9 Protection Against Contact with Hot Parts



CAUTION

**Housing surfaces could be extremely hot!
Danger of injury! Danger of burns!**

- ⇒ Do not touch housing surfaces near sources of heat! Danger of burns!
- ⇒ After switching the equipment off, wait at least ten (10) minutes to allow it to cool down before touching it.
- ⇒ Do not touch hot parts of the equipment, such as housings with integrated heat sinks and resistors. Danger of burns!

3.10 Protection During Handling and Mounting

Under certain conditions, incorrect handling and mounting of parts and components may cause injuries.



CAUTION

Risk of injury by incorrect handling! Bodily harm caused by crushing, shearing, cutting and mechanical shock!

- ⇒ Observe general installation and safety instructions with regard to handling and mounting.
- ⇒ Use appropriate mounting and transport equipment.
- ⇒ Take precautions to avoid pinching and crushing.
- ⇒ Use only appropriate tools. If specified by the product documentation, special tools must be used.
- ⇒ Use lifting devices and tools correctly and safely.
- ⇒ For safe protection wear appropriate protective clothing, e.g. safety glasses, safety shoes and safety gloves.
- ⇒ Never stand under suspended loads.
- ⇒ Clean up liquids from the floor immediately to prevent slipping.

3.11 Battery Safety

Batteries contain reactive chemicals in a solid housing. Inappropriate handling may result in injuries or material damage.



CAUTION

Risk of injury by incorrect handling!

- ⇒ Do not attempt to reactivate discharged batteries by heating or other methods (danger of explosion and cauterization).
- ⇒ Never charge non-chargeable batteries (danger of leakage and explosion).
- ⇒ Never throw batteries into a fire.
- ⇒ Do not dismantle batteries.
- ⇒ Do not damage electrical components installed in the equipment.

Note: Be aware of environmental protection and disposal! The batteries contained in the product should be considered as hazardous material for land, air and sea transport in the sense of the legal requirements (danger of explosion). Dispose batteries separately from other waste. Observe the legal requirements in the country of installation.

3.12 Protection Against Pressurized Systems

Certain motors and drive controllers, corresponding to the information in the respective Project Planning Manual, must be provided with pressurized media, such as compressed air, hydraulic oil, cooling fluid and cooling lubricant supplied by external systems. Incorrect handling of the supply and connections of pressurized systems can lead to injuries or accidents. In these cases, improper handling of external supply systems, supply lines or connections can cause injuries or material damage.



CAUTION

Danger of injury by incorrect handling of pressurized systems !

- ⇒ Do not attempt to disassemble, to open or to cut a pressurized system (danger of explosion).
- ⇒ Observe the operation instructions of the respective manufacturer.
- ⇒ Before disassembling pressurized systems, release pressure and drain off the fluid or gas.
- ⇒ Use suitable protective clothing (for example safety glasses, safety shoes and safety gloves)
- ⇒ Remove any fluid that has leaked out onto the floor immediately.

Note: Environmental protection and disposal! The media used in the operation of the pressurized system equipment may not be environmentally compatible. Media that are damaging the environment must be disposed separately from normal waste. Observe the legal requirements in the country of installation.

Notes

4 Module Layout, Address Assignment

4.1 Basic Module




Fig. 4-1: BTA20.4 – Basic module

The basic module of the BTA20.4 permits to insert a maximum of eight standard switching elements of the Telemecanique **ZB4-B...** program depending on the special user requirements. Each element features a maximum of two contacts and an indicator lamp. All cutouts in the front panel are pre-milled to 0,5 mm. The next section explains how to create a cutout. The keys are labeled by means of insert strips.

Instruction for Installing Additional Switches



ESD – electrostatic sensitive components!

⇒ Whenever you work with the open unit, your working position and the employed tools must comply with the ESD protective measures.

To insert additional switching elements in the front of the BTA20.4, proceed as follows:

1. Unscrew the electronics enclosure from the unit.
2. Dismantle the electronics unit.
 - a) Use a 5,5 mm socket wrench to loosen the six spacing bolts marked by arrows and the letters A or B (see Fig. 4-2).
 - b) Remove the electronics block LK-BIB and the main board.




Fig. 4-2: Position of the spacing bolts

Note: It is very important to remove the electronics part, as chips causing malfunctions may be produced while cutting out the front panel.

- Use a knife (scalpel) to cut the front film along the pre-milled cutout contour (see Fig. 4-3).




Fig. 4-3: Front panel cross section

- Use a knife and slightly scratch along the front panel contour pre-milled to 0,5 mm.
- Break out the center part.
- Remove the resulting burr and the chips from the front panel.
- Insert the required front panel element (pushbutton, lamp, key switch, etc.) and screw it tight.
- Plug the required switching elements (NC/NO contacts) onto the main board and preselect the jumper positions of the right switching element for internal or external operation.
- Position the board block onto the switching elements.
- Tighten the spacing bolts.
- Position the electronics enclosure and tighten the retaining screws.

Main Board Configuration




Fig. 4-4: Main board




Fig. 4-5: Plug-in socket

The main board is equipped with eight plug-in sockets (see Fig. 4-4). Such a socket has two slots for switching contacts (NC/NO contact) or a LED contact. The first contact is used for internal bus operation. To support external wiring, jumpers permit the right auxiliary contact of each switch to be set to either bus interface (internal) or to terminal strip X2 and X3 (external).

Address Assignment

Outputs	Position	Address
	LED S1	O *.0.0
	LED S2	O *.0.1
	LED S3	O *.0.2
	LED S4	O *.0.3
	LED S5	O *.0.4
	LED S6	O *.0.5
	LED S7	O *.0.6
	LED S8	O *.0.7

Fig. 4-6: LED addresses within the basic module

Inputs	Switching element / position	Address
	S 1 – left auxiliary contact	I *.6.0
	S 1 – right auxiliary contact	I *.6.1
	S 2 – left auxiliary contact	I *.6.2
	S 2 – right auxiliary contact	I *.6.3
	S 3 – left auxiliary contact	I *.6.4
	S 3 – right auxiliary contact	I *.6.5
	S 4 – left auxiliary contact	I *.6.6
	S 4 – right auxiliary contact	I *.6.7
	S 5 – left auxiliary contact	I *.7.0
	S 5 – right auxiliary contact	I *.7.1
	S 6 – left auxiliary contact	I *.7.2
	S 6 – right auxiliary contact	I *.7.3
	S 7 – left auxiliary contact	I *.7.4
	S 7 – right auxiliary contact	I *.7.5
	S 8 – left auxiliary contact	I *.7.6
	S 8 – right auxiliary contact	I *.7.7

Fig. 4-7: Addresses of the switching elements within the basic module

Interface Converter

In the normal mode the BTA20.4 provides RS422 communication via the connectors X8A and X9. The interface converter permits to organize data exchange with the mobile operator terminal BTC06.2 or a PLC.




Fig. 4-8: Switching concept of the interface converter

As shown in the figure above, the converter has a switching function. In its neutral position, there's a connection between the RS422 IN and the RS422 OUT, i.e. data can be received and transmitted using the RS422 protocol. The converter becomes active, if RS232 communication has to be connected with RS422 communication. If, for example, a MTS-P module (PLC plug-in board in the BTV20.3) is connected to a BTA20.4, the converter switches automatically over to connection X8 (RS232 IN). Precondition for this is the correct initialization of the MTS-P. Devices connected to X9 may exchange data with the PLC.

Note: In this case, connector X8A (RS422 IN) has no function.

To operate a BTC06.2, the key switch of the ND/NE or VE module is necessary. If the key switch is in left-hand position, the mobile operator terminal is connected to the PLC.

Note: In this case, connector X9 has no function.

It is not possible to use a BTC06.2 and, at the same time, maintain the communication with other RS422 devices.

4.2 Emergency Stop Module, Type NA




Fig. 4-9: Emergency stop module, type NA

The emergency stop module NA provides an emergency stop pushbutton and an indicator lamp that can be connected via INTERBUS.

From the emergency stop pushbutton a NC contact is looped into each of the two emergency stop circuits. Another NC contact, as well as the indicator lamp, is connected to the INTERBUS as auxiliary contact.

Address Assignment when Installing on the Left Module Slot

Outputs	Position	Address
	Indicator lamp	O *.1.0

Fig. 4-10: Address of the indicator lamp in the E-STOP module

Inputs	Switching element / position	Address
	Auxiliary contact: E-STOP	I *.8.0

Fig. 4-11: Address of the auxiliary contact in the E-STOP module

Address Assignment when Installing on the Right Module Slot

Outputs	Position	Address
	Indicator lamp	O *.1.4

Fig. 4-12: Address of the indicator lamp in the E-STOP module

Inputs	Switching element / position	Address
	Auxiliary contact: E-STOP	I *.9.0

Fig. 4-13: Address of the auxiliary contact in the E-STOP module

4.3 Emergency Stop Module, Type ND/NE




Fig. 4-14: Emergency stop module, type ND/NE

The module ND/NE has in addition to the emergency stop switch a BTC06.2 connection as well as a key switch to connect a mobile operator terminal (explanation of the key switch position see Fig. 4-15) if required.

From the emergency stop pushbutton a NC contact is looped into each of the two emergency stop circuits. Another NC contact is connected to the INTERBUS as auxiliary contact.

The connection for the mobile operator terminal is provided with two emergency stop circuits, which are jumpered via the short-circuit connector in the normal operating mode. To connect a mobile operator terminal, the emergency stop contacts of the female connector are jumpered during the plug-in process with the key switch located besides the female connector in position right (spring return). For this version, only two enabling circuits are used, the third is guided via the key switch.

Switching Positions of the Key Switch




Fig. 4-15: Switching positions of the key switch

Switching Position in the Center:

- Function: Neutral
- Removable key, no contact closed, interface for BTC06.2 not activated and switched in loop through mode to the subsequently connected BTA.

Switching Position on the Right (Spring Return)

- Function: During plugging-in the mobile operator terminal BTC06.2 the two emergency stop circuits are jumpered.
- Non-removable key, contacts closed to jumper the two emergency stop circuits, interface for BTC06.2 not activated and switched in loop through mode to the subsequently connected BTA. In this position the short-circuit connector at the connection for the mobile operator terminal can be removed and replaced by the BTC06.2 connector without interrupting the two emergency stop circuits.

Switching Position on the Left (Stay Put):

- Function: Mobile operator terminal active
- Removable key, interface for the BTC06.2 activated, no loop through mode to the subsequently connected BTA, INTERBUS input "Auxiliary contact for key switch" on log. 1, enabling circuit 3 closed on BTA connector X1.

Address Assignment when Installing on the Left Module Slot

Inputs	Switching element / position	Address
	Auxiliary contact: E-STOP	I *.8.0
	Acknowledgment contact for key switch	I *.8.4


Fig. 4-16: Address of the auxiliary contact in the E-STOP module

Address Assignment when Installing on the Right Module Slot

Inputs	Switching element / position	Address
	Auxiliary contact: E-STOP	I *.9.0
	Acknowledgment contact for key switch	I *.9.4

Fig. 4-17: Address of the auxiliary contact in the E-STOP module

4.4 Emergency Stop Module, Type NG



M_ng, EPS

Fig. 4-18: Emergency stop module, type NG

The emergency stop module NG provides an emergency stop pushbutton.

From the emergency stop pushbutton a NC contact is looped into each of the two emergency stop circuits. Another NC contact is connected to the INTERBUS as auxiliary contact.

Address Assignment when Installing on the Left Module Slot

Inputs

Switching element	Address
Auxiliary contact: E-STOP	I*.8.0

Fig. 4-19: Address of the auxiliary contact in the E-STOP module


Address Assignment when Installing on the Right Module Slot

Inputs

Switching element	Address
Auxiliary contact: E-STOP	I*.9.0

Fig. 4-20: Address of the auxiliary contact in the E-STOP module

4.5 Feed / Spindle Module, Type VB



M_vb.EPS

Fig. 4-21: Feed / spindle module, type VB

This module for special machines provides two Gray code override switches for feed and spindle.

Address Assignment when Installing on the Left Module Slot

Inputs	Switching element / position	Address
	Feedrate override bit 0	I *.8.0
	Feedrate override bit 1	I *.8.1
	Feedrate override bit 2	I *.8.2
	Feedrate override bit 3	I *.8.3
	Override spindle bit 4	I *.8.4
	Override spindle bit 5	I *.8.5
	Override spindle bit 6	I *.8.6
	Override spindle bit 7	I *.8.7

Fig. 4-22: Addresses of the override switches

Address Assignment when Installing on the Right Module Slot

Inputs	Switching element / position	Address
	Feedrate override bit 0	I *.9.0
	Feedrate override bit 1	I *.9.1
	Feedrate override bit 2	I *.9.2
	Feedrate override bit 3	I *.9.3
	Override spindle bit 4	I *.9.4
	Override spindle bit 5	I *.9.5
	Override spindle bit 6	I *.9.6
	Override spindle bit 7	I *.9.7

Fig. 4-23: Addresses of the override switches

Gray Code Table The output signals of the two override switches are delivered by a 4 bit Gray code switch with the following assignment:

Scale value Feed (Bit 0-3)	Scale value Spindle (Bit 4-7)	Bit 0 / 4	Bit 1 / 5	Bit 2 / 6	Bit 3 / 7
0 %	45 %				
1 %	50 %	X			
2 %	55 %	X	X		
4 %	60 %		X		
6 %	65 %		X	X	
8 %	70 %	X	X	X	
10 %	75 %	X		X	
20 %	80 %			X	
30 %	85 %			X	X
40 %	90 %	X		X	X
50 %	95 %	X	X	X	X
60 %	100 %		X	X	X
70 %	105 %		X		X
80 %	110 %	X	X		X
100 %	115 %	X			X
120 %	120 %				X

Fig. 4-24: Gray code table of the VB module

4.6 Feed Module, Type VD




Fig. 4-25: Feed module, type VD

This module for special machines provides one Gray code override switch for feed and spindle.

Address Assignment when Installing on the Left Module Slot

Inputs	Switching element / position	Address
	Override bit 0	I *.8.0
	Override bit 1	I *.8.1
	Override bit 2	I *.8.2
	Override bit 3	I *.8.3

Fig. 4-26: Address of the override switch

Address Assignment when Installing on the Right Module Slot

Inputs	Switching element / position	Address
	Override bit 0	I *.9.0
	Override bit 1	I *.9.1
	Override bit 2	I *.9.2
	Override bit 3	I *.9.3

Fig. 4-27: Address of the override switch

Gray Code Table The output signals of the override switch are delivered by a 4 bit Gray code switch with the following assignment:

Scale value	Bit 0	Bit 1	Bit 2	Bit 3
0 %				
1 %	X			
2 %	X	X		
4 %		X		
6 %		X	X	
8 %	X	X	X	
10 %	X		X	
20 %			X	
30 %			X	X
40 %	X		X	X
50 %	X	X	X	X
60 %		X	X	X
70 %		X		X
80 %	X	X		X
100 %	X			X
120 %				X

Fig. 4-28: Gray code table of the VD module

4.7 Feed Module, Type VE




Fig. 4-29: Feed module, type VE

This module provides a Gray code override switch, a key switch as well as a connection for a mobile operator terminal BTC06.2.

The connection for the mobile operator terminal is provided with two emergency stop circuits, which are jumpered via the short-circuit connector in the normal operating mode. To connect a mobile operator terminal, the emergency stop contacts of the female connector are jumpered during the plug-in process with the key switch located besides the female connector in position right (spring return). For this version, only two enabling circuits are used, the third is guided via the key switch.

Switching Positions of the Key Switch

See chapter 4.3 Emergency Stop Module, Type ND/NE.

Address Assignment when Installing on the Left Module Slot

Inputs	Switching element / position	Address
	Override bit 0	I *.8.0
	Override bit 1	I *.8.1
	Override bit 2	I *.8.2
	Override bit 3	I *.8.3
	Auxiliary contact for key switch	I *.8.4

Fig. 4-30: Address of the override switch

Address Assignment when Installing on the Right Module Slot

Inputs	Switching element / position	Address
	Override bit 0	I *.9.0
	Override bit 1	I *.9.1
	Override bit 2	I *.9.2
	Override bit 3	I *.9.3
	Auxiliary contact for key switch	I *.9.4

Fig. 4-31: Address of the override switch

Gray Code Table The output signals of the override switch are delivered by a 4 bit Gray code switch with the following assignment:

Scale value	Bit 0	Bit 1	Bit 2	Bit 3
0 %				
1 %	X			
2 %	X	X		
4 %		X		
6 %		X	X	
8 %	X	X	X	
10 %	X		X	
20 %			X	
30 %			X	X
40 %	X		X	X
50 %	X	X	X	X
60 %		X	X	X
70 %		X		X
80 %	X	X		X
100 %	X			X
120 %				X

Fig. 4-32: Gray code table of the VE module

4.8 Interface Switch-over for the Left / Right Module Slot

In addition, for all BTA20 modules with connection for a mobile operator terminal BTC06.2 it is necessary to adjust the switch on the rear side of the device (see Fig. 4-33) in the right way. The switching position depends on the module slot, on which the module with the connection for a mobile operator terminal was mounted. If the switch was not adjusted in the right way, i.e. corresponding to the module slot, a connected BTC06 is not able to operate. The switch provides the enabling of the interface block.




Fig. 4-33: Position of the switch for the BTC06.2 connection on the right-hand / on the left-hand side

5 Bus Systems

5.1 Overview




Fig. 5-1: Overview of the address assignments of the used bus systems

5.2 INTERBUS

Special Features of the INTERBUS

- INTERBUS ID code 3 (digital devices with inputs and outputs)
- Remote bus, 500 kbaud with 2 conductors
- Data width of the unit is 3 words, i. e. 48 bits.
24 outputs, 40 inputs
- All inputs for 24 volt level,
32 inputs for internal module and switching elements without electrical isolation ,
further eight inputs (input byte 4) on a 9-pin terminal strip of the INTERBUS unit (X5) with electrical isolation.
- All 24 outputs with 24 volt level,
16 outputs for internal indicator lamps and modules,
the remaining 8 as external outputs with electrical isolation on a 10-pin terminal strip of the INTERBUS unit (X4).

Status Indicators




Fig. 5-2: Position of the status indicators

LED	Meaning
RD, red	Remote bus disable flashes, if the remote bus is switched off.
BA, green	Bus active flashes, if an INTERBUS transmission occurs.
RC, green	Remote bus check, monitoring of the incoming INTERBUS cable (X6). RC flashes, if the connection is all right. RC does not flash, when resetting the INTERBUS of the control.
U, green	Power supply is applied.

Fig. 5-3: INTERBUS status LEDs

5.3 BT Bus

With the BT bus up to 4 operator panels of type BTM15/16 or BTA15/16/20 can be connected. The maximum length of a BT bus is **50 m**. This applies not only if one device is connected but also if maximum the four reliable devices are connected. A quick access on the I/O data of the operator panels from the PLC (e. g. %IBP*.*) is **not** possible.

The address assignments required for programming can be found in the documents accompanying the devices to be connected.

Addressing

The BT bus is addressed by assigning a logic user number in the I/O editor of the PLC programming interface. Both for the input image memory as well as for the output image memory a separate logic address is assigned.

The two image memories have respectively a seize of 128 bytes, which are provided for the connected operator panels. Depending on the operator panel a certain number of bytes are assigned in the image memory (see Fig. 5-4).

Device type	Memory assignment in the input/output image
BTM15	Depending on the configuration 2 bytes for digital I/Os (always assigned) 2 additional bytes for each module (except handwheel) 4 additional bytes for handwheel module
BTM16	14 bytes
BTA15/16/20	6 bytes

Fig. 5-4: Memory requirements of operator panels

Depending on the physical order of the operator panels connected to the BT bus, the addresses of the devices in the input and output image memory are continuously arranged corresponding to the memory requirements of the operator panels. According to the example in Fig. 5-5 the concept of the memory assignment is demonstrated.




Fig. 5-5: Memory assignment of the BT Bus

6 Technical Data

6.1 General Technical Data

Power Supply	18 - 30 V	
Max. Current Consumption	Approx. 1.0 A	
Max. Power Consumption	Approx. 18 W	
Dimensions (W x H x D)	407 mm x 169 mm x 119 mm	
Mounting Dimensions (W x H x D)	375 mm x 137 mm x 119 mm	
Weight	Approx. 2.1 kg	
Degree of protection	IP 65 (front panel)	
Color	Light gray (RAL 7035)	
Front Panel Material	Varnished aluminium front panel with holohedrally let in chemical resistant polyester foil	
Maximum ambient temperature (operation)	+5 °C to +45 °C	
Storage temperature	-20 °C to +60 °C	
Air pressure	860 to 1060 hPa, 1500 m	
Interfaces	1 x RS232 IN 1 x RS422 IN 1 x RS422 OUT 1 x INTERBUS IN 1 x INTERBUS OUT	
Data 24 V Inputs	Low level: 0 -10 V High level: 18 -30 V Input current: < 10 mA	
Data 24 V outputs	Output current per output: 200 mA	
E-STOP	Switching voltage U_{\max}	24 V DC / 42 V AC
	Switching current I_{\max}	2 A DC / 3 A AC
Enabeling Circuit	Switching voltage U_{\max}	24 V DC / 42 V AC
	Switching current I_{\max}	2 A DC / 3 A AC

6.2 Interface Converter

Baud Rate	0 to 38400 bauds
Input Voltage RS232	± 5 to ± 12 V
Output Voltage RS422	0/5 V, 5 V diff., max. 60 mA
+5 V Output for Bus Connection	Max. 50 mA

7 Connections

7.1 Position of the Plug-in Connector




Fig. 7-1: Position of the plug-in connector

7.2 24 V Outputs X4 (Isolated)

Address Assignment

Terminal	Address
X4 - 1	O *.2.0
X4 - 2	O *.2.1
X4 - 3	O *.2.2
X4 - 4	O *.2.3
X4 - 5	O *.2.4
X4 - 6	O *.2.5
X4 - 7	O *.2.6
X4 - 8	O *.2.7

Fig. 7-2: Addresses of the 24 V outputs (X4)

7.3 24 V Inputs X5 (Isolated)

Address Assignment

Terminal	Address
X5 - 1	I *.10.0
X5 - 2	I *.10.1
X5 - 3	I *.10.2
X5 - 4	I *.10.3
X5 - 5	I *.10.4
X5 - 6	I *.10.5
X5 - 7	I *.10.6
X5 - 8	I *.10.7

Fig. 7-3: Addresses of the 24 V inputs (X5)

7.4 INTERBUS Interface IN (X6)

Pin	Signal	Pin	Signal
1	DO1 Data Out 1	2	DI1 Data In 1
3	GnD	4	N. C.
5	N. C.	6	/DO1 Data Out 1
7	/DI1 Data In 1	8	N. C.
9	N. C.		

Fig. 7-4: INTERBUS IN (X6)

7.5 INTERBUS Interface OUT (X7)

Pin	Signal	Pin	Signal
1	DO2 Data Out 2	2	DI2 Data In 2
3	GnD	4	N. C.
5	+ 5 V out	6	/DO2 Data Out 2
7	/DI2 Data In 2	8	N. C.
9	RBST		

Fig. 7-5: INTERBUS OUT (X7)

7.6 Interface RS232 IN (X8)

Pin	Signal	Pin	Signal
1	Shield	2	/TxD
3	/RxD	4	DTR
5	GND	6	
7	RTS	8	
9			

Fig. 7-6: RS232 assignment X8

The RS232 input of the interface converter is connected by a line 1:1 switched through (female and male connector) with the serial interface MTS-P.

7.7 Interface RS422 IN (X8A)

Pin	Signal	Pin	Signal
1	Shield	2	N. C.
3	N. C.	4	RS422 RxD+
5	RS422 RxD-	6	N. C.
7	Signal Ground	8	N. C.
9	RS422 TxD+	10	Ground
11	RS422 TxD-	12	+5 V out
13	N. C.	14	N. C.
15	N. C.		

Fig. 7-7: RS422 assignment X8A

7.8 Interface RS422 OUT (X9)

Pin	Signal	Pin	Signal
1	Shield	2	N. C.
3	N. C.	4	RS422 RxD+
5	RS422 RxD-	6	N. C.
7	Signal Ground	8	N. C.
9	RS422 TxD+	10	Ground
11	RS422 TxD-	12	+5 V out
13	N. C.	14	N. C.
15	N. C.		

Fig. 7-8: RS422 assignment X9

7.9 Terminal Strips X1...X3




Fig. 7-9: Terminal strips X1...3

7.10 Terminal Strips X4 and X5




Fig. 7-10: Terminal strips X4 and X5

7.11 E-STOP and Enabeling Circuits

Using the Standard Modules




Fig. 7-11: Application example E-STOP and enabeling circuits

In this example the BTA20.4 is illustrated with a BTC06.2. For a better overview only one enabeling and E-STOP circuit is illustrated. For the modules ND/NE and VE enabeling circuits are used in conjunction with the BTC06.2, the third free circuit can be used by the customer alternatively.

8 Dimensions

8.1 Housing Dimensions




Fig. 8-1: Front, side and top view




Fig. 8-2: Rear view

8.2 Mounting Dimensions




Fig. 8-3: Mounting dimensions

9 Application Examples

9.1 INTERBUS Connections




Fig. 9-1: Application example with INTERBUS connection

9.2 General Notes on the BT Bus




Fig. 9-2: Application example with BT bus connection

App_BTb.FH7

9.3 RS422 Wiring with BTV20.3 (MTS-P0x.2), BTC06.2 and Several BTA10.1s

Device Arrangement




Fig. 9-3: Device arrangement to wire with BTV20.3, BTC06.2 and several BTA10.1s

Wiring of the Application




Fig. 9-4: Wiring the RS422 application with BTV20.3, BTC06.2 and several BTA10.1s

10.2 Accessories

Connectors and Ready-Made Cables














Ordering designation of the ready-made cables	Mating connector of the unit	Rexroth cable	Design of the cable end
<p>IKB0193/000,0 MN: 282 041 (RS232, max. 2m)</p>	<p>INS0525/L01</p>  <p>9-pin/male connector</p>	 <p>INK0234</p>	<p>INS0526/L01</p>  <p>9-pin/female connector</p>
<p>IKB0031/000,0 MN: 291805</p> <p>IKB0031/000,5 MN: 291806 (INTERBUS cable)</p>	<p>INS0703/L01</p>  <p>9-pin/male connector</p>	 <p>IKB0031</p>	<p>INS0702/L01</p>  <p>9-pin/female connector</p>
<p>IKS0190/000,0 Standard interface cable connection BTC06</p>	<p>INS0624/C</p> 		<p>INS0631/C</p> 
<p>IKB0015/000,0 MN: 282 870 (RS422, max. 400m)</p>	<p>INS0645/K01</p>  <p>15-pin/male connector</p>	 <p>INK0234</p>	<p>INS0645/K01</p>  <p>15-pin/male connector</p>
<p>INS0645/K01 MN: 282 040</p>		<p style="text-align: center;">Connector to be converted by yourself with termination</p> <p>INS0645/K01 RS422 (15-pin/male connector)</p>	

Fig. 10-2: Cable accessories of the BTA20.4

Ready-Made Interface Plug

For RS422 communication there's a plug already including a termination in its housing. The cable can be mounted with screw terminals. The pin assignment of the plug is illustrated in Fig. 10-3.




Fig. 10-3: Pin assignment of the ready-made plug housing

The termination can be activated by a switch.

11 List of Figures

- Fig. 1-1: BTA20.4 – Front view 1-1
- Fig. 3-1: Hazard classification (according to ANSI Z535) 3-1
- Fig. 4-1: BTA20.4 – Basic module 4-1
- Fig. 4-2: Position of the spacing bolts 4-2
- Fig. 4-3: Front panel cross section 4-2
- Fig. 4-4: Main board 4-3
- Fig. 4-5: Plug-in socket 4-3
- Fig. 4-6: LED addresses within the basic module 4-4
- Fig. 4-7: Addresses of the switching elements within the basic module 4-4
- Fig. 4-8: Switching concept of the interface converter 4-5
- Fig. 4-9: Emergency stop module, type NA 4-6
- Fig. 4-10: Address of the indicator lamp in the E-STOP module 4-6
- Fig. 4-11: Address of the auxiliary contact in the E-STOP module 4-6
- Fig. 4-12: Address of the indicator lamp in the E-STOP module 4-6
- Fig. 4-13: Address of the auxiliary contact in the E-STOP module 4-6
- Fig. 4-14: Emergency stop module, type ND/NE 4-7
- Fig. 4-15: Switching positions of the key switch 4-8
- Fig. 4-16: Address of the auxiliary contact in the E-STOP module 4-9
- Fig. 4-17: Address of the auxiliary contact in the E-STOP module 4-9
- Fig. 4-18: Emergency stop module, type NG 4-10
- Fig. 4-19: Address of the auxiliary contact in the E-STOP module 4-10
- Fig. 4-20: Address of the auxiliary contact in the E-STOP module 4-10
- Fig. 4-21: Feed / spindle module, type VB 4-11
- Fig. 4-22: Addresses of the override switches 4-11
- Fig. 4-23: Addresses of the override switches 4-11
- Fig. 4-24: Gray code table of the VB module 4-12
- Fig. 4-25: Feed module, type VD 4-13
- Fig. 4-26: Address of the override switch 4-13
- Fig. 4-27: Address of the override switch 4-13
- Fig. 4-28: Gray code table of the VD module 4-14
- Fig. 4-29: Feed module, type VE 4-15
- Fig. 4-30: Address of the override switch 4-16
- Fig. 4-31: Address of the override switch 4-16
- Fig. 4-32: Gray code table of the VE module 4-16
- Fig. 4-33: Position of the switch for the BTC06.2 connection on the right-hand / on the left-hand side 4-17
- Fig. 5-1: Overview of the address assignments of the used bus systems 5-1
- Fig. 5-2: Position of the status indicators 5-2
- Fig. 5-3: INTERBUS status LEDs 5-2
- Fig. 5-4: Memory requirements of operator panels 5-3
- Fig. 5-5: Memory assignment of the BT Bus 5-4

- Fig. 7-1: Position of the plug-in connector 7-1
- Fig. 7-2: Addresses of the 24 V outputs (X4) 7-1
- Fig. 7-3: Addresses of the 24 V inputs (X5) 7-2
- Fig. 7-4: INTERBUS IN (X6) 7-2
- Fig. 7-5: INTERBUS OUT (X7) 7-2
- Fig. 7-6: RS232 assignment X8 7-3
- Fig. 7-7: RS422 assignment X8A 7-3
- Fig. 7-8: RS422 assignment X9 7-3
- Fig. 7-9: Terminal strips X1...3 7-4
- Fig. 7-10: Terminal strips X4 and X5 7-5
- Fig. 7-11: Application example E-STOP and enabeling circuits 7-6
- Fig. 8-1: Front, side and top view 8-1
- Fig. 8-2: Rear view 8-2
- Fig. 8-3: Mounting dimensions 8-3
- Fig. 9-1: Application example with INTERBUS connection 9-1
- Fig. 9-2: Application example with BT bus connection 9-2
- Fig. 9-3: Device arrangement to wire with BTV20.3, BTC06.2 and several BTA10.1s 9-3
- Fig. 9-4: Wiring the RS422 application with BTV20.3, BTC06.2 and several BTA10.1s 9-4
- Fig. 10-1: Type code of the BTA20.4 10-1
- Fig. 10-2: Cable accessories of the BTA20.4 10-2
- Fig. 10-3: Pin assignment of the ready-made plug housing 10-3

12 Index

2

24 V inputs 6-1
24 V inputs X5 7-2
24 V outputs 6-1
24 V outputs X4 7-1

A

Address of the auxiliary contact in the emergency stop module 4-6
Address of the auxiliary contact in the E-STOP module, type NB 4-9
Address of the override switch, type VA 4-13, 4-16
Addresses of the override switches, type VB 4-11
Addresses of the switching elements 4-4
Air pressure 6-1
Ambient temperature 6-1
Application example 9-1
Appropriate use
 Area of application 2-2
 Introduction 2-1
 Uses 2-2
Auxiliary contact in the emergency stop module, type NA 4-6

B

Basic module 4-1
Baud rate 6-1
BT bus connection 9-2
BTC06.2 7-6
BTC06.2 connection 4-17

C

Cable accessories 10-2
Color 6-1
Connections 7-1
Converter 4-5
Current Consumption 6-1

D

Data width 5-2
Degree of protection 6-1
Dimensions 6-1

E

Electrical isolation 5-2
Emergency stop module, type NA 4-6
Emergency stop module, type ND/NE 4-7
Emergency stop module, type NG 4-10
Enabeling circuit 6-1, 7-6
E-STOP 6-1, 7-6

F

Feed module, type VB 4-11

G

Gray code table 4-12, 4-14, 4-16

I

Inappropriate use 2-2
 Consequences, Discharge of liability 2-1
Indicator lamp in the emergency stop module, type NA 4-6
INTERBUS 5-2
INTERBUS connection 9-1
INTERBUS IN 7-2
INTERBUS OUT 7-2
Interface converter 4-5, 6-1
Interface converter, input voltage 6-1
Interface converter, output voltage 6-1
Interfaces 6-1

K

Key switch (spring return) 4-7, 4-15

L

Lamp contact 4-3
LED addresses 4-4

M

Main board 4-3
Main board configuration 4-3
Mobile operator terminal 4-7, 4-15
Module layout 4-1
Mounting dimensions 6-1

O

Output for bus connection 6-1
Override switch 4-12, 4-14, 4-16

P

Plug-in connector 7-1
Plug-in socket 4-3
Power consumption 6-1
Power supply 6-1

R

Remote bus 5-2
RS232 assignment X8 7-3
RS422 assignment X8A 7-3
RS422 assignment X9 7-3

S

Safety Instructions for Electric Drives and Controls 3-1
Short-circuit connector 4-15
Status indicators 5-2
Storage temperature 6-1
Switching positions of the key switch 4-8

T

Technical data 6-1
Terminal strips X1...3 7-4
Terminal strips X4 and X5 7-5
Type code 10-1

U

Use *See appropriate use and inappropriate use*

W

Weight 6-1

X

X1...3 7-4
X4 7-1
X4 and X5 7-5
X5 7-2
X6 7-2
X7 7-2
X8 7-3
X8A 7-3
X9 7-3

13 Service & Support

13.1 Helpdesk

Unser Kundendienst-Helpdesk im Hauptwerk Lohr am Main steht Ihnen mit Rat und Tat zur Seite. Sie erreichen uns

- telefonisch - by phone:
über Service Call Entry Center
- via Service Call Entry Center
- per Fax - by fax:
- per e-Mail - by e-mail: service.svc@boschrexroth.de

Our service helpdesk at our headquarters in Lohr am Main, Germany can assist you in all kinds of inquiries. Contact us

49 (0) 9352 40 50 60
Mo-Fr 07:00-18:00
Mo-Fr 7:00 am - 6:00 pm

+49 (0) 9352 40 49 41

13.2 Service-Hotline

Außerhalb der Helpdesk-Zeiten ist der Service direkt ansprechbar unter

After helpdesk hours, contact our service department directly at

+49 (0) 171 333 88 26

oder - or

+49 (0) 172 660 04 06

13.3 Internet

Unter www.boschrexroth.com finden Sie ergänzende Hinweise zu Service, Reparatur und Training sowie die **aktuellen** Adressen *) unserer auf den folgenden Seiten aufgeführten Vertriebs- und Servicebüros.



Verkaufsniederlassungen



Niederlassungen mit Kundendienst

Außerhalb Deutschlands nehmen Sie bitte zuerst Kontakt mit unserem für Sie nächstgelegenen Ansprechpartner auf.

*) Die Angaben in der vorliegenden Dokumentation können seit Drucklegung überholt sein.

At www.boschrexroth.com you may find additional notes about service, repairs and training in the Internet, as well as the **actual** addresses *) of our sales- and service facilities figuring on the following pages.



sales agencies



offices providing service

Please contact our sales / service office in your area first.

*) Data in the present documentation may have become obsolete since printing.

13.4 Vor der Kontaktaufnahme... - Before Contacting Us...

Wir können Ihnen schnell und effizient helfen wenn Sie folgende Informationen bereithalten:

1. detaillierte Beschreibung der Störung und der Umstände.
2. Angaben auf dem Typenschild der betreffenden Produkte, insbesondere Typenschlüssel und Seriennummern.
3. Tel./Faxnummern und e-Mail-Adresse, unter denen Sie für Rückfragen zu erreichen sind.

For quick and efficient help, please have the following information ready:

1. Detailed description of the failure and circumstances.
2. Information on the type plate of the affected products, especially type codes and serial numbers.
3. Your phone/fax numbers and e-mail address, so we can contact you in case of questions.

13.5 Kundenbetreuungsstellen - Sales & Service Facilities

Deutschland – Germany

vom Ausland:

(0) nach Landeskennziffer weglassen!

from abroad:

don't dial (0) after country code!

Vertriebsgebiet Mitte Germany Centre Rexroth Indramat GmbH Bgm.-Dr.-Nebel-Str. 2 / Postf. 1357 97816 Lohr am Main / 97803 Lohr Kompetenz-Zentrum Europa Tel.: +49 (0)9352 40-0 Fax: +49 (0)9352 40-4885	SERVICE CALL ENTRY CENTER MO – FR von 07:00 - 18:00 Uhr from 7 am – 6 pm Tel. +49 (0) 9352 40 50 60 service.svc@boschrexroth.de	SERVICE HOTLINE MO – FR von 17:00 - 07:00 Uhr from 5 pm - 7 am + SA / SO Tel.: +49 (0)172 660 04 06 oder / or Tel.: +49 (0)171 333 88 26	SERVICE ERSATZTEILE / SPARES verlängerte Ansprechzeit - extended office time - ♦ nur an Werktagen - only on working days - ♦ von 07:00 - 18:00 Uhr - from 7 am - 6 pm - Tel. +49 (0) 9352 40 42 22
Vertriebsgebiet Süd Germany South Bosch Rexroth AG Landshuter Allee 8-10 80637 München Tel.: +49 (0)89 127 14-0 Fax: +49 (0)89 127 14-490	Vertriebsgebiet West Germany West Bosch Rexroth AG Regionalzentrum West Borsigstrasse 15 40880 Ratingen Tel.: +49 (0)2102 409-0 Fax: +49 (0)2102 409-406 +49 (0)2102 409-430	Gebiet Südwest Germany South-West Bosch Rexroth AG Service-Regionalzentrum Süd-West Siemensstr.1 70736 Fellbach Tel.: +49 (0)711 51046-0 Fax: +49 (0)711 51046-248	
Vertriebsgebiet Nord Germany North Bosch Rexroth AG Walsroder Str. 93 30853 Langenhagen Tel.: +49 (0) 511 72 66 57-0 Service: +49 (0) 511 72 66 57-256 Fax: +49 (0) 511 72 66 57-93 Service: +49 (0) 511 72 66 57-783	Vertriebsgebiet Mitte Germany Centre Bosch Rexroth AG Regionalzentrum Mitte Waldecker Straße 13 64546 Mörfelden-Walldorf Tel.: +49 (0) 61 05 702-3 Fax: +49 (0) 61 05 702-444	Vertriebsgebiet Ost Germany East Bosch Rexroth AG Beckerstraße 31 09120 Chemnitz Tel.: +49 (0)371 35 55-0 Fax: +49 (0)371 35 55-333	Vertriebsgebiet Ost Germany East Bosch Rexroth AG Regionalzentrum Ost Walter-Köhn-Str. 4d 04356 Leipzig Tel.: +49 (0)341 25 61-0 Fax: +49 (0)341 25 61-111

Europa (West) - Europe (West)

vom Ausland: (0) nach Landeskennziffer weglassen, **Italien:** 0 nach Landeskennziffer mitwählen
from abroad: don't dial (0) after country code, **Italy:** dial 0 after country code

Austria - Österreich Bosch Rexroth GmbH Electric Drives & Controls Stachegasse 13 1120 Wien Tel.: +43 (0)1 985 25 40 Fax: +43 (0)1 985 25 40-93	Austria - Österreich Bosch Rexroth GmbH Electric Drives & Controls Industriepark 18 4061 Pasching Tel.: +43 (0)7221 605-0 Fax: +43 (0)7221 605-21	Belgium - Belgien Bosch Rexroth AG Electric Drives & Controls Industrielaan 8 1740 Ternat Tel.: +32 (0)2 5830719 - service: +32 (0)2 5830717 Fax: +32 (0)2 5830731 service@boschrexroth.be	Denmark - Dänemark BEC A/S Zinkvej 6 8900 Randers Tel.: +45 (0)87 11 90 60 Fax: +45 (0)87 11 90 61
Great Britain - Großbritannien Bosch Rexroth Ltd. Electric Drives & Controls Broadway Lane, South Cerney Cirencester, Glos GL7 5UH Tel.: +44 (0)1285 863000 Fax: +44 (0)1285 863030 sales@boschrexroth.co.uk service@boschrexroth.co.uk	Finland - Finnland Bosch Rexroth Oy Electric Drives & Controls Ansatie 6 017 40 Vantaa Tel.: +358 (0)9 84 91-11 Fax: +358 (0)9 84 91-13 60	France - Frankreich Bosch Rexroth SAS Electric Drives & Controls Avenue de la Trentaine (BP. 74) 77503 Chelles Cedex Tel.: +33 (0)164 72-70 00 Fax: +33 (0)164 72-63 00 Hotline: +33 (0)608 33 43 28	France - Frankreich Bosch Rexroth SAS Electric Drives & Controls ZI de Thibaud, 20 bd. Thibaud (BP. 1751) 31084 Toulouse Tel.: +33 (0)5 61 43 61 87 Fax: +33 (0)5 61 43 94 12
France - Frankreich Bosch Rexroth SAS Electric Drives & Controls 91, Bd. Irène Joliot-Curie 69634 Vénissieux - Cedex Tel.: +33 (0)4 78 78 53 65 Fax: +33 (0)4 78 78 53 62	Italy - Italien Bosch Rexroth S.p.A. Via G. Di Vittoria, 1 20063 Cernusco S/N.MI Tel.: +39 02 92 365 1 +39 02 92 365 326 Fax: +39 02 92 365 500 +39 02 92 365 516378	Italy - Italien Bosch Rexroth S.p.A. Via Paolo Veronesi, 250 10148 Torino Tel.: +39 011 224 88 11 Fax: +39 011 224 88 30	Italy - Italien Bosch Rexroth S.p.A. Via del Progresso, 16 (Zona Ind.) 35020 Padova Tel.: +39 049 8 70 13 70 Fax: +39 049 8 70 13 77
Italy - Italien Bosch Rexroth S.p.A. Via Mascia, 1 80053 Castellammare di Stabia NA Tel.: +39 081 8 71 57 00 Fax: +39 081 8 71 68 85	Italy - Italien Bosch Rexroth S.p.A. Via Isonzo, 61 40033 Casalecchio di Reno (Bo) Tel.: +39 051 29 86 430 Fax: +39 051 29 86 490	Netherlands - Niederlande/Holland Bosch Rexroth Services B.V. Technical Services Kruisbroeksestraat 1 (P.O. Box 32) 5281 RV Boxtel Tel.: +31 (0) 411 65 16 40 +31 (0) 411 65 17 27 Fax: +31 (0) 411 67 78 14 +31 (0) 411 68 28 60 services@boschrexroth.nl	Netherlands - Niederlande/Holland Bosch Rexroth B.V. Kruisbroeksestraat 1 (P.O. Box 32) 5281 RV Boxtel Tel.: +31 (0) 411 65 19 51 Fax: +31 (0) 411 65 14 83 www.boschrexroth.nl
Norway - Norwegen Bosch Rexroth AS Electric Drives & Controls Berghagan 1 or: Box 3007 1405 Ski-Langhus 1402 Ski Tel.: +47 (0)64 86 41 00 Fax: +47 (0)64 86 90 62 jul.ruud@rexroth.no	Spain - Spanien Bosch Rexroth S.A. Electric Drives & Controls Centro Industrial Santiga Obradors s/n 08130 Santa Perpetua de Mogoda Barcelona Tel.: +34 9 37 47 94 00 Fax: +34 9 37 47 94 01	Spain - Spanien Goimendi S.A. Electric Drives & Controls Parque Empresarial Zuatzu C/ Francisco Grandmontagne no.2 20018 San Sebastian Tel.: +34 9 43 31 84 21 - service: +34 9 43 31 84 56 Fax: +34 9 43 31 84 27 - service: +34 9 43 31 84 60 sat.indramat@goimendi.es	Sweden - Schweden Bosch Rexroth AB Electric Drives & Controls - Varuvägen 7 (Service: Konsumentvägen 4, Älfsjö) 125 81 Stockholm Tel.: +46 (0)8 727 92 00 Fax: +46 (0)8 647 32 77
Sweden - Schweden Bosch Rexroth AB Electric Drives & Controls Ekvändan 7 254 67 Helsingborg Tel.: +46 (0) 42 38 88 -50 Fax: +46 (0) 42 38 88 -74	Switzerland West - Schweiz West Bosch Rexroth Suisse SA Electric Drives & Controls Rue du village 1 1020 Renens Tel.: +41 (0)21 632 84 20 Fax: +41 (0)21 632 84 21	Switzerland East - Schweiz Ost Bosch Rexroth Schweiz AG Electric Drives & Controls Hemrietstrasse 2 8863 Buttikon Tel. +41 (0) 55 46 46 111 Fax +41 (0) 55 46 46 222	

Europa (Ost) - Europe (East)

vom Ausland: (0) nach Landeskenziffer weglassen
from abroad: don't dial (0) after country code

<p>Czech Republic - Tschechien</p> <p>Bosch -Rexroth, spol.s.r.o. Hviezdoslavova 5 627 00 Brno Tel.: +420 (0)5 48 126 358 Fax: +420 (0)5 48 126 112</p>	<p>Czech Republic - Tschechien</p> <p>DEL a.s. Strojirenská 38 591 01 Zdar nad Sázavou Tel.: +420 566 64 3144 Fax: +420 566 62 1657</p>	<p>Hungary - Ungarn</p> <p>Bosch Rexroth Kft. Angol utca 34 1149 Budapest Tel.: +36 (1) 422 3200 Fax: +36 (1) 422 3201</p>	<p>Poland – Polen</p> <p>Bosch Rexroth Sp.zo.o. ul. Staszica 1 05-800 Pruszków Tel.: +48 22 738 18 00 – service: +48 22 738 18 46 Fax: +48 22 758 87 35 – service: +48 22 738 18 42</p>
<p>Poland – Polen</p> <p>Bosch Rexroth Sp.zo.o. Biuro Poznan ul. Dabrowskiego 81/85 60-529 Poznan Tel.: +48 061 847 64 62 /-63 Fax: +48 061 847 64 02</p>	<p>Romania - Rumänien</p> <p>East Electric S.R.L. Bdul Basarabia no.250, sector 3 73429 Bucuresti Tel./Fax.: +40 (0)21 255 35 07 +40 (0)21 255 77 13 Fax: +40 (0)21 725 61 21 eastel@rdsnet.ro</p>	<p>Romania - Rumänien</p> <p>Bosch Rexroth Sp.zo.o. Str. Drobety nr. 4-10, app. 14 70258 Bucuresti, Sector 2 Tel.: +40 (0)1 210 48 25 +40 (0)1 210 29 50 Fax: +40 (0)1 210 29 52</p>	<p>Russia - Russland</p> <p>Bosch Rexroth OOO Wjatskaja ul. 27/15 127015 Moskau Tel.: +7-095-785 74 78 +7-095 785 74 79 Fax: +7 095 785 74 77 laura.kanina@boschrexroth.ru</p>
<p>Russia - Russland</p> <p>ELMIS 10, Internationalnaya 246640 Gomel, Belarus Tel.: +375/ 232 53 42 70 +375/ 232 53 21 69 Fax: +375/ 232 53 37 69 elmis_ltd@yahoo.com</p>	<p>Turkey - Türkei</p> <p>Bosch Rexroth Otomasyon San & Tic. A..S. Fevzi Cakmak Cad No. 3 34295 Sefaköy - Istanbul Tel.: +90 212 413 34-00 Fax: +90 212 413 34-17</p>	<p>Slowenia - Slowenien</p> <p>DOMEL Otoki 21 64 228 Zelezniki Tel.: +386 5 5117 152 Fax: +386 5 5117 225 brane.ozebek@domel.si</p>	

Africa, Asia, Australia – incl. Pacific Rim

<p>Australia - Australien</p> <p>AIMS - Australian Industrial Machinery Services Pty. Ltd. 28 Westside Drive Laverton North Vic 3026 Melbourne</p> <p>Tel.: +61 3 93 59 0228 Fax: +61 3 93 59 0286 Hotline: +61 4 19 369 195 enquires@aimservices.com.au</p>	<p>Australia - Australien</p> <p>Bosch Rexroth Pty. Ltd. No. 7, Endeavour Way Braeside Victoria, 31 95 Melbourne</p> <p>Tel.: +61 3 95 80 39 33 Fax: +61 3 95 80 17 33 mel@rexroth.com.au</p>	<p>China</p> <p>Shanghai Bosch Rexroth Hydraulics & Automation Ltd. Waigaoqiao, Free Trade Zone No.122, Fu Te Dong Yi Road Shanghai 200131 - P.R.China</p> <p>Tel.: +86 21 58 66 30 30 Fax: +86 21 58 66 55 23 richard.yang_sh@boschrexroth.com.cn gf.zhu_sh@boschrexroth.com.cn</p>	<p>China</p> <p>Shanghai Bosch Rexroth Hydraulics & Automation Ltd. 4/f, Marine Tower No.1, Pudong Avenue Shanghai 200120 - P.R.China</p> <p>Tel.: +86 21 68 86 15 88 Fax: +86 21 58 40 65 77</p>
<p>China</p> <p>Bosch Rexroth China Ltd. 15/F China World Trade Center 1, Jianguomenwai Avenue Beijing 100004, P.R.China</p> <p>Tel.: +86 10 65 05 03 80 Fax: +86 10 65 05 03 79</p>	<p>China</p> <p>Bosch Rexroth China Ltd. Guangzhou Repres. Office Room 1014-1016, Metro Plaza, Tian He District, 183 Tian He Bei Rd Guangzhou 510075, P.R.China</p> <p>Tel.: +86 20 8755-0030 +86 20 8755-0011 Fax: +86 20 8755-2387</p>	<p>China</p> <p>Bosch Rexroth (China) Ltd. A-5F., 123 Lian Shan Street Sha He Kou District Dalian 116 023, P.R.China</p> <p>Tel.: +86 411 46 78 930 Fax: +86 411 46 78 932</p>	<p>China</p> <p>Melchers GmbH BRC-SE, Tightening & Press-fit 13 Floor Est Ocean Centre No.588 Yanan Rd. East 65 Yanan Rd. West Shanghai 200001</p> <p>Tel.: +86 21 6352 8848 Fax: +86 21 6351 3138</p>
<p>Hongkong</p> <p>Bosch Rexroth (China) Ltd. 6th Floor, Yeung Yiu Chung No.6 Ind Bldg. 19 Cheung Shun Street Cheung Sha Wan, Kowloon, Hongkong</p> <p>Tel.: +852 22 62 51 00 Fax: +852 27 41 33 44 alexis.siu@boschrexroth.com.hk</p>	<p>India - Indien</p> <p>Bosch Rexroth (India) Ltd. Electric Drives & Controls Plot. No.96, Phase III Peenya Industrial Area Bangalore – 560058</p> <p>Tel.: +91 80 51 17 0-211...-218 Fax: +91 80 83 94 345 +91 80 83 97 374 mohanvelu.t@boschrexroth.co.in</p>	<p>India - Indien</p> <p>Bosch Rexroth (India) Ltd. Electric Drives & Controls Advance House, II Floor Ark Industrial Compound Narol Naka, Makwana Road Andheri (East), Mumbai - 400 059</p> <p>Tel.: +91 22 28 56 32 90 +91 22 28 56 33 18 Fax: +91 22 28 56 32 93 singh.op@boschrexroth.co.in</p>	<p>India - Indien</p> <p>Bosch Rexroth (India) Ltd. S-10, Green Park Extension New Delhi – 110016</p> <p>Tel.: +91 11 26 56 65 25 +91 11 26 56 65 27 Fax: +91 11 26 56 68 87 koul.rp@boschrexroth.co.in</p>
<p>Indonesia - Indonesien</p> <p>PT. Bosch Rexroth Building # 202, Cilandak Commercial Estate Jl. Cilandak KKO, Jakarta 12560</p> <p>Tel.: +62 21 7891169 (5 lines) Fax: +62 21 7891170 - 71 rudy.karimun@boschrexroth.co.id</p>	<p>Japan</p> <p>Bosch Rexroth Automation Corp. Service Center Japan Yutakagaoka 1810, Meito-ku, NAGOYA 465-0035, Japan</p> <p>Tel.: +81 52 777 88 41 +81 52 777 88 53 +81 52 777 88 79 Fax: +81 52 777 89 01</p>	<p>Japan</p> <p>Bosch Rexroth Automation Corp. Electric Drives & Controls 1F, I.R. Building Nakamachidai 4-26-44, Tsuzuki-ku YOKOHAMA 224-0041, Japan</p> <p>Tel.: +81 45 942 72 10 Fax: +81 45 942 03 41</p>	<p>Korea</p> <p>Bosch Rexroth-Korea Ltd. Electric Drives and Controls Bongwoo Bldg. 7FL, 31-7, 1Ga Jangchoong-dong, Jung-gu Seoul, 100-391</p> <p>Tel.: +82 234 061 813 Fax: +82 222 641 295</p>
<p>Korea</p> <p>Bosch Rexroth-Korea Ltd. 1515-14 Dadae-Dong, Saha-Ku Electric Drives & Controls Pusan Metropolitan City, 604-050</p> <p>Tel.: +82 51 26 00 741 Fax: +82 51 26 00 747 gyhan@rexrothkorea.co.kr</p>	<p>Malaysia</p> <p>Bosch Rexroth Sdn.Bhd. 11, Jalan U8/82, Seksyen U8 40150 Shah Alam Selangor, Malaysia</p> <p>Tel.: +60 3 78 44 80 00 Fax: +60 3 78 45 48 00 hockhwa@hotmail.com rexroth1@tm.net.my</p>	<p>Singapore - Singapur</p> <p>Bosch Rexroth Pte Ltd 15D Tuas Road Singapore 638520</p> <p>Tel.: +65 68 61 87 33 Fax: +65 68 61 18 25 sanjay.nemade@boschrexroth.com.sg</p>	<p>South Africa - Südafrika</p> <p>TECTRA Automation (Pty) Ltd. 71 Watt Street, Meadowdale Edenvale 1609</p> <p>Tel.: +27 11 971 94 00 Fax: +27 11 971 94 40 Hotline: +27 82 903 29 23 georgv@tectra.co.za</p>
<p>Taiwan</p> <p>Bosch Rexroth Co., Ltd. Taichung Branch 1F., No. 29, Fu-Ann 5th Street, Xi-Tun Area, Taichung City Taiwan, R.O.C.</p> <p>Tel.: +886 - 4 -23580400 Fax: +886 - 4 -23580402 charlie.chen@boschrexroth.com.tw jim.lin@boschrexroth.com.tw david.lai@boschrexroth.com.tw</p>	<p>Thailand</p> <p>NC Advance Technology Co. Ltd. 59/76 Moo 9 Ramintra road 34 Tharang, Bangkhen, Bangkok 10230</p> <p>Tel.: +66 2 943 70 62 +66 2 943 71 21 Fax: +66 2 509 23 62 sonkawin@hotmail.com</p>		

Nordamerika – North America

USA Headquarters - Hauptniederlassung Bosch Rexroth Corporation Electric Drives & Controls 5150 Prairie Stone Parkway Hoffman Estates, IL 60192-3707 Tel.: +1 847 6 45 36 00 Fax: +1 847 6 45 62 01 servicebrc@boschrexroth-us.com repairbrc@boschrexroth-us.com	USA Central Region - Mitte Bosch Rexroth Corporation Electric Drives & Controls Central Region Technical Center 1701 Harmon Road Auburn Hills, MI 48326 Tel.: +1 248 3 93 33 30 Fax: +1 248 3 93 29 06	USA Southeast Region - Südwest Bosch Rexroth Corporation Electric Drives & Controls Southeastern Technical Center 3625 Swiftwater Park Drive Suwanee, Georgia 30124 Tel.: +1 770 9 32 32 00 Fax: +1 770 9 32 19 03	USA SERVICE-HOTLINE - 7 days x 24hrs - +1-800-REX-ROTH +1-800-739-7684
USA East Region – Ost Bosch Rexroth Corporation Electric Drives & Controls Charlotte Regional Sales Office 14001 South Lakes Drive Charlotte, North Carolina 28273 Tel.: +1 704 5 83 97 62 +1 704 5 83 14 86	USA Northeast Region – Nordost Bosch Rexroth Corporation Electric Drives & Controls Northeastern Technical Center 99 Rainbow Road East Granby, Connecticut 06026 Tel.: +1 860 8 44 83 77 Fax: +1 860 8 44 85 95	USA West Region – West Bosch Rexroth Corporation 7901 Stoneridge Drive, Suite 220 Pleasant Hill, California 94588 Tel.: +1 925 227 10 84 Fax: +1 925 227 10 81	
Canada East - Kanada Ost Bosch Rexroth Canada Corporation Burlington Division 3426 Mainway Drive Burlington, Ontario Canada L7M 1A8 Tel.: +1 905 335 55 11 Fax: +1 905 335-41 84 michael.moro@boschrexroth.ca	Canada West - Kanada West Bosch Rexroth Canada Corporation 5345 Goring St. Burnaby, British Columbia Canada V7J 1R1 Tel.: +1 604 205-5777 Fax: +1 604 205-6944 david.gunby@boschrexroth.ca	Mexico Bosch Rexroth Mexico S.A. de C.V. Calle Neptuno 72 Unidad Ind. Vallejo 07700 Mexico, D.F. Tel.: +52 55 57 54 17 11 Fax: +52 55 57 54 50 73 mariofelipe.hernandez@boschrexroth.com.mx	Mexico Bosch Rexroth S.A. de C.V. Calle Argentina No 3913 Fracc. las Torres 64930 Monterrey, N.L. Tel.: +52 81 83 65 22 53 +52 81 83 65 89 11 +52 81 83 49 80 91 Fax: +52 81 83 65 52 80 mario.quiroga@boschrexroth.com.mx

Südamerika – South America

Argentina - Argentinien Bosch Rexroth S.A.I.C. "The Drive & Control Company" Acassusso 48 41/47 1605 Munro Provincia de Buenos Aires Tel.: +54 11 4756 01 40 Fax: +54 11 4756 01 36 victor.jabif@boschrexroth.com.ar	Argentina - Argentinien NAKASE Servicio Tecnico CNC Calle 49, No. 5764/66 B1653AOX Villa Balester Provincia de Buenos Aires Tel.: +54 11 4768 36 43 Fax: +54 11 4768 24 13 nakase@usa.net nakase@nakase.com gerencia@nakase.com (Service)	Brazil - Brasilien Bosch Rexroth Ltda. Av. Tégula, 888 Ponte Alta, Atibaia SP CEP 12942-440 Tel.: +55 11 4414 56 92 +55 11 4414 56 84 Fax sales: +55 11 4414 57 07 Fax serv.: +55 11 4414 56 86 alexandre.wittwer@rexroth.com.br	Brazil - Brasilien Bosch Rexroth Ltda. R. Dr.Humberto Pinheiro Vieira, 100 Distrito Industrial [Caixa Postal 1273] 89220-390 Joinville - SC Tel./Fax: +55 47 473 58 33 Mobil: +55 47 9974 6645 prochnow@zaz.com.br
Columbia - Kolumbien Refflutec de Colombia Ltda. Calle 37 No. 22-31 Santafé de Bogotá, D.C. Colombia Tel.: +57 1 368 82 67 +57 1 368 02 59 Fax: +57 1 268 97 37 reflutec@neutel.com.co reflutec@007mundo.com			

Bosch Rexroth AG
Electric Drives and Controls
Bgm.-Dr.-Nebel-Str. 2
97816 Lohr, Germany
info@boschrexroth.de
www.boschrexroth.de



296393