


# Pressure Transmitter Type 8326

## Instruction Manual

S - Nr.232083

443879 - Ind\*\* / Juli 00



## Contents

<b>1</b>	<b>General Safety Instructions</b>	<b>2</b>
<b>2</b>	<b>Product Description</b>	<b>3</b>
2.1	Construction	3
2.1.1	Pressure Transducer	3
2.1.2	Control Interface Unit	3
2.1.3	Display Unit	4
2.2	Function	5
2.2.1	Functions of Devices without Displays	5
2.2.2	Functions of Devices with Displays	5
2.3	Installation Examples	6
<b>3</b>	<b>Technical Data</b>	<b>8</b>
3.1	Input-values	8
3.2	Output-values	8
3.3	Construction	9
3.4	Auxiliary Power	9
3.5	Ambient Conditions	9
3.6	Process Conditions	10
3.7	Identification Plates	10
<b>4</b>	<b>Installation</b>	<b>11</b>
4.1	Pressure Transmitter Installation	11
4.2	Display Unit Upgrades	11
4.3	Housing Reconfiguration	12
4.4	Electrical Connection	13
4.5	Pressure Compensation when using a Relative Pressure Sensor	14
<b>5</b>	<b>Operation of Devices without Displays</b>	<b>15</b>
5.1	Preparation	15
5.2	Key Functions	15
5.3	Calibration with Pressure	16
5.3.1	Zero Point Calibration	16
5.3.2	Span Calibration	16
5.4	Calibration without Pressure	17
5.4.1	Zero Point Calibration	17
5.4.2	Span Calibration	17
5.5	Integration Time (Dampening) Adjustment	19
5.6	Reset to Default	19

<b>6</b>	<b>Operation of Devices with Displays</b> . . . . .	<b>20</b>
6.1	The Display . . . . .	20
6.2	Key Functions . . . . .	21
6.3	The Programming Mode . . . . .	21
6.4	Default Data (factory setting). . . . .	22
6.5	Main Menu. . . . .	23
6.5.1	Main Menu: Display. . . . .	24
6.5.2	Main Menu: Calibration of zero and span (with / without pressure) . . . . .	26
6.5.3	Main Menu: Output . . . . .	27
6.5.4	Main Menu: Evaluation . . . . .	28
6.5.5	Main Menu: Language. . . . .	29
6.5.6	Main Menu: Service. . . . .	30
<b>7</b>	<b>Diagnostics and Service</b> . . . . .	<b>31</b>
<b>8</b>	<b>Disposal</b> . . . . .	<b>31</b>
<b>9</b>	<b>Appendix</b> . . . . .	<b>32</b>
9.1	Dimension Diagrams . . . . .	32
9.2	Warranty Conditions . . . . .	33
9.3	Glossary . . . . .	33
9.4	Units of Pressure Measurement . . . . .	33

## 1 General Safety Instructions



**Warning**

*Observe the national regulations about safety and accident prevention, as well as the safety instructions in this operating manual when operating the pressure transmitter.*



**Warning**

*Any operation not described in the following instructions must not be carried out.*



**Attention**

*If a failure cannot be repaired, the transmitter must be switched off. The operator then must make sure, that it is only switched on again after the failure has been repaired.*



**Attention**

*Repairs should only be carried out by the manufacturer. All other repairs or modifications of the transmitter are unauthorized.*



**Information**


*Other important safety guidelines can be found in the different sections of this instruction manual.*

## 2 Product Description

The 8326 pressure transmitter can be used in level control applications as well as for pressure measurement applications in process industry. A variety of process connections, measurement ranges, main boards and display options result in a product for a wide range of applications.

### 2.1 Construction

The 8326 consists of a pressure sensor, a control interface unit and a housing cover with optional display. Due to this modular design, different transmitter versions can be mounted.




#### 2.1.1 Pressure Transducer

The pressure transducer has a piezo-resistive or thinfilm measurement cell depending on the pressure range. The sensors are temperature compensated, and have a hermetically welded membrane which is "helium" leak-tested. The Pressure transducers do not have internal sealing elements.


Pressure transducers further distinguish themselves from one another based on their pressure ranges and the different materials of wetted parts. Different process connections can be selected to serve a wide range of applications.

#### 2.1.2 Processing Unit

The processing unit, which is integrated in the housing contains the terminal compartment and the keypad used for programming the transmitter. The four keys must be activated (unlocked) before use. During normal operation the keypad is locked to protect data and functions previously entered. The keypad is automatically locked when no key is hit for 10 minutes. The processing unit converts the digitalized signal from the measuring unit into a standard 4...20 mA current signal.



### 2.1.3 Display Unit



The measured-value indicator has four digits (in a 7-segment display) + symbols. Below it, is line 1 (16-segment display) used to display error codes and the signal's unit of measure. The unit of measure can be selected by the operator.

Additional information is displayed in lines 2 and 3 (16-segment display). The operator can enter commands in the programming mode on the display unit by means of menu guided, clear-text prompts.

Transmitters with displays offer a larger number of programming and processing options. These options include alarm status, damping, signal inversion, tank linearization and diagnostic messages.



*Display units can be easily upgraded (see Section 4.2).*

## 2.2 Function

The mode of operation for signal conversion works in the same way for all versions. The pressure transducer converts the existing pressure into an electrical signal. Microelectronics further process the input signal and produce a proportional 4-20 mA standard signal.

The display-version allows programming (parameterization) and the display of extended functions such as inversion, damping, alarm status and linearization.

### 2.2.1 Functions of Transmitters without Displays

- Calibration of zero and span under pressure (see 5.3)
- Calibration of zero and span without pressure (dry adjustment) (see 5.4)
- Setting the dampening / integrating the output signal 0-40 s (see 5.5)
- Reset to manufacturer's default values (see 5.6)


### 2.2.2 Functions of Transmitters with Displays

- Settable units of measurement (mbar, bar, psi, mA, %, m, mm WS) (see 6.5.1)
- Temperature and Min/Max values shown in display (see 6.5.1)
- Nominal pressure range of the sensor shown in display (see 6.5.1)
- Zero and span calibration (with/without pressure) (see 6.5.2)
- Setting of damping / integration of output signal 0-40 s (see 6.5.3)
- Inversion of the output current signal (see 6.5.3)
- Setting the output current value in case of alarm (3.6 mA or 21 mA) (see 6.5.3)
- Setting the limits of the output signal (see 6.5.3)
- Offset of the output signal (see 6.5.3)
- Mounting correction of the sensor
- Measuring circuit test function (see 6.5.6)
- Reset functions (see 6.5.6)
- Password activation (see 6.5.6)
- Selecting the language of the display (see 6.5.5)
- Entering of a table function for the linearization of the output signal (see 6.5.4)
- Entering the medium density (see 6.5.4)


### 2.3 Installation Examples

The 8326 is primarily used to monitor the pressure in pipes, technical equipment and tanks. Depending on the pressure range pressures between 20 mbar up to 1000 bar can be measured. The pressure is measured using absolute (against a vacuum) or relative (against external or air pressure) measurement depending on the type of sensor selected.


The 8326 is also used for hydrostatic pressure measurement within liquid filled pipes and containers.




*Process Pressure Measurement:*  
Used to measure pressure of liquids  
or gases in pipelines.




*Process Pressure Measurement:*  
Used to measure container pressure.




*Process Pressure Measurement:*  
Installed behind feed pumps for  
process control or monitoring of pump  
functions.




*Process Pressure Measurement:*  
Installed in front of and behind the filter.  
Uses the pressure differential for moni-  
toring the function or accumulation of dirt  
in the filter. Both output signals are pro-  
cessed by a PLC or signal converter.




*Level Control:*  
*Externally mounted*  
*(with front flat diaphragm)*



*Level Control:*  
*Combined pressure and head pressure*  
*are measured by two externally mounted*  
*pressure transducers. The two signals*  
*are analyzed and the differential is cal-*  
*culated by a PLC or suitable signal con-*  
*verter.*



*Level Control:*  
*Rope type suspended from top of tank.*



*Level Control:*  
*Rod type installed through top of tank.*



### 3 Technical Data

#### 3.1 Input-values

Pressure Ranges (Absolute pressure upon request)	/ overpressure limit /	Burst pressure
0 ... 0.4 bar	2	2
0 ... 1,6 bar	10	10
0 ... 6 bar	35	35
0 ... 16 bar	80	80
0 ... 40 bar	80	400
0 ... 100 bar	200	800
0 ... 250 bar	500	1200
0 ... 600 bar	1200	2400
0 ... 1.000 bar	1500	3000
others ... 1.000 bar		

#### 3.2 Output-values

Output signal	4 ... 20 mA
Accuracy [% of span] (linearity, hysteresis, repeatability)	< 0.10 at ranges of > 40 bar < 0.15 at ranges of < 40 bar
Turn down behavior: (1/k) up to 1 : 5 1 : 5 to 1 : 20	no changes of deviation the accuracy must be multiplied by the factor (turn down / 5) example for TD = 1:15, (k = 15) accuracy = 0.10 * (15/5) = 0.3
Overall deviation (at +10 °C ... +40 °C)	≤ 0.15 % for pressure ranges of ≥ 40 bar (limit point calibration) < 0.2 % for pressure ranges of < 40 bar
Load	$R_A \leq (U_B - 12 \text{ V}) / 0.023 \text{ A}$ with $R_A$ in Ohm and $U_B$ in Volt
Fault signal	3.6 mA or 21 mA, programmable
Integration time	0 s, 1 s, 5 s, 20 s, 40 s, programmable
Adjustment of the span	Up to Turn Down 1 : 20
Integrated lightning protection	optional
Zero point adjustment	0 ... 99 %

### 3.3 Construction

Process connections	G 1/2 B per DIN 16288 (1/2 NPT) G 1/2 B flush diaphragm with O-Ring (Ranges: 0 ... 6 to 0 ... 600 bar) G 1 B flush diaphragm with O-Ring according to EHEDG
Materials	highly resistive, fiberglass-enforced plastic (PBT)
Housing	CrNi-steel 1.4571 (316 Ti) and 1.4542 (630 17.4 PH)
wetted parts:– standard	CrNi-steel 1.4571 (316 Ti) and O-Ring: FPM
– with a flush diaphragm	CrNi-steel 1.4435 (316 L) and O-Ring: EPDM
– EHEDG	
Internal transmission fluid	– Standard – EHEDG-version is FDA approved
Electrical connection per EN 60 529/ IEC529	M 20 x 1.5 cable gland with internal terminal block (see 4.4)
Electric protection	Reverse polarity, overload and short circuit protection

### 3.4 Auxilliary Power

Power supply	12 ... 36 V DC
--------------	----------------

### 3.5 Ambient Conditions

Ambient temperature	– 40 °C ... + 85 °C (– 20 °C ... 70 °C with display)
Storage temperature	– 40 °C ... + 85 °C (– 35 °C ... 80 °C with display)
Climate class	D per DIN IEC 654-1
Ingress protection per EN 60 529	IP 65 (IP 67 upon request)
EMC per	EN 50 081-2, EN 50 082-2, NAMUR NE 21


**3.6 Process Conditions**

Medium temperatures	- 30 °C ... + 100 °C
Max. wash-down temperatures	120 °C



*The transmitter must not be subjected to the wash-down temperature for more than 10 minutes at a time! A maximum wash-down temperature of 105° C is allowed for devices installed in hazardous areas.*  
 (°F = (°C \* 1.8) + 32)

**3.7 Identification Plates**



## 4 Installation

The device should be installed/operated in accordance with the regulations of ElexV, the Device Safety Regulation, this operating manual and generally recognized industry standards.

### 4.1 Pressure Transmitter Installation



Attention

*The pressure transmitter's diaphragm should not come into contact with hard or sharp objects.*

#### Installation Using a Weld-on Adapter:

- Insert a filler piece (a pressure transmitter dummy) into the weld-on adapter.
- Weld the adapter into the container/pipe wall (section-weld process).
- Remove the filler piece.
- Install the pressure transmitter in the weld-on adapter.

### 4.2 Display Unit Upgrades


The display unit can be easily upgraded at any time.

- Remove the housing cover and the supporting string.
- Attach the display unit's supporting string to the same place.
- Plug the display unit's connector into the appropriate jack.  
The display unit can be mounted at 90° angles.
- Fasten the display unit with screws.



Attention

*When installing the display unit, make sure that the connection cable and the supporting string are not kinked or pinched. If the cable is damaged, correct function may be impaired.  
On EX-Model the Ex-protection of the transmitter will no longer exist.*



All functions are programmable once the pressure transmitter has been upgraded with a display unit. The adjusted parameters are stored after the display unit is removed.

The display unit can be rotated in 300°, so that it can be read under various installation conditions. The housing cover with built-in display can be fastened to the housing at all four side positions.


#### 4.3 Housing Reconfiguration

Rotate the housing of the display unit in order to be able to read the display from above when the pressure transmitter is installed in an upright position.

- Loosen the 4 internal hexagonal screws.
- Lightly lift off the housing with the display unit.
- Carefully turn the housing by 180°.
- Re-tighten the screws.



*When tightening the 4 hollow screws, make sure that they are adequately and securely seated in order to ensure that the transmitter is properly sealed.*



017-DS-D

#### 4.4 Electrical Connection

**Attention**


*Please observe local installation regulations (Germany: VDE-Standard).  
The terminal voltage should not exceed 36 V (30 V for intrinsic safety transmitters).*

The supply voltage is between 12 and 36 V DC (12 and 30 V for intrinsic safety transmitters). The power supply and the output signal are transmitted via a two-wire cable (max. 12 mm outer diameter, max. 14 AWG) and connected in accordance with the pin configuration.

Supply voltage can be supplied by a power unit, a transmitter power supply or by means of a PLC connection.

It is suggested to use a model with integrated lightning protection for preventing damage due to voltage peaks.

**Terminal Configuration**



⏏ Ground

L- Negative

L+ Positive

I Test circuit; connect the ampere meter between terminals L+ and I

The unit must be properly grounded in order to guarantee EMC resistance.

**4.5 Pressure Compensation when using a Relative Pressure Sensor**

A Goretex diaphragm is used to compensate for the atmospheric pressure under the IP 65 Protection Method.

A special cable with capillaries for relative pressurization is used for Ingress Protection IP 67.

### 5 Operation of Devices without Displays

#### 5.1 Preparation

This unit can be programmed before or after installation.

- Connect an ampere meter to the device's output (between terminals I and L+).
- Note that after each action, a brief oscillation/deflection of 20 mA occurs (verification of a successful action).

The following functions can be programmed without a display unit:

- Zero point adjustment with a full or empty container (with/without pressure)
- Span adjustment with a full or empty container (with/without pressure)
- Integration time
- Reset to manufacturer's defaults
















*An error signal is caused by a current surge (21 mA or 3.6 mA; 5 sec) when the zero point or span setting fall outside of the sensor's nominal pressure range during adjustments with existing pressure. No values are stored.*



*The keypad becomes inactive after 10 min. of disuse. All settings will default to previously stored values. Only settings that have been confirmed with the "OK" function are stored.*

#### 5.2 Key Functions

Function 1		Function 2	
 span	Basic setting, store span	 span	Action: upward, increase value
 zero	Basic setting, store zero point	 zero	Action: downward, decrease value
 esc	Exit key or programming mode	 esc  ok	Activate keys (push simultaneously for 2 sec.)
 ok	Verification (store)		
 span  zero	Basic setting Integration time/ damping (push simultaneously for 2 sec.)	 esc  zero  ok	Reset to default (push simultaneously for 2 sec.)




### 5.3 Calibration with Pressure

#### 5.3.1 Zero Point Calibration



*Make sure that the pressure to be used as the zero point (P 0 %), is present at the transmitter diaphragm before calibration.*




#### 5.3.2 Span Calibration

Calibration of the measurement range (span).



*Make sure that the pressure to be used as the span end-point (P 100 %) is present at the transmitter diaphragm.*



*A change in the zero point has no effect on the calibrated span. However, if the span end-point is higher than the peak value of the sensor's nominal pressure range, then span end-point is fixed at this peak value and the span is reduced accordingly.*

*A change in the span setting has no effect on the zero point. The zero point and span end-point must fall within the sensor's nominal pressure range.*

## 5.4 Calibration without Pressure

Determine the current reference values for the zero point and the span to be entered in the transmitter before calibration. This is done as follows:

### 5.4.1 Zero Point Calibration

- Determine the hydrostatic pressure of the liquid's surface that meets the zero point.
- Adjust this pressure in proportion to the sensor's nominal pressure range.
- Multiply this proportion by 16 mA and add 4 mA to the result.


This produces the calculated current (value  $I_{calc}$ ), which is entered in the transmitter and used to program the zero point (0%).

*Example:*

A pressure transducer with 0 ... 400 mbar (nominal pressure) needs to be programmed. The liquid's surface (with a density of 1) is 1 m above the diaphragm at the zero point producing a pressure of 100 mbar.

$$I_{calc} = \frac{\text{Zero point pressure (0%) } 100 \text{ mbar}}{\text{Sensors nominal pressure } 400 \text{ mbar}} \cdot 16 \text{ mA} + 4 \text{ mA} = 8 \text{ mA}$$

This means that the device's current value must be set to 8 mA when performing a dry (empty) calibration.



### 5.4.2 Span Calibration

- Determine the hydrostatic pressure of the liquid's surface, which corresponds to the span end-point.
- Calculate the difference of the pressure value between span end-point and zero point and divide this difference by the nominal pressure range of the sensor.
- Multiply this proportion by 16 mA and add 4 mA to the result.

This produces the calculated current (value  $I_{calc}$ ), which is entered in the transmitter and used to program the span end-point (100%).


The measurement range between zero point and span end-point will be stored as span.

*Example:*

A pressure transducer with 0 ... 400 mbar (nominal pressure) is to be programmed. The liquid's surface (with a density of 1) is 1 m above the diaphragm at the zero point. The maximum (span end-point) should be 3 m.

$$I_{calc} = \frac{\text{pressure difference (span)} (300 \text{ mbar} - 100 \text{ mbar})}{\text{Sensors nominal pressure } 400 \text{ mbar}} \cdot 16 \text{ mA} + 4 \text{ mA} = 12 \text{ mA}$$

This means that the output must be set to 12 mA during programming.



*A change in the zero point has no effect on the adjusted span. However, if the span end-point is higher than the peak value of the sensor's nominal pressure range, then the span end-point is fixed at this peak value and the span is reduced accordingly.*

*A change in the span setting has no effect on the zero point. The zero point and span end-point must fall within the sensor's nominal pressure range.*




**Important**

*A test / correction of the zero point is suggested after adjusting the span in order to maintain optimum accuracy.*

### 5.5 Integration Time (Damping) Adjustment

The following integration time settings can be used: 0, 1, 5, 20 and 40 s.

The sensor's measured values can then be averaged using the adjusted integration time.



### 5.6 Reset to Default

All default data settings are restored by simultaneously pressing the "zero", "esc" and the "ok" buttons for 2 seconds (see Para. 6.4).




**Important**

*Calibrated special measurement ranges i. e. 4 bar on a 6 bar transmitter can be adjusted by factory pre-setting. A reset to default will reset the sensor back to its nominal range (i. e. 6 bar). The factory pre-setting gets lost.*







## 6 Operation of Transmitters with Displays

### 6.1 The Display

In order to program the device, remove the display with a screwdriver and re-attach it to the housing as shown in the diagram below.



### 6.2 Key Functions

Button	Functions		
	Main Menu	Sub-menu	Edit Functions
	back to the previous menu option	back to the previous menu option	increase value
	forward to next menu option	forward to next menu option	decrease value
	back to value display without saving	back to main menu without saving	back to the sub-menu without saving
	to the sub-menu	to the edit functions	save value
 	activate keypad (push simultaneously; 2 s)		

### 6.3 The Programming Mode

The transmitter can be programmed before or after installation.

The keypad is activated and the device can be programmed by simultaneously pressing the "esc" and "ok" keys (for 2 sec.). This method is used to access the main menus. Each main menu has one or more sub-menus and each sub-menu, may have its own sub-menus.



*The keypad becomes inactive after 10 min. of disuse. All settings will default to previously stored values. Only settings that have been confirmed with the "OK" function are stored.*



*A change in the starting measurement (zero point) has no effect on the measurement span. Likewise, a change in the span has no effect on the starting measurement.*



*An error signal occurs when the zero point or span settings fall outside of the sensor's nominal pressure range during calibration with pressure. Nothing is saved.*


### 6.4 Default Data (factory setting)

Function		Defaults
Display	Unit of measurement (Line 1)	Pressure display (in bar)
	Line 2	Temperature display (in °C)
	Line 3	Sensor's nominal pressure range (in bar)
Calibration		zero 4 mA = nom. pressure range start span 20 mA = nom. pressure range end
Output	Damping	0 s
	Inversion	no
	Fault	21 mA (upscale)
	Limits	3.8 ... 20.5 mA
	I-offset	0 mA
Service password		no active password
Service mounting correction		not activated
Language		English
Evaluation	linear	yes
	density	1 g/cm <sup>3</sup>


**Important**

*Calibrated special measurement ranges i. e. 4 bar on a 6 bar transmitter can be adjusted by factory pre-setting. A reset to default will reset the sensor back to its nominal range (i. e. 6 bar). The factory pre-setting gets lost.*

**6.5 Main Menu**







**6.5.1 Main Menu: Display**




The density of a medium must be entered to calculate the correct fill-level when displaying or adjusting the level in height units (e.g. mm, m, feet, inch)(see 6.5.4).





**6.5.2 Main Menu: Calibration of zero and span (with / without pressure)**



A single pressure value is set for the zero point or the span end-point within the sensor's nominal pressure range, and assigned to the associated output current signal when making adjustments with existing pressure. An error signal occurs when the existing pressure lies outside of the sensor's nominal pressure range. The value is not saved in this case.



**Important**

A mounting correction should be performed before or after making an adjustment without pressure (dry adjustment) (see 6.5.6). The sensor must therefore be placed in the reference position for the measurement (installation site) without pressure on the diaphragm.




A mounting correction is unnecessary when making an adjustment with pressure (wet adjustment). Otherwise, the mounting correction must be performed before saving the zero point and span end-point.



**Important**


A test / correction of the zero point is suggested after adjusting the span in order to maintain optimum accuracy.

**6.5.3 Main Menu: Output**



033-DS-D

**6.5.4 Main Menu: Evaluation**



Enter height values, which are each assigned a volumetric value of measure for tank linearization. The linearization and the assignment of the 4 ... 20 mA output signal are converted into tank volumes using this value pair.



Please check the following if "Wrong Entry" appears in the Evaluation menu:

- whether or not more than 32 value pairs are entered in the table for tank linearization (please note: P 0 and P 31 are fixed at 0% and 100% respectively)
- whether or not an existing height value was tried to be stored again  
Please enter correct values.

*Example:*

Level 100 %: 4000 mm

Density: 1 g/cm<sup>3</sup>

Density correction: 0.9 g/cm<sup>3</sup>

Span end point:  $\frac{4000 \text{ mm} \cdot 1 \text{ g/cm}^3}{0.9 \text{ g/cm}^3} = 4444 \text{ mm}$


The span (end-point) must be re-calibrated (with or without pressure) to 4000 mm in order to prevent a 4000 mm level tank from being overfilled.



**Important**


*A change or correction in the density causes a change in the span end-point's unit of measure (mm, m, inch, feet). The span end-point must be re-calibrated when changing the medium to be measured (due to a change in density).*

### 6.5.5 Main Menu: Language



035-DS-D

### 6.5.6 Main Menu: Service



034-DS-D

## 7 Diagnostics and Service



Attention

*If a failure cannot be repaired, the transmitter must be switched off. The operator then must make sure, that it is only switched on again after the failure has been repaired.*



Attention

*Repairs should only be carried out by the manufacturer. All other repairs or modifications are unauthorized.*

The following error messages can appear on devices with displays (see also para. 2.1.3):

Error Code	Error	Error Correction Measures
E00	ROM-error	Return device to manufacturer
E01	Power supply error	Check power supply
E03	EEPROM communications error	Disconnect and reconnect power supply
E04	Sensor's temperature range was exceeded	Return sensor's temperature to specified limits
E06	Sensor recognition	Disconnect and reconnect power supply
E07	General communications error between the sensor and the control interface unit	Check the connection between the sensor and the control interface unit

## 8 Disposal



Important


*Please observe local guidelines and regulations when disposing of transmitters that are no longer serviceable.*

*Please turn any recycleable components in to the appropriate local organizations.*



**9 Appendix**

**9.1 Dimension Diagrams**



## 9.2 Warranty Conditions

The pressure transmitter has a 12 month warranty in accordance with the ZVEI General Terms of Delivery.



Attention

*Repairs may only be carried out by the manufacturer. All other repairs and device modifications are unauthorized and will void the warranty.*

## 9.3 Glossary

Adjustment	Allocation of the signal output range (4 ... 20 mA) to the desired pressure measurement range or level measurement range.
Integration	Also damping: timely communication of the measurement signal; rise time of the current output signal after a signal surge
Inversion	Conversion of the output signal from 4 ... 20 mA to 20 ... 4 mA
Nom. pressure range	The operating pressure range for which the sensor was designed
Zero point	Start of the pressure measurement range
Parameterization	Also configuration: programming of the relevant parameters and the pressure measurement range specific to the application and measurement location.
Span	The programmed pressure measurement range
Span end point	The highest pressure value of the programmed measurement span (end-point of the span)
Tank linearization	Determination of approximate volume/pressure ratio values with non-linear correlations based on varying container designs  For example, a non-linear correlation exists between the fill level and the volume in spherical containers. During linearization, the non-linear volume is assigned the 4 ... 20 mA output signal from a table of values (proximity process by means of up to 32 support points).
Defaults	The sensor parameters are pre-programmed by the manufacturer

## 9.4 Units of Pressure Measurement

1 atm (atmospheres)	= 760 mm Hg = 760 Torr
	= 1.033 kp/cm <sup>2</sup> = 0.1013 MPa
1 Torr	= 133.3 Pa
1 kp/mm <sup>2</sup>	= 9.81 N/mm <sup>2</sup> = 9.81 MPa
1 bar	= 0.1 MPa
1 mbar	= 1 hPa (Hectopascal)
1 psi (pound per square inch)	= 6.895 · 10 <sup>3</sup> Pa
1 bar	= 33.5 feet of water

# SERVICE

---

## Australia

Bürkert Fluid Control Systems  
Unit 1 No.2, Welder Road  
Seven Hills NSW 2147  
Tel +61 (0) 2 967 461 66  
Fax +61 (0) 2 967 461 67

## Austria

Bürkert Contromatic GmbH  
Central and Eastern Europe  
Diefenbachgasse 1-3  
A-1150 Wien  
Tel +43 (0) 1 894 13 33  
Fax +43 (0) 1 894 13 00

## Belgium

Bürkert Contromatic N.V./S.A.  
Middelmolenlaan 100  
B-2100 Deurne  
Tel +32 (0) 3 325 89 00,  
Fax +32 (0) 3 325 61 61

## Canada

Bürkert Contromatic Inc.  
760 Pacific Road, Unit 3  
Oakville, Ontario, L6L 6M5  
Tel +1 905 847 55 66,  
Fax +1 905 847 90 06

## China

Bürkert Contromatic  
(Suzhou) Co. Ltd.  
2/F, 71 Zhu Yuan Road  
215011 Suzhou  
Tel +86 512 808 19 16  
Fax +86 512 824 51 06

## Bürkert Contromatic

China/HK Ltd.  
Rm. 1313  
No. 103, Cao Bao Road  
200233 Shanghai P.R.C.  
Tel +86 21 6427 1946  
Fax +86 21 6427 1945

Bürkert Contromatic  
China/HK Ltd.  
Beijing Office  
Rm. 808, Jing Tai Building  
No. 24, Jianguomen  
Waidajie  
100022 Beijing P.R.C.  
Tel +86 10 65 15 65 08  
Fax +86 10 65 15 65 07

## Bürkert Contromatic China/HK Ltd.

Cheng Du Representative Office  
Rm. 502, Fuji Building  
No. 26 Shududadao  
Dongfeng Street  
Chengdu P.R.C.  
Tel +86 28 443 1895  
Fax +86 28 445 1341

Bürkert Contromatic  
China/HK Ltd.  
Guangzhou Representative Office  
Rm. 1305, Tower 2  
Dong-Jun Plaza  
Dongfeng, Road East  
Guangzhou P.R.C.  
Tel +86 28 443 1895  
Fax +86 28 445 1341

## Denmark

Bürkert-Contromatic A/S  
Hørkær 24  
DK-2730 Herlev  
Tel +45 44 50 75 00  
Fax +45 44 50 75 75

## Finland

Bürkert Oy  
Atomitie 5  
SF-00370 Helsinki  
Tel +358 (0) 9 549 706 00  
Fax +358 (0) 9 503 12 75

## France

Bürkert Contromatic  
B.P. 21  
Triembach au Val  
F-67220 Villé  
Tel +33 (0) 388 58 91 11  
Fax +33 (0) 388 57 09 61

## Germany / Deutschland

Bürkert Steuer- und Regeltechnik  
Christian-Bürkert-Straße 13-17  
D-74653 Ingelfingen  
Tel +49 7940 10-0  
Fax +49 7940 10 361

Niederlassung NRW  
Holzener Straße 70  
D-58708 Menden  
Tel +49 2373 96 81-0  
Fax +49 2373 96 81-52

Niederlassung Frankfurt  
Am Flugplatz 27  
D-63329 Egelsbach  
Tel +49 6103 94 14-0  
Fax +49 6103 94 14-66

Niederlassung München  
Paul-Gerhardt-Allee 24  
D-81245 München  
Tel +49 89 82 92 28-0  
Fax +49 89 82 92 28-50

Niederlassung Berlin  
Bruno-Taut-Straße 4  
D-12524 Berlin  
Tel +49 30 67 97 17-0  
Fax +49 30 67 97 17-66

Niederlassung Dresden  
Christian Bürkert Straße 2  
D-01900 Großbröhrsdorf  
Tel +49 35952 3 63 00  
Fax +49 35952 3 65 51

Niederlassung Hannover  
Rendsburger Straße 12  
D-30569 Hannover  
Tel +49 511 9 02 76-0  
Fax +49 511 9 02 76-66

Niederlassung Stuttgart  
Karl-Benz-Straße 19  
D-70794 Filderstadt (Bernh.)  
Tel +49 711 4 51 10-0  
Fax +49 711 4 51 10-66

## Great Britain

Bürkert Contromatic Ltd.  
Brimscombe Port Business Park  
Brimscombe, Stroud, Glos.  
GL5 2QF  
Tel. +44 (0) 1453 73 13 53  
Fax +44 (0) 1453 73 13 43

## Hong Kong

Bürkert Contromatic  
(China/HK) Ltd.  
Unit 708, Prosperity Centre  
77-81 Container Port Road  
Kwai Chung N.T.  
Hong Kong  
Tel +852 248 012 02  
Fax +852 241 819 45

## Italy

Bürkert Contromatic Italiana S.p.A.  
Centro Direzionale 'Colombiolo'  
Via Roma 74  
I-20060 Cassina De' Pecchi (MI)  
Tel +39 02 959 071  
Fax +39 02 959 07 251

## Japan

Bürkert Contromatic Ltd.  
3-39-8 Shoan  
Suginami-ku  
Tokyo 167-0054  
Tel +81 (0) 3 3247 3411  
Fax +81 (0) 3 3247 3472

## Korea

Bürkert Contromatic Korea Co. Ltd.  
4-10 Yangjae-Dong  
Seocho-Ku  
Seoul 137-130  
Tel. +82 (0) 2 346 255 92  
Fax +82 (0) 2 346 255 94

# SERVICE

## Malaysia

Bürkert Malaysia Sdn. Bhd.  
N° 22 Lorong Helang 2  
11700, Sungai Dua  
Penang  
Tel. +60 (0) 4 657 64 49  
Fax +60 (0) 4 657 21 06

## Netherlands

Bürkert Contromatic BV  
Computerweg 9  
NL-3606 AV Maarssen  
Tel. +31 (0) 346 58 10 10  
Fax +31 (0) 346 56 37 17

## New Zealand

Burkert Contromatic Ltd.  
Unit 5, 23 Hannigan drive  
Mt Wellington  
Auckland  
Tel +64 (0) 9 570 25 39  
Fax +64 (0) 9 570 25 73

## Norway

Bürkert Contromatic A/S  
Hvamstubben 17  
Box 243  
N-2026 Skjetten  
Tel +47 63 84 44 10  
Fax +47 63 84 44 55

## Philippines

Bürkert Contromatic Inc.  
8467, West Service Rd Km 14  
South Superhighway, Sunvalley  
Paranaque City, Metro Manila  
Tel +63 (0) 2 776 43 84  
Fax +63 (0) 2 776 43 82

## Poland

Bürkert Contromatic Sp.z.o.o.  
Bernardynska street  
PL-02-904  
Warszawa  
Tel +48 (0) 22 840 60 10  
Fax +48 (0) 22 840 60 11

## Singapore

Burkert Contromatic Singapore Pte.Ltd.  
No.11 Playfair Road  
Singapore 367986  
Tel +65 383 26 12  
Fax +65 383 26 11

## Spain

Bürkert Contromatic Española S.A.  
Avda. Barcelona, 40  
E-08970 Sant Joan Despi,  
Barcelona  
Tel +34 93 477 79 80  
Fax +34 93 477 79 81

## South Africa

Burkert Contromatic Pty.Ltd.  
P.O.Box 26260, East Rand 1462  
Republic of South Africa  
Tel +27 (0) 11 397 2900  
Fax +27 (0) 11 397 4428

## Sweden

Bürkert Contromatic AB  
Skeppsbron 13 B  
S-21120 Malmö  
Tel +46 (0) 40 664 51 00  
Fax +46 (0) 40 664 51 01

## Switzerland

Bürkert Contromatic AB  
Havsörnstorget 21  
Box 1002  
S-12349 Farsta  
Tel +46 (0) 40 664 51 00  
Fax +46 (0) 8 724 60 22

## Switzerland

Bürkert-Contromatic AG Schweiz  
Bösch 71  
CH-6331 Hünenberg / ZG  
Tel +41 (0) 41 785 66 66  
Fax +41 (0) 41 785 66 33

## Taiwan

Bürkert Contromatic Taiwan Ltd.  
3F No. 475 Kuang-Fu South Road  
R.O.C - Taipei City  
Tel +886 (0) 2 275 831 99  
Fax +886 (0) 2 275 824 99

## Turkey

Bürkert Contromatik  
Akiskan Kontrol Sistemleri Ticaret  
A.S  
1203/8 Sok. No. 2-E  
Yenisehir  
Izmir  
Tel +90 (0) 232 459 53 95  
Fax +90 (0) 232 459 76 94

## Tzechia

Bürkert Contromatic Spol.s.r.o  
Prosenice c. 180  
CZ - 751 21 Prosenice  
Tel +42 0641 226 180  
Fax +42 0641 226 181

## USA/West/Main office

Burkert Contromatic Corp.  
2602 McGraw Avenue  
Irvine, CA 92614, USA  
Tel. +1 949 223 31 00  
Fax +1 949 223 31 98

## USA/South

Burkert Contromatic Corp.  
6724 Alexander Road  
Charlotte, North Carolina, 28270  
Tel. +1 704 367 11 73  
Fax +1 704 367 11 74

## USA/North-East

Burkert Contromatic Corp.  
7173 Thermal Road  
Charlotte, North Carolina, 28211  
Tel. +1 704 366 21 41  
Fax +1 704 366 24 28

## USA/West

Burkert Contromatic Corp.  
4449 East Bradford  
Orange, CA 92867  
Tel. +1 714 637 26 39  
Fax +1 714 637 21 62

## USA/Mid-West

Burkert Contromatic Corp.  
726 Evergreen Street North  
Royalton, MN 56373  
Tel. +1 320 584 58 47  
Fax +1 320 584 58 71

