

## TABLE OF CONTENTS

## 8025 LOW FLOW

<b>1</b>	<b>INTRODUCTION</b> .....	<b>E-2</b>
1.1	Unpacking and Control .....	E-2
1.2	About this Manual .....	E-2
1.3	User's Responsibility for Safety .....	E-2
1.4	Electromagnetic Compatibility .....	E-2
<b>2</b>	<b>SPECIFICATION</b> .....	<b>E-3</b>
2.1	Transmitter Specification .....	E-3
2.2	Sensor Specification .....	E-3
2.3	Design and Measuring Principle .....	E-4
2.4	Technical Data .....	E-4
2.5	Dimensions .....	E-5
<b>3</b>	<b>INSTALLATION</b> .....	<b>E-6</b>
3.1	Installation Guidelines .....	E-6
3.2	Transmitter setting according to sensor .....	E-8
3.2.1	Connection and switches .....	E-9
3.3	General Electrical Connection .....	E-10
3.4	Connection of Pulse Output to a PLC .....	E-10
3.5	Electrical Connection Panel Version .....	E-11
3.5.1	Type 8025 without relay .....	E-11
3.5.2	Type 8025 with relays .....	E-12
3.6	Electrical Wiring IP65 Version .....	E-13
3.6.1	Type 8025 IP65 12/30 VCC .....	E-13
3.6.2	Type 8025 IP65 115/230 VAC .....	E-14
3.7	Connection of the flow sensor type 8031 .....	E-15
3.7.1	Connection to the transmitter type 8025 panel .....	E-15
3.7.2	Connection to the transmitter type 8025 wall-mounted .....	E-15
<b>4</b>	<b>OPERATION</b> .....	<b>E-16</b>
4.1	Transmitter Operating and Control Elements .....	E-16
4.2	Operation Mode Display .....	E-17
4.3	Calibration Mode Display .....	E-17
4.3.1	Languages .....	E-18
4.3.2	Engineering Units .....	E-18
4.3.3	K-Factor .....	E-19
4.3.4	Output Current .....	E-20
4.3.5	Pulse Output .....	E-20
4.3.6	Relay .....	E-20
4.3.7	Filter Function .....	E-21
4.3.8	Totalizer .....	E-21
4.4	Test Menu .....	E-22
4.4.1	Offset-Compensation .....	E-23
4.4.2	Span-Compensation .....	E-23
4.4.3	Frequency Display .....	E-23
4.4.4	Flow Simulation .....	E-23
<b>5</b>	<b>MAINTENANCE</b> .....	<b>E-24</b>
5.1	Trouble-shooting .....	E-24
5.2	Factory Settings of 8025 "LOW FLOW" transmitter .....	E-24
5.3	Limit values for 8025 "LOW FLOW" setting .....	E-24
5.4	Spare Parts List .....	E-25
	Spare Parts List Panel version .....	E-25
	Spare Parts List Wall-mount version .....	E-26

Dear Customer,

Congratulations on your purchase of our 8025 digital flow transmitter.

**BEFORE INSTALLING OR USING THIS PRODUCT, PLEASE TAKE OUR ADVICE AND READ THE ENTIRE MANUAL THOROUGHLY.**

This will enable you to fully profit from all of the advantages offered by this product.

## 1.1 Unpacking and Control

Please verify that the product is complete and free from any damage. The standard delivery must include:

- 1 8025 digital Flow Transmitter, either or in panel version with mounting accessories (1 gasket, 4 spacer bolts, 1 protective plate, 4 screws, 4 lockwashers, 2 cable clips and 1 cut-away film), or in IP65 wall-mount version.
- 1 Operating Instruction Manual.

Compare the Type specifications on the label to the adjacent list to ensure that you have received the proper unit. If there is any loss or damage, please contact your local Bürkert subsidiary.

## 1.2 About this Manual

This manual does not contain any warranty statement. Please refer to our general terms of sale and delivery.

Only properly-trained staff should install and/or repair this product. If difficulties should occur at the time of installation, please contact your nearest Bürkert sales office for assistance.

## 1.3 User's Responsibility for Safety

Bürkert manufactures a broad range of flow transmitters. While each of these products is designed to operate in a wide variety of applications, it is the user's responsibility to select a transmitter model that is appropriate for the application, install it properly, and maintain all components. Special attention must be paid to the chemical resistance of the transmitter against the fluids which are directly contacting the product.



This symbol appears in the manual to call special attention to instructions that affect the safe installation, function and use of the product.

## 1.4 Electromagnetic compatibility

This device conforms to the EMC-Directive of the Council of European Communities 89/336/EEC.

In order to comply with this directive, the wiring instructions must be followed.

## 2 SPECIFICATION

## 8025 LOW FLOW

### 2.1 Transmitter designation

#### Transmitter 8025 "LOW FLOW" Panel version

Designation	Power Supply	Order Nr
4...20 mA, 2 relays, pulse output, 2 totalizers	13-30 VDC	419538Z
4...20 mA, pulse output, 2 totalizers	13-30 VDC	419537Q

#### Transmitter flow 8025 "LOW FLOW" Wall-mounted version

Designation	Power Supply.	Order Nr
4...20 mA, 2 relays, pulse output, 2 totalizers	13-30 VDC	419541U
4...20 mA, pulse output, 2 totalizers	13-30 VDC	419540F
4...20 mA, 2 relays, pulse output, 2 totalizers	230 VAC	419544X
4...20 mA, pulse output, 2 totalizers	230 VAC	419543W

### 2.2 Sensor designation

Flow sensors for transmitter 8025 "LOW FLOW"

**Measuring principle :** Inductive, Hall effect or optical.

**Power supply:** 12 VCC to 30 VCC

**Sensor output:** Open collector R=2,2 K $\Omega$  ou 470  $\Omega$   
NPN; PNP or TTL.

Type	Gasket	Flow max l/min	K-Factor <sup>2</sup>	Order Nr
8031	FPM	150	10200	783721V
8031	EPDM	150	10200	783722W
8031	FPM	600	3400	783724Y
8031	EPDM	600	3400	783725Z
8031	FPM	130	2350	006416M
8031	FPM	170	1000	006417N
8031	FPM	250	570	006418X
8031	FPM	360	335	006419Y
8031	FPM	720	165	006420V

<sup>1</sup> Please note the required power supply of your sensor to set switches of the transmitter 8025 LOW FLOW. (cf § 3.3.1)

<sup>2</sup> Please note the K-Factor of the sensor to allow the setting of the transmitter 8025 "LOW FLOW" (cf § 4.3.3)

## 2 SPECIFICATION

## 8025 LOW FLOW

### 2.3 Design and Measuring Principle

#### Design

The panel version consists of an electronic board integrated in a front-cover.

The output signals are available on terminal strips on the electronic board.

The wall-mount version consists of a transducer with display in a splash-proof plastic IP65 enclosure.

The output signals are provided on a terminal strip inside the electrical enclosure via 3 PG 9.

#### Measuring Principle

The sensor produces pulses, which frequency is proportional to the flow.

The transducer has a measuring range of 2,5 to 1400 Hz corresponding to a flow range from 0,025 ml/s to 12884 l/s.

A 4...20 mA standard output signal proportional to the flow is available.

The transducer requires a power supply of 13...30 VDC.

The thresholds values of the transducer with two additional relays are freely adjustable.

OPTION: The flow transmitter in wall-mount version can be fitted with a 115/230 VAC power supply.

### 2.4 Technical Data

#### Operational conditions:

Ambient temperature	0 to 60°C (32 to 140°F)
Storing temperature	0 to 60°C ((32 to 140°F)
Relative humidity	80 % max
Enclosure	wall-mount version IP65 (ABS) panel version IP20 (rear plate);IP65 (front plate); PC
<b>Power supply:</b>	13...30 VDC (115/230 VAC option panel version)
Consumption	60 mA (without relay) or 100 mA (with relays)
<b>Output signal:</b>	4...20 mA programmable, proportional to the flow.
Max load:	1300 Ω at 30 V 1000 Ω at 24 V 550 Ω at 15 V 400 Ω at 13 V
Pulse	NPN or PNP, 5-30 V, 30 mA protected, adjustable.
Display	15x60 mm LCD 8 digits, alphanumeric 15 segments
Relay output (optional)	2 adjustable relays 3 A, 220 VAC

#### Sensor specification:

Type:	Hall sensor, optic, inductive
Power supply	according to transmitter power supply (13..30 VDC) + 12 V to + 27 V (115/230 V power supply option)
Pulse (square or sinusoid)	NPN, PNP, open collector with 470 Ω or 2,2 KΩ resistor
Input voltage	200 mV mini; 30 V max
Frequency	2,5 to 1400 Hz
K Factor	min 0,01; 80000 max
Flow min	0,025 ml/s
Resolution	0,001 ml

## 2 SPECIFICATION

## 8025 LOW FLOW

### 2.5 Dimensions




Fig. 2.1 Dimensions 8025 Transmitter panel version




Fig. 2.2 Dimensions 8025 Transmitter wall-mount version

### 3.1 Installation Guidelines

#### Panel version

For the cut-away of the front panel, follow the instructions on the enclosed delivery film. Install device as follows:

1. Put gasket **2** on the cover **1** and place the complete unit in the panel cut-away.
2. Screw the spacer bolts **3** on the panel fixing screws **4**.
3. Insert the cable clips **10**, to hold the different cables (power supply, outputs, sensor) of the transmitter, into plate **7**.
4. Set the switches SW100 and SW101 (cf 3.3)
5. Plug connector **5** on socket **6** and fasten plate **7** with screws **9** on bolts **3**. Do not forget the lockwashers **8**.

Mount the sensor according to specific instruction manual.




Fig. 3.1 Installation panel version

## 3 INSTALLATION

## 8025 LOW FLOW

### 3.1 Installation Guidelines

#### Wall-mount version

The flow transmitter in wall-mount version has 4 fixing holes in the bottom enclosure. Remove the white blanking stripes and the cover to access to fixing holes **1**. For sensor installation, please consult specific instruction manual.




Fig. 3.2 Installation wall-mount version

#### 3.2 Setting of sensor type

Set the switches SW100 and SW101 according to output signal and power supply of the connected sensor.




Fig. 3.3 Sensor type switches

SW101	Sensor Power supply
1	None
2	+12 V
3	+27 V (115/230 VAC version; external power supply or 13-30 VDC Version)

SW100	Output signal
1	Open collector, relay Reed Load R=2,2 K $\Omega$
2	Open collector, relay Reed Load R=470 $\Omega$
3	TTL; CMOS; coil Load R=100 $\Omega$







Switch SW100 and SW101 before setting power supply.



### 3 INSTALLATION

### 8025 LOW FLOW

#### 3.2.1 Connection and switch setting

Sensor output standard	Sensor Connector Transmitter
<p>① Open collector            SW100 = 1 (R = 2,2 KΩ)            SW100 = 2 (R = 470 Ω)</p> <p><u>Flow sensor type 8031</u></p>	
<p>② Relay REED            SW100 = 1 (R = 2,2 KΩ)            SW100 = 2 (R = 470 Ω)</p>	
<p>③ TTL            SW100 = 3 (R = 100 KΩ)</p>	
<p>④ Coil            SW100 = 3 (R = 100 KΩ)</p>	



Switch SW100 and SW101 before setting power supply.

## 3 INSTALLATION

## 8025 LOW FLOW

### 3.3 General Electrical Connection

The connecting line conducts the measuring signal and must not be installed in combination with high voltage or high frequency carrying lines. If a combined installation cannot be avoided, either keep a min. space of 30 cm (approx. 1 ft) or use coax cables. When using coax cables observe faultless grounding of the shield. For normal operating conditions, the measuring signal can be transmitted by a simple cable of 0.75 mm<sup>2</sup> cross section. In case of doubt, always use a coax cable. The power supply must be of good quality (filtered and regulated).



**For EMC purposes, the earth must be connected to the transmitter and, eventually, to the sensor.**

### 3.4 Connection of the pulse and current output to a PLC




Fig. 3.4 Switch position for PLC connection and current output





Fig. 3.5 Pulse output connection to a PLC

## 3 INSTALLATION

## 8025 LOW FLOW

### 3.5 Electrical connection 8025 "LOW FLOW" panel version

#### 3.5.1 8025 Transmitter without relay



Electronic card connector

Pins connection:

1: 4...20 mA

2: L+ (13...30 VDC)

3: L-

4: Earth (Earth lug)

5: Pulse output  $\ominus$

6: Pulse output  $\oplus$

Fig. 3.6 Electronic card 8025 without relay

**Note:** PLC-connection. Depending on the PLC-version, the switch **1** on the circuit board must be put to position A or B (see Fig. 3.4 and 3.6).




Fig. 3.7 Connection card 8025 without relay.





### 3 INSTALLATION

### 8025 LOW FLOW

#### 3.5.2 Type 8025 "LOW FLOW" panel version with relays

Electronic card connector

Pins connection:

- 1: 4...20 mA
- 2: L+ (13...30 VDC)
- 3: L-
- 4: Earth (earth lug)
- 5: ⊖ pulse output
- 6: ⊕ pulse output
- 7: Relay 2 
- 8: Relay 2 
- 9: Relay 1 
- 10: Relay 1 




Fig. 3.8 Electronic card 8025 with relays

**Note:** PLC-connection, depending on the PLC-version, the switch **1** on the circuit board must be set in position A or B (see Fig. 3.4 and 10).




Fig. 3.9 Connection card 8025 with relays

### 3 INSTALLATION

### 8025 LOW FLOW

#### 3.6 Electrical wiring 8025 "LOW FLOW" wall mounted version

##### 3.6.1 Electrical wiring 8025 "LOW FLOW" wall-mounted 13-30 VDC

Open the cover to access the terminals. Wire according to transmitter version and to the following figures.




Fig. 3.10 13..30 VDC Power supply - without relay




Fig. 3.11 13..30 VDC Power supply- with relays

### 3 INSTALLATION

### 8025 LOW FLOW

#### 3.6.2 Electrical wiring 8025 wall-mounted version 115-230 VAC

Open the cover to access the terminals. Wire according to transmitter version and to the figures 3.12 and 3.13.




Fig. 3.12 115..230 VAC Power supply - without relay




Fig. 3.13 115..230 VAC Power supply - with relays



Warning: Check the position of the power supply selection switch, before starting the device (fig. 3.2.)

### 3 INSTALLATION

### 8025 LOW FLOW

#### 3.7 Connection of the flow sensor type 8031 "LOW FLOW"

##### 3.7.1 Transmitter 8025 "LOW FLOW" panel version




Fig. 3.14 Connection of the flow sensor type 8031 (8025 Panel version)

##### 3.7.2 Transmitter 8025 "LOW FLOW" wall-mounted version




Fig. 3.15 Connection of the flow sensor type 8031 (8025 wall-mounted version)

## 4 OPERATION

## 8025 LOW FLOW

The operation of the 8025 is classified according to three levels.

### A) Display

This menu displays flow, output current, main totalizer and daily totalizer. The daily totalizer can also be reset in this menu.

### B) Parameter Definition


All the necessary settings, such as the language, engineering units, K-factor, 4...20 mA measuring range, pulse output, relay and filter are carried through in this menu. Here, the main, as well as the daily totalizer are simultaneously reset.

### C) Testing

A flow can be simulated in this menu, which allows to test a process in the "dry-run condition".

This menu also displays the sensor frequency and allows to change the basic settings (Offset, Span) of the device.

### 4.1 Transmitter Operating and Control Elements






## 4 OPERATION

## 8025 LOW FLOW

### 4.2 Operation Mode Display


The following variables are displayed in the operation mode:



### 4.3 Calibration Mode

Press simultaneously for 5 seconds


The following variables can be set in the parameter definition menu:




## 4 OPERATION

## 8025 LOW FLOW

### 4.3.1 Language



### 4.3.2 Engineering Units



**Note:** Return to the main menu via the sub-menu "TOTAL".


The "TOTAL" menu is only activated for metric units. Choose of US (or IMP) flow units enforces US (or IMP) units for volume measurements.

4.3.3 K-Factor

Enter the K-factor of the fitting in this menu (min 0.01 ... max 80000). The "Teach in" function allows to practically determine the application specific K-factor. The user only needs to run a known quantity of liquid through the system.

**Example:** In order to determine a quantity as accurately as possible, fill a tank of 100 litres. When the message "TEACH YES" appears, press the Enter key to start the measuring procedure. The message "FILL END" (end of filling) will appear. Then switch on a pump or open a valve. As soon as the tank is full, switch off the pump or close the valve. Pressing Enter stops the measurement. Finally enter the measured volume (100 liters). The calculated K-factor is displayed after validation.

**Note:** The transmitter uses the last entered or determined K-Factor.




**Note:** A decimal point can be entered by simultaneously pressing keys . It will always be positioned to the right of the flashing digit. Two positions are possible, «0000.0» or «000.00»

4.3.4 Output current

The measuring range of the flow, corresponding to the 4...20 mA output current is entered here, i.e. 0 to 180 l/min corresponds to 4...20 mA. The beginning of the measuring range can be larger than the end of it, i.e. 0 to 180 l/min corresponds to 20...4 mA (inverted output signal).

The settings (unit and decimal place), as selected for the flow indication will apply.


Check the acceptability of max values and minimum difference in §5.3.



4.3.5 Pulse output

In this menu, the parameters of the pulse output are defined, and the volume corresponding to one pulse is entered. First enter the unit, then the value.

Example: 1 impulse corresponds to 5 L



The impulse unit is set by the flow unit. Metric unit will be m<sup>3</sup> or Liter


4.3.6 Relay

The parameter definition of the limit contacts is done in this menu. Two limit values are entered for each relay ; 1- and 1+ or 2- and 2+. The user also has the possibility to invert the relays. The unit and decimal place, as selected in the sub-menu "UNIT" are activated. Check the acceptability of max values in §5.3.

Caution! The following condition must be observed: 1- ≤ 1+, 2- ≤ 2+.


## 4 OPERATION

## 8025 LOW FLOW




### 4.3.7 Filter

The damping is specified in this sub-menu. The low pass filter prevents fluctuations of the display and output current. There are ten levels available. The first level ("FILTER 0") has no damping effect.




4.3.8 Totalizer

The main and daily totalizers are reset in this menu. The reset procedure only starts when Enter is pressed, at the "END" position in the parameter definition menu.




4.4 Test Menu: Press    simultaneously for 5 seconds

The following compensations and tests are carried through in the test menu:




4.4.1 Offset-compensation

Here, the customer has the option to correct the basic setting of 4 mA. He only needs one current meter. When Enter is pressed while "OFFSET" is displayed, the transmitter produces 4 mA. If this value is incorrect, it can be corrected by entering the measured value.




4.4.2 Span-compensation

Here, the customer has the option to correct the basic adjustment of 20 mA. The procedure is identical to the Off-set procedure. When Enter is pressed while "SPAN" is indicated, the transmitter produces 20 mA. If this value is incorrect, it can be corrected by entering the measured value.




4.4.3 Frequency display

Here, the sensor frequency is displayed until the Enter key is pressed.



4.4.4 Flow simulation

A flow can be simulated in this menu. This allows the user to test his system without any liquid. Even though the simulated value influences the output current and the relays, it has no impact on the pulse output. Unit and decimal place, as selected in the sub-menu "UNIT" are active.



The simulation is active until the user enters into another sub-menu.

## 5 MAINTENANCE

## 8025 LOW FLOW

### 5.1 Trouble-shooting

The message "ERROR" on the display indicates that calibration data has been lost. By pressing ENTER, the user can access the operation menu but the device works with the factory settings (see §5.2). The transmitter must be re-calibrated. If this message appears more often, please return the product to the factory.

Please refer to specific manual for the sensor maintenance.

### 5.2 Factory-settings of 8025 "LOW FLOW" transmitter at Delivery

Language:	English	Relay:	1-:	00.10
Unit of flow:	L/s		1+:	00.50
Unit of totalizers:	L		Invert:	YES
Decimal points:	2		2-:	00.10
K-factor:	100.00		2+:	02.00
Current:	4 mA: 00.00		Invert:	YES
	20 mA: 00.00	Filter:		Filter 2
Pulse output unit:	L			
PU:	000.10			

### 5.3 Limit values for setting 8025 "LOW FLOW" transmitter.

Flow Unit	Current 4...20 mA		Switch Relais max value
	max value	mini difference	
ml/s	1.400.000/K	100/K	1.400.000/K
ml/min	84.000.000/K	6.000/K	84.000.000/K
ml/H	5.040.000.000/K	360.000/K	5.040.000.000/K
l/s	1.400/K	0.1/K	1.400/K
l/min	84.000/K	6/K	84.000/K
l/H	5.040.000/K	360/K	5.040.000/K
m <sup>3</sup> /s	1,4/K	0,0001/K	1,4/K
m <sup>3</sup> /min	84/K	0,006/K	84/K
m <sup>3</sup> /H	5.040/K	0,36/K	5.040/K
US gal/s	1.400/K	0.1/K	1.400/K
US gal/min	84.000/K	6/K	84.000/K
US gal/H	5.040.000/K	360/K	5.040.000/K
Imp gal/s	1.400/K	0.1/K	1.400/K
Imp gal/min	84.000/K	6/K	84.000/K
Imp gal/H	5.040.000/K	360/K	5.040.000/K



## 5 MAINTENANCE

## 8025 LOW FLOW

### 5.4 Spare parts

#### Spare parts 8025 panel version

Item	Designation	Order Nr
1	Cover with screws, front panel and electronic card Transmitter 8025 "LOW FLOW" without relay.	425528M
2	Cover with screws, front panel and electronic card Transmitter 8025 "LOW FLOW" with relays	425529N
3	Gasket	419350Q
4	Protective plate	419779J
5	Mounting accessories (screws, lockwashers, spacer bolts, cable clips)	418388A
	Instruction manual	419566V




Fig. 5.1 Spare parts explosion drawing panel version

## 5 MAINTENANCE

## 8025 LOW FLOW

### Spare parts 8025 wall-mount version

Item	Designation	Order Nr
6	Electronic card 8025 "LOW FLOW" without relay with F6 software	425411G
7	Electronic card 8025 "LOW FLOW" with relays and F6 software	425410K
8	Power card 12...30 VDC	419639E
	Power card 230/115 VAC	419640K
9	Connection cable between power card and electronic card	420403Y
10	Complete IP65 enclosure	418389B
	Instruction manual	419566V





Fig. 5.2 Spare Parts Explosion Drawing Wall-mount Version




**Beispiel - Example - Exemple: *Easy* LINK**

Anschluss Durchfluss Transmitter 8025 Schalttafel 13-30 VDC mit Relais

Connection flow transmitter 8025 Panel 13-30 VDC with relays

Connexion transmetteur de débit 8025 Encastré 13-30 VCC avec relais

**Type 8031:** See also § 3.7 - Siehe auch § 3.7 - Voir § 3.7



**Beispiel - Example - Exemple:** *Easy* LINK

Anschluss Durchfluss Transmitter 8025 Wandmontage 115/230 VDC mit Relais

Connection flow transmitter 8025 wall-mounted 115/230 VDC with relays

Connexion transmetteur de débit 8025 mural 115-230 VCC avec relais

**Type 8031:** See also § 3.7 - Siehe auch § 3.7 - Voir § 3.7

## SERVICE

---

### Australia

Bürkert Fluid Control Systems  
Unit 1 No.2, Welder Road  
Seven Hills NSW 2147  
Tel +61 2 967 461 66  
Fax +61 2 967 461 67

### Austria

Bürkert Contromatic GmbH  
Central and Eastern Europe  
Diefenbachgasse 1-3  
Postfach 89  
A-1150 Wien  
Tel +43 1 894 13 33  
Fax +43 1 894 13 00

### Belgium

Bürkert Contromatic N.V./S.R  
Middelmolenlaan 100  
B-2100 Deurne  
Tel +32 3 325 89 00,  
Fax +32 3 325 61 61

### Brasil

Conterval Ind. E. Com. Ltda.  
Rua Pinheiros 358  
Caixa Postal 11167  
05422 San Paulo  
Tel +55 11 852 93 77  
Fax +55 11 852 95 61

### Canada

Bürkert Contromatic Inc.  
760 Pacific Road, Unit 3  
Oakville, Ontario, L6L 6M5  
Tel +1 905 847 55 66,  
Fax +1 905 847 90 06

### Chile

Termodinamica Ltd.  
Av. Bulnes 195, Cas. 118  
Santiago de Chile  
Tel +56 2 635 39 50  
Fax +56 2 635 39 47

### China

Bürkert Contromatic  
(Suzhou) Co. Ltd.  
2/F, 71 Zhu Yuan Road  
215011 Suzhou  
Tel +86 512 808 19 16  
Fax +86 512 824 51 06

Bürkert Contromatic  
China/HK Ltd.  
Rm. 1313  
No. 103, Cao Bao Road  
200233 Shanghai P.R.C  
Tel +86 21 6484 7007  
Fax +86 21 6484 7008

Bürkert Contromatic  
China/HK Ltd.  
Beijing Office  
Rm. 808, Jing Tai Building  
No. 24, Jianguomen  
Waldajie  
100022 Beijing P.R.C  
Tel +86 10 6508 33 31  
Fax +86 10 6592 86 29

Bürkert Contromatic  
China/HK Ltd.  
Cheng Du Representative Office  
Rm. 502, Fujii Building  
No. 26 Shududadao  
Dongfeng Street  
Chengdu P.R.C  
Tel +86 28 443 1895  
Fax +86 28 445 1341

### Denmark

Bürkert-Contromatic A/S  
Horkær 24  
DK-2730 Herlev  
Tel +45 44 50 75 00  
Fax +45 44 50 75 75

### Finland

Bürkert Oy  
Atomitie 5  
SF-00370 Helsinki  
Tel +358 9 549 70 600  
Fax +358 9 503 12 75

### France

Bürkert Contromatic  
B.P. 21  
Triembach au Val  
F-67220 Villé  
Tel +33 (0) 388 58 91 11  
Fax +33 (0) 388 57 09 61

### Germany / Deutschland

Bürkert Steuer- und Regeltechnik  
Christian-Bürkert-Straße 13-17  
D-74653 Ingelfingen  
Tel +49 7940 10-0  
Fax +49 7940 10 361

Niederlassung NRW  
Holzener Straße 70  
D-58708 Menden  
Tel +49 2373 96 81-0  
Fax +49 2373 96 81-52

Niederlassung Frankfurt  
Am Flugplatz 27  
D-63329 Egelsbach  
Tel +49 6103 94 14-0  
Fax +49 6103 94 14-66

Niederlassung München  
Paul-Gerhardt-Allee 24  
D-81245 München  
Tel +49 89 82 92 28-0  
Fax +49 89 82 92 28-50

Niederlassung Berlin  
Bruno-Taut-Straße 4  
D-12524 Berlin  
Tel +49 30 67 97 17-0  
Fax +49 30 67 97 17-66

Niederlassung Dresden  
Christian Bürkert Straße 2  
D-01900 Großröhrsdorf  
Tel +49 35952 3 63 00  
Fax +49 35952 3 65 51

Niederlassung Hannover  
Rendburger Straße 12  
D-30569 Hannover  
Tel +49 511 9 02 76-0  
Fax +49 511 9 02 76-66

Niederlassung Stuttgart  
Karl-Benz-Straße 9  
D-70794 Filderstadt (Bernh.)  
Tel +49 711 4 51 10-0  
Fax +49 711 4 51 10-66

### Greece

Tevox E.E  
3 Xirogianni Straße  
Zografos Athen  
Tel +30 1-7 71 50 97  
Fax +30 1-7 75 12 26

### Great Britain

Bürkert Contromatic Ltd.  
Brimmscombe Port Business Park  
Brimmscombe, Stroud, Glos.  
GL5 2QF  
Tel. +44 (0) 1453 73 13 53  
Fax +44 (0) 1453 73 13 43

### Hong Kong

Bürkert Contromatic  
(China/HK) Ltd.  
Unit 708, Prosperity Centre  
77-81 Container Port Road  
Kwai Chung N.T.  
Hong Kong  
Tel +852 2480 1202  
Fax +852 2418 1945

### Indonesia

P.T. Fulkosindo  
JLKH Hasyim Ashari No. 38-A  
Jakarta 10140  
Tel +62 21 386 24 85  
Fax +62 21 386 24 85

---

## SERVICE

---

### Italy

Bürkert Contromatic Italiana S.p.A.  
Centro Direzionale 'Colombiolo'  
Via Roma 74  
I-20060 Cassina De Pecchi (MI)  
Tel +39 02 952 071  
Fax +39 02 952 07 251

### Japan

Bürkert Contromatic Ltd.  
3-39-8 Shoan  
Suginami-ku  
Tokyo 167-0054  
Tel +81 3 324 734 11  
Fax +81 3 324 734 72

### Korea

Bürkert Contromatic Korea Co. Ltd.  
4-10 Yangjae-Dong  
Secho-Ku  
Seoul 137-130  
Tel. +82 2 346 255 92  
Fax +82 2 346 255 94

### Malaysia

Bürkert Malaysia Sdn. Bhd.  
N° 22 Lorong Helang 2  
11700, Sunggai Dua  
Penang  
Tel. +60 4 657 64 49  
Fax +60 4 657 21 06

### Netherlands

Bürkert Contromatic BV  
Computerweg 9  
NL-3606 AV Maarssen  
Tel. +31 346 58 10 10  
Fax +31 346 56 37 17

### New Zealand

Bürkert Contromatic Ltd.  
Unit 5, 23 Hannigan drive  
Mt Wellington  
Auckland  
Tel +64 9 570 25 39  
Fax +64 9 570 25 73

### Norway

Bürkert Contromatic A/S  
Hvamstuppen 17  
P.O. Box 243  
N-2013 Skjetten  
Tel +47 63 84 44 10  
Fax +47 63 84 44 55

### Philippines

Delrene EB Controls Center  
2461 Uradaneta St. Guadelupe  
Nuevo Makati Metro  
Manila 3116  
Tel +63 2 819 05 36  
Fax +63 2 819 05 47

### Poland

Bürkert Contromatic Sp.z.o.o.  
1 Szpitalna Street  
PL-00-684  
Warszawa  
Tel +48 22 627 47 20  
Fax +48 22 627 47 20

### Portugal

LA 2ª P Lda  
Rua Almirante Sousa Dias  
Loja D. Nova Oeiras  
P-2780 Oeiras  
Tel. +351 1 442 26 08  
Fax +351 1 442 28 08

### Singapore

Bürkert Contromatic Singapore  
Pte.Ltd.  
No.11 Playfair Road  
Singapore 367986  
Tel +65 383 26 12  
Fax +65 383 26 11

### Spain

Bürkert Contromatic Española S.A.  
San Gabriel 40-44  
E-08950 Esplugues de Llobregat  
Tel +34 93 371 08 58  
Fax +34 93 371 77 44

### South Africa

Bürkert Contromatic Pty.Ltd.  
P.O.Box 26260, East Rand 1452  
Republic of South Africa  
Tel +27 11 397 2900  
Fax +27 11 397 4428

### Sweden

Bürkert Contromatic AB  
Skeppsbron 13 B, 5 tr.  
S-21120 Malmö  
Tel +46 40 664 51 00  
Fax +46 40 664 51 01

### Bürkert Contromatic AB

Havsörnstorget 21  
Box 1002  
S-12329 Farsta  
Tel +46 40 664 51 00  
Fax +46 8 724 60 22

### Switzerland

Bürkert-Contromatic AG Schweiz  
Bösch 65  
CH-6331 Hünenberg / ZG  
Tel +41 41 785 66 66  
Fax +41 41 785 66 33

### Taiwan

Bürkert Contromatic Taiwan Ltd.  
3F No. 475 Kuang-Fu South Road  
R.O.C - Taipei City  
Tel +886 2 275 831 99  
Fax +886 2 275 824 99

### Thailand

Alpha Contromatic Co. Ltd.  
259/13 Sukhvit 22  
Bangkok 10110  
Tel +420 641 22 61 80  
Fax +420 641 22 61 81

### Turkey

Bürkert Contromatic Ltd.  
Kontrol Sistemleri Ticaret A.S  
1203/8 Sok. No. 2-E  
Yenisehir  
Izmir  
Tel +90 232 459 53 95  
Fax +90 232 459 76 94

### Tzechia

Bürkert Contromatic Spool.s.r.o  
Prosenice c. 180  
CZ - 751 21 Prosenice  
Tel +42 0641 226 180  
Fax +42 0641 226 181

### USA

Bürkert Contromatic Corp.  
2602 McGaw Avenue  
Irvine, CA 92614, USA  
Tel. +1 949 223 31 00  
Fax +1 949 223 31 98

