

((

# Configurable indicator with 2 or 4 alarms 1/8 DIN - 96 x 48 mm Universal JM line JT line for transducers

This new family of microprocessor-based indicators, with total configurability from keyboard, is available in 2 versions: the JM line, for the most common industrial sensors and trasmitters, and JT line suitable for transducers. They can also be used as transmitters thanks to measurement retransmission and serial communications port.

- Accuracy class: 0.2.
- Measurement input: from Pt100, J, L, K, N, S,R, T, W for mA, mV and Volt transmiters (with or without)
   <sup>2</sup>√and also transducers (JT series).
- Auxiliary inputs: 3 of logic type
- Fast sampling time: 62 msec.
- **Display:** 4 digit green LED's of 14 mm.
- Hold: peak, valley or actual value.
- Access to Set points: 3

different levels.

 Parameters protection: with password

• Power supply for transmitter: 24 Vdc, 25 mA

 Excitation Voltage for transducer:
 5 or 10 Vdc, 30 mA, stabilized.

• Front protection: IP54 std, IP65 kit on request.

• Dimensions: 96x48DIN, depth 150 mm.

**Opzions** 

 Alarms: 2 or 4 configurable with relay output also with ISA sequence.

Retransmission output:
4..20 mA or 0..10 V. isolated

Serial communication port.





# Δ5COΠ

Certified ISO 9001

### Indicator-transmitter

Multi-input, total configurability from keyboard, with 2 or 4 alarms, with serial Power supply for Transmitters Digit communications port ... increment **Excitation voltage** for Transducers Switching power supply selection (scroll) 100...240 Vac Serial communications Data selection and configuration Measurement display Alarm 4 Alarm 3 Alarm 2 Alarm 1 Hold control Seal IP54 or IP65 Engineering

units

label

Extraction screw below the flap door

... also for pressure transducers and load cells.

#### **Technical Data**

#### INPUT

#### Common features

- A/D converter: 50,000 points.
- Measurement sampling time:
   62 msec.
- Input shift: from -50 to +50 steps.
- Filter time constant: from 0 to 30 sec.
- Safety: range measurement or failure on the input line (interruption or short-circuit) is signaled on the display, and the alarms go into the safety state selected in the configuration phase.
- For mains voltage variations from 100 to 240 Vac, the error of measurement is irrelevant.

#### For thermocouples

- Cold junction incorporated
- Line resistance: 150 Ω max
- Measurement accuracy:
   0.2% ± 1°C at 25°C ambient temperature
- Measurement drift:
  - < 20 μV/10°C ambient temperature
  - $< 0.5^{\circ}\mu\text{V}/10\,\Omega$  line resistance

#### For RTD Pt100

- 2 or 3-wire connection
- Line resistance: 20Ω max. for 3-wire connection

- Measurement accuracy:
   0.2% at 25°C ambient temperature
- Measurement drift:
  - < 0.1°C/10°C ambient temperature
  - < 0.5°C/10  $\Omega$  line resistance (3 wire)

#### DC current and voltage:

- Input resistance: in current: 30Ω in voltage: 10kΩ 10MΩ for range ≤ 300 mV
- Measurement accuracy:
   0.1% at 25°C ambient temperature
- Measurement drift:
   < 0.1%/20°C ambient temperature</li>
- <sup>2</sup>√enclosed or excluded

#### For transducer (JT model)

- Selectable measurement ranges: 0...60mV or 0...300mV
- Scale range: zero and end of scale calibration
- Zero calibration: within ± 10% of span
- Full scale calibration: 80% of scale span
- · Accuracy and drift: as DC input.

#### **AUXILIARY POWER SUPPLY**

#### For transmitter

 For a 2-wire, 4...20mA or a 3-wire transmitter: 24 Vdc ± 10%, 25mA max

#### For transducer bridge

- Excitation voltage:
   5 or 10Vdc ± 5%, selectable
- Stability ± 0.1%/ 20°C ambient temp.
- Max. output: 30mA

#### ALARMS Y1, Y2 AND Y3, Y4 (OPTIONS)

For every alarm:

- Output: 1 contact, 5A, 250Vac max
- Signalisation: red LED, flashing in alarm, steady after acknowledgment (if configured as ISA-A)
- · Set point: settable within the scale
- Hysteresis: from 0.1 to 10.0% scale span
- Delay in relay operating time: 0 to 100 sec.

For every alarm, it is possible to select: (see figure).

In configuration (G-H-I-L indexes):

- Type of alarm:
- disabled
- normal
- with ISA A sequence and acknowledgment
- Alarm operating mode:
  - activated above the threshold
  - activated below the threshold


#### In programmation:

- Contact state:
- NO closes in case of alarm
- NC opens in case of alarm
- Safety state in case of input failure
  - Alarm state
- Non-alarm state
- · Alarm inhibit control on startup:
- disabled
- enabled

#### ANALOGIC OUTPUT Y5 (OPTION)

- Signal: 4...20mA, 10V. max. or 0...10V., 20 mA max., isolated
- Accuracy: 0.1% at 25°C ambient temperature
- Resolution: 12 Bits (0,025%)

#### ALARMS: selection of the type and mode of operation



## Connections and overall dimensions

#### **SERIAL COMMUNICATIONS**


- Passive 20 mA C.L. isolated interface
- ASCII code or Modbus/Jbus protocol
- Baud rate configurable between: 600, 1200, 2400, 4800 or 9600 (only for Modbus/Jbus) Bit/s
- Interface with RS232C, RS422A, RS485 port via traffic concentrator ALS type (it's possible to connect up to 64 ASCON instruments, also of different type)

#### **GENERAL DATA**


- Power supply: 100...240 Vac or 16...28 Vac, 20...30 Vdc Power consumption: 4 VA max.
- Isolation group:
   C according to VDE 0110.
- Climatic group: KWF according to DIN 40040.
- Ambient operating temperature: from 0 to 50°C
- Protection according to DIN 40050 front: IP54 case: IP30 terminal board: IP20 self-extinguishing material: UL94 V1
- · Weight: about 0.6 kg.
- Dimensions: 96x48, depth 150 mm.

#### CONNECTIONS


#### JM models with universal input



#### JT models with input for transducer bridge



#### **DIMENSIONS**



# General description

#### **MEASUREMENT INPUT**

The JM series provides an input for the more common industrial temperature sensors: thermocouples (J, L, K, N, S, R, T, W), RTD, and also normalized signals in mA, Volts, or mV with or without  $\sqrt[7]{}$ . The input type, scale range and the beginning and end of scale values for inputs in current or voltage, are configurable from keyboard.

The JT series provides an input for transducers of the "strain gauge" or similar type; in this case, a stabilized excitation voltage programmable from keyboard (5 or 10 Vdc, 30 mA max.) is incorporated and a very simple automatic procedure is provided for field calibration of the zero and full scale.

#### **LOGIC INPUTS**

It is possible, by means of external contacts applied to the 3 available logic inputs, to:

- freeze the measurement
- store a peak or a valley
- acknowledge the alarm state.

#### **FILTER**

A digital filter, with time constant settable from keyboard, permits measurements of noisy signals.

#### INPUT SHIFT

An "Input shift" function allows to shift the scale to compensate measurement offset.

#### HOLD

Two functions are available: peak or valley capture, and hold of the last measurement carried out.

The peak remains displayed for the

time preset in programmation or for the entire closing time of an external contact. This function does not inhibit measurement acquisition, the alarms and retransmission therefore remaining operative. On the other hand the hold, obtainable through the closing of an external contact, inhibits further measurement acquisitions and freezes all instrument functions.

#### **ALARMS**

The optional alarms may be 2 or 4. They are totally programmable from keyboard.

For every alarm, it is possible to configure:

- the type of action: disabled, normal, or with ISA A sequence.
- the operating mode: active high or active low.
- the contact state: closed, or open in case of alarm.
- the safety state: alarm or non-alarm, in case of input failure.
   If selected, the alarm startup inhibit control permits unwanted interventions to be avoided in the parameter setting phase. It is also possible to set a delayed time for

#### ANALOGUE RETRANSMISSION

relay intervention.

Provided in option for measurement retransmission. The measurement values corresponding with zero and full scale of the retransmitted signal can be configured freely. Galvanically isolated.

#### SERIAL COMMUNICATIONS

This is an option: it permits the indicator to be used as an "smart" transmitter, therefore easily introduced into a distributed control system.

A traffic concentrator can connects up to 64 instruments to a single serial line, whether these are JM, JT indicators or other ASCON instruments with serial communications port.

#### CONFIGURATION

Configuration may be carried out via serial line using a personal computer or simply from the front panel keyboard. The configuration code is viewed on the display. If the instrument is not configured, the digits 9999 appear. If the instrument is already configured, the configuration indexes are shown on the display and the secret code must be introduced in order to modify them.

#### **PROTECTION**

All parameters and configuration values are stored in a non-volatile memory for an unlimited period of time


Introduction of the relative secret codes is necessary for access to the parameters and configuration. Only the alarm Set points are directly accessible to the operator; however, in order to avoid tampering or inadvertent alterations of alarm thresholds, their "accessibility level" may be configured:

1st level: Visible and modifiable Set point

2nd level: Visible but non alterable Set point

3rd level: "Non visible" Set point,

# Models and configurations



#### MODEL CODE:

Power supply	А
100240V 50/60 Hz	3
1628V 50/60 Hz and 2030 Vdc	5

Serial communications	В
Not fitted	0
20 mA C.L. Ascon std. protocol	1
20 mA C.L. Modbus/Jbus protocol	2

Measurement retransmission, output Y <sub>5</sub>	C
Not fitted	0
420 mA	1
010 Vdc	2

Alarms	D
Not fitted (indicator only)	0
2 Alarms	2
4 Alarms (JM models only)	4

#### **CONFIGURATION CODE: (1)**

Inp	put type and scale range (2)			E	F
	RTD IEC 751	Pt100	-200600°C	0	0
	IEC 751	Pt100	-99,9300,0°C	1	0
		Type J	. 0600°C	2	0
		Type W	02200°C	2	2
0.20	_	Type L	* 0600°C	3	0
	Termo- couples IEC 584	Type K	01200°C	4	0
		Type N	01200°C	5	0
₹		Type S	01600°C	6	0
7		Type R	01600°C	7	0
		Type T	-100400°C	8	0
	Lin. inp. (•) 420 mA		Conf. eng. units	9	0
	Lin. inp. (•) 020 mA		Conf. eng. units	9	1
	Lin. inp. (•)	060 mV	Conf. eng. units	9	2
	Lin.inp.(•) 0.	300 mV	Conf. eng. units	9	3
	Lin. inp. (•)	01 V	Conf. eng. units	9	4
	Lin. inp. (•) 010 V		Conf. eng. units	9	5
F	060 mV c	alibrable	Conf. eng. units	9	6
5	0300 mV	calibrable	Conf. eng. units	9	7

<sup>\*</sup> Fe-Const DIN 43710

Type and ope	erating mode - Alarm Y <sub>1</sub> (3)	G
Disabled		0
Normal	Active high (above SP)	1
	Active low (below SP)	2
With ISA A sequence	Active high	3
	Active low	4

Type and operating mode - Alarm Y <sub>2</sub> (3)		Н
Disabled		0
Normal	Active high	1
	Active low	2
With ISA A sequence	Active high	3
	Active low	4

Type and ope	rating mode - Alarm Y <sub>3</sub> (3)	1
Disabled		0
Normal	Active high	1
	Active low	2
With ISA A sequence	Active high	3
	Active low	4

Type and ope	rating mode - Alarm Y <sub>4</sub> (3)	L
Disabled		0
Normal	Active high	1
Normai	Active low	2
With ISA A sequence	Active high	3
	Active low	4

Excitation Voltage for transducers (JT models)	M
Not fitted (JM models)	0
5 Vdc ± 5% 30 mA max	1
The state of the s	

#### Notes on configuration

- 1 To receive a non-configured instrument, indicate code 9999-999.
- 2 For inputs in mA and Volts, the beginning and end of scale values can be configured in engineering units between -999 and 9999. The minimum scale span is 100 steps.

The values can be expressed in units (xxxx), in tenths (xxx.x), hundredths (xx.xx) or thousands (x.xxx). Lacking the indication of beginning and end of scale values, the instrument will be supplied with 0.0...100.0 scale. Codes 96 and 97 are reserved to transducer inputs (JT models only).

- 3 The following can also be defined for every alarm in the programming phase:
- contact state in case of alarm
- safety state in case of input failure
- alarm inhibit startup control.

#### Ordering examples:

JM-3000/4000-000 JT-3000/9600-001

models without alarms (indicator only)

JM-3002/4012-000 JT-3002/9612-001


models with 2 alarms

JM-3004/4012-120 models with 4 alarms (JM only)


**JM-3000/9999-999 JT-3000/9999-999** not configured

#### **ACCESSORIES**

 SERIAL COMMUNICATIONS INTERFACE for 64 ASCON controllers



 FRONTAL PROTECTION KIT IP65: mod. F10-170-2A101



<sup>(•)</sup> With or without square root extraction